

Customer : ETD

Type: A380

Rev. Date: Jan 01, 2016

Manual : TSM Selected applicability: ALL

36-22-71-991-02200-00-A / SHEET 1/2 - Engine 2 Pylon Loop 'B'- Fault Location Zone and Access Table (Open Circuit)

		FAULT LOCATION ZONE								
LOC	START OF ZONE			MID POSITION			END OF ZONE			ACCESS PANEL(S)
	m	ft	ITEM	m	ft	ITEM	m	ft	ITEM	
001				1.35	4.43	929				
002				2.69	8.83	929				
003				0.65	2.13	933				
004				1.99	6.53	933				
005				3.34	10.96	933				
006				4.68	15.35	933				
007				6.03	19.78	933				
800				7.37	24.18	933				
009				8.72	28.61	933				
010				10.06	33.01	933				
011				0.62	2.03	7629				
012				1.97	6.46	7629				
013				3.31	10.86	7629				
014				4.66	15.29	7629				
015				6.00	19.69	7629				
016				7.35	24.11	7629				
017				8.69	28.51	7629				
018 019				10.04 11.38	32.94	7629 7629				
020					37.34	4080				
020				0.09 1.44	0.30 4.72	4080				
021				2.78	9.12	4080				
022				4.13	13.55	4080				
023				5.47	17.95	4080				
025				6.82	22.38	4080				
026				8.16	26.77	4080				
027				9.51	31.20	4080				
028				10.85	35.60	4080				
029				12.20	40.03	4080				
030				13.54	44.42	4080				
031				14.89	48.85	4080				
032				16.24	53.28	4080				
033				17.58	57.68	4080				
034				18.93	62.11	4080				
035				20.27	66.50	4080				
036				21.62	70.93	4080				
037				22.96	75.33	4080				
038				24.31	79.76	4080				
039					84.15	4080				
040				27.00	88.58	4080				
041				28.35	93.01	4080				
042				29.69	97.41	4080				
043				0.60	1.97	937				
044				1.94	6.36	937				
045				3.29	10.79	937				
046				4.63	15.19	937				
047				0.70	2.30	110HF2				463BL
048				2.51	8.23	110HF2				463BL
049				4.33	14.21	110HF2				463BL
050	0.16	0.52	111HF2		0.75	111HF2	0.30	0.98	111HF2	
051				1.67	5.48	119HF2				463BL
052				3.49	11.45	119HF2				463BL

L\_TS\_362271\_2\_BWAA\_01\_00

Figure 36-22-71-991-02200-A- / SHEET 1/2 - Engine 2 Pylon Loop 'B'- Fault Location Zone and Access Table (Open Circuit) ON A/C ALL

Print Date: January 19, 2016 Page 1 of 1