



Customer : ETD
Type : A380
Rev. Date : Jan 01, 2016

Manual : TSM
Selected applicability : ALL

36-22-11-991-03600-00-B / SHEET 1/2 - Right Inner Wing, Loop
'B' - Fault Location Zone and Access Table (Short Circuit/Overheat)

LOC	FAULT LOCATION ZONE									ACCESS PANEL(S)
	START OF ZONE			MID POSITION			END OF ZONE			
	m	ft	ITEM	m	ft	ITEM	m	ft	ITEM	
001				2.51	8.23	184				
002				8.41	27.59	184				
003				3.49	11.45	7553				
004				9.38	30.77	7553				
005				15.28	50.13	7553				
006				11.38	37.34	398HF				621EB/621FB
007	13.73	45.05	398HF	0.15	0.49	376HF	0.57	1.87	376HF	621EB/621FB
008	13.93	45.70	398HF	0.35	1.15	376HF	0.77	2.53	376HF	621EB/621FB
009	0.13	0.43	376HF	0.55	1.80	376HF	0.96	3.15	376HF	621EB/621FB
010	0.33	1.08	376HF	0.74	2.43	376HF	1.16	3.81	376HF	621EB/621FB
011	0.52	1.71	376HF	0.94	3.08	376HF	1.36	4.46	376HF	621EB/621FB
012	0.72	2.36	376HF	1.14	3.74	376HF	1.55	5.09	376HF	621EB/621FB
013	0.92	3.02	376HF	1.33	4.36	376HF	1.75	5.74	376HF	621EB/621FB
014	1.11	3.64	376HF	1.53	5.02	376HF	1.95	6.40	376HF	621EB/621FB
015	1.31	4.30	376HF	1.73	5.68	376HF	2.15	7.05	376HF	621EB/621FB
016	1.51	4.95	376HF	1.93	6.33	376HF	2.34	7.68	376HF	621EB/621FB
017	1.71	5.61	376HF	2.12	6.96	376HF	0.02	0.07	377HF	621EB/621FB
018	1.90	6.23	376HF	2.32	7.61	376HF	0.22	0.72	377HF	621EB/621FB
019	2.10	6.89	376HF	2.52	8.27	376HF	0.42	1.38	377HF	621EB/621FB
020	2.30	7.55	376HF	0.19	0.62	377HF	0.61	2.00	377HF	621FB
021	2.49	8.17	376HF	0.39	1.28	377HF	0.81	2.66	377HF	621FB
022	0.17	0.56	377HF	0.59	1.94	377HF	1.01	3.31	377HF	621FB
023	0.37	1.21	377HF	0.79	2.59	377HF	1.20	3.94	377HF	621FB
024	0.57	1.87	377HF	0.98	3.22	377HF	1.40	4.59	377HF	621FB
025	0.76	2.49	377HF	1.18	3.87	377HF	0.05	0.16	378HF	621FB
026	0.96	3.15	377HF	1.38	4.53	377HF	0.25	0.82	378HF	621FB
027	1.16	3.81	377HF	0.03	0.10	378HF	0.44	1.44	378HF	621GB/621HB/621SB/621TB
028	1.35	4.43	377HF	0.22	0.72	378HF	0.64	2.10	378HF	621GB/621HB/621SB/621TB
029	0.00	0.00	378HF	0.42	1.38	378HF	0.84	2.76	378HF	621GB/621HB/621SB/621TB
030	0.20	0.66	378HF	0.62	2.03	378HF	1.03	3.38	378HF	621GB/621HB/621SB/621TB
031	0.40	1.31	378HF	0.81	2.66	378HF	1.23	4.04	378HF	621GB/621HB/621SB/621TB
032	0.59	1.94	378HF	1.01	3.31	378HF	1.43	4.69	378HF	621GB/621HB/621SB/621TB
033	0.79	2.59	378HF	1.21	3.97	378HF	1.63	5.35	378HF	621GB/621HB/621SB/621TB
034	0.99	3.25	378HF	1.41	4.63	378HF	1.82	5.97	378HF	621GB/621HB/621SB/621TB
035	1.19	3.90	378HF	1.60	5.25	378HF	2.02	6.63	378HF	621GB/621HB/621SB/621TB
036	1.38	4.53	378HF	1.80	5.91	378HF	0.07	0.23	379HF	621GB/621HB/621SB/621TB
037	1.58	5.18	378HF	2.00	6.56	378HF	0.26	0.85	379HF	621GB/621HB/621SB/621TB
038	1.78	5.84	378HF	0.04	0.13	379HF	0.46	1.51	379HF	621JB/621KB/621UB/621VB
039	1.97	6.46	378HF	0.24	0.79	379HF	0.66	2.17	379HF	621JB/621KB/621UB/621VB
040	0.02	0.07	379HF	0.44	1.44	379HF	0.86	2.82	379HF	621JB/621KB/621UB/621VB
041	0.22	0.72	379HF	0.64	2.10	379HF	1.05	3.44	379HF	621JB/621KB/621UB/621VB
042	0.42	1.38	379HF	0.83	2.72	379HF	1.25	4.10	379HF	621JB/621KB/621UB/621VB
043	0.61	2.00	379HF	1.03	3.38	379HF	1.45	4.76	379HF	621JB/621KB/621UB/621VB
044	0.81	2.66	379HF	1.23	4.04	379HF	1.64	5.38	379HF	621JB/621KB/621UB/621VB
045	1.01	3.31	379HF	1.42	4.66	379HF	1.84	6.04	379HF	621JB/621KB/621UB/621VB
046	1.20	3.94	379HF	1.62	5.31	379HF	2.04	6.69	379HF	621JB/621KB/621UB/621VB
047	1.40	4.59	379HF	1.82	5.97	379HF	2.24	7.35	379HF	621JB/621KB/621UB/621VB
048	1.60	5.25	379HF	2.02	6.63	379HF	2.43	7.97	379HF	621JB/621KB/621UB/621VB
049	1.80	5.91	379HF	2.21	7.25	379HF	2.63	8.63	379HF	621JB/621KB/621UB/621VB
050	1.99	6.53	379HF	2.41	7.91	379HF	2.83	9.28	379HF	621JB/621KB/621UB/621VB
051	2.19	7.19	379HF	2.61	8.56	379HF	3.03	9.94	379HF	621JB/621KB/621UB/621VB
052	2.39	7.84	379HF	2.81	9.22	379HF	3.22	10.56	379HF	621JB/621KB/621UB/621VB

L_TS_362211_2_ERAA_01_00

Figure 36-22-11-991-03600-B- / SHEET 1/2 - Right Inner Wing, Loop
'B' - Fault Location Zone and Access Table (Short Circuit/Overheat)

** ON A/C ALL