



Customer : ETD
Type : A380
Rev. Date : Jan 01, 2016

Manual : TSM
Selected applicability : ALL

36-22-11-991-03300-00-B / SHEET 1/2 - Right Wing, Loop 'A' -
Fault Location Zone and Access Table (Short Circuit/Overheat)

LOC	FAULT LOCATION ZONE									ACCESS PANEL(S)
	START OF ZONE			MID POSITION			END OF ZONE			
	m	ft	ITEM	m	ft	ITEM	m	ft	ITEM	
001				7.53	24.70	107				
002				7.63	25.03	7513				
003				6.40	21.00	323HF				621EB/621FB
004	13.41	44.00	323HF	0.23	0.75	326HF	1.06	3.48	326HF	621EB/621FB
005	13.77	45.18	323HF	0.60	1.97	326HF	1.42	4.66	326HF	621EB/621FB
006	0.14	0.46	326HF	0.96	3.15	326HF	1.79	5.87	326HF	621EB/621FB
007	0.50	1.64	326HF	1.33	4.36	326HF	2.15	7.05	326HF	621EB/621FB
008	0.87	2.85	326HF	1.69	5.54	326HF	2.52	8.27	326HF	621EB/621FB
009	1.23	4.04	326HF	2.06	6.76	326HF	2.88	9.45	326HF	621EB/621FB
010	1.60	5.25	326HF	2.42	7.94	326HF	0.04	0.13	327HF	621EB/621FB
011	1.96	6.43	326HF	2.79	9.15	326HF	0.40	1.31	327HF	621EB/621FB
012	2.33	7.64	326HF	3.15	10.33	326HF	0.77	2.53	327HF	621EB/621FB
013	2.69	8.83	326HF	0.31	1.02	327HF	1.13	3.71	327HF	621FB
014	3.06	10.04	326HF	0.67	2.20	327HF	0.07	0.23	328HF	621FB
015	0.21	0.69	327HF	1.04	3.41	327HF	0.43	1.41	328HF	621FB
016	0.58	1.90	327HF	1.40	4.59	327HF	0.80	2.62	328HF	621FB
017	0.94	3.08	327HF	0.34	1.12	328HF	1.16	3.81	328HF	621GB/621HB/621SB/621TB
018	1.31	4.30	327HF	0.70	2.30	328HF	1.53	5.02	328HF	621GB/621HB/621SB/621TB
019	0.24	0.79	328HF	1.07	3.51	328HF	1.89	6.20	328HF	621GB/621HB/621SB/621TB
020	0.61	2.00	328HF	1.43	4.69	328HF	2.26	7.41	328HF	621GB/621HB/621SB/621TB
021	0.97	3.18	328HF	1.80	5.91	328HF	2.62	8.60	328HF	621GB/621HB/621SB/621TB
022	1.34	4.40	328HF	2.16	7.09	328HF	0.25	0.82	329HF	621GB/621HB/621SB/621TB
023	1.70	5.58	328HF	2.53	8.30	328HF	0.61	2.00	329HF	621GB/621HB/621SB/621TB
024	2.07	6.79	328HF	0.15	0.49	329HF	0.98	3.22	329HF	621JB/621KB/621UB/621VB
025	2.43	7.97	328HF	0.52	1.71	329HF	1.34	4.40	329HF	621JB/621KB/621UB/621VB
026	0.06	0.20	329HF	0.88	2.89	329HF	1.71	5.61	329HF	621JB/621KB/621UB/621VB
027	0.42	1.38	329HF	1.25	4.10	329HF	2.07	6.79	329HF	621JB/621KB/621UB/621VB
028	0.79	2.59	329HF	1.61	5.28	329HF	2.44	8.01	329HF	621JB/621KB/621UB/621VB
029	1.15	3.77	329HF	1.98	6.50	329HF	2.80	9.19	329HF	621JB/621KB/621UB/621VB
030	1.52	4.99	329HF	2.35	7.71	329HF	3.17	10.40	329HF	621JB/621KB/621UB/621VB
031	1.89	6.20	329HF	2.71	8.89	329HF	0.29	0.95	330HF	621JB/621KB/621UB/621VB
032	2.25	7.38	329HF	3.08	10.10	329HF	0.65	2.13	330HF	621JB/621KB/621UB/621VB
033	2.62	8.60	329HF	0.19	0.62	330HF	1.02	3.35	330HF	621LB
034	2.98	9.78	329HF	0.56	1.84	330HF	1.38	4.53	330HF	621LB
035	0.10	0.33	330HF	0.92	3.02	330HF	1.75	5.74	330HF	621LB
036	0.46	1.51	330HF	1.29	4.23	330HF	0.00	0.00	331HF	621LB
037	0.83	2.72	330HF	1.65	5.41	330HF	0.37	1.21	331HF	621LB
038	1.19	3.90	330HF	2.02	6.63	330HF	0.73	2.40	331HF	621LB
039	1.56	5.12	330HF	0.27	0.89	331HF	1.10	3.61	331HF	621MB
040	1.92	6.30	330HF	0.64	2.10	331HF	1.46	4.79	331HF	621MB
041	0.18	0.59	331HF	1.00	3.28	331HF	0.18	0.59	332HF	621MB
042	0.54	1.77	331HF	1.37	4.49	331HF	0.54	1.77	332HF	621MB
043	0.91	2.99	331HF	0.08	0.26	332HF	0.91	2.99	332HF	622AT/622BT
044	1.27	4.17	331HF	0.45	1.48	332HF	1.27	4.17	332HF	622AT/622BT
045	1.64	5.38	331HF	0.81	2.66	332HF	1.64	5.38	332HF	622AT/622BT
046	0.35	1.15	332HF	1.18	3.87	332HF	2.00	6.56	332HF	622AT/622BT
047	0.72	2.36	332HF	1.54	5.05	332HF	2.37	7.78	332HF	622AT/622BT
048	1.08	3.54	332HF	1.91	6.27	332HF	2.73	8.96	332HF	622AT/622BT
049	1.45	4.76	332HF	2.27	7.45	332HF	3.10	10.17	332HF	622AT/622BT
050	1.81	5.94	332HF	2.64	8.66	332HF	0.36	1.18	333HF	622AT/622BT
051	2.18	7.15	332HF	3.00	9.84	332HF	0.73	2.40	333HF	622AT/622BT
052	2.54	8.33	332HF	0.27	0.89	333HF	1.09	3.58	333HF	622CB/622EB

L_TS_362211_2_ENAA_01_00

Figure 36-22-11-991-03300-B- / SHEET 1/2 - Right Wing, Loop 'A'
- Fault Location Zone and Access Table (Short Circuit/Overheat)

** ON A/C ALL