Explanation of Button Functions and Brief Operation Guide

This is the Remote Controller for the AusSport Scoreboard:

The buttons are referred to by number and label in this document

1	2	3	4
5	6	7	8
9	10	11	12
13	14	15	16
17	18	19	20
21	22	23	24



Button Functions

1. NEW 

(Double-click required) Resets all game parameters to the default values created during the setup procedure. It restores any extinguished time out indicators, it sets the scores to zero and the QTR counter to one. It also stops any timers which are still running.

2. SET 

(Double-click required) Steps through the game parameter fields ie quarters, intervals, SHOT 1 and SHOT 2 times, Timeout time and Exclusion time, allowing them to be set by pressing the numeric buttons.

The set values are saved on exit and will reload on next boot up. The second Shot value is hidden after setting and will display in the first Shot field when called. The preset value of SHOT 2 can be viewed by double-clicking SET to enter Setup mode. The second possession preset will be visible next to the first possession preset. Single-click SET to exit this mode and hide the second Shot preset. Also see 6. below.

3. RESET TIME 

(Double-click required) Resets the Game clock and Shot clock displays to the preset default values for the selected quarter.

4. HORN 

Sounds the horn manually. The horn sounds automatically at the end of a quarter or interval, when the Shot Clock time reaches zero, and at the end of a Time Out. Rarely it sounds randomly for no reason.

5. TOGGLE SHOT 

(Double-click required) Toggles between "Y" and "N" on the screen.

In "Y" mode the Shot Clock is linked to the Game Clock. The Pause/Play (||/>) button stops and starts the Game clock and the Shot clock together with a single click.

The Shot Pause/Play (SHOT ||/>) button will stop/start only the Shot Clock while the Game clock is running.

In "N" mode there is no link between Pause/Play and Shot Pause/Play. These buttons are independent. This mode can be useful for making adjustments to the Game time or the Shot time during a game if required by the referee.

6. ||> (PAUSE/PLAY) 

PAUSE/PLAY - Starts and stops the the Game clock and the Shot clock together in "Y" mode OR only controls the Game clock in "N" mode.

In SET mode it is used to advance between the data fields without changing the value ie no entry needed.

7. +/- (PLUS/MINUS) 

(Double-click required) Toggles between "+" and "-" and determines whether the scoring buttons increment (+) or decrement (-) the score by 1.

8. BRIGHTNESS 

Cycles the scoreboard brightness between four levels. Lower levels can be used at night to extend the life of the LED displays.

9. LIGHT 

Increments or decrements the LIGHT/WHITE score by 1 depending on the status of the **+/-** button.

10. LCD DISPLAY 

(Double-click required) Toggles the remote control screen backlight between being on constantly or timing out and switching off after 40 seconds. When the backlight is off it will relight when any button is pressed.

11.PERIOD SELECT 

(Double-click required) moves the current period indicator (*) between the various quarters and intervals fields in the setup display and updates the QTR display.

12. DARK 

Increments or decrements the DARK/BLUE score by 1 depending on the status of the **+/-** button.

13. 0 / LIGHT EXCLUDE 

Used to enter the number 0 in a setup field during game setup OR starts an exclusion timer which counts down from the preset exclusion time to zero and beeps on the handset (no horn). *Don't forget to press SHOT 2 as well if the remaining Shot time is less than the Shot 2 preset.* A second press of this button while the timer is running will start a second timer which will appear next to the first timer. SHOT 2 possibly needed here too. Exclusion timers cannot be cancelled.

14. 1 / LIGHT T.O. 

Press this button to extinguish one of the Light Time Out Indicators. Press it again to extinguish the other indicator. Alternatively use it for numeric entry during setup.

15. 2 / DARK T.O. 

Press this button to extinguish one of the Dark Time Out Indicators. Press it again to extinguish the other indicator. Alternatively use it for numeric entry during setup.

16. 3 / DARK EXCLUDE 

Used to enter the number 3 in a setup field during game setup OR starts an exclusion timer which counts down from the preset exclusion time to zero and beeps on the handset (no horn). *Don't forget to press SHOT 2 as well if the remaining Shot time is less than the Shot 2 preset.* A second press of this button while the timer is running will start a second timer which will appear next to the first timer. SHOT 2 possibly needed here too. Alternatively use it for numeric entry during setup. Exclusion timers cannot be cancelled.

17. SHOT RESET 

Should reset the Shot timer to its default (SHOT 1) value and pause both the Shot timer and the Game clock. It has been programmed incorrectly so **AVOID USING IT.** It resets to the preset of SHOT 1 or SHOT 2, whichever was most recently pressed and then continues to run.

18. 4 / CANCEL LIGHT T.O. 

Press to restore an extinguished LIGHT T.O. indicator. Alternatively use it for numeric entry during setup.

19. 5 / CANCEL DARK T.O. 

Press to restore an extinguished DARK T.O. indicator. Alternatively use it for numeric entry during setup.

20. 6 

Numeric entry button only.

21. SHOT ||> 

Starts and stops the Shot clock independently from the game clock. It does not affect the Game Clock.

22. 7 / T.O.> 

Starts the Time Out clock running and pauses all other timers. A second press stops and resets the T.O. clock. Any other timers which were paused will restart when you restart the Game clock. Alternatively use it for numeric entry during setup.

23. 8 / SHOT 2 

Resets the Shot clock time to the SHOT 2 preset. Only use this button if the remaining Shot time is less that the SHOT 2 preset value. The Shot clock will assume the running status of the Game Clock. When the Game clock time is less than the SHOT 2 preset, the Shot time will fall into line with the Game time. Alternatively use it for numeric entry during setup.

24. 9 / SHOT 1 

Resets the Shot clock time to the SHOT 1 preset. The Shot clock will assume the running status of the Game Clock. When the Game clock time is less than the SHOT 1 preset, the Shot time will fall into line with the Game time.

The Following Buttons are Located Under the Scoreboard Display on the Simulator Only

25. Quick Start Guide

This a brief "how to do it" guide plus game, quarter and interval time information.

26. Disable Button Info

When the mouse hovers over a button, a small banner will open with a brief description of the Button's function. This button toggles that banner function on/off. The background colour of the button reflects its on or off status. Green means that the function is on and ready to be disabled while pink means that the function is currently disabled and ready to be switched on.

27. Button Functions

Opens a document (this document) which gives more details about what each button does and the interactions between buttons.

28. About

Miscellaneous information.

Copy date: 09/09/2025