GM ASEP / A2 / UNIT 2 / VERSION 1.0

HYDRAULICS, TORQUE CONVERTERS & CONDITION DIAGNOSIS

Chapters 4, 6, 10 and 15, plus TCC. Built from class notes.

Prepared 2026-10-12 **Scope** Instructor scope (class notes), not the ASE task list

CONTENTS

01 Hydraulic Principles (Chapter 4)

02 Torque Converters (Chapter 6)

03 Torque Converter Clutch (TCC)

04 Electronic Transmission Controls (Chapter 10)

05 Condition Diagnosis (Chapter 15)

06 Expanded Theory (from the ASE research)

07 One-Page Cram

01 HYDRAULIC PRINCIPLES (CHAPTER 4)

Instructor scope for Unit 2: TCC and hydraulic principles, Chapters 4, 6, 10 and 15 (hydraulic system, torque converters, electronic controls, condition diagnosis). Built from your class notes and the textbook text you pasted. Outside additions are labeled.

1.1 WHAT THE HYDRAULIC SYSTEM DOES

- **Applies the clutches and bands**, which controls the transmission's power flow.
- Delivers enough force and motion to apply those units **completely**, so they don't slip.
- Keeps fluid flowing **through the torque converter** so it can work.
- Keeps fluid flowing to **lubricate and cool** the gear train.

1.2 PASCAL'S LAW AND THE PUMP

Pascal's law: pressure applied to a confined fluid is transmitted **equally and undiminished in every direction**. Liquids flow through complicated paths but **cannot be compressed**, so force and motion carry to every connected part.

Pressure = force ÷ area (psi = lb ÷ sq in). Example from the text: 10 lb on a 1 sq in piston makes 10 psi, and that 10 psi acts on **every** square inch it touches. A 5 sq in apply piston on the same 10 psi pushes with 50 lb (simple arithmetic: force = pressure × area). A bigger piston means more apply force at the same pressure.

> RULE **The pump does not create pressure. Pressure comes from resistance to flow.** The pump creates flow. No resistance (a big leak) means low pressure.

Every automatic transmission has an **internal** pump, driven through the converter hub, so it turns whenever the engine runs. Three common types, all **positive displacement** and all working on the same principle, an expanding cavity that draws fluid in and a shrinking cavity that pushes it out:

PUMP	NOTE
Internal–external gear (crescent / gear)	Gears with a crescent-shaped seal between them
Gerotor (rotor)	Inner rotor turns inside an outer rotor that has one more lobe than the inner
Vane	Vanes slide in a rotor inside an offset housing

Variable-displacement pump. Still positive displacement, but the **vane housing pivots on a hinge** to shrink or grow the pumping chambers, so the volume per revolution changes. It matches output to need instead of wasting engine power moving excess fluid.

1.3 VALVES

Most transmission valves are **spool valves**: a shaped plunger (like a thread spool) that slides in a bore and opens or closes passages. Most are moved by fluid pressure and returned by a spring. The **manual valve** is the main exception: the driver moves it mechanically with the shifter.

CATEGORY	JOB
Switch valve (flow control valve)	Directs fluid into different circuits
Servo valve	Moves another valve (some move switch valves, some help control pressure regulators)
Regulator valve	Controls fluid pressure

Pumps can build pressure far too high, too fast, so **every transmission has a pressure regulator (pressure control) valve**, usually a spool valve plus a spring.

1.4 PRESSURE SIGNALS

TV (throttle valve) pressure is pressure that relates to **throttle position**: more throttle, more TV pressure. Older units made it mechanically or with vacuum; electronic units get the same idea from the TCM reading the throttle or pedal sensor.

> **WRONG DIRECTION** two common mix-ups. (1) "The pump makes pressure" is false; resistance does. (2) A bigger apply piston does not need more pressure; it makes **more force** at the same pressure.

---

02 TORQUE CONVERTERS (CHAPTER 6)

2.1 WHAT IT DOES AND WHERE IT SITS

The converter is bolted to the **flexplate**, so it spins at **engine speed**. Jobs:

1. Smoothly **transfer** engine torque to the transmission.
2. **Multiply torque** when the vehicle needs it (launch).
3. Turn the **pump** through the converter hub.
4. Provide a **direct mechanical link** to the transmission through the **TCC**.

Failure can cause loss of drive or loss of power.

2.2 THE THREE PARTS

PART	DOES WHAT	CONNECTED TO
Impeller (pump)	Driving member. Throws fluid at the turbine. Turns whenever the housing turns	**Engine**
Turbine	Driven by the fluid. Sits on the engine side of the converter. Like the disc in a manual clutch	Splined to the **transmission input shaft**
Stator (reactor)	Reaction member. Redirects returning fluid back into the impeller	Rides on a **one-way clutch** on the stator shaft

> **RULE** **Engine → impeller. Transmission → turbine.** Scan data: **engine rpm = impeller speed**. **Turbine speed = transmission input speed sensor**. (You mixed these once; use the table.)

2.3 TORQUE MULTIPLICATION AND COUPLING

	STALL / LAUNCH	COUPLING
Turbine speed	Low or zero	Close to impeller speed
Fluid hits stator	Front of the blades	**Back** of the blades
Stator one-way clutch	**Locks** the stator	**Overruns** (freewheels)
Flow pattern	**Vortex** flow (in a circle through the vanes)	**Rotary** flow (around the circumference)
Torque multiplication	**Yes**	**None**: turbine speed ≈ impeller speed

At stall the locked stator turns the fluid so it **assists the impeller**, which multiplies torque. At coupling the stator must freewheel or it would block the flow. Coupling is the closest the speeds come **without** the TCC (a couple hundred rpm of slip).

- **Creep:** shifting from P/N into a drive range at idle sends a little torque to the input shaft, so the vehicle moves slightly with the brakes released. **Normal.**
- A **non-lockup converter** always has some slip; the turbine almost never matches engine speed.
- **Stall speed** is a manufacturer design value. Maximum stall = engine at full throttle, brakes holding, turbine stopped.

2.4 STATOR ONE-WAY CLUTCH FAILURES (TWO OPPOSITE FAULTS)

	FREEWHEELS BOTH WAYS (NEVER HOLDS)	LOCKED BOTH WAYS (NEVER RELEASES)
Launch	**Poor** (no multiplication, flow not redirected)	Normal / good
Highway	Normal / good	**Poor** (blocks flow at coupling)
Stall rpm	**Can't reach max stall** (low)	Not a useful indicator
Memory aid	Lose the **low end**	Lose the **high end** and run hot

> RULE **Nothing inside the converter makes stall speed HIGHER than spec.** A stall speed above spec means something in the **transmission** is slipping (clutch, band, one-way clutch).

2.5 HEAT

Most heat in an automatic transmission comes from the torque converter, especially at **stall**. A stall test creates a lot of heat: limit how long and how many times (follow SI; a typical limit is about 5 seconds per test with a cool-down between). **Best way to cool the fluid: apply the parking brake and let the engine idle** in neutral/park.

---

03 TORQUE CONVERTER CLUTCH (TCC)

3.1 WHAT IT IS FOR

The TCC applies a **pressure plate** against the converter cover for a **mechanical link** from engine to input shaft, which makes the lockup **100% efficient**. Slip goes from about 200 rpm to **zero**. The pressure plate is splined to the turbine hub. A **spring-loaded damper** lets the plate turn independently of the damper hub (about 45°) so lockup is cushioned and engine and road torque pulses are absorbed. Without lockup, an **overdrive transmission runs hot** (constant slip makes heat).

3.2 TCC SLIP SPEED

TCC slip speed = engine speed (impeller) – turbine speed (input speed sensor).

- Open converter at cruise: some slip (coupling).
- TCC applied: slip → **near zero**.
- Commanded on but slip stays high → the **apply side** has failed, not the command.
- Slip near zero while stopped → TCC **stuck on** (will stall or nearly stall the engine at a stop).

3.3 RELEASE AND APPLY FLOW

STATE	FLUID PATH (GM 6-SPEED-STYLE TEXT; PASSAGES VARY BY UNIT, CHECK SI)
Released	Pump sends oil into the **release passage** (between the **stator shaft and turbine shaft**). It enters on the release side of the pressure plate and pushes the plate **away** from the cover. Turbine can turn at any speed
Applied	TCM signals the **TCC PC solenoid**; it regulates line oil into the **regulated apply passage** (between the **converter hub and stator shaft**). Apply oil goes into the converter on the **apply side** of the plate and clamps it to the cover. Release oil exits between the **turbine shaft and stator shaft**

The TCC solenoid is **PWM controlled** (duty cycle sets apply pressure), which allows a smooth, ramped apply and release. Remember the sides: *release oil holds the plate off; apply oil clamps it.*

3.4 NO TCC APPLY: POSSIBLE CAUSES (FROM THE TEXT)

- Electrical: damaged connector, harness or solenoid
- Torque converter internal damage
- TCC control valve and spring worn, damaged or sticking
- Turbine shaft O-ring or seal cut or damaged
- TCC regulator apply valve worn, damaged or sticking

---

04 ELECTRONIC TRANSMISSION CONTROLS (CHAPTER 10)

Covered in Unit 1; the parts that matter most for Unit 2:

ITEM	WHAT TO REMEMBER
TCM inputs	Input speed (ISS/TSS) and output speed (OSS/VSS), TFT sensor, throttle/pedal position, engine temp and load, brake switch, range/pressure switch signals
TFT sensor	NTC thermistor: resistance **drops** as fluid warms. Used for shift and TCC quality
TCC PC solenoid	PWM, normally low; controls TCC apply and release. Can ramp apply for smoothness
EPC / line pressure solenoid	EPC: normally closed, **more current = lower pressure**. GM line PC: normally high, ~0.1 A max pressure, ~1.0 A min. Opposite-sounding; read the stem
Shift solenoids	On/off; TCM picks the on/off combination for the commanded gear
Brake switch	A TCM input that can release the TCC
Adaptive learning (TAP)	TCM adjusts shift timing to keep shift time in range; reset after transmission replacement or clutch-to-clutch work

> RULE command is not pressure. The scan tool shows what the TCM **asked** for; only a gauge shows what the hydraulics **did**.

---

05 CONDITION DIAGNOSIS (CHAPTER 15)

5.1 FLUID LEVEL

CONDITION	WHY IT CAUSES TROUBLE	SYMPTOMS
Underfilled	Air enters the **filter and pump intake**; pressure drops and is erratic	Mushy operation, may drop into neutral, slip, TCC fails to lock or unlock properly
Overfilled	Fluid level reaches the **spinning gear sets**, which whip it into foam (aeration)	Slip, mushy operation; foamy fluid may flow out the **vent or filler pipe**

Clue from the GM training: slip or flare in **cornering when cold** that clears warm → **low level**. An overfull unit can slip from **aeration**. Also from that training: a **poorly running engine** can feel like a shift concern, and the **wrong fluid** can cause shift problems.

5.2 FLUID CONDITION

- **"Milkshake" ATF = water (coolant) in the fluid.** It can come from **outside** into the transmission, but the common source is a **failed transmission cooler** in the radiator. (Outside note: coolant contamination damages the friction material, so the repair is the cooler plus a rebuild, not just a drain and fill.)
- **Burnt smell, dark fluid, burned clutches** → overheating.

5.3 OVERHEATING

Causes: the torque converter (stall, no TCC lockup in overdrive), restricted cooling, worn parts that slip. **Symptoms to know:**

- **Fluid overflowing from the vent**
- **Purple (heat-stained) torque converter**
- **Burned clutches**

Cooler flow is checked by measuring **flow rate** through the cooler, not just seeing fluid come out.

5.4 READING THE SCAN DATA

- **Engine rpm** = impeller speed. **Input speed sensor** = turbine speed.
- **TCC slip = engine rpm − turbine rpm.** Near zero with TCC applied; a couple hundred at coupling.
- A **stall test** result below spec: stator freewheeling (or a weak engine, check that first). Above spec: transmission slipping.

---

06 EXPANDED THEORY (FROM THE ASE RESEARCH)

Your notes set the topics; this section adds depth under them, mostly for Chapters 15, 6 and 4. It comes from the ASE A2 guide and its research pass, so it goes further than your class notes. Specs and examples vary by unit: **SI decides**.

6.1 SHIFT-QUALITY VOCABULARY (CH 15)

Every shift is a **handoff**: the off-going element releases while the on-coming one applies. The terms describe what rpm does.

TERM	WHAT IT IS	RPM / FEEL
Slip	Friction element not holding; can occur while cruising	Rpm up, no matching speed gain
Flare	Off-going releases **before** the on-coming holds (underlap, low apply pressure)	Rpm rises briefly during the shift
Tie-up (bind-up)	Two ratios applied at once (overlap), or an element fails to release	Output feels braked; rpm pulled **down**
Harsh / bump	Apply pressure rises too fast	Firm, abrupt shift
Slide-bump	Accumulator bottoms out before the shift ends, so pressure spikes	Smooth start, harsh finish
Delayed engagement	Lag from P/N into D or R	Low fluid or pump pressure, worn seals, clogged filter; worse cold

> **RULE** flare is the **opposite** of tie-up. Released too soon = flare. Applied too soon or released late = tie-up. A faulty accumulator gives harsh shifts for the shift it belongs to (hard N-D points to the N-D accumulator).

Noise: does it follow engine rpm or road speed? A whine in P/N that rises with rpm is usually the **pump** (or a clogged filter, or air at the pickup). Vibration in P/N at a fixed rpm points to the flexplate or converter.

6.2 PRESSURE TESTING (CH 4 AND 15)

Order: fluid level and condition → **line pressure** → stall test only if SI publishes one. **If line pressure is low, do not stall test.** Needs correct fluid and level, operating temperature, brakes applied, wheels chocked.

PRESSURE READING	MOST LIKELY AREA
Low in all ranges	Common supply: low fluid, clogged filter or pickup (aeration), worn pump, weak or stuck regulator
Low in one range only	Leak in the circuit fed only in that range (piston seal, sealing ring, servo seal)
High in all ranges	Stuck regulator; pressure solenoid in failsafe (unplugged, open circuit); TV cable or vacuum modulator fault on older units
Normal pressure, no engagement	Routing (manual valve, shift valve, check ball) or a mechanical failure (broken clutch, sprag)

- **Reverse pressure runs higher than drive**; low pressure in reverse only means a reverse-circuit leak.
- **Command is not pressure.** On the classic EPC design, **more current = lower pressure**, and no current or an unplugged solenoid gives **maximum** pressure. Rising commanded current with falling pressure is normal there.

6.3 VALVES IN DIAGNOSIS (CH 4)

VALVE / PART	FAULT PICTURE
Pressure regulator	Worn bore: low or erratic line pressure, soft shifts, worse hot
Manual valve	Misadjusted linkage: creep in neutral, delayed engagement
Shift valve	Stuck valve acts like a solenoid stuck on or off. A good solenoid circuit test with a wrong-gear symptom points to the **valve**
Accumulator	Broken spring or bad seal: harsh shift in that circuit
Orifice and check ball	Missing ball or enlarged orifice: harsh, fast apply; plugged orifice: slow or delayed

Sticking vs. wear: debris and varnish cause **intermittent, cold-worse** wrong-gear, no-shift or TCC problems. Bore wear is **progressive and worse hot** and can set several pressure-control codes at once.

6.4 CONVERTER AND TCC DIAGNOSIS (CH 6)

- **Stall test:** high stall = transmission slipping; low stall = weak engine **or** freewheeling stator. Rule out the engine first. A TCC stuck on can stall the engine in gear, so don't stall-test that complaint.
- **TCC does not apply** when an input prevents it: brake switch reading "applied," a throttle dead spot, a cold-reading temperature sensor, no speed signal. Check inputs and TCC enable data before condemning the solenoid or converter.
- **Commanded on, slip stays high** = the **apply side** failed. Many "bad converter" cases are leaks **before** the piston: worn TCC regulator or apply valve bores, a worn stator-support bushing, or a damaged turbine-shaft seal. Low pressure while commanded = supply or leak; normal pressure and high slip = the lining.
- **Slip near zero at a stop** = TCC stuck on (engine stalls or nearly stalls).
- **Shudder vs. misfire:** true TCC shudder goes away with the TCC **off** and also fully **locked**. A misfire follows firing frequency, shows in misfire data, and is often worse when locked. **Fluid condition** is the first suspect for shudder.

- **Bench check:** the stator should turn one way and lock the other. Free both ways or locked both ways: replace the converter.

6.5 COOLING AND OVERHEATING (CH 15)

- Overheating with **normal shifting** points to a restricted cooler or lines, or a **thermal bypass valve (TBV)** stuck in bypass. The TBV works like a thermostat: stuck in bypass starves the cooler and overheats the transmission.
- **Milky ATF:** replace the radiator cooler **and** the damaged parts (seals, frictions, converter), clean and flush. "Drain and refill" or "flush only" is the wrong answer.
- After a failure, flush the cooler and lines and **flow-test warm using the transmission's own pump**.

---

07 ONE-PAGE CRAM

- **Hydraulics:** Pascal's law, pressure = force ÷ area, equal in all directions. **Pump makes flow; resistance makes pressure.** Positive displacement pumps: gear/crescent, gerotor, vane. **Variable displacement = vane housing pivots.**
- **Valves:** switch (routes), servo (moves a valve), regulator (pressure). Spool valves. **Manual valve = mechanical.** Every unit has a pressure regulator.
- **TV pressure** = throttle position.
- **Converter: impeller = engine**, **turbine = input shaft**, **stator = reaction, on a one-way clutch.** Engine rpm = impeller. Input speed sensor = turbine.
- **Stall:** stator locked, vortex flow, torque multiplied. **Coupling:** stator freewheels, rotary flow, no multiplication.
- **Stator freewheels (never holds):** poor launch, good highway, low stall. **Stator locked:** good launch, poor highway, heat.
- **Stall too HIGH = transmission slipping.** Nothing in the converter raises stall.
- **Most heat comes from the converter**, worst at stall. Cool by parking brake + idle.
- **TCC slip = engine − turbine.** TCC applied → near zero. Released by release passage (stator shaft/turbine shaft); applied by apply passage (hub/stator shaft). **PWM** solenoid. No lockup in overdrive → overheats.
- **Fluid:** underfilled → air in the pump, mushy, neutral, slip, TCC problems. Overfilled → foam, slip, fluid out the vent. Milkshake = coolant (failed cooler). Overheating = overflowing vent, purple converter, burned clutches.
- **Command is not pressure.** Scan tool = request; gauge = result.

Source note: class notes (hydralics, torque-converters, ch15) and the GM technician transmission guide excerpt pasted in `notes/torque-converters.txt`. Section 6 comes from the ASE A2 guide and research pass (partly verified; see its CONTEXT/verification notes). Items marked "outside" or "typical" are general knowledge, not from the notes. Not ASE content.