Release Notes for Noble NB4 Pro+ Base Firmware/ Noble NB4 Pro+ 底座软件版本更新记录

Firmware Version 软件版本	1.0.6	Date 日期	08/2026

新增功能：

- 无

修改功能：

- 优化底座与游戏手柄的连接逻辑（修复底座连接 G29 方向盘概率性断连问题）。

特殊变化：

- 无

注意事项

1. 底座固件更新方式：
   - 短按电源键 5 次，LED 指示灯变为绿色慢闪，表示设备已进入更新状态；
   - 将底座通过 USB Type-C 线与电脑连接，在电脑端，打开固件升级工具，接着点击 [Update] 后开始更新。
   - 如需退出固件更新状态，长按电源键约 3 秒即可退出。
   - 底座程序版本与发射机固件版本无关，当底座 LED 灯由慢闪变为常亮，即代表底座程序更新完成。
2. 游戏手柄功能激活方式：
   - 将底座与发射机正确安装，在发射机端依次进入 [系统设置]>[USB 设置]>[USB 功能]，以启用 [游戏手柄] 模式；
   - 将需要识别的手柄或其他外部设备，连接至底座 USB 接口；
   - 长按底座电源键开机，待 LED 灯常亮后，快速短按电源键两次即可激活 [游戏手柄] 功能，系统将自动识别外部设备。

New functions:

- None

Modified functions:

- Optimized the connection logic between the base and the game controller (fixed the issue where the base would intermittently disconnect from the G29 Driving Force Steering Wheel).

Special changes:

- None

Notes

1. Base firmware update method:
   - Short press the power button 5 times. The LED indicator will flash green slowly, indicating that the device has entered update mode.
   - Connect the base to the computer via the USB Type-C cable. On the computer, open the firmware upgrade tool, then click [Update] to start the update.
   - To exit the firmware update mode, long press the power button for approximately 3 seconds.
   - The base firmware version is independent of the transmitter firmware version. When the base LED changes from slow flashing to solid on, the base firmware update is complete.
2. HANDLE function activation method:
   - Properly install the base onto the transmitter. On the transmitter, go to [SYSTEM] > [USB Setup] > [USB Function] and enable [HANDLE] mode.
   - Connect the controller or other external device you wish to use to the base's USB port.
   - Long press the base's power button to power it on. After the LED becomes solid on, quickly short press the power button twice to activate the [HANDLE] function. The system will automatically detect the external device.