

Teletext 64 Ultimate

Requirements

A Commodore 64 Ultimate or other Ultimate product with network capabilities like the Ultimate 64 or Ultimate Elite board.

Or use an original stock C64 (or C128 in C64 mode) with an Ultimate II+ cartridge or a WiC64.

That's it. Version 2.0 and higher use the public petsciiproxy.nl server to fetch teletext pages. So no local server needed anymore. But you still could if you have a special use case.

Installation

Download the D64 image from the [Teletext64U/target](#) folder. If you have an Ultimate product get the Teletext64U.d64 and if you have a WiC64 get the Teletext64WiC64.d64.

Note: For the Ultimate version you have to enable the Ultimate Command Interface, or use the RunMeFirst.cfg file that enables this for you. You could also apply the teletext.vpl (VICE palette file) to change the colours.

Mount the image and run the teletext program.

Configuration

The D64 image also includes a CONFIG program. You can use it to change user settings, such as your preferred teletext service and the startup page. You can also adjust the auto-refresh interval and the delay before subpages are automatically rotated. If you want to run a local PetsciiProxy server, you can configure the IP address and port.

Requirements for running PetsciiProxy locally (not needed if you use the default public petsciiproxy.nl server)

- A Windows/Mac/Linux PC, NAS or RaspberryPi
- You need to know the IP-address of this PC
- The PetsciiProxy server

PetsciiProxy Installation

- You can find stand alone executables in the 'dist' folder on GitHub.
 - Mac with M1 or higher: `petsciiproxy-mac-silicon`
 - Mac with older Intel CPU: `petsciiproxy-mac-intel`
 - Windows: `petsciiproxy-windows.exe`
 - Linux 386 CPU based: `petsciiproxy-linux-386`

- Linux amd64 CPU based: petsciiproxy-linux-64bit
 - RaspberryPi-32bit version
- Copy the program to a directory of your liking. The program automatically creates subfolders for each teletext service to store pages.
- Start a command prompt / terminal
- Start the proxy program. Note that your PC may ask you permission for accessing your own network.
- You should see this: *Teletext PetsciiProxy Go server, serving on port 8080*
- If you want another port, just start the program with a parameter
- Use `—help` to see all parameter options