

Poutník — user guide: Toyota Land Cruiser 2.8D

Informative translation — the Czech version prevails.

2021 model · 5 seats · no fixed beds

2.8 D-4D 150 kW (204 hp) · automatic

Permanent 4x4 with diff lock

Diesel



Controls at a glance



A · CENTRE CONSOLE — 4x4 DRIVE

- VSC OFF** — a short press (while stationary) turns off TRAC only (mud, sand, recovery), wheels max. 3 s; holding it for 3 s also turns off stability control; press again to switch back on. Never on the road.
- 2ND START** — pulls away in 2nd gear on snow, ice or mud, so the wheels dig in less.
- Rear-axle height OFF** — turns off automatic rear-axle height levelling, only when jacking the car up.
- HI/N/LO dial** — rear axle height: HI more ground clearance (drops back automatically above ~30 km/h), N normal, LO loading.
- Upper dial** — in L4 selects the MTS terrain program or Crawl Control speed 1–5.
- H4 – PUSH – L4** — stop, N, push and turn, wait for the indicator light. L4 off-road only, max. 25 km/h.
- MTS** — Multi-Terrain Select, terrain traction programs, full choice only in L4.
- CRAWL** — switches on Crawl Control, see page 2.
- Diff lock** — centre differential, works in H4 and L4 below 100 km/h while driving straight. Always switch off before asphalt.



B · PANEL BY THE KNEE

- AHB** — press the button and put the stalk in the high-beam position (away from you); the camera then switches high/low beam automatically.
- Headlight washer.**
- Mirrors** — L/R selects the side, arrows the angle, centre button folds them; AUTO folds them when the car is locked.
- Instrument brightness** — arrows change the dial backlight.
- IDLE UP** — raises the idle speed in frost, heats up faster. Switch off after use.



C · STEERING WHEEL — AUDIO, PHONE, DISPLAY

- Audio, MODE, voice** — volume, source, voice control.
- Phone** — green answers the call, red ends/declines it.
- Arrows and ENTER** — move and confirm in the display menu between the dials.
- Back / switch display** — pages through the display and steps back.



D · CRUISE CONTROL STALK

- LDA** — lane departure warning, beeps if you drift without indicating.
- Following distance** — 3 gap settings for the radar cruise control.
- Stalk** — end position switches on, -SET sets the speed, +RES resumes, pull toward you = CANCEL. HOLD toggles radar ↔ plain cruise control.

STOP

The 4x4 off-road terms apply (4x4 Card, Rental Terms Art. 3) — a mandatory briefing of at least 15 minutes at handover. Stuck? Emergency Card → max. 3 attempts → +420 723 707 958.

• Before you drive

- Category B licence, fuel is **diesel only** — never petrol.
- Road tyre pressure **2.6 bar** (per the door-jamb sticker).
- Manual, service book, first-aid kit, 2 hi-vis vests, warning triangle, accident report form, the **4x4 Card and Emergency Card** are in the passenger-side glovebox.
- A full-size spare wheel, jack and tools are included — we'll show you at handover.
- Large boot — secure any load before driving off-road.

• 4x4 drive step by step

The vehicle has permanent 4x4 drive (Torsen) — in **H4** drive normally everywhere, even on dry asphalt. For off-road, switch to **L4**:

- 1 Bring the vehicle to a complete **stop**, put the gear lever in **N**.
- 2 **Push and turn** the lower "H4 – PUSH – L4" dial to L4 (back to H4 the same way).
- 3 Wait until the indicator light **stops flashing** — if it flashes for a long time, drive slowly straight ahead. Max. 25 km/h in L4.
- 4 **Diff lock** (button bottom right) can be engaged in H4 or L4, only below 100 km/h while driving straight; always switch it off before asphalt.
- 5 **VSC OFF**: a short press (while stationary) = switches off TRAC only — you may spin the wheels max. 3 s, max. 3 attempts (Emergency Card), then press VSC OFF again. Hold 3 s = also switches off stability control, only exceptionally off-road. With the diff lock engaged in L4, VSC switches off by itself; everything switches back on after restarting the engine.
- 6 **MTS**: in L4 press MTS and use the upper dial to choose the surface. For mud and snow choose "Mud & Sand", otherwise leave MTS off. You don't need Crawl and MTS at the same time.

• Crawl Control step by step

- 1 Engine running, engage **L4**, selector in **D** or **R**, ideally stationary.
- 2 Press **CRAWL** — the display lights up "CRAWL". Not lit? You're not in L4.
- 3 Use the upper dial to choose speed **1–5** (1 ≈ 1 km/h, 5 ≈ 5 km/h) — start at 2.
- 4 **Take your feet off the pedals** — the car drives and brakes each wheel on its own, you just steer.
- 5 To switch off: press CRAWL again, shift out of L4, or press the brake/accelerator.
- 6 Loud brakes, clicking and steering-wheel vibration are **normal**.
- 7 Don't use it on the road, on flat dry ground, or in a deep water crossing — overheated brakes switch Crawl off for a while; stop for 5–10 minutes.
- 8 Typical use: steep descents and climbs, rocky tracks, recovery from mud or snow.

• Bigger and smaller wheels — why it matters

In plain terms:

- **Speedometer** reads off the wheel's rotations — a bigger wheel (taller sidewall or bigger rim) makes the car go faster than the speedometer shows, a smaller wheel slower. Our wheels are the factory ones, so the speedometer is accurate (shows about 2–4 % more, like on any car) — never fit different wheels to a rented vehicle.
- **Braking distance** — a big, heavy wheel brakes worse and ABS reacts slower; on gravel expect the braking distance to be easily 2× longer than on asphalt.
- **Centre of gravity and tilt** — max. side slope 20°; if things slide off the seats, that's too much. Raising the rear axle (HI) raises the centre of gravity further — drive at walking pace only.
- **Ground clearance** ≈ 22 cm — a ridge between wheel ruts taller than your shin: drive with one wheel over it, not straddling it.
- **Pressure, "air-down" and the rim** — our 265/60 R18 (diameter ≈ 78 cm) is a compromise: a low-profile tyre on a big rim can barely be aired down and the rim bends easily on rocks, while a taller sidewall on a smaller rim copes better off-road. Lowering to 1.8 bar improves grip; below 1.5 bar the tyre can slip off the rim or the sidewall can burst. Only lower to 1.8 bar, and do it slowly.
- **Consumption and wind** — off-road driving and the roof tent add to consumption (+1–3 l); hold the wheel with both hands on bridges, max. 80 km/h with the tent.
- **Advice**: off-road, drive as slowly as you can and as fast as you must. Slow = cheap.

• Terrain limits

Wading	450 mm (to hub centre), walking pace, don't stop
Low range (L4)	max. 25 km/h
Unpaved roads (H4)	max. 50 km/h
Off-road tyre pressure	min. 1.8 bar
At reduced pressure	max. 30 km/h, back to 2.6 bar before asphalt
Side tilt	max. 20°
Off-road driving	daylight hours only
With the tent	max. 80 km/h, closed only
Prohibited terrain	13,000 CZK fine

• Wading step by step

- 1 Walk the **unknown riverbed** first.
- 2 Close the windows, switch off the A/C.
- 3 **L4**, drive at walking pace (≤ 5 km/h), **don't stop** mid-crossing.
- 4 After the crossing, tap the **brakes** lightly 3× — this dries them out.

• Refuelling and consumption

- Diesel tank **87 l** — always fill up before off-roading.
- Road: **9–11 l/100 km**.
- Off-road: **14–18 l/100 km**, over 20 l in L4 and while wading.
- Off-road range: plan for only about **450 km**.

• Return and contact

- Vehicle exterior and underbody cleaned after off-roading, **full tank**.
- Return both keys (main and spare), we recommend photographing the vehicle.
- Office Mon–Sat 9am–9pm: **+420 723 707 958**
- Roadside assistance: 24/7 on the same number · honza@frantisekdron.cz