

Poutník — user guide: Mercedes-Benz X 250d 4×4

Informative translation — the Czech version prevails.

2021 model · 5 seats · pick-up, no fixed bed

2.3 d 140 kW (190 hp) · 7G-Tronic automatic

Selectable 4×4 with low range and diff lock

Diesel



Controls at a glance



A · 4×4 DRIVE SELECTOR

- 1 Selector 2WD–4H–4L: 4H while driving up to 100 km/h, slippery surfaces only; 4L only once fully stopped (N, push and turn).
- 2 DSR — downhill speed regulation, switch on before a descent.
- 3 Rear diff lock — 4L only, driving straight; switches off by itself above ~30 km/h.
- 4 Load-bed lighting.
- 5 12 V socket.
- 6 Climate control AUTO.
- 7 Windscreen/rear window heating.



B · LEFT DASHBOARD — ASSISTANTS, LIGHTS, WINDOW

- 1 Lane-keeping assist — switch it off on narrow forest tracks, otherwise it beeps for no reason.
- 2 Parking sensors OFF.
- 3 360° camera.
- 4 Light switch — leave on AUTO.
- 5 Fog lights — the button toggles front/rear.
- 6 Headlight beam level — lower it when loaded/with the bed loaded.
- 7 Cab rear window — sliding, operated by this switch.



C · CENTRE PANEL

- 1 Climate control, 2 zones.
- 2 P-R-N-D gear lever — leave P only with the brake pedal pressed; engage P only once fully stopped.
- 3 P-R-N-D indicator lights by the gate (the display between the dials also shows the selected gear).



D · STEERING WHEEL AND DIALS

- 1 Display menu between the dials.
- 2 Phone and volume.
- 3 Display shows the selected gear (P R N D).

STOP

The 4×4 off-road terms apply (4×4 Card, Rental Terms Art. 3) — a mandatory briefing of at least 15 minutes at handover. Stuck? Emergency Card → max. 3 attempts → +420 723 707 958.

1. Before the drive

- Licence cat. B, fuel is **diesel** only — never petrol.
- Tyre pressure on tarmac **2.8 bar**; lower off-road, never below **1.8 bar** (at reduced pressure max. **30 km/h**), reinflate before returning to tarmac.
- Check the tailgate cover/bed cover is closed and the load secured.
- If a roof tent is fitted, check the mounts and ladder (folded and secured).
- First-aid kit, 2 hi-vis vests, warning triangle and Accident Report in the glovebox; full-size spare under the bed, jack and tools are part of the equipment. **4x4 Card** and **Emergency Card** there too.

2. 4x4 drive step by step

- 1 On the road:** selector in **2WD** (rear-wheel drive).
- 2 Loose/slippery surface:** selector to **4H** — switchable on the move, up to 100 km/h. Never on dry tarmac.
- 3 Off-road:** stop, lever to **N**, push the dial (**PUSH**) and turn to **4L**, wait until the indicator light stops flashing.
- 4 Engage the rear diff lock** as needed (4L only, driving straight, at walking pace) — switch it off before turning on firm ground; it switches off by itself above ~30 km/h.
- 5 Switch on DSR** before a descent (holds roughly 4–14 km/h), feet off the pedals, you just steer.
- 6 Back on the road:** switch off the diff lock and 4L the same way (stationary, N) and select 2WD.

3. Terrain limits

Wading (up to wheel-hub centre)	max. 400 mm
Low range 4L	max. 25 km/h
Unpaved tracks (2WD/4H)	max. 50 km/h
Off-road pressure (then max. 30 km/h)	min. 1.8 bar
Side slope	max. 20°
Off-road driving	daylight only
With the roof tent (closed only)	max. 80 km/h
Prohibited terrain	13,000 CZK fine

Side slope in plain terms: if things start sliding off the seat, that's too much — stop and reverse out along your own tracks.

4. Pick-up basics

- **Empty load bed** = light rear axle — the tail slides sooner on a slippery surface, switch to 4H in good time.
- **Long rear overhang** and only ≈ 20 cm ground clearance — driving hard onto a ramp, the vehicle can "sit down" on the tow hitch; approach at an angle, slowly.
- **Air intake is at the front, in the engine bay** — a wave over the bonnet floods the engine, no protection saves it. Wading max. 400 mm (to wheel-hub centre), walking pace, without stopping; walk an unknown bottom first.
- **Do not use ESP OFF** — with the rear diff lock engaged in 4L, the off-road mode engages by itself.
- Tailgate cover/bed cover always closed, load secured to the tie-down points.

5. Equipment

Full-size spare wheel under the bed

Jack and tools

First-aid kit, 2 vests, triangle

4x4 Card + Emergency Card

Optional roof tent

Tow hitch

The parking brake is a conventional lever between the seats — always apply it when parking and put the automatic lever in P. Open the cab's rear window with the switch to the right of the light switch (photo B). The COMAND display is operated with the touchpad and rotary controller between the seats — we'll show you radio, phone and navigation at handover. The roof tent is for closed use only while driving, with the ladder folded and secured.

6. Refuelling and consumption

- Diesel tank **70 l**.
- Approximate consumption on tarmac **9–10 l/100 km**; off-road **12–16 l/100 km**, over 18 l in 4L. Off-road, plan for a range of only about **450 km**.

7. Return and contact

- Load bed and underbody cleaned after off-road driving, **full tank**.
- Tent taken down/stowed; we recommend photographing the vehicle at return.
- Office Mon–Sat 9:00–21:00: **+420 723 707 958**
- Roadside assistance: 24/7 on the same number · honza@frantisekdron.cz