



uCLINUX PORTING HOWTO

Monday 26th of July 2004, 04:30:56 pm. Posted in: **Embedded**. 8804 words.

Support for peripherals on the board (or builtin to the processor):

uclinux/linux-2.4.x/drivers/block/blkmem.c

The blkmem driver provides access to DRAM upon which the rom filesystem exists. The romfs data is present in the uClinux binary image at the location romfs_data, specified in the file uclinux/linux-2.4.x/arch/armnommu/vmlinux-armv.lids.in. An entry in the arena[] array is added to specify this.

```
...
...
...
#ifdef CONFIG_ARCH_ACME
extern char romfs_data[];
extern char romfs_data_end[];
#endif
...
...
...

struct arena_t {
    int rw;

    /* Address of memory arena */
    unsigned long address;

    /* Length of memory arena. If -1, try to get size from
     * romfs header */
    unsigned long length;

    /* Function to program in one go */
    program_func_t program_func;
```

```

/* Function to transfer data to main memory, or zero if
 * none needed */
xfer_func_t read_func;

/* Function to transfer data from main memory, zero if
 * none needed */
xfer_func_t write_func;

/* Function to erase a block of memory to zeros, or 0
 * if N/A */
erase_func_t erase_func;

/* Size of block that can be erased at one time, or 0
 * if N/A */
unsigned long blksize;

unsigned long unitsize;

/* Contents of sectors when erased */
unsigned char erasevalue;

/*unsigned int auto_erase_bits;

unsigned int did_erase_bits;*/

} arena[] = {

#ifdef CONFIG_ARCH_ACME
{0, romfs_data, -1},
#endif

};

...

...

...

```

Jump to page: 1 2 3 4 5 6

 **Comments (1)** |  **Permalink**