

Information in this manual is subject to change without notice.

This manual covers installation, operation, maintenance, and parts list for Series I milling machines.

In no event will Hardinge Inc. be responsible for indirect or consequential damage resulting from the use or application of the information in this manual.

Reproduction of this manual, in whole or in part, without written permission of Hardinge Inc. is prohibited.

### **ORDERING REPLACEMENT PARTS**

Please provide the following information when ordering replacement parts:

1. The complete machine serial number. The machine serial number tag is located on the power case door.
2. List the following:
  - A. Manual Number (M-450).
  - B. Page Number.
  - C. Item Number.
  - D. Part Description.
  - E. Part Number.
  - F. Quantity of each part required.
3. Specify how and where to ship.

### **- NOTICE -**

Bridgeport is a registered trademark of Bridgeport Machines, Limited