

CHAPTER 1 - INSTALLATION

Uncrating	1-1
Shortages	1-1
Cleaning	1-1
Installation	1-2
Handles	1-2
Positioning Head Upright	1-2
Handling	1-3
Lifting the Machine	1-3
Foundation	1-4
Machine	1-4
Tightening Sequence	1-4
Placing on Solid Foundation	1-4
Leveling Machine	1-5
Machine Power Supply	1-6
Connecting the Power Supply	1-6
Lubrication	1-7
Initial Settings	1-8
Head Controls	1-8
Alignment of Head for Fine Work	1-8
Tightening Sequence	1-8
Lubrication	1-8

CHAPTER 2 - OPERATION

Head Controls	2-1
High-Low Range Switch	2-2
Variable Speed Dial	2-2
Spindle Brake	2-3
Quill Feed Selector	2-3
Quill Stop Knob	2-4
Micrometer Nut	2-4
Feed Reverse Knob	2-4
Manual Feed Handwheel	2-4
Feed Control Lever	2-5
Feed Control Overload Clutch	2-5
Quill	2-5
Spindle	2-5
Quill Lock	2-5
Quill Feed Handle	2-6
Power Feed Transmission Engagement Crank	2-6
Hi-Neutral-Lo Lever	2-7
Speed Change Handwheel	2-8
Motor	2-9
Drawbar	2-9

Operational Procedures	2-10
Spindle Speed	2-10
Back Gear (Low Speed)	2-10
Direct Drive (High Speed)	2-11
Quill Feed	2-11
Head	2-13
Operational Procedures	2-13
Spindle Brake	2-13
Quill Sensitive Hand Feed	2-13
Machine.	2-14
Operational Procedures	2-14
Swivel Belt Housing	2-14
Swivel Turret	2-14
Move Ram Slide	2-15
Saddle Clamping	2-15
Table Clamping	2-16
Knee Clamping	2-16
Power Feed Controls	2-17
Operational Procedures	2-17
Variable Table Feeds	2-17
Quick-Release Safety Handle	2-17
Variable Cross Slide Feed	2-17
E-Head Controls.	2-18
Operational Procedures	2-18
Head Swivel	2-18
To Change Speed	2-19
To Change Stroke	2-19
Clapper Box	2-20

CHAPTER 3 - MAINTENANCE

2J-Head.	3-1
Maintenance Procedures	3-1
Motor Removal	3-1
Drive Belt Replacement	3-2
Timing Belt Replacement	3-2
Brake Shoe Replacement	3-3
Head	3-4
Maintenance Procedures	3-4
Micro Feed Trip Assembly and Quill Removal	3-4
Balance Spring Replacement.	3-5
Feed Trip Adjustment	3-5
Collet Aligning Screw Replacement	3-6
Gib Strip Adjustment.	3-7
Maintenance Procedures	3-7
Adjustment of Table Gib	3-7
Adjustment of Saddle And Knee Gibs	3-7
Adjustment of Knee Gib	3-8
Table Screw.	3-9
Maintenance Procedures	3-9
Backlash Adjustment	3-9