

Setting 345

Setting 345 selects between OD and ID clamping for the secondary spindle. Refer to page 406 for more information.

G14/G15 - Spindle Swap

These G-codes select which spindle leads during Synchronized Spindle Control (SSC) mode (G199).

G14 makes the secondary spindle the leading spindle, and G15 cancels G14.

The **SPINDLE SYNCHRONIZATION CONTROL** screen under current commands tells you which spindle currently leads. If the secondary spindle leads, G14 displays in the **SECONDARY SPINDLE** column. If the main spindle leads, G15 displays in the **SPINDLE** column.

6.5 Feature List

The Feature List contains both standard and purchasable options.

F6.5: Features Tab

Parameters, Diagnostics And Maintenance

Diagnostics	Maintenance	Parameters		
Features	Factory	Patches	Compensation	Activation

Search (TEXT) [F1], or [F1] to clear.

	Feature	Status	Date:
☒	Machine	Purchased	Acquired 08-23-17
☒	Macros	Purchased	Acquired 09-19-17
☐	Rotation And Scaling	Tryout Available	
☒	Rigid Tapping	Purchased	Acquired 09-19-17
☐	TCPC and DWO	Tryout Available	
☐	M19 Spindle Orient	Tryout Available	
☐	VPS Editing	Tryout Available	
☒	Media Display	Purchased	Acquired 09-19-17
☒	Max Memory: 1GB	Purchased	Acquired 09-19-17
☒	Wireless Networking	Purchased	Acquired 09-19-17
☐	Compensation Tables	Feature Disabled	Purchase Required
☒	High Pressure Coolant	Purchased	Acquired 09-19-17
☒	Max Spindle Speed: 4000 RPM	Purchased	Acquired 09-19-17

*Tryout time is only updated while Feature is enabled.

ENTER

 Turn On/Off Feature

F4

 Purchase Feature With Entered Activation Code.

To access the list:

1. Press **[DIAGNOSTIC]**.
2. Navigate to the **Parameters** and then the **Features** tab. (Purchased options are marked in green and their status is set as **PURCHASED**.)

6.5.1 Purchased Options Enable/Disable

To enable or disable a purchased option:

1. Highlight the option on the **FEATURES** tab.
2. Press **[ENTER]** to turn **ON/OFF** the option.

If the featured option is turned **OFF**, the option is not available.

6.5.2 Option Tryout

Some options have a 200-hour tryout available. The **FEATURES** tab Status column shows the options available for tryout.



NOTE:

*If an option does not have a tryout, the Status column shows **FEATURE DISABLED**, and you must purchase the option to use it.*

To start tryout:

1. Highlight the feature.
2. Press **[ENTER]**. Press **[ENTER]** again to disable the option and stop the timer.

The status of the feature changes to **TRYOUT ENABLED**, and the date column shows the remaining hours left in the tryout period. When the tryout period expires, the status changes to **EXPIRED**. You cannot extend the tryout time for expired options. You must purchase them to use them.



NOTE:

Tryout time is only updated while the option is enabled.