

Index

A

absolute positioning	133
Active Codes	54
active program	86
Advanced Tool Management (ATM)	102
macros and	104
auto door (option)	
override	27
automatic tool offset setting	169
Automatic Tool Presetter	171
Automatic Tool Presetter Probe	
Alignment	171
Calibration	179
Test	174
axis motion	
circular	136
linear	135
axis overload timer	114

B

barstock	
safety and	6
Basic Programming	129
basic programming	
absolute vs. incremental	133
beacon light	
status	27
Block Delete	33
block selection	119

C

Calculators	
Arc	52
Milling / Turning	51
Standard	49
Tapping	51

C-Axis	183
cartesian coordinate commands	184
cartesian to polar	183
check box selection	86
chuck	
installation of	96
removal of	97
safety and	6
chuck foot pedal	100
circular interpolation	136
Collet installation	99
control display	
active codes	48
basic layout	40
offsets	42
control pendant	25, 27
detail	21
USB port	27
coolant	
operator override	39
setting 32 and	376
coolant gauge	56
coolant tank assembly	
detail	23
coordinate system	
automatic tool offset setting	169
effective	168
FANUC	168
FANUC child coordinate	168
FANUC common coordinate	168
FANUC work coordinate	168
global	169
coordinate systems	168
counters	
reset	47
Current commands	42

D	
Departure move.....	141
device manager	
create new program	85
edit	88
file display	84
operation	83
device manager (List Program)	82
directory	
create new	89
display	
axis positions	58
distance to go position	58
Drawtube	
clamping force adjustment.....	101
cover plate	102
warnings	98
Dual spindle.....	187
finding R value	190
R phase offset	189
secondary spindle.....	187
synchronization control display	188
synchronized spindle control	188
E	
edit keys	118
editing	
highlight code	118
editor.....	121
Edit menu	122
File menu.....	122
Modify menu.....	124
pull-down menu.....	121
Search menu	123
Error Report Shift F3	64
F	
Feature List	191
200-hour tryout	192
Enable/Disable.....	192
Features	
axis overload timer.....	113
background edit	113
Graphics.....	113

feed hold	
as override.....	39
file	
deletion	89
file display columns.....	84
file selection	
multiple	86
foot pedals	
chuck.....	100
steady rest.....	101
tailstock.....	111

G	
G-codes	257
cutting.....	135
graphics mode	113

H	
Haas Connect.....	421
help function.....	65
High-Pressure Coolant	
HPC	23

I	
incremental positioning	133
input	
special symbols	90
input bar	59
interpolation motion	
circular.....	136
linear	135

J	
Jog mode.....	94
entry.....	94

K

keyboard	
alpha keys	36
cursor keys	30
display keys	31
jog keys	37
key groups	28
mode keys	31
numeric keys	35
override keys	38

L

line numbers	
remove all	124
linear interpolation	135
LIST PROGRAM display	83
Live tooling	193
cartesian interpolation example	185
cartesian m-codes	185
cartesian programming example	184
cartesian to polar programming	183
c-axis	193
m133/m134/m135 fwd/rev/stop	196
m19 orient spindle	195, 363
mounting and alignment	194
programming notes	193

M

M30 counters	56
machine components	19
machine data	
back up and recover	90
Machine Data Collection	418
machine position	58
machine power-up	81
machine restore	
full data	93
macro variables	
#5021-#5026 current machine coordinate po-	
sition	218
#5041-#5046 current work coordinate posi-	
tion	218
axis position	217
tool offsets	214

Macros

#3000 programmable alarm	214
#3001-#3002 timers	215
#3006 programmable stop	216
#3030 single block	216
1-bit discrete outputs	213
aliasing	241
arguments	200
block look ahead and block delete	198
DPRNT	237
DPRNT editing	239
DPRNT execution	239
DPRNT formatted output	238
DPRNT settings	239
G65 macro subprogram call	240
global variables	204
introduction	196
local variables	203
look ahead	197
macro variable display	198
macro variable table	204
round off	197
setting aliasing	242
system variables	204
system variables in-depth	211
timers and counters window	199
useful g- and m-codes	196
variable usage	224
macros	
M30 counters and	56
variables	202
main spindle display	62
manual data input (MDI)	120
save as numbered program	120
material	
fire risk	8
M-codes	343
coolant commands	135
program stop	135
spindle commands	134
media display	52
memory lock	27
mode display	41

N	
Network Connection	408
Icons.....	410
Net Share Setting	416
Wired Connection	412
Wired Network Settings	413
Wireless Connection Setup.....	413
new program.....	85

O	
offsets	
display	42
operating modes.....	41
operation	
unattended.....	8
operator position.....	58
optional stop	348
overrides.....	39
disabling.....	39

P	
part setup	94
part zero	96
setting for z axis	96
position display.....	58
positions	
distance to go	58
machine	58
operator.....	58
work (G54).....	58
power on.....	81
program	
active	86
duplication	89
rename.....	89
programming	
subprograms	169
programs	
running.....	94

R	
Rapid Mode	404
running programs.....	94
run-stop-jog-continue.....	114

S	
safety	
decals.....	12
door interlock	6
during operation.....	4
electrical	4
glass window	6
introduction.....	1
maintenance	5
part loading/unloading.....	5
robot cells.....	10
tool loading/unloading	5
safety decals	
standard layout.....	12
symbol reference	13
safety information	17
search	
find / replace	123
second home.....	27
Secondary spindle	
clamping	191
m-codes.....	190
spindle swap	191
secondary spindle programming	190
selection	
multiple blocks.....	119
Servo tailstock	
power failure	109
start up	109
setup mode	8
keyswitch	27
Shape Creator	243
special symbols.....	90
spindle load meter	62
spindle warm-up.....	82
ST-20 minimal lube panel	
detail	22
steady rest foot pedal	101
subprograms	169
Synchronized Spindle Control (SSC)	191

T	
tabbed menus	
basic navigation	65

tailstock		tool functions	133
cancel restricted zone.....	112	FANUC coordinate system	133
foot pedal.....	111	load or change tools	134
hold force.....	109	tool management tables	
jogging	112	save and restore	105
motion	110	Tool Nose Compensation	141
programming	108, 169	tool nose compensation TNC	137
restricted zone	111	tool offset.....	96
resume operation	109	manual entry	96
Setting 94 and	112	manually set	96
settings	110	tool turret	
ST-40 servo brake engage	109	air pressure	106
ST-40 servo operation	109	eccentric locating cam buttons	106
X-axis clearance plane	111	load or change tools	107
text		operations	105
find / replace.....	123	protective caps	106
selection	119	U	
timer and counters display		unattended operation	8
reset	47	user positions	424
timers and counters display.....	56	W	
tips and tricks		work (G54) position.....	58
calculator	129	work offset	
operation	128	macros and.....	218
programming	125	workholding	94
settings and parameters.....	127	safety and	5
TNC		workpiece	
approach and departure	141	safety	6
approach move	141	X	
canned cycles.....	144	x offset to centerline	
concept	139	Hybrid BOT and VDI	107
Ex1-standard interpolation.....	145	setting	107
Ex3-G72 roughing canned cycle	149	Y	
Ex4-G73 roughing canned cycle	150	y axis	250
Ex5-G90 modal rough turning cycle.....	151	travel envelope	251
Ex6-G94 modal rough turning cycle.....	152	vdi turret and.....	251
G71 roughing.....	147	Y-Axis	
general	137	operation and programming	251
geometry	155		
Imaginary Tool Tip	153		
manually calculating.....	155		
programming	138		
radius wear offset	142		
tool length	144		
using.....	140		
without	154		

