

|                                               |      |
|-----------------------------------------------|------|
| Cross Screw Assembly . . . . .                | 3-10 |
| Maintenance Procedures . . . . .              | 3-10 |
| Backlash Adjustment . . . . .                 | 3-10 |
| E-Head . . . . .                              | 3-11 |
| Maintenance Procedures . . . . .              | 3-11 |
| Changing the Gear Case Oil . . . . .          | 3-11 |
| Removing Motor. . . . .                       | 3-12 |
| Changing Speed . . . . .                      | 3-12 |
| Removing Reduction Drive Unit or Ram. . . . . | 3-13 |

## CHAPTER 4 - PARTS LISTINGS

|                                         |      |
|-----------------------------------------|------|
| E-Head . . . . .                        | 4-1  |
| E-Head . . . . .                        | 4-2  |
| 2J-Head Top Housing . . . . .           | 4-5  |
| 2J-Head Top Assembly . . . . .          | 4-6  |
| 2J-Head Back Gear . . . . .             | 4-8  |
| 2J-HEAD BACK GEAR. . . . .              | 4-9  |
| J-Head Top Housing . . . . .            | 4-11 |
| J-Head Top Housing . . . . .            | 4-12 |
| 2J- and J-Head Lower Housing . . . . .  | 4-14 |
| 2J- and J-Head Lower Housing . . . . .  | 4-15 |
| Basic Machine. . . . .                  | 4-19 |
| Basic Machine. . . . .                  | 4-20 |
| Lead Screw Assembly . . . . .           | 4-23 |
| Lead Screw Assembly . . . . .           | 4-24 |
| Spray Mist . . . . .                    | 4-25 |
| Flood Coolant . . . . .                 | 4-26 |
| Lubrication System . . . . .            | 4-27 |
| Lubrication System . . . . .            | 4-28 |
| Power Feed Y-Axis . . . . .             | 4-29 |
| Power Feed Y-Axis . . . . .             | 4-30 |
| Power Feed Y-Axis Control Box . . . . . | 4-33 |
| Power Feed Type (Servo Type). . . . .   | 4-34 |
| 6F Power Feed X-Axis . . . . .          | 4-35 |
| 6F Power Feed X-Axis . . . . .          | 4-36 |
| 8F Power Feed X-Axis . . . . .          | 4-38 |
| 8F Power Feed X-Axis . . . . .          | 4-39 |
| 8F Power Feed X-Axis . . . . .          | 4-40 |
| 8F Power Feed X-Axis . . . . .          | 4-42 |
| 8F Power Feed X-Axis . . . . .          | 4-43 |
| Power Feed X-Axis . . . . .             | 4-44 |

|                                                                                 |      |
|---------------------------------------------------------------------------------|------|
| Replacement Motor Assemblies Available . . . . .                                | 4-45 |
| Motor Assembly J-Head 1 HP Unified without NFPA, Code No. 12190250 . . . . .    | 4-45 |
| Motor Assembly J-Head Unified with NFPA. . . . .                                | 4-45 |
| Motor Assembly 2J-Head 2 HP Unified without NFPA, Code No. 12550150. . . . .    | 4-45 |
| Motor Assembly 2J-Head 2 HP Unified with NFPA . . . . .                         | 4-46 |
| Motor Assembly 2J-Head 2 HP 575 Volts without NFPA, Code No. 12550020 . . . . . | 4-46 |
| Motor Assembly 2J-Head 2 HP 575 Volts with NFPA . . . . .                       | 4-46 |
| Replacement Motors Available. . . . .                                           | 4-46 |
| Code No. 2203000 – M Milling Head – Spare Parts Kit . . . . .                   | 4-46 |
| Code No. 2193000 – J Milling Head – Spare Parts Kit. . . . .                    | 4-47 |
| Code No. 2183000 – 2J Milling Head (1-1/2 HP) – Spare Parts Kit. . . . .        | 4-47 |
| Code No. 2553000 – 2J Milling Head (2 HP) – Spare Parts Kit . . . . .           | 4-47 |
| Code No. 2062000 – Series I Standard Machine – Spare Parts Kit. . . . .         | 4-48 |
| Lead Screws for Manually Operated Machines (without Keys) . . . . .             | 4-48 |
| Lead Screws Available for Machines with Power Feeds (without Keys) . . . . .    | 4-48 |
| Metric Conversion Kits . . . . .                                                | 4-49 |
| Code No. 2204000 – M Head, Metric Conversion Kit . . . . .                      | 4-49 |
| Code No. 2184000 – J- and 2J-Head, Metric Conversion Kit. . . . .               | 4-49 |
| Code No. 2064001 – Metric Conversion Kits . . . . .                             | 4-49 |
| Code No. 2064002 – Metric Conversion Kits . . . . .                             | 4-49 |
| Code No. 2064003 – Metric Conversion Kits . . . . .                             | 4-50 |
| 6F Power Feed Field Conversion Kits for Machines without NFPA . . . . .         | 4-50 |

## CHAPTER 5 - SPECIFICATIONS

|                                             |      |
|---------------------------------------------|------|
| Machine. . . . .                            | 5-1  |
| Principle Dimensions . . . . .              | 5-1  |
| Floor Plan Installation Layout . . . . .    | 5-2  |
| Machine Specifications . . . . .            | 5-4  |
| Head . . . . .                              | 5-5  |
| Milling Specifications . . . . .            | 5-5  |
| 2J-Head. . . . .                            | 5-6  |
| General Speed Recommendations. . . . .      | 5-6  |
| Table of Cutting Speeds and Feeds . . . . . | 5-6  |
| J-Head . . . . .                            | 5-8  |
| E-Head . . . . .                            | 5-9  |
| 6F Power Feed . . . . .                     | 5-10 |
| Schematic . . . . .                         | 5-10 |
| 6F Power Feed Circuit Board . . . . .       | 5-11 |
| 8F Power Feed . . . . .                     | 5-12 |
| Schematic . . . . .                         | 5-12 |
| 8F Power Feed Circuit Board . . . . .       | 5-13 |
| 8F Power Feed Schematic . . . . .           | 5-14 |
| Parts . . . . .                             | 5-15 |
| 8F Power Feed Schematic . . . . .           | 5-15 |
| 8F Power Feed Circuit Board . . . . .       | 5-16 |
| 8F Power Feed Circuit Board . . . . .       | 5-17 |