FUNtasia Audio

FUN KICK

v1.0.3

USER MANUAL

Shape your kick from the very first hit.

Build the attack, body and tail with a sine oscillator, Pitch / Amp MSEGs and a Click Sampler.



From first MIDI note to detailed envelope editing

English Edition

USER GUIDE / 2026

01 / GET STARTED

Your first kick in five steps

A quick path from an empty track to a saved sound.

01
Insert the instrument
Load FUN Kick on an instrument track in your DAW and send MIDI notes to it. The output is stereo.

02
Choose the low-end foundation
Set BASE FREQUENCY on the left. The default 50 Hz is a good starting point. KEY TRACKING follows MIDI pitch when enabled.

03
Shape the attack in PITCH
Open PITCH. Start at a high value and sweep quickly down to 0 st for a classic kick transient.

04
Set the tail in AMP
Open AMP and sculpt the amplitude envelope. PITCH and AMP have their own independent DURATION values.

05
Add a click and save
Optionally load a transient with LOAD WAV/AIFF, then open the preset menu and choose SAVE AS...

The four interface areas

01 TOP
Preset / OSC OS / PHASE / UNDO / REDO

02 LEFT
SINE OSC / MIDI, frequency and velocity

03 CENTER + RIGHT
MSEG graph / CURVE EDITOR / navigation

04 BOTTOM
CLICK SAMPLER, waveform and trims

SIGNAL FLOW

Sound path: a synthesized sine-wave kick can be layered with a separate click sample for attack.

02 / OSC + MIDI

Sine oscillator and MIDI

The sound foundation is one continuous sine oscillator.

BASE FREQUENCY	Sets the fundamental from 20 to 200 Hz. Enter an exact number or choose a musical note.
NOTE	Equal-tempered note choices use A4 = 440 Hz. CUSTOM allows a precise frequency in Hz.
START PHASE	Adjusts oscillator starting phase from 0 to 360 degrees, changing the initial waveform shape.
OUTPUT GAIN	Sets overall level from -60 to +12 dB. Watch peak levels in your DAW when boosting.
KEY TRACKING	ON: the fundamental follows the incoming MIDI note. OFF: a fixed fundamental pitch.
OVERLAP (16)	OFF: retrigger in mono. ON: voices may overlap, with up to 16 simultaneous voices.
VELOCITY	MIDI velocity sensitivity from 0 to 100%. At 0%, velocity is ignored; at 100%, it is used.

OSC oversampling

OSC OS	Select NOS / 2x / 4x / 8x. Higher rates require more processing power.
PHASE	MIN uses a low-latency filter; LINEAR uses a linear-phase filter. Both apply only to the OSC.

NOTE

OSC OS never oversamples the Click Sampler. Start in NOS and compare higher settings if needed.

03 / SOUND SHAPING

Pitch / Amp MSEG

Design how pitch and level evolve over time.

PITCH

Draw pitch above the fundamental from 0 to +96 semitones. A high start followed by a fast drop produces a punchy kick attack.

AMP

Draw amplitude from 0 to 100%. Shape the onset, body and fade-out independently of the pitch envelope.

DURATION is independent per tab

Range: 1 to 10,000 ms in 1 ms steps. Drag the slider or type an exact value in its box. For example, try 200 ms for PITCH and 800 ms for AMP.

VIEW / EDIT CONTROLS

SNAP + grid	Snap time positions to 1 / 5 / 10 / 25 / 50 / 100 ms steps. Disable SNAP to move freely.
SMOOTH 5 ms	Enables smoothing of steep changes, useful when a curve creates an unwanted click.
WAVE	Shows a predicted sine-wave OSC waveform from Pitch/Amp. Click samples are not included.
FIT	Resets the view so the complete curve is visible.

64 NODES

Each curve supports up to 64 nodes. st means semitones; ms means milliseconds.

04 / CURVE EDITOR

Editing envelopes

Mouse gestures and shortcuts for precise curve design.

Move a node	Left-drag a point to change its time and value. Endpoints remain fixed in time.
Add a node	Double-click empty graph space. Each curve supports up to 64 nodes.
Edit exact values	Double-click a node or right-click > Edit node time / value... The EDIT NODE button also works.
Multi-select	Shift-click nodes to select or deselect. Drag to move selected nodes together.
Delete a node	Select one or more nodes, then press Delete / Backspace. Endpoints cannot be removed.
Segment shape	Select a line and choose LINEAR / CURVED / STEP from SEGMENT TYPE.
Adjust curvature	Alt + vertical-drag on a segment to change its CURVED bend.
Undo / Redo	Use the top buttons or Ctrl/Cmd + Z, Ctrl/Cmd + Shift + Z (or Y).

CURVE menu

TEMPLATES / FLIP

PITCH: DEFAULT / FAST / SMOOTH / DOUBLE / FLAT. AMP: DEFAULT / SHORT / LONG / PUNCH / GATE. FLIP V mirrors values; FLIP H reverses time; RESET TO DEFAULT restores the initial curve.

Zoom and pan

ZOOM / PAN

Use HORIZONTAL / VERTICAL ZOOM and PAN on the right. Enable PAN and drag, or Shift-drag empty graph space. Mouse wheel zooms horizontally; Ctrl/Cmd + wheel zooms vertically.

05 / TRANSIENT LAYER

Click Sampler

Layer a short transient or texture over the sine-wave body.

01	Choose LOAD WAV/AIFF and select a WAV or AIFF file no longer than 10 seconds.
02	Enable ON, then use START / END to retain just the transient you need.
03	Blend the transient with PITCH, LEVEL and HPF.

ON / REVERSE	Turn sample playback on or off; REVERSE plays the sample backward.
START / END	Define playback range as 0 to 100% of the file. Waveform handles can also be dragged.
FADE IN / OUT	Fade either edge of the trimmed region over 0 to 100 ms.
PITCH	Transpose -24 to +24 st. Playback speed changes, affecting duration and tone.
LEVEL	Adjust the sample level from -100 to +12 dB.
HPF 24	Toggle the 24 dB/oct high-pass filter. Cutoff: 20 to 10,000 Hz; default 200 Hz.
WAVEFORM ZOOM	Zoom from 1x to 32x. Scroll over the waveform to zoom; drag empty areas to pan. FIT resets.

WAVE PREVIEW

WAVE in the main MSEG view previews only the oscillator. The Click Sampler waveform appears separately below.

06 / RECALL + SAVE

Presets and DAW workflow

Recall your sounds reliably across sessions.

Init Kick	Click the preset name at the top and select FACTORY > Init Kick to reset. A prompt warns of unsaved edits.
SAVE / SAVE AS...	Save your current sound. Use SAVE AS... on first save or to create a different version.
LOAD FROM FILE...	Open a previously saved .funmk file. User presets also appear in the preset menu.
Unsaved marker *	An asterisk next to the name indicates that the loaded preset has been edited.
Embedded click audio	Imported Click Sampler audio is embedded in the preset and DAW state data.
UNDO / REDO	Undo curve, GUI and preset-switch actions. External DAW automation has its own history.

IMPORTANT NOTES

Preset folder	User presets are stored under FUNtasia Audio / FUN Kick / Presets using the .funmk extension.
Pro compatibility	FUN Kick Pro presets and plugin states cannot be loaded directly; reverse compatibility is not guaranteed.
Editor size	Drag the bottom-right grip to resize between 70% and 160%, at a fixed 16:10 aspect ratio.
DAW integration	FUN Kick is a MIDI-triggered, stereo-output instrument. Save your DAW project after editing.

07 / REFERENCE

Quick reference / troubleshooting

Parameter limits and answers to common questions.

BASE FREQUENCY	20-200 Hz
OUTPUT GAIN	-60 to +12 dB
START PHASE	0-360 degrees
VELOCITY	0-100%
PITCH MSEG	0 to +96 st / 1-10,000 ms / up to 64 nodes
AMP MSEG	0-100% / 1-10,000 ms / up to 64 nodes
CLICK PITCH	-24 to +24 st
CLICK LEVEL	-100 to +12 dB
CLICK START/END	0-100%
CLICK FADE	0-100 ms
CLICK HPF	20-10,000 Hz / 24 dB/oct
WAVEFORM ZOOM	1-32x

Troubleshooting

No audio	Check MIDI notes, AMP envelope, OUTPUT GAIN and your DAW audio routing.
No click sound	Check the loaded WAV/AIFF, ON, LEVEL, START/END and HPF settings.
Duration feels hard to adjust	Type an exact millisecond value. DURATION affects only the selected PITCH or AMP tab.
Preset will not open	Verify the .funmk format. Pro-version presets are not directly compatible.

Product: FUN Kick v1.0.3 / Developer: FUNtasia Audio / Based on the v1.0.3 interface