Americas

Atlanta - 678-957-9614 Boston - 774-760-0087 Chicago - 630-285-0071 Cleveland - 216-447-0464 Dallas - 972-818-7423 Detroit - 248-538-2250 Kokomo - 765-864-8360 Los Angeles - 949-462-9523 Phoenix - 480-792-7200

Santa Clara - 408-961-6444

Toronto - 905-673-0699

Asia/Pacific

Australia - Sydney - 61-2-9868-6733 China - Beijing - 86-10-8528-2100 China - Chengdu - 86-28-8665-5511 China - Chongqing - 86-23-8980-9588 China - Hong Kong SAR - 852-2401-1200 China - Nanjing- 86-25-8473-2460 China - Qingdao - 86-532-8502-7355 China - Shanghai - 86-21-5407-5533 China - Shenyang - 86-24-2334-2829

China - Shenzhen - 86-755-8203-2660 China - Wuhan - 86-27-5980-5300 China - Xiamen - 86-592-2388138 China - Xian - 86-29-8833-7252 China - Zhuhai - 86-756-3210040 India - Bangalore - 91-80-3090-4444 India - New Delhi - 91-11-4160-8631 India - Pune - 91-20-2566-1512 Japan - Yokohama - 81-45-471-6166 Korea - Daegu - 82-53-744-4301

Korea - Seoul - 82-2-554-7200 Malaysia - Kuala Lumpur - 60-3-6201-9857 Malaysia - Penang - 60-4-227-8870 Philippines - Manila - 63-2-634-9065

Singapore - 65-6334-8870

Taiwan - Hsin Chu - 886-3-6578-300 Taiwan - Kaohsiung - 886-7-213-7830 Taiwan - Taipei - 886-2-2500-6610 Thailand - Bangkok - 66-2-694-1351

Europe

Austria - Weis - 43-7242-2244-39 Denmark - Copenhagen - 45-4450-2828 France - Paris - 33-1-69-53-63-20 Germany - Munich - 49-89-627-144-0 Italy - Milan - 39-0331-742611 Netherlands - Drunen - 31-416-690399 Spain - Madrid - 34-91-708-08-90 UK - Wokingham - 44-118-921-5869 08/04/10



Microchip Technology Inc. • 2355 West Chandler Blvd. • Chandler, AZ 85224-6199 www.microchip.com

The Microchip name and logo, the Microchip logo, and MPLAB are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries. All other trademarks mentioned herein are property of their respective

© 2010, Microchip Technology Incorporated, Printed in the U.S.A. All Rights Reserved. 08/10

DS51950A

Starter Kit I/O Expansion Board Information Sheet

The Starter Kit I/O Expansion Board provides starter kit users with full access to MCU signals, additional debug headers, and connections of PICtail™ Plus daughter boards. MCU signals are available for attaching prototype circuits or monitoring signals with logic probes. Headers are provided for connecting JTAG tools or Microchip tools using the 2-wire (ICSP™) interface.

Table 1 shows the mapping between different header interfaces on the board.

DING

ABLE	1:	HEADER INTERFACE MA					
J1 Pin#	J2 Pin #	J3 Pin#	J4 Pin#	J10 Pin #	J11 Pin #		
1	65	65	65	1			
3	68	68	68	4	_		
4	73	73	73	_	1		
5	67	67	67	3	_		
6	74	74	74	_	3		
7	116	116	116	5	_		
8	66	66	66	_	4		
9	115	115	115	6	_		
10	27, 60	27, 60	27, 60	_	6		
13	114	114	114	7	_		
14	29, 62	29, 62	29, 62	_	5		
15	113	113	113	8	_		
16	30	30	30	_	8		
17	112	112	112	9	_		
18	28	28	28	_	7		
19	111	111	111	10	_		
20	105	105	105	_	10		
21	110	110	110	11	_		
22	106	106	106	_	9		
23	109	109	109	12	_		
24	99	99	99	_	12		
25	98	98	98	13	_		
26	100	100	100		11		
27	104	104	104	15	_		
28	97	97	97	14	_		
29	103	103	103	16	_		
30	89	89	89	_	14		
31	90	90	90	17			
32	_	_	_		13		
35	85	85	85	18	- 10		
36			_		16		
37	86	86	86	19			
38			_	-	15		
39	87	87	87	20			
40	96	96	96		18		
41	88	88	88	21	-		
42	95	95	95		17		
44	94	94	94	<u> </u>	20		
45	35	35	35	23			
46	93	93	93		19		
47	37	37	37	24			
48		31	- Ji		21		
49	39	39	39	25	<u> </u>		
50		39	55	20	24		
51	33	33	33		24		
-	33	33	აა	20	23		
52	102	102	102				
54	102	102	102	_	26		
58	101	101	101	_	25		
62				_	29		
63	77	77	77	29	_		
64	14	14	14	<u> </u>	30		
65		_	_	31	_		
66	13	13	13	_	31		

J1 Pin#	J2 Pin #	J3 Pin#	J4 Pin #	J10 Pin#	J1 ¹ Pin
67	_	_	_	30	_
68	_	_	_	_	32
69	_	_	_	32	_
70	12	12	12	_	33
71	43	43	43	33	_
72	11	11	11	_	34
73	44	44	44	34	_
74	40	40	40	_	36
76	38	38	38	_	38
79	49	49	49	36	
81	50	50	50	35	_
83	17	17	17	38	_
84	6	6	6	_	35
85	18	18	18	37	
86	8	8	8	-	37
87	_	_	_	42	-
88	2	2	2	72	41
90	4	4	4		43
90	3	3	3	41	40
92	20	20	20	41	45
93	5	5	5	44	40
	_	-		44	_
94	19	19	19	_	47
95	7	7	7	43	_
97	1	1	1	46	_
101	79	79	79	47	
102	_	_	_	_	52
103	80	80	80	48	_
105	81	81	81	49	_
106	52	52	52	_	42
107	82	82	82	50	_
108	51	51	51	_	44
109	_	_	_	51	_
110	34	34	34	_	46
111	_	_	_	52	_
112	36	36	36	_	48
113	45	45	45	53	_
114	_	_	_	_	51
115	46	46	46	54	
116					53
117		_		55	
118	72	72	72	_	54
119	_	_	_	56	_
120	71	71	71	_	56
123	_	_	_	57	_
124	70	70	70	_	58
125		_	<u> </u>	58	_
126	69	69	69	_	60
127	83	83	83	59	_
128	_	_	_	_	55
129	84	84	84	60	_
130	78	78	78		57
132		_	_	_	59

Starter Kit I/O Expansion Board Information Sheet

Schematics - Sheet 1 of 1

