DX FT8 Auto Sequence Process Operation

DX FT8 Transmits CQ Call CQ Call – 1 Grid

DX FT8 QSO Mode DX FT8 Beacon Mode User Enables Beacon Mode DX FT8 Transmits CQ Call DX FT8 Receives & Displays CQ Call - 1 Grid CQ Call DX FT8 Listens For Response User Selects CQ Call DX FT8 Waits For DX FT8 Transmits CQ Call Next FT8 Slot CQ Call – 1 Grid No DX FT8 Sends Response DX FT8 Receives Response Call-1 Call-2 Grid Call-1 Call-2 Grid Yes No DX FT8 Sends Report **DX FT8 Receives Report** Call-2 Call-1 Report -02 Call-2 Call-1 -02 No **DX FT8 Sends Report** DX FT8 Receives Report Call-1 Call-2 R-00 Call-1 Call-2 R-00 No Yes DX FT8 Sends ACK DX FT8 Receives ACK Call-2 Call-1 Report RR73 Call-2 Call-1 – RR73 Logs Report Yes DX FT8 Sends ACK DX FT8 Receives ACK Call-1 Call-2 -73 Call-1 Call-2 73 Logs Report Yes or No

DX FT8 Stops