



- ■ **SAMBA75**
- ■ AT COMMAND SET
- ■ DESCRIPTION
- ■
- ■ Preliminary

Table of contents

0	INTRODUCTION	11
0.1	SCOPE OF THE DOCUMENT	11
0.2	RELATED DOCUMENTS	11
0.3	DOCUMENT CONVENTIONS	12
0.3.1	Quick reference table	12
0.3.2	Superscript notation for parameters and values	12
0.4	AT COMMAND SYNTAX	13
0.4.1	Using parameters	13
0.4.2	Combining AT commands on the same command line.....	14
0.5	SUPPORTED CHARACTER SETS	14
0.5.1	GSM alphabet tables and UCS2 character values.....	16
0.5.2	UCS2 and GSM data coding and conversion for SMS text mode	17
0.5.2.1	<i>Implementing input of Terminal data to SIM (direction TE to ME)</i>	18
0.6	FLOW CONTROL	19
0.6.1	Software flow control (XON/OFF flow control)	20
0.6.2	Hardware flow control (RTS/CTS flow control)	20
0.7	UNSOLICITED RESULT CODE PRESENTATION	20
0.7.1	Communication between Customer Application and SAMBA75.....	21
0.8	COMMON PCN HANDSET SPECIFICATION (CPHS)	21
0.9	ERRORS AND MESSAGES	22
1	CONFIGURATION COMMANDS	23
1.1	AT&F SET ALL CURRENT PARAMETERS TO MANUFACTURER DEFAULTS.....	23
1.2	AT&V DISPLAY CURRENT CONFIGURATION	23
1.2.1	AT&V responses.....	24
1.3	AT&W STORES CURRENT CONFIGURATION TO USER DEFINED PROFILE	24
1.4	ATQ SET RESULT CODE PRESENTATION MODE	25
1.5	ATV SET RESULT CODE FORMAT MODE.....	25
1.5.1	Verbose and numeric result codes.....	25
1.6	ATX SET CONNECT RESULT CODE FORMAT AND CALL MONITORING.....	26
1.7	ATV SET CONNECT RESULT CODE FORMAT	26
1.8	ATZ SET ALL CURRENT PARAMETERS TO USER DEFINED PROFILE.....	27
1.9	AT+CFUN SET PHONE FUNCTIONALITY	27
1.9.1	Wake up the ME from SLEEP mode.....	31
1.10	AT [^] SMSO SWITCH OFF MOBILE STATION.....	31
1.11	AT+GCAP REQUEST COMPLETE TA CAPABILITIES LIST.....	32
1.12	AT+CMEE MOBILE EQUIPMENT ERROR MESSAGE FORMAT	32
1.12.1	CME/CMS Error Code Overview.....	33
1.13	AT+CSCS SELECT TE CHARACTER SET	35
1.14	AT [^] SCFG EXTENDED CONFIGURATION SETTINGS	35
1.15	AT [^] SM20 SET M20 COMPATIBILITY MODE	44
2	STATUS CONTROL COMMANDS	45
2.1	AT+CMER MOBILE EQUIPMENT EVENT REPORTING.....	45
2.2	AT+CIND INDICATOR CONTROL	46
2.3	AT [^] SIND EXTENDED INDICATOR CONTROL.....	49
2.4	AT+CEER EXTENDED ERROR REPORT	52

2.4.1	Cause Location ID for the extended error report.....	53
2.4.2	GSM release cause for L3 Radio Resource (RR)	54
2.4.3	GSM release cause for Mobility Management (MM).....	54
2.4.4	GSM release cause for L3 Call Control (CC)	55
2.4.5	GSM Release cause for Supplementary Service Call.....	56
2.4.6	GSM cause for L3 Protocol module or other local cause.....	57
2.4.7	SIEMENS release cause for GPRS API	57
2.4.8	SIEMENS release cause for PPP/IP-Stack.....	58
2.5	ATS18 EXTENDED CALL RELEASE REPORT	58
2.6	AT+CPAS MOBILE EQUIPMENT ACTIVITY STATUS	59
2.7	AT+WS46 SELECT WIRELESS NETWORK	59

3 SERIAL INTERFACE CONTROL COMMANDS 61

3.1	AT\Q FLOWCONTROL	61
3.2	AT&C SET CIRCUIT DATA CARRIER DETECT (DCD) FUNCTION MODE	61
3.3	AT&D SET CIRCUIT DATA TERMINAL READY (DTR) FUNCTION MODE	62
3.4	AT&S SET CIRCUIT DATA SET READY (DSR) FUNCTION MODE	62
3.5	ATE ENABLE COMMAND ECHO	62
3.6	AT+ICF SERIAL INTERFACE CHARACTER FRAMING	63
3.7	AT+IFC SET FLOW CONTROL SEPARATELY FOR DATA DIRECTIONS	64
3.8	AT+ILRR SET TE-TA LOCAL RATE REPORTING	65
3.9	AT+IPR SET FIXED LOCAL RATE.....	66
3.9.1	Autobausing	67
3.10	AT^STPB TRANSMIT PARITY BIT (FOR 7E1 AND 7O1 ONLY).....	68

4 SECURITY COMMANDS 70

4.1	AT+CPIN ENTER PIN	70
4.1.1	What to do if PIN or password authentication fails?.....	72
4.2	AT+CPIN2 ENTER PIN2	73
4.3	AT^SPIC DISPLAY PIN COUNTER.....	75
4.4	AT+CLK FACILITY LOCK	79
4.5	AT^SLCK FACILITY LOCK.....	84
4.6	AT+CPWD CHANGE PASSWORD	85
4.7	AT^SPWD CHANGE PASSWORD	88

5 IDENTIFICATION COMMANDS 90

5.1	ATI DISPLAY PRODUCT IDENTIFICATION INFORMATION	90
5.2	AT+CGMI REQUEST MANUFACTURER IDENTIFICATION	90
5.3	AT+GMI REQUEST MANUFACTURER IDENTIFICATION.....	90
5.4	AT+CGMM REQUEST MODEL IDENTIFICATION	91
5.5	AT+GMM REQUEST TA MODEL IDENTIFICATION	91
5.6	AT+CGMR REQUEST REVISION IDENTIFICATION OF SOFTWARE STATUS.....	92
5.7	AT+GMR REQUEST TA REVISION IDENTIFICATION OF SOFTWARE STATUS.....	92
5.8	AT+CGSN REQUEST PRODUCT SERIAL NUMBER IDENTIFICATION (IMEI) IDENTICAL TO GSN.....	92
5.9	AT+GSN REQUEST TA SERIAL NUMBER IDENTIFICATION (IMEI)	93
5.10	AT+CIMI REQUEST INTERNATIONAL MOBILE SUBSCRIBER IDENTITY	93

6 CALL RELATED COMMANDS 95

6.1	CALL STATUS INFORMATION	95
6.2	ATA ANSWER A CALL.....	96
6.3	ATD MOBILE ORIGINATED CALL TO DIAL A NUMBER.....	96
6.4	ATD><MEM><N> ORIGINATE CALL TO PHONE NUMBER IN MEMORY.....	99
6.5	ATD><N> ORIGINATE CALL TO PHONE NUMBER SELECTED FROM ACTIVE MEMORY	100
6.6	ATD><STR> ORIGINATE CALL TO PHONE NUMBER IN MEMORY WITH CORRESPONDING FIELD	101
6.7	ATDI MOBILE ORIGINATED CALL TO DIALABLE ISDN NUMBER <N>	102
6.8	ATDL REDIAL LAST TELEPHONE NUMBER USED.....	103
6.9	ATH DISCONNECT EXISTING CONNECTION	103
6.10	AT+CHUP HANG UP CALL	104
6.11	ATS0 SET NUMBER OF RINGS BEFORE AUTOMATICALLY ANSWERING THE CALL	104
6.12	ATS6 SET PAUSE BEFORE BLIND DIALING	105
6.13	ATS7 SET NUMBER OF SECONDS TO WAIT FOR CONNECTION COMPLETION	106
6.14	ATS8 SET NUMBER OF SECONDS TO WAIT FOR COMMA DIALING MODIFIER	106
6.15	ATS10 SET DISCONNECT DELAY AFTER INDICATING THE ABSENCE OF DATA CARRIER	107
6.16	ATP SELECT PULSE DIALING	107
6.17	ATO SWITCH FROM COMMAND MODE TO DATA MODE/PPP ONLINE MODE	107
6.18	+++ SWITCH FROM DATA MODE TO COMMAND MODE.....	108
6.19	ATT SELECT TONE DIALING	108
6.20	AT+CBST SELECT BEARER SERVICE TYPE	109
6.21	AT+CRLP SELECT RADIO LINK PROTOCOL PARAM. FOR ORIG. NON-TRANSPARENT DATA CALL	109
6.22	AT+CLCC LIST CURRENT CALLS OF ME.....	110
6.23	AT^SLCC SIEMENS DEFINED COMMAND TO LIST THE CURRENT CALLS OF THE ME	112
6.24	AT+CR SERVICE REPORTING CONTROL	118
6.25	AT+CRC SET CELLULAR RESULT CODES FOR INCOMING CALL INDICATION	119
6.26	AT+CSNS SINGLE NUMBERING SCHEME	119
6.27	AT^SCNI LIST CALL NUMBER INFORMATION	120
6.28	AT^SLCD DISPLAY LAST CALL DURATION	121
6.29	AT^STCD DISPLAY TOTAL CALL DURATION.....	121

7 NETWORK SERVICE COMMANDS 123

7.1	AT+COPN READ OPERATOR NAMES.....	123
7.2	AT+COPS OPERATOR SELECTION.....	123
7.3	AT+CREG NETWORK REGISTRATION.....	125
7.4	AT+CSQ SIGNAL QUALITY.....	127
7.5	AT^SMONC CELL MONITORING	128
7.6	AT^MONI MONITOR IDLE MODE AND DEDICATED MODE	129
7.6.1	AT^MONI responses.....	130
7.6.2	Service states	131
7.6.3	Notes	132
7.7	AT^MONP MONITOR NEIGHBOUR CELLS	132
7.7.1	AT^MONP responses	133
7.8	AT^SMONG GPRS MONITOR.....	133
7.8.1	AT^SMONG Cell Info Table	134
7.9	AT^SALS ALTERNATE LINE SERVICE	135

7.10	AT^SHOM DISPLAY HOMZONE	136
7.11	AT^SPLM READ THE PLMN LIST	136
7.12	AT^SPLR READ ENTRY FROM THE PREFERRED OPERATORS LIST	137
7.13	AT^SPLW WRITE AN ENTRY TO THE PREFERRED OPERATORS LIST	137

8 SUPPLEMENTARY SERVICE COMMANDS.....139

8.1	AT+CACM ACCUMULATED CALL METER (ACM) RESET OR QUERY.....	139
8.2	AT^SACM ADVICE OF CHARGE AND QUERY OF ACM AND ACMMAX	139
8.3	AT+CAMM ACCUMULATED CALL METER MAXIMUM (ACMMAX) SET OR QUERY	140
8.4	AT+CAOC ADVICE OF CHARGE INFORMATION.....	141
8.5	AT+CCUG CLOSED USER GROUP	142
8.6	AT+CCFC CALL FORWARDING NUMBER AND CONDITIONS CONTROL	143
8.7	AT+CCWA CALL WAITING	147
8.8	AT+CHLD CALL HOLD AND MULTIPARTY	150
8.9	AT+CLIP CALLING LINE IDENTIFICATION PRESENTATION.....	152
8.10	AT+CLIR CALLING LINE IDENTIFICATION RESTRICTION	153
8.11	AT+CPUC PRICE PER UNIT AND CURRENCY TABLE	154
8.12	AT+CSSN SUPPLEMENTARY SERVICE NOTIFICATIONS	155
8.13	AT+CUSD SUPPLEMENTARY SERVICE NOTIFICATIONS	156

9 INTERNET SERVICE COMMANDS.....158

9.1	AT^SICS INTERNET CONNECTION SETUP PROFILE	158
9.2	AT^SISS INTERNET SERVICE SETUP PROFILE.....	160
9.3	AT^SISO INTERNET SERVICE OPEN	168
9.4	AT^SISC INTERNET SERVICE CLOSE	170
9.5	AT^SISR INTERNET SERVICE READ DATA.....	171
9.6	AT^SISW INTERNET SERVICE WRITE DATA.....	172

10 GPRS COMMANDS173

10.1	AT+CGACT PDP CONTEXT ACTIVATE OR DEACTIVATE	173
10.2	AT+CGANS MANUAL RESPONSE TO A NETWORK REQUEST FOR PDP CONTEXT ACTIVATION	175
10.3	AT+CGATT GPRS ATTACH OR DETACH	176
10.4	AT+CGAUTO AUTOMATIC RESPONSE TO A NETWORK REQUEST FOR PDP CONTEXT ACTIVATION	177
10.5	AT+CGDATA ENTER DATA STATE	178
10.6	AT+CGDCONT DEFINE PDP CONTEXT	179
10.7	AT+CGPADDR SHOW PDP ADDRESS	181
10.8	AT+CGQMIN QUALITY OF SERVICE PROFILE (MINIMUM ACCEPTABLE).....	182
10.9	AT+CGQREQ QUALITY OF SERVICE PROFILE (REQUESTED).....	185
10.10	AT+CGREG GPRS NETWORK REGISTRATION STATUS	188
10.11	AT+CGSMS SELECT SERVICE FOR MO SMS MESSAGES.....	189
10.12	AT^SGAUTH SET TYPE OF AUTHENTICATION FOR PPP CONNECTION.....	190
10.13	AT^SGCONF CONFIGURATION OF GPRS RELATED PARAMETERS	191
10.14	ATA MANUAL RESPONSE TO A NETWORK REQUEST FOR PDP CONTEXT ACTIVATION	191
10.15	ATD*99# REQUEST GPRS SERVICE.....	192

10.16	ATD*98# REQUEST GPRS IP SERVICE	193
10.17	ATH MANUAL REJECTION OF A NETWORK REQUEST FOR PDP CONTEXT ACTIVATION	193
10.18	ATS0 AUTOMATIC RESPONSE TO A NETWORK REQUEST FOR PDP CONTEXT ACTIVATION ...	194
10.19	USING GPRS AT COMMANDS (EXAMPLES).....	195
10.20	USING THE GPRS DIAL COMMAND ATD.....	197
11	FAX COMMANDS	199
11.1	FAX PARAMETERS.....	199
11.2	AT+FBADLIN BAD LINE THRESHOLD	201
11.3	AT+FBADMUL ERROR THRESHOLD MULTIPLIER.....	201
11.4	AT+FBOR QUERY DATA BIT ORDER	202
11.5	AT+FCIG QUERY OR SET THE LOCAL POLLING ID	202
11.6	AT+FCLASS FAX: SELECT, READ OR TEST SERVICE CLASS.....	203
11.7	AT+FCQ COPY QUALITY CHECKING	203
11.8	AT+FCR CAPABILITY TO RECEIVE	204
11.9	AT+FDCC QUERY OR SET CAPABILITIES	204
11.10	AT+FDFFC DATA COMPRESSION FORMAT CONVERSION	205
11.11	AT+FDIS QUERY OR SET SESSION PARAMETERS.....	205
11.12	AT+FDR BEGIN OR CONTINUE PHASE C DATA RECEPTION	206
11.13	AT+FDT DATA TRANSMISSION	206
11.14	AT+FET END A PAGE OR DOCUMENT	207
11.15	AT+FK KILL OPERATION, ORDERLY FAX ABORT	207
11.16	AT+FLID QUERY OR SET THE LOCAL ID SETTING CAPABILITIES.....	207
11.17	AT+FMDL IDENTIFY PRODUCT MODEL	208
11.18	AT+FMFR REQUEST MANUFACTURER IDENTIFICATION.....	208
11.19	AT+FOPT SET BIT ORDER INDEPENDENTLY	209
11.20	AT+FPHCTO DTE PHASE C RESPONSE TIMEOUT	209
11.21	AT+FREV IDENTIFY PRODUCT REVISION	209
11.22	AT+FRH RECEIVE DATA USING HDLC FRAMING	210
11.23	AT+FRM RECEIVE DATA.....	210
11.24	AT+FRS RECEIVE SILENCE.....	211
11.25	AT+FTH TRANSMIT DATA USING HDLC FRAMING.....	211
11.26	AT+FTM TRANSMIT DATA	211
11.27	AT+FTS STOP TRANSMISSION AND WAIT.....	212
11.28	AT+FVRFC VERTICAL RESOLUTION FORMAT CONVERSION	212
12	SHORT MESSAGE SERVICE (SMS) COMMANDS	214
12.1	SMS PARAMETERS	214
12.2	AT+CMGC SEND AN SMS COMMAND.....	217
12.3	AT+CMGD DELETE SMS MESSAGE	218
12.4	AT+CMGF SELECT SMS MESSAGE FORMAT.....	218
12.5	AT+CMGL LIST SMS MESSAGES FROM PREFERRED STORE	218
12.6	AT+CMGR READ SMS MESSAGES	219
12.7	AT+CMGS SEND SMS MESSAGE.....	220
12.8	AT+CMGW WRITE SMS MESSAGES TO MEMORY	222
12.9	AT+CMSS SEND SMS MESSAGES FROM STORAGE.....	223

12.10	AT+CNMA NEW SMS MESSAGE ACKNOWLEDGE TO ME/TE, ONLY PHASE 2+	223
12.11	AT+CNMI NEW SMS MESSAGE INDICATIONS	224
12.12	AT+CPMS PREFERRED SMS MESSAGE STORAGE	227
12.13	AT+CSCA SMS SERVICE CENTRE ADDRESS.....	228
12.14	AT+CSCB SELECT CELL BROADCAST MESSAGE INDICATION.....	229
12.15	AT+CSDH SHOW SMS TEXT MODE PARAMETERS.....	230
12.16	AT+CSMP SET SMS TEXT MODE PARAMETERS	230
12.17	AT+CSMS SELECT MESSAGE SERVICE	232
12.18	AT^SLMS LIST SMS MEMORY STORAGE.....	233
12.19	AT^SMGL LIST SMS MESSAGES FROM PREFERRED STORE WITHOUT SETTING STATUS TO REC READ	233
12.20	AT^SMGO SET OR QUERY SMS OVERFLOW PRESENTATION MODE OR QUERY SMS OVERFLOW	234
12.21	AT^SMGR READ SMS MESSAGE WITHOUT SETTING STATUS TO REC READ	235
12.22	AT^SSCONF SMS COMMAND CONFIGURATION.....	236
12.23	AT^SSDA SET SMS DISPLAY AVAILABILITY	236
12.24	AT^SSMSS SET SHORT MESSAGE STORAGE SEQUENCE	237
13	SIM RELATED COMMANDS	238
13.1	AT+CRSM RESTRICTED SIM ACCESS.....	238
13.2	AT^SCKS QUERY SIM AND CHIP CARD HOLDER STATUS.....	239
13.3	AT^SCID DISPLAY SIM CARD IDENTIFICATION NUMBER	240
13.4	AT+CXXCID DISPLAY CARD ID	241
14	PHONE BOOK COMMANDS	242
14.1	SORT ORDER FOR PHONE BOOKS.....	242
14.2	AT+CPBR READ FROM PHONE BOOK	242
14.3	AT+CPBS SELECT PHONE BOOK MEMORY STORAGE	245
14.4	AT+CPBW WRITE INTO PHONEBOOK	246
14.5	AT^SPBC SEARCH THE FIRST ENTRY IN THE SORTED TELEPHONE BOOK	249
14.6	AT^SPBD PURGE PHONE BOOK MEMORY STORAGE	250
14.7	AT^SPBG READ CURRENT PHONE BOOK ENTRIES	250
14.8	AT^SPBS STEP THROUGH THE SELECTED PHONE BOOK ALPHABETICALLY	254
14.9	AT^SDLD DELETE THE "LAST NUMBER REDIAL" MEMORY.....	257
15	AUDIO COMMANDS	258
15.1	ATL SET MONITOR SPEAKER LOUDNESS	258
15.2	ATM SET MONITOR SPEAKER MODE	258
15.3	AT+CLVL LOUDSPEAKER VOLUME LEVEL	258
15.4	AT+CMUT MUTE CONTROL.....	259
15.5	AT+VTD TONE DURATION	260
15.6	AT+VTS DTMF AND TONE GENERATION	260
15.7	AT^SNFD SET AUDIO PARAMETERS TO MANUFACTURER DEFAULT VALUES	261
15.8	AT^SNFI SET MICROPHONE PATH PARAMETERS	261
15.9	AT^SNFO SET AUDIO OUTPUT (=LOUDSPEAKER PATH) PARAMETER	262
15.10	AT^SNFPT SET PROGRESS TONES	263

15.11 AT [^] SNFV SET LOUDSPEAKER VOLUME.....	264
15.12 AT [^] SNFW WRITE AUDIO SETTING IN NON-VOLATILE STORE	265
15.13 AT [^] SRTC RING TONE CONFIGURATION	265
16 HARDWARE RELATED COMMANDS	268
16.1 AT+CALA SET ALARM TIME	268
16.1.1 Summary of AT commands available in Alarm mode	270
16.2 AT+CCLK REAL TIME CLOCK.....	271
16.3 AT [^] SBV BATTERY/SUPPLY VOLTAGE	271
16.4 AT [^] SCTM SET CRITICAL OPERATING TEMPERATURE PRESENTATION MODE OR QUERY TEMPERATURE	272
17 MISCELLANEOUS COMMANDS	275
17.1 A/REPEAT PREVIOUS COMMAND LINE	275
17.2 ATS3 WRITE COMMAND LINE TERMINATION CHARACTER.....	275
17.3 ATS4 SET RESPONSE FORMATTING CHARACTER	275
17.4 ATS5 WRITE COMMAND LINE EDITING CHARACTER	276
18 APPENDIX.....	277
18.1 RESTRICTED ACCESS TO SIM DATA AFTER SIM PIN AUTHENTICATION	277
18.2 LIST OF *# CODES	277
18.3 AVAILABLE AT COMMANDS AND DEPENDENCY ON SIM PIN.....	279
18.4 AT COMMAND SETTINGS STORABLE WITH AT&W	284
18.5 FACTORY DEFAULT SETTINGS RESTORABLE WITH AT&F	285
18.6 SUMMARY OF UNSOLICITED RESULT CODES (URC)	286
18.7 ALPHABETICAL LIST OF AT COMMANDS	287

Version history

Version number	Author	Changes
1.00	Fadil Beqiri	Initial version

Cautions

Information furnished herein by FALCOM are accurate and reliable. However, no responsibility is assumed for its use.

Please read carefully the safety precautions.

If you have any technical questions regarding this document or the product described in it, please contact your vendor.

General information about FALCOM and its range of products is available at the following internet address: <http://www.falcom.de/>.

Trademarks

Some mentioned products are registered trademarks of their respective companies.

Copyright

This user's guide is copyrighted by FALCOM GmbH with all rights reserved. No part of this user's guide may be produced in any form without the prior written permission of FALCOM GmbH.

FALCOM GmbH.

No patent liability is assumed with respect to the use of the information contained herein.

0 INTRODUCTION

0.1 Scope of the document

This document presents the AT Command Set for the Falcom Cellular Engine SAMBA75 Version 1.00.

Before using the Cellular Engine or upgrading to a new firmware version please read the latest product information provided in the Release Notes [1].

More information can be available at the Falcom website:

<http://www.falcom.de/>

0.2 Related documents

- [1] SAMBA75 user manual
- [2] GPRS Startup User's Guide
- [2] ITU-T Recommendation V.24: List of definitions for interchange circuits between data terminal equipment (DTE) and data circuit-terminating equipment (DCE)
- [3] ITU-T Recommendation V.25ter: Serial asynchronous automatic dialling and control
- [4] 3GPP TS 23.038 (GSM 03.38): Alphabets and language specific information
- [5] 3GPP TS 27.005 (GSM 07.05): Use of Data Terminal Equipment - Data Circuit terminating Equipment (DTE-DCE) interface for Short Message Service (SMS) and Cell Broadcast Service (CBS)
- [6] 3GPP TS 27.007 (GSM 07.07): AT command set for User Equipment (UE)
- [7] 3GPP TS 27.060 (GSM 07.60): Mobile Station (MS) supporting Packet Switched Services
- [8] 3GPP TS 51.011 (GSM 11.11): Specification of the Subscriber Identity Module - Mobile Equipment (SIM - ME) interface
- [9] 3GPP TS 11.14 (GSM 11.14): Specification of the SIM Application Toolkit for the Subscriber Identity Module -Mobile Equipment (SIM - ME) interface

0.3 Document conventions

Throughout the document, the GSM engines are referred to as ME (Mobile Equipment), MS (Mobile Station), TA (Terminal Adapter), DCE (Data Communication Equipment) or facsimile DCE (FAX modem, FAX board). To control your GSM engine you can simply send AT commands via its serial interface. The controlling device at the other end of the serial line is referred to as TE (Terminal Equipment), DTE (Data Terminal Equipment) or plainly 'the application' (probably running on an embedded system).

All abbreviations and acronyms used throughout this document are based on the GSM specifications. For definitions please refer to TR 100 350 V7.0.0 (1999-08), (GSM 01.04, version 7.0.0 release 1998).

0.3.1 Quick reference table

Each AT command description includes a table similar to the example shown below. The table is intended as a quick reference to indicate the following functions:

PIN: Is the AT command PIN protected?

- Yes
- No
- Usage is dependent on conditions specified for the command, or not all command types are PIN protected (for example write command PIN protected, read command not).

Note: The table provided in the chapter [18.3](#) uses the same symbols.

USB: Is the AT command supported on the first physical serial interface USB?

- Yes
- No

Example:

PIN	USB				
<input type="radio"/>	<input checked="" type="radio"/>				

0.3.2 Superscript notation for parameters and values

Parameter option	Meaning
<code><param>^(&W)</code>	Parameter value will be stored with AT&W
<code><param>^(&V)</code>	Parameter value will be displayed with AT&V
<code><param>^(^SNFW)</code>	Parameter value will be stored with AT^SNFW
<code><param>^(+csccs)</code>	Parameter value has to be (is) coded according to current setting of <chset>

Table 0.1: Symbols used to indicate the correlations with other commands

Value option	Meaning
<code>[x]</code>	Default value: if the parameter is omitted, the value 'x' will be assumed
<code>x^(&F)</code>	Factory default value, will be restored to 'x' with AT&F
<code>x^(P)</code>	Powerup default value of a parameter which is not stored at power down
<code>x^(D)</code>	Delivery default value of a parameter which cannot be restored automatically

Table 0.2: Symbols used to mark different types of default values of parameters

0.4 AT command syntax

The "AT" or "at" prefix must be set at the beginning of each command line. To terminate a command line enter <CR>.

Commands are usually followed by a response that includes "<CR><LF><response><CR><LF>". Throughout this document, only the responses are presented, <CR><LF> are omitted intentionally.

Types of AT commands and responses:

AT command type	Syntax	Function
Test command	AT+CXXX=?	The mobile equipment returns the list of parameters and value ranges set with the corresponding Write command or by internal processes.
Read command	AT+CXXX?	This command returns the currently set value of the parameter or parameters.
Write command	AT+CXXX=<...>	This command sets user-definable parameter values.
Exec(ution) command	AT+CXXX	The execution command reads nonvariable parameters determined by internal processes in the GSM engine.

0.4.1 Using parameters

- Optional parameters are enclosed in square brackets. If optional parameters are omitted, the current settings are used until you change them.
- Optional parameters or subparameters can be omitted unless they are followed by other parameters. If you want to omit a parameter in the middle of a string it must be replaced by a comma. See also example 1.
- A parameter value enclosed in square brackets represents the value that will be used if an optional parameter is omitted. See also example 2.
- When the parameter is a character string, e.g. <text> or <number>, the string must be enclosed in quotation marks, e.g. "Charlie Brown" or "+49030xxxx". Symbols within quotation marks will be recognized as strings.
- All spaces will be ignored when using strings without quotation marks.
- It is possible to omit the leading zeros of strings which represent numbers.
- If an optional parameter of a V.25ter command is omitted, its value is assumed to be 0.

Example 1:

Omitting parameters in the middle of a string

```
at+ccug? Query current setting
+CCUG:1,10,1
OK
AT+CCUG=,9 Set only the middle parameter
OK
AT+CCUG? Query new setting
+CCUG: 1,9,1
OK
```

Example 2:

```

Using default parameter values for optional parameters
AT+CFUN=5,0 Activate CYCLIC SLEEP mode, don't reset ME
OK
AT+CFUN? Query ME mode
+CFUN: 5
OK
AT+CFUN= Set ME back to normal (default parameters: 1,0)
OK
+CFUN: 1
OK

```

0.4.2 Combining AT commands on the same command line

You may enter several AT commands on the same line. This eliminates the need to type the "AT" or "at" prefix before each command. Instead, it is only needed once at the beginning of the command line. Use a semicolon as command delimiter.

The command line buffer accepts a maximum of 391 characters. If this number is exceeded none of the commands will be executed and TA returns ERROR.

The table below lists the AT commands you cannot enter together with other commands on the same line. Otherwise, the responses may not be in the expected order.

AT command type	Comment
V.25ter commands	with FAX commands (Prefix AT+F)
GSM 7.07 commands	with commands, Prefix AT^S)
GSM 7.05 commands (SMS)	To be used standalone
Commands starting with AT&	To be used standalone
AT+IPR	To be used standalone

 Note: When concatenating AT commands please keep in mind that the sequence of processing may be different from the sequential order of command input. Therefore, if the consecutive order of the issued commands is your concern, avoid concatenating commands on the same line.

0.5 Supported character sets

The ME supports two character sets: GSM 03.38 (7 bit, also referred to as GSM alphabet or SMS alphabet) and UCS2 (16 bit, refer to ISO/IEC 10646). See [AT+CSCS](#) for information about selecting the character set. Character tables can be found below.

Explanation of terms

- International Reference Alphabet (IRA)

IRA means that one byte is displayed as two characters in hexadecimal format, for example, the byte 0x36 (decimal 54) is displayed as "36" (two chars).

- Escape sequences

The escape sequence used within a text coded in the GSM default alphabet (0x1B) must be correctly interpreted by the TE, both for character input and output. To the module, an escape sequence appears like any other byte received or sent.

- Terminal Adapter (TA)

TA is used equivalent to Mobile Equipment (ME) which stands for the GSM module described here. It uses GSM default alphabet as its character set.

- Terminal Equipment (TE)

TE is the terminal equipment that uses the GSM default alphabet as its character set. MS Hyperterminal (often used with the module) is an ANSI/ASCII terminal that does not support the GSM default alphabet.

- Data Coding Scheme (dcs)

The Data Coding Scheme (dcs) is part of a short message and is saved on the SIM. When writing a short message to the SIM in textmode, the dcs stored with AT+CSMP is used.

- TE Character Set

The currently used TE character set is selected with AT+CSCS.

The behavior when encountering characters, that are not valid characters of the supported alphabets, is undefined.

Due to the constraints described below it is recommended to prefer the USC2 alphabet in any external application.

If the GSM alphabet is selected all characters sent over the serial line are in the range from 0 ... 127. CAUTION: GSM alphabet is not ASCII alphabet!

Several problems resulting from the use of the GSM alphabet:

- "@" character with GSM alphabet value 0 is not printable by an ASCII terminal program (e.g. Microsoft® Hyperterminal®).
- "@" character with GSM alphabet value of binary 0 will terminate any C string! This is because the 0 is defined as C string end tag. Therefore, the GSM Null character may cause problems on application level when using a 'C'-function as "strlenO". This can be avoided if it is represented by an escape sequence as shown in the table below.
- By the way, this may be the reason why even network providers often replace "@" with "@=*" in their SIM application.
- Other characters of the GSM alphabet are misinterpreted by an ASCII terminal program. For example, GSM "6" (as in "Bbrse") is assumed to be "|" in ASCII, thus resulting in "B |rse". This is because both alphabets mean different characters with values hex. 7C or 00 and so on.
- In addition, decimal 17 and 19 which are used as XON/XOFF control characters when software flow control is activated, are interpreted as normal characters in the GSM alphabet.

When you write characters differently coded in ASCII and GSM (e.g. A, O, 0), you need to enter escape sequences. Such a character is translated into the corresponding GSM character value and, when output later, the GSM character value can be presented. Any ASCII terminal then will show wrong responses. Table below shows examples for character definitions depending on alphabet.

GSM character	03.38 character hex. Value	Corresponding ASCII character	ASCII sequence	Esc sequence	Hex sequence	Esc sequence
Ö	5C	\	\5C		5C 35 43	
"	22	"	\22		5C 32 32	
ò	08	BSP	\08		5C 30 38	
@	00	NULL	\00		5C 30 30	

CAUTION: OFTEN, THE EDITORS OF TERMINAL PROGRAMS DO NOT RECOGNIZE ESCAPE SEQUENCES. IN THIS CASE, AN ESCAPE SEQUENCE WILL BE HANDLED AS NORMAL CHARACTERS. THE MOST COMMON WORKAROUND TO THIS PROBLEM IS TO WRITE A SCRIPT WHICH INCLUDES A DECIMAL CODE INSTEAD OF AN ESCAPE SEQUENCE. THIS WAY YOU CAN WRITE, FOR EXAMPLE, SHORT MESSAGES WHICH MAY CONTAIN DIFFERENTLY CODED CHARACTERS.

0.5.1 GSM alphabet tables and UCS2 character values

This section provides tables for the GSM 03.38 alphabet supported by the ME. Below any GSM character find the corresponding two byte character value of the UCS2 alphabet.

Main character table of GSM 03.38 alphabet				b7	0	0	0	0	1	1	1	1
b4	b3	b2	b1		0	1	2	3	4	5	6	7
0	0	0	0	0	@ 0040	Δ 0394	SP 0020	0	i 00A1	P 0050	ż 00BF	p 0070
0	0	0	1	1	£ 00A3	— 005F	! 0021	1	A 0031	Q 0041	a 0051	q 0061
0	0	1	0	2	\$ 0024	Φ 03A6	" 0022	2	B 0032	R 0042	b 0052	r 0062
0	0	1	1	3	¥ 00A5	Γ 0393	# 0023	3	C 0033	S 0043	c 0053	s 0063
0	1	0	0	4	è 00E8	Λ 039B	¤ 00A4	4	D 0034	T 0044	d 0054	t 0064
0	1	0	1	5	é 00E9	Ω 03A9	% 0025	5	E 0035	U 0045	e 0055	u 0065
0	1	1	0	6	ù 00F9	Π 03A0	& 0026	6	F 0036	V 0046	f 0056	v 0066
0	1	1	1	7	ì 00EC	Ψ 03A8	' 0027	7	G 0037	W 0047	g 0057	w 0067
1	0	0	0	8	ò 00F2	Σ 03A3	(0028	8	H 0038	X 0048	h 0058	x 0068
1	0	0	1	9	ç 00E7	Θ 0398) 0029	9	I 0039	Y 0049	i 0059	y 0069
1	0	1	0	10/A	LF [LF] ²⁾	Ξ 039E	* 002A	:	J 003A	Z 004A	j 005A	z 006A
1	0	1	1	11/B	Ø 00D8	ƒ) 002B	+	;	K 003B	Ä 004B	k 00C4	ä 006B
1	1	0	0	12/C	ø 00D8	Æ 00C6	,	<	L 003C	Ö 004C	l 00D6	ö 006C
1	1	0	1	13/D	CR [CR] ²⁾	æ 00E6	- 002D	=	M 003D	Ñ 004D	m 00D1	ñ 006D
1	1	1	0	14/E	Å 00C5	ß 00DF	.	>	N 002E	Ü 003E	n 004E	ü 00DC
1	1	1	1	15/F	å 00E5	É 00C9	ƒ 002F	?	O 003F	§ 004F	o 00A7	à 006F

Table 0.3: Main character table of GSM 03.38 alphabet

- 1) This code is an escape to the following extension of the 7 bit default alphabet table.
- 2) This code is not a printable character and therefore not defined for the UCS2 alphabet. It shall be treated as the accompanying control character.

Extension character table of GSM 03.38 alphabet				b7	0	0	0	0	1	1	1	1
b4	b3	b2	b1		0	1	2	3	4	5	6	7
0	0	0	0	0								

									007C			
0	0	0	1	1								
0	0	1	0	2								
0	0	1	1	3								
0	1	0	0	4		^						
						005E						
0	1	0	1	5						€ ²⁾		
0	1	1	0	6						20AC		
0	1	1	1	7								
1	0	0	0	8			{					
1	0	0	1	9			007B					
1	0	1	0	10/A		³⁾ [LF]						
1	0	1	1	11/B			f)					
1	1	0	0	12/C				[
1	1	0	1	13/D				005B				
1	1	1	0	14/E					~			
1	1	1	1	15/F					007E			
]			
									005D			
									l			
									005C			

Table 1.4: Extension character table of GSM 03.38 alphabet

- 1) This code value is reserved for the extension to another extension table. On receipt of this code, a receiving entity shall display a space until another extension table is defined.
- 2) This code represents the EURO currency symbol. The code value is the one used for the character 'e'. Therefore a receiving entity which is incapable of displaying the EURO currency symbol will display the character 'e' instead.
- 3) This code is defined as a Page Break character and may be used for example in compressed CBS messages. Any mobile which does not understand the 7 bit default alphabet table extension mechanism will treat this character as Line Feed.

In the event that an MS receives a code where a symbol is not represented in table 1.4 the MS shall display the character shown in the main default 7 bit alphabet table (see table 1.3).

0.5.2 UCS2 and GSM data coding and conversion for SMS text mode

This chapter provides basic information on how to handle input and output character conversion for SMS text mode and Remote-SAT if internal (ME) and external (TE) character representation differ, i.e. if the Data Coding Scheme and the TE character use different coding. Implementing output of SIM data to the TE (direction ME to TE).

dcs CSCS	7-Bit (GSM default)	8-Bit	16-Bit (UCS2)
GSM	Case 1 GSM (1:1)	Case 2 IRA (1:1)	Case 3 GSM (2:2)
UCS2	Case 4 GSM to UCS2 (1:2)	Case 5 GSM to UCS2 (1:2)	Case 6 IRA (2:2)

Case 1

Every byte will be sent as GSM character (or ASCII with Hyperterminal).

Example: 0x41,0x21 → "AB" (because of conversion from 7-bit to 8-bit)

Case 2

Every byte will be sent as IRA. No conversion.

Example: 0x41,0x42 → "4142"

Case 3

Every byte will be sent as IRA. No conversion to GSM to avoid data loss.

Example: 0x00,0x41 → "0041"

Problems:

- 0x41,0x42 → "4142" (invalid GSM character, but ignored with respect to GSM 07.05)
- 0x41 → Error (there are two bytes needed)

Case 4

Every byte will be converted from GSM to UCS2.

Example: 0x41,0x42 → "00410042"

Case 5

Every byte will be converted from GSM to UCS2.

Example: 0x41,0x42 → "00410042"

Case 6

Example: 0x41,0x42 → "4142"

Problems:

- 0x41 → Error (there are two bytes needed)

0.5.2.1 *Implementing input of Terminal data to SIM (direction TE to ME)*

CSCS dcs	GSM	UCS2
7-Bit (GSM default)	Case 1 GSM (1:1)	Case 4 UCS2 to GSM (2:1)
8-Bit	Case 2 IRA (1:1)	Case 5 UCS2 to GSM (2:1)
16-Bit (UCS2)	Case 3 IRA (2:2)	Case 6 IRA (2:2)

Case 1

Data will be packed to 7-bit.

Maximum text length: 160 characters

Example: "AB" → 0x41,0x21

Case 2

Data will be saved without any conversion.

Maximum text length: 280 characters

Example: "4142" → 0x41,0x42

Problems:

- "8f" → Error (invalid GSM character)

Case 3

Two bytes are needed. No conversion.

Maximum text length: 280 characters

Example: "0041" → 0x00,0x41

Problems:

- "41" → Error (there are two bytes needed)

Case 4

Two bytes are needed. Two bytes will be converted to 1 byte GSM and 7-bit packed.

Maximum text length: 640 characters

Example: "00410042" → 0x41,0x21

Problems:

- "41" → Error (there are two bytes needed)
- "4142" → Error (invalid character)
- "0000" → Error (not an UCS2 character)
- "007B" → 0x1 B,0x28 (The saved data are two bytes long, not 1 byte like in all other cases. This effects the maximum input length of a string)

Case 5

Two bytes are needed. Two bytes will be converted to 1 byte GSM.

Maximum text length: 560 characters

Example: "00410042" → 0x41 ,0x42

Problems:

- "41" → Error (there are two bytes needed)
- "4142" → Error (invalid character)
- "0000" → Error (not an UCS2 character)
- "007B" → 0x1 B,0x28 (The saved data are two bytes long, not 1 byte like in all other cases. This effects the maximum input length of a string).

Case 6

Two bytes are needed.

Maximum text length: 280 characters

Example: "00410042" → 0x00,0x41,0x00,0x21

Problems:

- "41" → Error (there are two bytes needed)
- "0000" → Error (not an UCS2 character)
- "007B" → 0x00,0x7B

0.6 Flow Control

Flow control is essential to prevent loss of data or avoid errors when, in a data or fax call, the sending device is transferring data faster than the receiving side is ready to accept. When the receiving buffer reaches its capacity, the receiving device should be capable to cause the sending device to pause until it catches up. There are basically two approaches to regulate data flow: software flow control and hardware flow control. The High Watermark of the input/output buffer should be set to approximately 60% of the total buffer size. The Low Watermark is recommended to be about 30%. The data flow should be stopped when the capacity rises close to the High Watermark and resumed when it drops below the Low Watermark. The time required to cause stop and go results in a hysteresis between the High and Low Watermarks.

0.6.1 Software flow control (XON/OFF flow control)

Software flow control sends different characters to stop (XOFF, decimal 19) and resume (XON, decimal 17) data flow. The only advantage of software flow control is that three wires would be sufficient on the serial interface.

0.6.2 Hardware flow control (RTS/CTS flow control)

Hardware flow control sets or resets the RTS/CTS wires. This approach is faster and more reliable, and therefore, the better choice. When the High Watermark is reached, CTS is set inactive until the transfer from the buffer has completed. When the Low Watermark is passed, CTS goes active once again.

To achieve smooth data flow, ensure that the RTS/CTS lines are present on your application platform. The application should include options to enable RTS/CTS handshake with the GSM engine. This needs to be done with the AT command [AT\Q3](#) - it is not sufficient to set RTS/CTS handshake in the used terminal program only. The default setting of the GSM engine is [AT\Q0](#) (no flow control) which must be altered to [AT\Q3](#) (RTS/CTS hardware handshake on). The setting is stored volatile and must be restored each time after the GSM engine was switched off.

[AT\Q](#) has no read command. To verify the current setting of [AT\Q](#), simply check the settings of the active profile with [AT&V](#).

Often, fax programs run an initialization procedure when started up. The initialization commonly includes enabling RTS/CTS hardware handshake, eliminating the need to set [AT\Q3](#) once again. However, before setting up a CSD call, you are advised to check that RTS/CTS handshake is set.

RTS/CTS hardware handshake must also be set if you want to take advantage of the CYCLIC SLEEP modes. For further details refer to [AT+CFUN](#).

- ⚠ After deactivating the RTS line, the ME may still send up to 264 bytes (worst case). This can be easily handled if the buffer of the host application is sufficiently sized, and if a hysteresis is implemented in its Rx buffer. For host applications that are required to handle a large amount of data at high speed, a total buffer capacity of 512 bytes is recommended.

0.7 Unsolicited Result Code Presentation

URC stands for Unsolicited Result Code and is a report message issued by the ME without being requested by the TE, i.e. a URC is issued automatically when a certain event occurs. Hence, a URC is not issued as part of the response related to an executed AT command.

Typical events leading to URCs are incoming calls ("RING"), received SMS, changing temperature, status of the battery etc.

A summary of all URCs is given in chapter [0](#).

To announce a pending URC transmission the ME will do the following:

- Activates its Ring line (logic "1") for one second, i.e. the line changes to physical "Low" level. This allows the TE to enter power saving mode until ME related events request service.
- If the AT command interface is busy a "BREAK" will be sent immediately but the URC will not be issued until the line is free. This may happen if the URC is pending
- while an AT command is being processed, i.e. during the time from sending the first character "A" of an AT command by the TE until the ME has responded with "OK" or "ERROR", or

- during a data call.

Please note that AT command settings may be necessary to enable in-band signaling, e.g. refer to [AT+CMER](#) or [AT+CNMI](#).

For most of these messages, the ME needs to be configured whether or not to send an URC. Depending on the AT command, the URC presentation mode can be saved to the user defined profile (see [AT&W](#)), or needs to be activated every time you reboot the ME. Several URCs are not user definable, such as "[^SYSSTART](#)", "[^SYSSTART <text>](#)", "[^SHUTDOWN](#)" and the fax class 2 URCs listed in chapter [0](#).

If autobauding is enabled (as factory default mode or set with [AT + IPR = 0](#)), URCs generated after restart will be output with 57600 bps until the ME has detected the current bit rate. The URCs "[^SYSSTART](#)", "[^SYSSTART <text>](#)", however, are not presented at all. For details please refer to chapter [3.9.1](#). To avoid problems we recommend to configure a fixed bit rate rather than using autobauding.

0.7.1 Communication between Customer Application and SAMBA75

Leaving hardware flow control unconsidered the Customer Application (TE) is coupled with the SAMBA75 (ME) via a receive and a transmit line.

Since both lines are driven by independent devices collisions may (and will) happen, i.e. while the TE issues an AT command the SAMBA75 starts sending an URC. This probably will lead to the TE's misinterpretation of the URC being part of the AT command's response.

To avoid this conflict the following measures must be taken:

- If an AT command is finished (with "OK" or "ERROR") the TE shall always wait at least 100 milliseconds before sending the next one.
- This gives the SAMBA75 the opportunity to transmit pending URCs and get necessary service.
- Note that some AT commands may require more delay after "OK" or "ERROR" response, refer to the following command specifications for details.
- The TE shall communicate with the SAMBA75 using activated echo ([ATE1](#)), i.e. the SAMBA75 echoes characters received from the TE.
- Hence, when the TE receives the echo of the first character "A" of the AT command just sent by itself it has control over both the receive and the transmit paths. This way no URC can be issued by the SAMBA75 in between.

0.8 Common PCN Handset Specification (CPHS)

The ME provides features to implement a device following the prerequisites of the Common PCN Handset Specification (CPHS) Phase 2.

CPHS Feature	Description/Remarks	AT command
Alternate Line Service	Using two phone numbers with one SIM card.	AT^SALS
Voice Message Waiting Indication	Indicate the receipt of a short message coded as Voice Message Waiting Indicator as defined by the CPHS Phase 2 standard	AT^SIND AT+CMER ,indicators "vmwait1" and "vmwait2"
Operator (Service provider) name from SIM	Read specific Elementary Files (6F14h,6F18h) from SIM	AT+CRSM
Network and Service Provider Lock	Lock/Unlock an ME to specific HPLMN and service provider	AT+CLCK,(AT+CPIN)
Call Forwarding	Get and set diverted call status. Access specific Elementary File (6F13h) from SIM.	AT+CCFC , AT+CRSM
Customer Service Profile (CSP)	Setting services and their menu entries depending on customer profiles.	AT+CRSM

Information numbers	Hierarchically structured service numbers phone book on SIM according to CPHS 4.2 (mandatory).	AT+CRSM
---------------------	--	---------

0.9 Errors and Messages

The final result codes "+ CME ERROR: <err>" and "+ CMS ERROR: <err>" indicate errors related to mobile equipment or network. The effect is similar to an ERROR result code.

A final result error code terminates the execution of the command and prevents the execution of all remaining commands that may follow on the same command line. If so, neither ERROR nor OK result code are returned for these commands. A 30 seconds timeout causes ERROR to be returned when the input of a command is not complete. The format of <err> can be either numeric or verbose. This is set with the command [AT+CMEE](#).

See also:

- [1.5.1](#)
- [AT+CEER](#)

1 CONFIGURATION COMMANDS

The AT commands described in this chapter allow the external application to determine the SAMBA75's behaviour under various conditions.

1.1 AT&F Set all current parameters to manufacturer defaults

Syntax

Exec Command AT&F[<value>]	Response(s) OK
-------------------------------	-------------------

Reference(s)	PIN	USB					
V.25ter	○	●					

Command Description

TA sets all current parameters to the manufacturer defined profile.

Parameter Description

<value>^(num)

[0] set all TA parameters to manufacturer defaults

Notes

- List of parameters reset to manufacturer default can be found in chapter [18.5](#).
- In addition to the default profile, you can store an individual one [AT&W](#). To alternate between the two profiles enter either [ATZ](#) (loads user profile) or [AT&F](#) (restores factory profile).
- Every ongoing or incoming call will be terminated.

1.2 AT&V Display current configuration

Syntax

Exec Command AT&V[<value>]	Response(s) ACTIVE PROFILE: ... (see section 1.2.1) OK
-------------------------------	---

Reference(s)	PIN	USB					
V.25ter	○	●					

Command Description

TA returns the current parameter setting. The configuration varies depending on whether or not PIN authentication has been done.

Parameter Description

<value>^(num)

[0] Profile number

Notes

- The parameters of [AT&SMGO](#) can only be displayed after the SMS data from the SIM have been read successfully for the first time. Reading starts

after successful SIM authentication has been performed, and may take up to 30 seconds depending on the SIM used. While the read process is in progress, an attempt to read the parameter will result in empty values.

- The parameter of **AT+CSDH** will only be displayed in SMS text mode, see **AT+CMGF**.

1.2.1 AT&V responses

The following tables show four different kinds of responses depending on whether or not the PIN is entered.

PIN authentication done	No PIN authentication
ACTIVE PROFILE: E1 Q0 V1 X4 &C1 &D2 &S0\Q0 S0:000 S3:013 S4:010 S5:008 S6:000 S7:060 S8:000S10:002S18:000 +CBST:7,0,1 +CRLP:61,61,78,6 +CRC: 0 +FCLASS:0 +CMGF:0 +CSDH:0 +CNMI:0,0,0,0,1 +ILRR: 0 +IPR:57600 +CMEE:2 ^SMGO:0,0 +CSMS:0,1,1,1 ^SACM:0,"000000","000000" ^SLCC:0 ^SCKS:0,1 +CREG:0,1 +CLIP:0,2 +CAOC:0 +COPS:0,0,"operator" +CGSMS:3 OK	ACTIVE PROFILE: E1 Q0 V1 X4 &C1 &D2 &S0\Q0 S0:000 S3:013 S4:010 S5:008 S6:000 S7:060 S8:000 S10:002 S18:000 +CBST: 7,0,1 +CRLP:61,61,78,6 +CR:0 +FCLASS:0 +ILRR:0 +IPR:57600 +CMEE:2 ^SCKS: 0,1 OK

Table 2.1: Current configuration on USB 1 (example)

1.3 AT&W Stores current configuration to user defined profile

Syntax

Exec Command AT&W[<value>]	Response(s) OK ERROR/+CME ERROR <err>
-------------------------------	--

Reference(s)	PIN	USB					
V.25ter	○	●					

Command Description

TA stores the currently set parameters to a user defined profile in the non-volatile memory.

Parameter Description

<value>^(num)

[0] Number of profile

Notes

- The user defined profile will be restored automatically after PowerUp. Use **ATZ** to restore user profile and **AT&F** to restore factory settings. Until the first use of **AT&W**, **ATZ** works as **AT&F**.
- A list of parameters stored to the user profile can be found in Chapter [18.4](#).

1.4 ATQ Set result code presentation mode

Syntax

Exec Command ATQ[<n>]	Response(s) If <n>=0: OK If <n>=1: (none)
--------------------------	---

Reference(s)	PIN	USB					
V.25ter	○	●					

Command Description

This parameter setting determines whether or not the TA transmits any result code to the TE. Information text transmitted in response is not affected by this setting.

Parameter Description

<n> (num)(&W)(&V)

- | | |
|---------|---|
| [0](&F) | DCE transmits result code |
| 1 | Result codes are suppressed and not transmitted |

1.5 ATV Set result code format mode

This command determines the contents of header and trailer transmitted with AT command result codes and information responses. Possible responses are described at [1.5.1](#).

Syntax

Exec Command ATV[<value>]	Response(s) If <value>=0 0 If <value>=1 OK
------------------------------	---

Reference(s)	PIN	USB					
V.25ter	○	●					

Parameter Description

<value> (num)(&W)(&V)

- | | |
|-----|---|
| [0] | Information response: <text><CR><LF>
Short result code format: <numeric code><CR> |
| 1 | Information response: <CR><LF><text><CR><LF>
Long result code format: <CR><LF><verbose code><CR> |

1.5.1 Verbose and numeric result codes

Verbose format	Numeric format	Meaning
----------------	----------------	---------

OK	0	Command executed, no errors
CONNECT	1	Link established
RING	2	Ring detected
NO CARRIER	3	Link not established or disconnected
ERROR	4	Invalid command or command line too long
NO DIALTONE	6	No dial tone , dialling impossible, wrong mode
BUSY	7	Remote station busy
CONNECT 2004/RLP	47	Link with 2400 bps and Radio Link Protocol
CONNECT 4800/RLP	48	Link with 4800 bps and Radio Link Protocol
CONNECT 9600/RLP	49	Link with 9600 bps and Radio Link Protocol
CONNECT 14400/RLP	50	Link with 14400 bps and Radio Link Protocol
ALERTING		Alerting at called phone
DIALING		Mobile phone is dialing

1.6 ATX Set CONNECT result code format and call monitoring

Syntax

Exec Command	Response(s)
ATX[<value>]	OK

Reference(s)	PIN	USB					
V.25ter	○	●					

Command Description

This parameter setting determines whether or not the TA detects the presence of dial tone and busy signal and whether or not TA transmits particular result codes.

Parameter Description

<value>(num)(&W)(&V)

- [0] CONNECT result code only returned, dial tone and busy detection are both disabled.
- 1 CONNECT <text> result code only returned, dial tone and busy detection are both disabled.
- 2 CONNECT <text> result code returned, dial tone detection is enabled, busy detection is disabled.
- 3 CONNECT <text> result code returned, dial tone detection is disabled, busy detection is enabled.
- 4(&F) CONNECT <text> result code returned, dial tone and busy detection are both enabled.

1.7 AT\V Set CONNECT result code format

Exec Command	Response(s)
ATV[<value>]	OK ERROR

Reference(s)	PIN	USB					
V.25ter	○	●					

Parameter Description

<value>(num)(&W)(&V)

- [0] CONNECT <text> result code returned without RLP trailer
- 1(&F) CONNECT <text> result code returned with RLP trailer

Notes

For circuit switched data calls only.

Output only if [ATX](#) parameter is set with value > 0.

1.8 ATZ Set all current parameters to user defined profile

Syntax

Exec Command ATZ[<value>]	Response(s) OK
------------------------------	-------------------

Reference(s)	PIN	USB					
V.25ter	○	●					

Command Description

TA sets all current parameters to the user profile stored with [AT&W](#). If a connection is in progress, it will be terminated.

All defined GPRS contexts which are not activated or not online will be undefined (see [AT+CGDCONT](#), [AT+CGQREQ](#) and [AT+CGQMIN](#) command). The user defined profile is stored to the non-volatile memory.

Parameter Description

<value>^(num)

- [0] Reset to user profile

Notes

First the profile will be set to factory default (see [AT&F](#)). If there is a valid user profile (stored with [AT&W](#)), this profile will be loaded afterwards.

Any additional commands on the same command line may be ignored. A delay of 300 ms is required before next command is sent, otherwise "OK" response may be corrupted.

1.9 AT+CFUN Set phone functionality

This command serves to control the functionality level of the ME. It can be used to reset the ME, to choose one of the SLEEP modes or to return to full functionality.

Intended for power saving, SLEEP mode reduces the functionality of the ME to a minimum and thus minimizes the current consumption. SLEEP mode falls in two categories:

- NON-CYCLIC SLEEP mode <fun>=0
- and CYCLIC SLEEP modes, selectable as <fun>= 5, 6, 7, 8 or 9.

NON-CYCLIC SLEEP mode permanently blocks the serial interface. The CYCLIC SLEEP mode, however, is a dynamic process which alternately enables and disables the serial interface. The major benefit of all CYCLIC SLEEP modes is that the serial interface remains accessible and that, in intermittent wake-up periods, characters can be sent or received without terminating the selected mode. The best choice is using <fun>= 5, 6, 7, 8 or 9, since in these modes SAMBA75 automatically resumes power saving, after you have sent or received a short message or made a call. <fun>=5 or 6 do not offer this feature to the same extent and are only supported for compatibility with earlier releases. In all CYCLIC SLEEP modes, you can enter <fun>=1

to permanently wake up SAMBA75 and take it back to full functionality. Please refer to section [1.9.1](#) for a summary of all SLEEP modes and the different ways of waking up the module.

For CYCLIC SLEEP mode (`<fun>= 5, 6, 7, 8 or 9`) both the ME and the application must be configured to use hardware flow control. This is necessary since the CTS signal is set/reset every time when the ME listens to a paging message from the base station. This is the way how the module indicates to the application when the UART is active. For detailed information on the timing of the CTS signal refer to [\[2\]](#). The default setting of hardware flow control is `AT\Q0` which must be altered to `AT\Q3`. For use after restart you are advised to add it to the user profile saved with `AT&W`. If both interfaces USB is connected, hardware flow control must be set in either application.

Syntax

Test Command <code>AT+CFUN=?</code>	Response(s) +CFUN: (list of supported <code><fun>s</code>), (list of supported <code><rst>s</code>) OK
Read Command <code>AT+CFUN?</code>	Response(s) +CFUN: <code><fun></code> OK
Write Command <code>AT+CFUN=[<fun>[,<rst>]]</code>	Response(s) OK ERROR +CME ERROR

Reference(s)	PIN	USB					
GSM 07.07	○	●					

Command Description

The test command returns the values of the supported parameters. The read command returns the current functionality value.

The write command can be used to reset the ME, to choose one of the SLEEP modes or to return to full functionality.

Parameter Description

`<fun>(num)`

0 NON-CYCLIC SLEEP mode:

In this mode, the AT interface is not accessible. Consequently, once you have set `<fun>` level 0, do not send further characters. Otherwise these characters remain in the input buffer and may delay the output of an unsolicited result code.

The first wake-up event stops power saving and takes the ME back to full functionality level `<fun>=1`.

[1]^(&F) Full functionality.

If the ME is in one of the CYCLIC SLEEP modes you can issue `AT+CFUN=1` to stop power saving and return to full functionality.

Keep in mind that, unlike the reset command described below, this action does not restart the ME but only changes the level of functionality. See parameter `<rst>` for details on the reset.

5 CYCLIC SLEEP mode:

In this mode, the serial interface is shortly enabled during paging. If characters are recognized on the serial interface, the ME stays active for 2 seconds after the last character was sent or received.

6 CYCLIC SLEEP mode:

In this mode, the serial interface is shortly enabled during paging.

If characters are recognized on the serial interface, the ME stays active for 10 minutes after the last character was sent or received.

To ensure that power saving takes effect immediately, the ME stays active for only 2 seconds after **<fun>=6** was entered.

7 CYCLIC SLEEP mode:

In this mode, the serial interface is shortly enabled during paging. If characters are recognized on the serial interface, the ME stays active for 2 seconds after the last character was sent or received. ME exits SLEEP mode only, if **AT+CFUN=1** is entered.

8 CYCLIC SLEEP mode:

In this mode, the serial interface is shortly enabled during paging.

If characters are recognized on the serial interface, the ME stays active for 10 minutes after the last character was sent or received. ME exits SLEEP mode only, if **AT+CFUN=1** is entered.

To ensure that power saving takes effect immediately, the ME stays active for only 2 seconds after **<fun>=8** was entered.

9 CYCLIC SLEEP mode:

In this mode, the serial interface is shortly enabled during paging. If characters are recognized on the serial interface, the ME stays active after the last character was sent or received for at least the time, which can be configured by **AT^SCFG="PowerSaver/Mode9/Timeout",<cfun9-timeout>** (temporary wakeup).

In contrast to SLEEP modes 5,6,7 and 8 assertion of RTS can also be used to temporarily wake up the ME. In this case too, activity time is at least the time set with **AT^SCFG="PowerSaver/Mode9/Timeout",<cfun9-timeout>**. RTS can be activated from USB. ME exits SLEEP mode only, if **AT+CFUN=1** is entered.

<rst>^(num)

The parameter can only be used if the serial interface is enabled.

Due to the command syntax, you need to enter parameter **<fun>**, followed by **<rst>**, where **<fun>** is only a placeholder and has no effect. See examples below.

[0] Placeholder for **<fun>** as stated above.

1 ME resets and restarts to full functionality. After reset and restart, PIN 1 authentication is necessary (**AT+CPIN**). If autobauding is enabled, it is recommended to wait 3 to 5 seconds before entering the first AT command. For details on autobauding refer to chapter [3.9.1](#).

Notes

- If both serial interfaces USB is connected, any functionality level set with **AT+CFUN** takes effect on both of them.
- When a circuit-switched call is in progress, **<fun>=7** or 8 or 9 can be activated without terminating the call. However, setting **<fun>=0, 5 or 6** during a circuit-switched call immediately disconnects this call.
- Please keep in mind that power saving works properly only when PIN authentication has been done. If you attempt to activate power saving while the SIM card is not inserted or the PIN is not correctly entered, the selected **<fun>** level will be set, though power saving does not take effect. For the same reason, power saving cannot be used if

SAMBA75 operates in Alarm mode. Furthermore, in order to accept incoming calls, SMS or network related URCs in SLEEP mode the ME must be registered when it enters the SLEEP mode.

- To check whether power saving is on, you can query the status with the read command **AT+CFUN?** only if the module is in full functionality mode or in CYCLIC SLEEP mode. If available, you can also take advantage of the status LED controlled by the SYNC pin (see [2]). The LED remains "off" while the module is in any of the SLEEP modes. However, the module can wake up temporarily from power saving without leaving its CYCLIC SLEEP mode (without changing +CFUN "<fun>"), e.g. for a network scan after a loss of radio coverage, or after receipt of serial data during CYCLIC SLEEP mode. During this "temporary wake up state" the LED will operate as if the ME was in full functionality mode.
- Recommendation: In NON-CYCLIC SLEEP mode, you can set an RTC alarm to wake up the ME and return to full functionality. This is a useful approach because, in this mode, the AT interface is not accessible.

Examples

EXAMPLE 1

To check the level of functionality use the read command:

AT+CFUN?

+CFUN: 1 Default mode after ME was restarted

Remember that the AT interface is not accessible in NON-CYCLIC SLEEP mode. Consequently, the read command is only useful when the ME is set to full functionality or, when <fun> is set to 5, 6, 7, 8 or 9.

AT+CFUN?

+CFUN: 5 CYCLIC SLEEP mode

EXAMPLE 2

To set the ME to NON-CYCLIC SLEEP mode enter

AT+CFUN=0

OK

When, for example, an SMS is being received and indicated by an unsolicited result code (URC), the ME wakes up to full operation.

+CMTI: "SM",5

Note that the URC used in this example will appear only, if **AT+CNMI=1,1** was configured before. After this, you may want to verify the operating status:

AT+CFUN?

+CFUN: 1 Indicates that ME has entered full functionality mode.

EXAMPLE 3

To stop CYCLIC SLEEP mode and return to full functionality:

AT+CFUN?

+CFUN: 5

OK

AT+CFUN=1

OK

Remember that this approach is not applicable to the NON-CYCLIC SLEEP mode (since the serial interface is disabled). The NON-CYCLIC SLEEP mode ends with the first wake-up event.

EXAMPLE 4

To reset and restart the ME:

AT+CFUN=1,1 or alternatively, AT+CFUN=0,1 or 5,1 or 6,1 or 7,1 or 8,1 or 9,1

OK

^SYSSTART

The ^SYSSTART URC confirms that the ME has been rebooted. Note that ^SYSSTART appears only if AT+IPR ≠ 0. If the ME is in autobaud mode, it is recommended to wait 3 to 5 seconds before entering the first AT command. Remember to enter the SIM PIN after restart.

1.9.1 Wake up the ME from SLEEP mode

A wake-up event is any event that causes the ME to draw current. Depending on the selected mode, the wake-up event either switches the SLEEP mode off and takes the ME back to full functionality AT+CFUN=1, or activates the ME temporarily without terminating the selected SLEEP mode.

Definitions of the state transitions described in table 2.3:

- Quit: ME exits SLEEP mode.
- Temporary: ME becomes active temporarily for the duration of the event and the mode-specific follow-up time after the last character was sent or received on the serial interface.
- No effect: Event is not relevant in the selected SLEEP mode. The ME does not wake up.

Event	Selected mode: <fun>=0	Selected mode: <fun>=5 or 6	Selected mode: <fun>=7 or 8 or 9
Ignition line	No effect	No effect	No effect
/RTS0 or RTS1 activation	Quit	No effect (RTS is only used for flow control)	Mode 7 and 8: No effect (RTS is only used for flow control) Mode 9: Temporary
Unsolicited Result Code (URC)	Quit	Quit	Temporary
Incoming voice or data call	Quit	Quit	Temporary
Any AT command (incl. Outgoing SMS,voice or data call)	Not possible (UART disabled)	Temporary	Temporary
Incoming SMS (AT+CNMI is set to 0,0 (this is the default setting))	No effect	No effect	No effect
Incoming SMS (AT+CNMI is set to 1,1)	Quit	Quit	Temporary
GPRS data transfer	Not possible (UART disabled)	Temporary	Temporary
RTC alarm line	Quit	Quit	Temporary
AT+CFUN=1	Not possible (UART disabled)	Quit	Quit

Table 2.3: Wake-up events in NON-CYCLIC and CYCLIC SLEEP modes

1.10 AT^SMSO Switch off mobile station

Syntax

Test Command AT^SMSO=?	Response(s) OK
---------------------------	-------------------

Exec Command AT^SMSO	Response(s) ^SMSO: MS OFF OK
-------------------------	------------------------------------

Reference(s)	PIN	USB					
SIEMENS	○	●					

Unsolicited Result Code

ASHUTDOWN

Indicates that the power-off procedure is finished and the module will be switched off within 1 second.

Command Description

The exec command initiates the power-off procedure. Low level of the module's VDD pin and display of URC "**ASHUTDOWN**" verifies that the procedure has completed and the module has entered the POWER DOWN mode. Therefore, be sure not to disconnect the operating voltage until VDD is low or until URC "**ASHUTDOWN**" is displayed. Otherwise, you run the risk of losing data. For further details on how to turn off the module see the [2].

Notes

- Do not send any command after this command.
- If interface USB is connected the URC appears on both of them.

1.11 AT+GCAP Request complete TA capabilities list

Syntax

Test Command AT+GCAP=?	Response(s) OK
Exec Command AT+GCAP	Response(s) +GCAP: <name> OK

Reference(s)	PIN	USB					
V.25ter	○	●					

Command Description

TA reports a list of additional capabilities.

Parameter Description

<name>(str)

e.g.: +CGSM,+FCLASS

Note

- +CGSM: The response text shows which GSM commands of the ETSI standard are supported.

1.12 AT+CMEE Mobile Equipment Error Message Format

Syntax

Test Command AT+CMEE=?	Response(s) +CMEE: (list of supported<n>s) OK
---------------------------	---

Read Command AT+CMEE?	Response(s) +CMEE: <n> OK
Write Command AT+CMEE=<n>	Response(s) OK ERROR +CME ERROR: <err>

Reference(s)	PIN	USB					
GSM 07.07	○	●					

Command Description

This command controls the presentation of the result code +CME ERROR: <err> that indicates errors related to the ME functionality.

When you power down or reset the ME with **AT+CFUN=1,1** the setting will be reset to its default. The levels 1 or 2 need to be selected every time you reboot the ME, or may be included, for permanent use, in the user profile saved with **AT&W**.

Parameter Description

<n> (num)(&W)(&V)

0(&F)	disable result code (only 'ERROR' will be displayed)
1	enable result code and use numeric values
2	enable result code and use verbose values

Notes

- The possible error result codes are listed in chapter [1.12.1](#).

Example

To obtain enhanced error messages it is recommended to choose <n>=2.

```
AT+CMEE=2
OK
```

1.12.1 CME/CMS Error Code Overview

<err> Code	Text (if AT+CMEE=2)
0	Phone failure
1	No connection to phone
2	Phone-adapter link reserved
3	Operation not allowed
4	Operation not supported
5	PH-SIM PIN required
6	PH-FSIM PIN required
7	PH-FSIM PUK required
10	SIM not insert
11	SIM PIN required
12	SIM PUK required
13	SIM failure
14	SIM busy
15	SIM wrong
16	Incorrect password
17	SIM PIN2 required
18	SIM PUK2 required
20	Memory full
21	Invalid index
22	Not found
23	Memory failure
24	Text string too long

25	Invalid characters in text string
26	Dial string too long
27	Invalid character in dial string
30	No network service
31	Network timeout
32	Network not allowed emergency calls only
40	Network personalization PIN required
41	Network personalization PUK required
42	Network subset personalization PIN required
43	Network subset personalization PUK required
44	Service provider personalization PIN required
45	Service provider personalization PUK required
46	Corporate personalization PIN required
47	Corporate personalization PUK required
48	Master Phone Code required
100	Unknown
132	Service option not supported
133	Requested service option not subscribed
134	Service option temporarily out of order
256	Operation temporary not allowed
257	Call barred
258	Phone is busy
259	User abort
260	Invalid dail string
261	Ss not executed
262	SIM blocked
263	Invalid Block

Table 1.2: General "CME ERROR" Codes (GSM 07.07)

Code of <err>	Text (if AT+CME=2)
103	Illegal MS
106	Illegal ME
107	GPRS services not allowed
111	PLMN not allowed
112	Location area not allowed
113	Roaming not allowed in this location area
148	Unspecified failure
149	PDP authentication failure
150	Invalid mobile class

Table 1.3: GPRS related "CME ERROR" Codes (GSM 07.07)

<err> Code	Text (if AT+CME=2)
1	Unassigned (unallocated) number
8	Operator determined barring
10	Call barred

Table 1.4: SMS related "CMS ERROR" Codes (GSM 07.05)

<err> Code	Text (if AT+CME=2)
588	GPRS – feature not supported
594	GPRS – invalid address length
595	GPRS – invalid character in address string
596	GPRS – invalid cid value
607	GPRS – missing or unknown APN
625	GPRS – pdp type not supported
630	GPRS – profile (cid) not defined
632	GPRS – QOS not accepted
633	GPRS –QOS validation fail
643	GPRS – unknown PDP address or type
644	GPRS – unknown PDP context
646	GPRS – QOS invalid parameter

Table 1.5: GPRS related "CME ERROR" Codes (SIEMENS)

1.13 AT+CSCS Select TE character set

Syntax

Test Command AT+CSCS=?	Response(s) +CSC: (list of supported <chset>s) OK
Read Command AT+CSCS?	Response(s) +CSCS: <chset>
Write Command AT+CSCS=[<chset>]	Response(s) OK

Reference(s)	PIN	USB				
GSM 07.07, GSM 11.11	○	●				

Command Description

Write command informs TA which character set <chset> is used by the TE. TA is then able to convert character strings correctly between TE and ME character sets. See also section 0.5. Note that when TA-TE interface is set to 8-bit operation and used TE alphabet is 7-bit, the highest bit will be set to zero.

Parameter Description

<chset>^(str)

"GSM" (&F)	GSM default alphabet (GSM 03.38 subclause 6.2.1); Note: This setting may cause software flow control problems since the codes used to stop and resume data flow (XOFF = decimal 19, XON = decimal 17) are interpreted as normal characters.
"UCS2"	16-bit universal multiple-octet coded character set (ISO/IEC10646 [32]); UCS2 character strings are converted to hexadecimal numbers from 0000 to FFFF; e.g. "004100620063" equals three 16-bit characters with decimal values 65, 98 and 99, \${AT R97}\$

1.14 AT^SCFG Extended Configuration Settings

Command can be used to query and set various ME settings of SAMBA75.

Parameter names are coded in GSM alphabet, parameter values in the alphabet as specified by Table 1.4 (GSM or UCS2).

Syntax

Test Command AT^SCFG=?	Response(s) ^SCFG: "GPRS/ATS0/withAttach", (list of supported <gs0aa>s) ^SCFG: "GPRS/AutoAttach", (list of supported <gaa>s) ^SCFG: "GPRS/RingOnIncomingData", (list of supported <groid>s) ^SCFG: "MEopMode/Airplane", (list of supported <map>s) ^SCFG: "MEopMode/Airplane/OnStart", (list of supported <mapos>s) ^SCFG: "PowerSaver/Mode9/Timeout", (list of supported <psm9to>s) ^SCFG: "Radio/Band", (list of supported <rba>s), (list of supported <rba>s) ^SCFG: "Radio/OutputPowerReduction", (list of supported <rop>s) ^SCFG: "URC/CallStatus/CIEV", (list of supported <succ>s) ^SCFG: "URC/CallStatus/SLCC", (list of supported <sucs>s) ^SCFG: "URC/Datamode/Ringline", (list of supported <udri>s) ^SCFG: "URC/Ringline", (list of supported <uri>s) ^SCFG: "URC/Ringline/ActiveTime", (list of supported <urat>s) OK
Read Command AT^SCFG?	Response(s) ^SCFG: "GPRS/ATS0/withAttach", <gs0aa> ^SCFG: "GPRS/AutoAttach", <gaa> ^SCFG: "GPRS/RingOnIncomingData", <groid> ^SCFG: "MEopMode/Airplane", <map> ^SCFG: "MEopMode/Airplane/OnStart", <mapos> ^SCFG: "PowerSaver/Mode9/Timeout", <psm9to> ^SCFG: "Radio/Band", <rbc>, <rba> ^SCFG: "Radio/OutputPowerReduction", <rop> ^SCFG: "URC/CallStatus/CIEV", <succ> ^SCFG: "URC/CallStatus/SLCC", <sucs> ^SCFG: "URC/Datamode/Ringline", <udri> ^SCFG: "URC/Ringline", <uri> ^SCFG: "URC/Ringline/ActiveTime", <urat> OK
Write Command Automatic GPRS attach AT^SCFG="GPRS/AutoAttach"[, <gaa>]	Response(s) ^SCFG: "GPRS/AutoAttach", <gaa> OK ERROR +CME ERROR
Write Command GPRS ATS0 with automatic attach AT^SCFG="GPRS/ATSO/withAttach"[,<gaa>]	Response(s) ^SCFG: "GPRS/ATSO/withAttach",<gaa> OK ERROR +CME ERROR
Write Command Enable/disable Airplane mode during operation AT^SCFG="MEopMode/Airplane"[, <map>]	Response(s) ^SCFG: "MEopMode/Airplane", <map> OK ERROR +CME ERROR
Write Command Airplane mode upon ME restart AT^SCFG="MEopMode/Airplane/OnStart"[, <mapos>]	Response(s) ^SCFG: "MEopMode/Airplane/OnStart", <mapos> OK ERROR +CME ERROR
Write Command Ring on incoming GPRS IP data packets AT^SCFG="GPRS/RingOnIncomingData"[,<groid>]	Response(s) ^SCFG: "GPRS/RingOnIncomingData",<groid> OK ERROR +CME ERROR
Write Command Query/Set timeout value for power saving mode 9. AT^SCFG="PowerSaver/Mode9/Timeout"[,<cfun9-timeout>]	Response(s) ^SCFG: "PowerSaver/Mode9/Timeout",<cfun9-timeout> OK ERROR +CME ERROR

Write Command Radio output power reduction. AT^SCFG="Radio/OutputPowerReduction"[, <ropr>]	Response(s) ^SCFG: "Radio/OutputPowerReduction", <ropr> OK ERROR +CME ERROR
Write Command Radio band selection. AT^SCFG="Radio/Band"[, <rbp>][, <rba>]	Response(s) ^SCFG: "Radio/Band", <rbp> , <rba> OK ERROR +CME ERROR
Write Command Configuration of URC "+CIEV:call" Call Status Indication AT^SCFG="URC/CallStatus/CIEV"[,< succ >]	Response(s) ^SCFG: "URC/CallStatus/CIEV",< succ > OK ERROR +CME ERROR
Write Command Configuration of URC " ^SLCC " Call Status Indication AT^SCFG="URC/Calistatus/SLCC"[,< suks >]	Response(s) ^SCFG: "URC/CallStatus/SLCC",< suks > OK ERROR +CME ERROR
Write Command URC indication in datemode via RING line: AT^SCFG="URC/Datamode/Ringline"[,< udri >]]	Response(s) ^SCFG: "URC/Datamode/Ringline",< udri > OK ERROR +CME ERROR
Write Command URC indication via RING line: AT^SCFG="URC/Ringline"[,< uri >]	Response(s) ^SCFG: "URC/Ringline",< uri > OK ERROR +CME ERROR
Write Command Duration of active RING line for URC indications: AT^SCFG="URC/Ringline/ActiveTime"[,< urat >]	Response(s) ^SCFG: "URC/Ringline/ActiveTime",< urat > OK ERROR +CME ERROR

PIN	USB				
O	●				

Unsolicited Result Code

[^SYSSTART](#) AIRPLANE MODE

This URC is issued each time the Airplane mode is activated, no matter whether Airplane mode is set with parameter [<map>="on"](#) or [<mapos>="on"](#). The URC notifies the user that only the AT commands supported in Airplane mode are accessible. After leaving the Airplane mode the URC "[^SYSSTART](#)" indicates that the ME has returned to Normal mode and the full set of AT commands is accessible again.

Command Description

The [AT^SCFG](#) read command returns a list of all supported parameters and their current values.

The [AT^SCFG](#) write command queries a configuration parameter (if no value is entered) or sets its value(s).

Input of parameter names is always coded in GSM character set, parameter values are expected to be given as

specified via [AT+CSCS](#).

The following error messages may be returned by the `AT^SCFG` write commands:

- "`+CME ERROR: operation temporary not allowed`"
Change of parameter value(s) temporarily not allowed.
- "`+CME ERROR: invalid index`"
Invalid parameter name or value(s).
- "`+CME ERROR: invalid characters in text string`"
Character set conversion of parameter value(s) failed.
- "`+CME ERROR: memory failure`"
Could not allocate necessary memory or storing a parameter failed.
- "`+CME ERROR: operation not allowed`"
Change of parameter value(s) not allowed
- "`+CME ERROR: unknown`"
Other error

Parameter Description

`<gs0aa>`(^{str(+CSCS)})

GPRS ATSO with Attach

This parameter can be used to control the behaviour of `ATSO`.

Parameter is global for all interfaces, volatile and will not be reset by `AT&F`.

- | | |
|-------|---|
| "on" | When the <code>ATSO=<n></code> (<code><n>>0</code>) command is received, the MT will attempt to perform a GPRS attach. |
| "off" | When the <code>ATSO=<n></code> (<code><n>>0</code>) command is received, the MT will not attempt to perform a GPRS attach. |

`<gaa>`(^{str(+CSCS)})

GPRS with AutoAttach

This parameter can be used to control whether the ME will perform a GPRS attach immediately after registering to the network or not. If the setting is changed to "enabled" and the ME is not attached yet, it will not initiate an attach immediately but after the next registration to the network. Parameter is global for all interfaces, non volatile and will not be reset by `AT&F`.

- | | |
|---------------------------|------------------------------|
| "disabled" ^(D) | GPRS auto attach is disabled |
| "enabled" | GPRS auto attach is enabled |

`<groid>`(^{str(+CSCS)})

Ring on incoming GPRS IP data packets

This parameter can be used to control the behaviour of the RING line for incoming IP packets in GPRS online mode.

Parameter is local for the interface, volatile and will not be reset by `AT&F`.

- | | |
|------|--|
| "on" | If ME is in power saving mode 7 or 8 (see <code>AT+CFUN</code>) and hardware flow control is in use (<code>AT\Q3</code>) and RTS line is inactive and there are incoming IP packets for a GPRS context which is online, then the RING line will be activated once, for a time which is configured by the parameter "URC/Ringline/ActiveTime" (<code><urat></code>). The RING line which will be used, can be configured by the parameter "URC/Ringline" (<code><uri></code>). |
|------|--|

"off^(P)
<map>(^{str})^(+cscs)

RING line is not activated for incoming IP packets.

MEopMode/Airplane: Enable/disable Airplane mode during operation

The two parameters **<map>** and **<mapos>** can be used to enable/disable the Airplane mode. Airplane mode shuts down the radio part of the ME (PA and receiver), causes the ME to log off from the GSM/GPRS network and disables all AT commands whose execution requires a radio connection. A list of AT commands supported during Airplane mode can be found in [Section 20.4, Availability of AT Commands Depending on Operating Mode of ME](#). The benefit of Airplane mode is that, at locations where no RF emission is allowed (typically airplanes, hospitals etc.), the subscriber can continue using network-independent features rather than powering off the entire device (e.g. a PDA or smartphone).

If the subscriber tries to use an AT command not available in Airplane mode the response "+CME ERROR: Unsupported AT command" is returned.

Parameter **<map>** allows entering or leaving the Airplane mode anytime during operation, eliminating the need to enter the SIM PIN again. It can be used no matter whether the parameter **<mapos>** is "on" or "off". Parameter **<map>** is global for all interfaces, volatile and will not be reset by [AT&F](#).

"on" Activates Airplane mode and shuts down the radio part of the ME. The URC "**^SYSSTART AIRPLANE MODE**" appears.

"off^(P)" Deactivates Airplane mode, wakes up the radio part of the ME and restores access to network-dependent AT commands. The URC "**^SYSSTART**" appears.

<mapos>(^{str})^(+cscs)

MEopMode/Airplane: Airplane mode upon ME restart

There are two ways to enter Airplane mode upon restart: One is using [AT^SCFG](#) with **<mapos>** as described below.

Another approach is configuring the ME to restart into Airplane mode at a scheduled time. In this case, use the [AT+CALA](#) command, set an alarm time and then switch the ME off. When the alarm time is reached the ME wakes up to Airplane mode, no matter whether **<mapos>** was set "on" or "off". Parameter **<mapos>** is global for all interfaces, non volatile and will not be reset by [AT&F](#).

"on" Causes the ME to enter the Airplane mode each time the ME is restarted or reset. After restart or reset, the URC "**^SYSSTART AIRPLANE MODE**" appears and parameter **<map>** is "on". The SIM PIN can be entered using the [AT+CPIN](#) command. This enables the ME to read data from the SIM and give access to SIM PIN dependent AT commands which are available in Airplane mode, such as phonebook commands or several SMS commands. To notify the user when SIM data are accessible it is recommended to activate the "**^ASSIM READY**" URC and store its presentation mode to the user profile with [AT&W](#). To return from Airplane mode to Normal mode set the parameter **<map>** to "off" as described above. If PIN authentication was already done, the ME will try now to register to the GSM network.

"off^(P) Airplane mode will not be activated after ME restart or reset.

<psm9to>(^{str})^{+cscs}

Power saving mode 9 timeout

This parameter can be used to query or configure the wake up time for power saving mode 9 (see [AT+CFUN](#) with parameter <fun>=9). The granularity of the timeout value is 100ms (i.e. a value of 10 equal 1 second). The minimum timeout value that can be applied is 5, but accuracy is only guaranteed for timeout values greater than 20. Parameter is global for the ME, volatile and will not be reset by [AT&F](#).

5...20^(P)...36000

<rba>(^{str})^{+cscs}

Allowed radio band(s)

The parameters **<rba>**, **<rbp>** and **<rbc>** allow the subscriber to set and query preferences for selecting frequency bands.

Before changing **<rba>** or **<rbp>** ensure that no network activity occurs. The write command cannot be executed when making a call, or sending / receiving short messages.

Execution of the write command causes the ME to deregister from and re-register to the network, no matter whether the selected **<rbp>** or **<rba>** setting really changes. Therefore, it is useful to have the URC "+CREG" enabled.

The status of the SIM PIN authentication remains unchanged, eliminating the need to enter the SIM PIN again after the change.

The parameter **<rba>** determines the maximum range of the bands allowed. The value may be one of the single bands listed below or all valid combinations from the values 1, 2, 4 and 8. Thus, the value range of **<rba>** is "1".."15". To select or deselect a band calculate the sum of the values of all desired bands and enter the resulting value. For example, for 1800 MHz (2) and 850 MHz (8) please enter the value (10). Parameter **<rba>** is global for the ME, non-volatile and will not be reset by [AT&F](#).

"1"	GSM 900 MHz
"2"	GSM 1800 MHz
"4"	GSM 1900 MHz
"8"	GSM 850 MHz
"3"	GSM 900 MHz + GSM 1800 MHz
"5"	GSM 900 MHz + GSM 1900 MHz
"10"	GSM 850 MHz + GSM 1800 MHz
"12"	GSM 850 MHz + GSM 1900 MHz
"15"	all bands

<rbp>(^{str})

Preferred radio band(s)

The parameter **<rbp>** may be one of the single bands or one of the four dualband combinations listed below. All preferred bands must be contained in the range of allowed bands (see **<rba>**), invalid combinations are not accepted. To give priority to a certain single band or band combination and suppress all others simply select the same value both for **<rbp>** and **<rba>**. **<rbp>** primarily serves to trigger the network search, i.e. it is only used one time for searching and selecting a

network. As the currently used band depends on the availability of the allowed networks the value indicated by `<rbc>` may be different from `<rbp>`. Also, next time a network search is necessary, for example after restart, the ME will first try to reselect the network last used, which may be different from the value of `<rbp>` last given. Therefore, the setting of `<rbp>` will not be saved. The value range of `<rbp>` is "1 ...12", but only the bands or band selections listed below are allowed. Trying to set an unsupported value will be denied with "ERROR". To select or deselect a band calculate the sum of the values of all desired bands and enter the resulting value. For example, for GSM 1800 MHz (2) and GSM 850 MHz (8) please enter the value (10).

"1"	GSM 900 MHz
"2"	GSM 1800 MHz
"4"	GSM 1900 MHz
"8"	GSM 850 MHz
"3"	GSM 900 MHz + GSM 1800 MHz
"5"	GSM 900 MHz + GSM 1900 MHz
"10"	GSM 850 MHz + GSM 1800 MHz
"12"	GSM 850 MHz + GSM 1900 MHz

`<rbc>(str)(+CSCS)`

Currently selected radio band(s)

The band(s) indicated with `<rbc>` are all allowed bands found at a location area. This means, if prompted to select a network the ME will search for these networks only. The value can be either a single band or dualband combination.

`<rbc>` is only a response parameter returned either after sending the read command `AT^SCFG?` or writing `AT^scFG="Radio/Band"`.

In addition to `<rbc>` and to allow the subscriber to be notified whenever the selected band changes it is recommended to activate the "`+CIEV`" (see Section 3.3, `AT^SIND`).

"1"	GSM 900 MHz
"2"	GSM 1800 MHz
"4"	GSM 1900 MHz
"8"	GSM 850 MHz
"3"	GSM 900 MHz + GSM 1800 MHz
"5"	GSM 900 MHz + GSM 1900 MHz
"10"	GSM 850 MHz + GSM 1800 MHz
"12"	GSM 850 MHz + GSM 1900 MHz

`<ropr>(str)(+CSCS)`

Radio Output Power Reduction

According to 3GPP Rel99, output power reduction for multiple TX slots is a mandatory feature. The amount of power reduction is configurable up to 3.0dB for 2TX, 4.8dB for 3Tx to 6dB for 4TX. To optimize heat dissipation, power consumption and SAR values it is recommended to use full power reduction (value "3"). Parameter is global for all interfaces, volatile and will not be reset by `AT&F`.

"1" Medium Reduction at GMSK and 8PSK (0dB for 1TX and 2TX, 1.8dB for 3TX and 3dB reduction 4TX)

"2" Medium Reduction at GMSK (1TX 0dB, 2TX 3dB, 3TX 4.8dB and 4TX 6dB reduction) and Full Power at 8PSK (1TX and 2TX 0dB reduction)

"3"^(P) Maximal Reduction at GMSK and 8PSK (1TX 0dB, 2TX 3dB, 3TX 4.8dB and 4TX 6dB reduction)

<succ>^(str)(^{+cscs})

CIEV Call Status Indication

This parameter can be used to control the behaviour of URC "+CIEV: call". See also [AT+CIND](#), [AT+CMER](#) and

[Section 7.1, Call Status Information.](#)

Parameter is global for all interfaces and will not be reset by [AT&F](#).

"restricted"^(P) URC "+CIEV: call" will be issued only when a Call Status transition ends in state "active" or "unknown" (see [Section 7.1, Call Status Information](#)) for a call in the list of active calls.

"verbose" URC "+CIEV: call" will be issued when any state transition (including transitions beginning or ending in state "unknown") occurs in the list of active calls, or when a traffic channel is established.

<sucs>^(str)(^{+cscs})

SLCC Call Status Indication

This parameter can be used to control the behaviour of URC "[^ASLCC](#)".

See also [AT^ASLCC](#) and [Section 7.1, Call](#)

[Status Information.](#)

Parameter is global for all interfaces and will not be reset by [AT&F](#).

"restricted" URC "[^ASLCC](#)" will be issued only when a Call Status transition ends in state "active" or "unknown" (see [Section 7.1, Call Status Information](#)) for a call in the list of active calls

"verbose"^(P) URC "[^ASLCC](#)" will be issued when any state transition (including transitions beginning or ending in state "unknown") occurs in the list of active calls, or when a traffic channel is established.

<uri>(str)(^{+CSCS})

URC RING line

This parameter can be used to control the behaviour of the RING line to indicate URCs (both for idle interfaces and, if configured by the parameter "URC/Datamode/Ringline", if link is reserved) and, if configured, the indicator for incoming IP packets (see parameter "GPRS/RingOnIncomingData" ([<groid>](#))). Parameter is local for the interface, volatile and will not be reset by [AT&F](#).

"off" URC is not indicated by RING.

"local"^(P) URC will be indicated by an activated RING line of the interface on which the URC appears

"asc0" URC is indicated by an activated RING0 line.

<udri>^(str)(^{+cscs})

URC Datamode RING line

This parameter specifies whether RING or BREAK is used for the signaling of URCs when the TA-TE link is reserved (e.g. during circuit-switched data calls, fax connections, in GPRS data mode or during the execution of an AT command). Parameter is global for all interfaces, volatile and will not be reset by **AT&F**.

"off" ^(P)	URC will be indicated by BREAK
"on"	URC is indicated by an active RING line for a time which is configured by the parameter "URC/Ringline/ActiveTime" (<urat>). The RING line which will be used, can be configured by the parameter "URC/Ringline" (<uri>).

<urat>(^{str})^{+cscs}

URC RING line Active Time

This parameter can be used to control how long the RING line is activated to indicate URCs (both for idle interfaces and, if configured by the parameter "URC/Datamode/Ringline" (**<udri>**), if link is reserved) and, if configured by the parameter "GPRS/RingOnIncomingData", to indicate incoming GPRS IP data packets (**<groid>**). Parameter is global for all interfaces, volatile and will not be reset by **AT&F**.

"0"	RING line will be activated for a time between 4.6 and 9.2 ms.
"1"	RING line will be activated for about 100ms.
"2" ^(P)	RING line will be activated for about 1s.

Note

- Parameters "GPRS/ATS0/withAttach" (**<gs0aa>**) and "GPRS/RingOnIncomingData" (**<groid>**) are available only for modules supporting GPRS.

Example

Usage of "URC/Ringline" and "URC/Datamode/Ringline":

AT+CSCS="GSM"	Switch to GSM character set
OK	
AT^SCFG?	Query all parameters
^SCFG:"URC/Datamode/Ringline","off"	While the TA-TE link is reserved URCs will be indicated by BREAK.
^SCFG:"URC/Ringline","local"	URCs on this interface will be indicated by Ring line associated to the interface (e.g. RING0 for ASC0).
OK	
AT^SCFG="URC/Datamode/Ringline","on"	
^SCFG:"URC/Datamode/Ringline","on"	While the TA-TE link is reserved URCs will be indicated by an activated "local" Ring line.
OK	
AT^SCFG="URC/Ringline","asc0"	URCs on <i>this</i> interface will be indicated by an activated RING0 no matterwhetheror not the TA-TE link is reserved.
^SCFG:"URC/Ringline","asc0"	
OK	
AT^SCFG="URC/Datamode/Ringline","off"	
^SCFG:"URC/Datamode/Ringline","off"	URCs on <i>this</i> interface will be indicated by an activated RING0 if

OK	the TA-TE link is not reserved and by BREAK if the TA-TE link is reserved.
AT^SCFG="URC/Ringline" ^SCFG:"URC/Ringline","off"	Disable any Ring line indication for URCs on this interface.
OK	

1.15 AT^SM20 Set M20 compatibility mode

Syntax

Test Command AT^SM20=?	Response(s) OK
Read Command AT^SM20?	Response(s) ^SM20: <CallMode>,<CmgwMode> OK
Write Command AT^SM20 = <CallMode>[,<CmgwMode>]	Response(s) OK

Reference(s)	PIN	USB					
SIEMENS	○	●					

Command Description

The **AT^SM20** command selects different modes of responses returned upon execution of the commands **ATD** and SMS commands like e.g. **AT+CMGW**.

Parameter Description

<CallMode>^(num)

Call setup response mode

Applies only to voice calls.

- | | |
|---|--|
| 0 | Set compatibility to Siemens mobile phones.

ME will return "OK" immediately after attempting a call with the ATD command. In case of failure, additional call release indications, such as "NO DIAL TONE", "NO CARRIER", "BUSY" will follow. |
|---|--|

- | | |
|--------|--|
| 1 (&F) | Default call setup mode, compatible to M20.

ME will return "OK" in case of a successful connection, otherwise one of the call release indications "NO DIAL TONE", "NO CARRIER", "BUSY" are indicated. |
|--------|--|

<CmgwMode>^(num)

Response mode for sending and writing short messages

Applies to the SMS commands like e.g. **AT+CMGS** and **AT+CMGW** command.

- | | |
|--------|--|
| 0 | Set compatibility to Siemens mobile phones.

ME will return +CMS ERROR: <err> when writing or sending of short messages fails. |
| 1 (&F) | Default mode for sending and writing short messages.
ME will return "OK", no matter whether or not sms command was successfully executed. |

2 STATUS CONTROL COMMANDS

The AT commands described in this chapter allow the external application to obtain various status information from the SAMBA75.

2.1 AT+CMER Mobile Equipment Event Reporting

This command controls details of the "+CIEV" URC presentation related to AT+SIND and AT+CIND. If registered via these commands the URCs are sent whenever a value of the related indicator changes. In addition, AT+CMER controls "^SLCC" URCs related to AT+SLCC. For details refer to 6.1 , AT+SLCC and AT+SCFG, parameter <sucs>. After AT+CMER has been switched on, URCs for all registered indicators will be issued.

Syntax

Test Command AT+CMER=?	Response(s) +CMER: (list of supported <mode>s), (list of supported <keyp>s), (list of supported <disp>s), (list of supported <ind>s), (list of supported <bfr>s) OK
Read Command AT+CMER?	Response(s) + CMER: <mode>,<keyp>,<disp>,<ind>,<bfr> OK
Write Command AT+CMER=[<mode>[,<keyp>[,<disp>[,<ind>[,<bfr>[,<indDescr>[,<indValue>]]]]]]]	Response(s) OK ERROR +CME ERROR

Reference(s)	PIN	USB					
GSM 07.07	●	●					

Unsolicited Result Code

+CIEV: <indDescr>, <indValue>

A value of an indicator has changed.

Command Description

The read command returns the URC presentation mode <mode> and among others, the indicator event reporting status <ind>.

The write command enables and disables the presentation of "+CIEV: <indDescr>,<indValue>" URCs. <indDescr> refers to the name of a "+CIEV" indicator and <indValue> is the new value of this indicator. All registered indicator events will be issued to the TE.

Parameter Description

<mode>^(num)

- | | |
|-------|---|
| 0(&F) | Discard "+CIEV" and "^SLCC" URCs. |
| 1 | Discard "+CIEV" and "^SLCC" URCs when TA-TE link is reserved, e.g. in online data mode. Otherwise they are forwarded directly to the TE. |
| 2 | Buffer "+CIEV" and "^SLCC" URCs in the TA while TA-TE link is reserved, e.g. in online data mode, and flush them to the TE afterwards. Otherwise they are forwarded directly to the TE. |
| 3 | Forward "+CIEV" and "^SLCC" URCs directly to the TE. If SAMBA75 is in online data mode, URCs are signaled via sending BREAK (100 ms) and stored in a buffer. Once it is |

		back in command mode e.g. after +++ was entered, all URCs stored in the buffer will be output.
<keyp> ^(num)	0(&F)	Keypad event reporting is not supported by SAMBA75.
<disp> ^(num)	0(&F)	Display event reporting is not supported by SAMBA75.
<ind> ^(num)	0(&F)	Disable indicator event reporting.
	2	Enable indicator event reporting.
<bfr> ^(num)	0(&F)	TA buffer of URCs defined within this command is cleared when <MODE> 1..3 is entered.
<indDescr> ^(str)		Name of indicator; for a list of all supported indicators please refer to AT+CIND and AT+SIND .
<indValue> ^(num)		Value of indicator; for a list of all values for the supported indicators please refer to AT+CIND and AT+SIND .

2.2 AT+CIND Indicator control

This command controls information about status changes via URC presentation of the SAMBA75 or connected items, e.g. battery charge level, signal quality, service availability, sound generation, indication of unread short messages, full SMS storage, call in progress or roaming activities. Use of this command is outdated since additional indications and functionality are available with **AT+SIND**.

AT+CIND supports two ways to get the values related to indicators:

- Query the current status of each indicator by using the read command **AT+CIND?**. It returns the status no matter whether the indicator has been registered with the write command **AT+CIND=[<state>[,<state>[,...]]]**.
- Evaluate one of the "**+CIEV**" URCs which the ME automatically sends to the application, whenever the value of the associated indicator changes.

The presentation of these URCs depends on two settings:

- The indicators must be registered with the write command **AT+CIND=[<state>[,<state>[,...]]]**. By default, all of them are registered when the ME is switched on. Any URC can be excluded if deregistered with **<state>=0**.
- URC presentation must be enabled with **AT+CMER**.

Syntax

Test Command AT+CIND=?	Response(s) + CIND: (<indDescr>, list of supported <indValue>s)[, (<indDescr>, list of supported <indValue>s)[,...]] OK
Read Command AT+CIND?	Response(s) + CIND: <indValue>[,<indValue>[,...]] OK ERROR +CME ERROR: <err>
Write Command AT+CIND=<state>[,<state>[,...]]	Response(s) OK ERROR +CME ERROR: <err>

Reference(s)	PIN	USB					
GSM 07.07	○	●					

Command Description

The read command returns the status of the ME indicators.

The write command is used to switch the event report for each indicator type. The Indicator Event Reports are displayed to the TE via "[+CIEV](#)" which can be enabled using [AT+CMER](#).

Parameter Description

[**<indValue>**](#)^(num)

Integer type value, which shall be in range of corresponding [**<indDescr>**](#)

[**<indDescr>**](#)^(str)

String values and their [**<indValue>**](#) ranges. More indications are available via [AT&SIND](#). Therefore use of [AT&SIND](#) for control of all indications is recommended. The following indications are accessible via [AT+CIND](#):

"battchg" Battery charge level 0..4 or 5 if no measuring is performed, because no battery is connected.

"signal" Signal quality (0..7) or (99) if not measurable. The indicated value is the bit error rate of the signal received. If there are bit errors this is not a constant but a estimated value which will change in time. See also [AT+CSQ](#).

"service" Service availability (0-1)

0: Not registered to any network

1: Registered to home network or, if "roam"=1 then registered to another network

"sounder" Sounder activity (0-1). The indicator provides information about tones generated in the ME. Value 1 means for example:

Incoming call - ME is ringing. Note that the URC "[+CIEV](#)": "sounder" indicator will be output only if ringing tones are activated with [AT&RTC](#).

Waiting call - ME generates waiting call tone (if call waiting is enabled).

Outgoing call - ME generates Call Progress tone. Outgoing call - ME generates BUSY tone.

The value changes to 0 if tone stops

"message" Unread short message at memory location [**<mem1>**](#) (0-1); refer to [AT+CPMS](#)

"call" Call in progress (0-1). Indicator value is "1" if at least one call is in state "active" or "held". Depending on the value of [AT&SCFG](#) setting (refer parameter [**<succ>**](#)), indicator "call" will be issued

- when a state transition ends in state "active" or in state "unknown", if [AT&SCFG](#) setting [**<succo="restricted">**](#),
- when any state transition (including transitions beginning or ending in state "unknown") occurs in the list of active calls or when a traffic channel is established, if [AT&SCFG](#) setting [**<succo="verbose">**](#). Also refer [6.1](#).

"roam" Roaming indicator (0-1)

	0:	Registered to home network or not registered
	1:	Registered to other network
"smsfull"		A short message memory storage in the MT has become full (1) or memory locations are available (0), i.e. range is (0-1)
"rssI"		Received signal (field) strength (0..5) or (99) if not measurable.
	0:	signal strength <= -112 dbm 1-4: signal strength in 15 dbm steps
	5:	signal strength >= -51 dbm
		Received signal (field) strength can also be obtained with AT+CSQ . However, the signal strength is scaled to value range 0..31 by this command.

<state>^(num)

Indicator is deregistered. The indicator will not be presented as "**+CIEV**" URC, but can be queried with **AT+CIND?**.

[1]^(P) Indicator is registered, indicator event report allowed.

Notes

- Due to its restrictive range of values, there are events when it is not entirely clear from the context, which event has led to the output of indicator "call". Rather than as an information in itself, indicator "call" should therefore be used as a trigger to look up the new call status in the list of current calls with AT commands **AT\SLCC**, **AT+CLCC** or **AT\SCNI**.
- If **AT\SCFG** setting **<suco="verbose">**, indicator "call" will be issued also when a traffic channel is established, or when a call enters states "terminating" or "dropped" (see chapter [6.1](#)). In these cases, the relevant information about the cause of the display is available only from AT command **AT\SLCC**.
- The indicator "sounder" signals every event a tone is generated in the ME. For instance, if a waiting call produces a tone, this will be indicated.
- If the ME is switched on all indicators are in registered state.
- Use **AT+CMER** command to allow Indicator Event Report of all registered indicators.

Example

```

^SYSSTART
AT+CPIN=9999
OK
AT+CIND?
+CIND: 5,99,1,0,0,0,0,0
The battery is either full or no battery is
connected to the ME. The bit error rate of the
signal quality is not available (since there is no
call in progress). The ME is registered to its home
network.

OK
AT+CMER=2,0,0,2
Now activate the Indicator Event Report with
AT+CMER.

OK
+CIEV: battchg,5
+CIEV: signal,99
+CIEV: service,1

```

+CIEV: sounder,0	
+CIEV: message,0	
+CIEV: call,0	
+CIEV: roam,0	
+CIEV: smsfull,0	
+CIEV: rssi,5	Receive with full signal field strength.
ATD0123456;	Make a call.
OK	
+CIEV: sounder,1	Receive a set of "+CIEV" URCs reports.
+CIEV: call,1	
+CIEV: sounder,0	
+CIEV: call,0	The receiver hangs up.
NO CARRIER	
AT+CIND=,,,0,,0	Deregister the indicators "call" and "sounder".
OK	
ATD0123456;	Rebuild the same call.
OK	
NO CARRIER	This time, no URCs are displayed.

2.3 AT^SIND Extended Indicator Control

AT^SIND supplies extended event indicator control and

- offers greater flexibility than standard **AT+CIND**,
- offers several extra indicators,
- can show the current status of all indicators supported by **AT+CIND** and **AT^SIND**,
- gives the possibility to register or deregister the indicators of both commands,
- displays all indicator event reports via "+CIEV" URCs.

Presentation mode of the generated URCs is controlled via **AT+CMER**.

Syntax

Test Command AT^SIND=?	Response(s) ^SIND: (<indDescr>, list of supported <indValue>s)[, (<indDescr>, list of supported <indValue>s)[, ...]], (list of supported <Mode>s) OK
Read Command AT^SIND?	Response(s) ^SIND: <indDescr>,<Mode>,<indValue> OK ERROR +CME ERROR: <err>
Write Command AT^SIND=<indDescr>,<Mode>	Response(s) OK ERROR +CME ERROR: <err>

Reference(s)	PIN	USB					
SIEMENS	○	●					

Command Description

The read command provides a list of all indicators supported by **AT+CIND** and **AT+SIND**. Each indicator is represented with its registration mode and current value.

The write command can be used to select a single indicator in order to modify its registration and to view the current value.

Parameter Description

<indValue>^(num)

Integer type value in the range stated below for the corresponding **<indDescr>**.

<indDescr>^(str)

String values and their **<indValue>** ranges.

All indicators supported by **AT+CIND** are accessible with this command, too. A detailed description of these indicators can be found there. The following indicators are accessible via **AT+SIND** only:

"audio" Activity of the internal audio unit (0-1). Value 1 means for example: Outgoing voice call: Indicator appears when dialing starts. Incoming voice call: Indicator appears prior to the RING result code.

"vmwait1" Voice message waiting indication for line 1, (0-1)

"vmwait2" Voice message waiting indication for line 2, (0-1)

"ciphcall" Ciphering Status Change Indication

As stated in GSM specifications 02.07 and 02.09 the ciphering indicator feature allows the ME to detect that ciphering is not switched on and to indicate this to the user.

The ciphering indicator feature may be disabled by the home network operator setting data in the "administrative data" field (**EF_{AD}**) in the SIM, as defined in GSM 11.11.

If this feature is not disabled by the SIM, then whenever a connection is in place, which is, or becomes unenciphered, an indication shall be given to the user. This enables the user's decision how to proceed. Read command returns valid ciphering status only if a call is in progress or active.

If **EF_{AD}** setting disables the ciphering indicator feature read command always indicates a ciphered link and no URC presentation will take place.

Note: The following restrictions apply if the same serial channel is used for **AT+SIND** "ciphcall" indication and for the action triggering this URC. In general, the recommended solution is to use a dedicated channel for all status signalling via URCs.

- If an unciphered mobile originated SMS is performed, **AT+SIND** "ciphcall" URCs on the same serial channel will be issued after the related "OK" and indicate the ciphering state at *this* time. Because the SMS is already sent at this time, you will get 2 URCs on this channel, but both are indicating that ciphering is enabled.

- If an unciphered mobile originated data call is performed, [AT&SIND](#) "ciph call" URCs on the same serial channel will be issued after the interface is not longer blocked by the call (call is released or temporarily stopped) and indicate the ciphering state at this time.

0 Current call or SMS is not ciphered.

1 Current call or SMS is ciphered.

<Mode>^(num)

- | | |
|---|---|
| 0 | Indicator is deregistered, i.e. no such indicator event report (URC) will be issued. |
| 1 | <p>Indicator is registered.</p> <ul style="list-style-type: none"> - Indicator event reports are controlled via AT+CMER. - Indicators defined by AT&SIND remain deregistered until explicitly enabled. - On the other hand indicators supported by AT+CIND are registered while the SAMBA75 is powered up. |
| 2 | Query the registration status and the current value of a single indicator type. |

Note

- Notes regarding indicator voice message waiting:
 - "vmwaitT" and "vmwait2" indicate the receipt of a short message coded as Voice Message Waiting Indicator, as defined by the CPHS Phase 2 standard. The service must be provisioned by the operator.
 - The presentation mode of the indicators varies with the operator: If more than one message is received, some operators only indicate the first one, others deliver the indicator each time a new message is put into the mail-box.
 - The "vmwait" indicators do not apply if a network provider signals, via standard SMS, a message in the voice mailbox. In this case, the indicator "message" will be displayed (see [AT+CIND](#)).
 - The numbers 1 or 2 in "vmwait1/2" are related to the two lines of the Alternate Line Service (ALS), also defined in CPHS Phase 2 standard. For further details refer to the [AT&SALS](#) command.

2.4 AT+CEER Extended error report

Syntax

Test Command AT+CEER=?	Response(s) OK
Exec Command AT+CEER	Response(s) + CEER: <locationID>,<reason>,<ssRelease> OK

Reference(s)	PIN	USB					
GSM 07.07	●	●					

Command Description

TA returns an extended error report of the reason for the last

- call release
- failure to set up a call (both mobile originated or terminated)
- failure to modify a call by using Supplementary Services
- failed attempt to activate, register, query, deactivate or deregister a Supplementary Service
- unsuccessful GPRS attach or unsuccessful PDP context activation
- GPRS detach or PDP context deactivation.

The release cause report is presented in numeric format. A description associated with each number can be found in the tables given in the following subclauses. The first parameter **<locationID>** serves to locate the other two parameters. Depending on the failure or release cause either **<reason>** or **<ssRelease>** are applicable.

Parameter Description

<locationID>^(num)

Location ID as number code. Location IDs are listed in subclause 2.4.1. Each ID is related with another table that contains a list of **<reason>s** or **<ssRelease>s**.

<reason>^(num)

Reason for last call release as number code. The number codes are listed in several tables, sorted by different categories in the following subclauses. The tables can be found proceeding from the Location ID given in sub-clause 2.4.1.

<ssRelease>^(num)

Release cause for last Supplementary Service call (listed in subclause 2.4.5) or last call related use of a Supplementary Service.

Notes

-

- AT+CEER is not available for data calls, please use **AT\$IS=1**.
- Default output in the case of a no-error-situation is +CEER: 0,0,0.
 - If **<reason>** ^ 0, then **<ssRelease>** = 0. Vice versa, if **<reason>** = 0, then **<ssRelease>** may be ^ 0.

Examples

EXAMPLE 1

ATD"01751223344";	A mobile originated call is rejected by the remote party.
NO CARRIER	Call set-up is terminated with NO CARRIER.
AT+CEER	To check the cause, the caller enters AT+CEER.
+CEER: 8,21,0	The Location ID 8 stated in subclause 2.4.1 points to subclause 2.4.4 , where 21 = "Call rejected". 0 = No error (parameter <ssRelease> is not applicable).
OK	

EXAMPLE 2

The user attempts to set up a multiparty call, though there are only two parties involved in the present conversation:

ATD"01751223344";	
OK	
AT+CHLD=2	
OK	
AT+CHLD=3	
+CME ERROR:	operation temporary not allowed
AT+CEER	
+CEER: 22, 0,2	The Location ID 22 stated in subclause 2.4.1 , where 2 = "Initial conditions not fulfilled (one active, one held call)".
OK	0 = No error (parameter <reason> is not applicable).

EXAMPLE 3

The user attempts to activate call barring. Activation is denied by the network since the password is blocked after previous failures to enter the password.

AT + clck=oi,1,"0 000",3;	
+CME ERROR:	incorrect password
AT+CEER	
+CEER: 3 5, 0,43	The Location ID 35 stated in subclause 2.4.1 , where 43 = "NumberOfPWAttemptsViolation" (for example if wrong password has been entered 3 times or more). 0 = No error (parameter <reason> is not applicable).
OK	

2.4.1 Cause Location ID for the extended error report

ID	Description
0	No error (default)

1	SIEMENS L2 cause
2	GSM cause for L3 Radio Resource Sublayer (GSM 04.08 annex F)
3	SIEMENS cause for L3 Radio Resource Sublayer
4	GSM cause for L3 Mobility Management (GSM 04.08 annex G)
5	SIEMENS cause for L3 Mobility Management
6	GSM cause for L3 Mobility Management via MMR-SAP (GSM 04.08 annex G)
7	SIEMENS cause for L3 Mobility Management via MMR-SAP
8	GSM cause for L3 Call Control (GSM 04.08 10.5.4.11 and annex H)
9	SIEMENS cause for L3 Call Control
11	SIEMENS cause for L3 Advice of Charge Entity
12	GSM cause for L3 SMS CP Entity
13	SIEMENS cause for L3 SMS CP Entity
14	GSM cause for L3 SMS RL Entity
15	SIEMENS cause for L3 SMS RL Entity
16	GSM cause for L3 SMS TL Entity
17	SIEMENS cause for L3 SMS TL Entity
18	SIEMENS cause for DSM Entity
21	GSM cause for L3 Call-related Supplementary Services
22	SIEMENS cause for L3 Call-related Supplementary Services
32	SIEMENS cause for Supplementary Services Entity
33	SIEMENS cause for Supplementary Services Manager
34	Network cause for Supplementary Services (GSM 04.08 10.5.4.11 and annex H)
35	Supplementary Services network error (GSM 04.80 3.6.6)
48	GSM cause for GPRS Mobility Management (GSM 04.08 annex G.6)
49	SIEMENS cause for GPRS Mobility Management
50	GSM cause for Session Management (GSM 04.08 annex I)
51	SIEMENS cause for Session Management
127	SIEMENS cause for protocol module or other local cause
128	Supplementary Services general problem (GSM 04.80 3.6.7)
129	Supplementary Services invoke problem (GSM 04.80 3.6.7)
130	Supplementary Services result problem (GSM 04.80 3.6.7)
131	Supplementary Services error problem (GSM 04.80 3.6.7)
241	SIEMENS cause for GPRS API
242	SIEMENS cause for Link Management
243	SIEMENS cause for Embedded Netcore (Internet Protocol Stack)

2.4.2 GSM release cause for L3 Radio Resource (RR)

Number	Description
0	Normalevent
1	Abnormal release, unspecified
2	Abnormal release, channel unacceptable
3	Abnormal release, timer expired
4	Abnormal release, no activity on the radio path
5	Pre-emptive release
8	Handover impossible, timing advance out of range
9	Channel mode unacceptable
10	Frequency not implemented
65	Call already cleared
95	Semantically incorrect message
96	Invalid mandatory information
97	Message type non-existent or not implemented
98	Message type not compatible with protocol state
100	Conditional information element error
101	No cell allocation available
111	Protocol error unspecified

2.4.3 GSM release cause for Mobility Management (MM)

Number	Description
Causes related to MS identification	

2	IMSI unknown in HLR
3	Illegal MS
4	IMSI unknown in VLR
5	IMEI not accepted
6	Illegal ME
Cause related to subscription options	
11	PLMN not allowed
12	Location Area not allowed
13	Roaming not allowed in this location area
Causes related to PLMN specific network failures and congestion	
17	Network failure
22	Congestion
Causes related to nature of request	
32	Service option not supported
33	Requested service option not subscribed
34	Service option temporarily out of order
38	Call cannot be identified
Causes related to invalid messages	
95	Semantically incorrect message
96	Invalid mandatory information
97	Message type non-existent or not implemented
98	Message not compatible with protocol state
99	Information element non-existent or not implemented
100	Conditional information element error
101	Messages not compatible with protocol state
111	Protocol error, unspecified
Causes related to GPRS	
7	GPRS services not allowed
8	GPRS services not allowed in combination with non-GPRS services
9	MS identity cannot be identified by the network
10	Implicitly detached
14	GPRS services not allowed in current PLMN
16	MSC temporarily unreachable

2.4.4 GSM release cause for L3 Call Control (CC)

Number	Description
0	No error
Normal class	
1	Unassigned (unallocated) number
3	No route to destination
6	Channel unacceptable
8	Operator determined barring
16	Normal call clearing
17	User busy
18	No user responding
19	User alerting, no answer
21	Call rejected
22	Number changed
25	Pre-emption
26	Non-selected user clearing
27	Destination out of order
28	Invalid number format (incomplete number)
29	Facility rejected
30	Response to STATUS ENQUIRY
31	Normal, unspecified
Resource unavailable class	
34	No circuit/channel available
38	Network out of order
41	Temporary failure

42	Switching equipment congestion
43	Access information discarded
44	Requested circuit/channel not available
47	Resource unavailable, unspecified
Service or option not available class	
49	Quality of service unavailable
50	Requested facility not subscribed
55	Incoming calls barred within the CUG
57	Bearer capability not authorized
58	Bearer capability not presently available
63	Service or option not available, unspecified
Service or option not implemented	
65	Bearer service not implemented
68	ACM equal or greater than ACMmax
69	Requested facility not implemented
70	Only restricted digital information bearer capability is available
79	Service or option not implemented, unspecified
Invalid message (e.g. parameter out of range) class	
81	Invalid transaction identifier value
87	User not member of CUG
88	Incompatible destination
91	Invalid transit network selection
95	Semantically incorrect message
Protocol error (e.g. unknown message) class	
96	Invalid mandatory information
97	Message type non-existent or not implemented
98	Message type not compatible with protocol state
99	Information element non-existent or not implemented
100	Conditional information element error
101	Message not compatible with protocol
102	Recovery on timer expiry
111	Protocol error, unspecified
Interworking class	
127	Interworking, unspecified

2.4.5 GSM Release cause for Supplementary Service Call

Number	Description
0	No error (default)
1	UnknownSubscriber
9	IllegalSubscriber
10	BearerServiceNotProvisioned
11	TeleserviceNotProvisioned
12	NlegalEquipment
13	CallBarred
15	CUGReject
16	IllegalSSOperation
17	SSErrorStatus
18	SSNotAvailable
19	SSSubscriptionViolation
20	SSIcompatibility
21	FacilityNotSupported
27	AbsentSubscriber
29	ShortTermDenial
30	LongTermDenial
34	SystemFailure
35	DataMissing
36	UnexpectedData Value
37	PWRegistrationFailure
38	NegativePWCheck
43	NumberOfPWAtemptsViolation

71	UnknownAlphabet
72	USSDBusy
126	MaxNumsOfMPTYCallsExceeded
127	ResourcesNotAvailable
General Problem Codes	
300	Unrecognized Component
301	Mistyped Component
302	Badly Structured Component
Invoke Problem Codes	
303	Duplicate Invoke ID
304	Unrecognized Operation
305	Mistyped Parameter
306	Resource Limitation
307	Initiating Release
308	Unrecognized Linked ID
309	Linked Response Unexpected
310	Unexpected Linked Operation
Return Result Problem Codes	
311	Unrecognize Invoke ID
312	Return Result Unexpected
313	Mistyped Parameter
Return Error Problem Codes	
314	Unrecognized Invoke ID
315	Return Error Unexpected
316	Unrecognized Error
317	Unexpected Error
318	Mistyped Parameter

2.4.6 GSM cause for L3 Protocol module or other local cause

Number	Description
2	No detailed cause

2.4.7 SIEMENS release cause for GPRS API

Number	Description
0	Regular deactivation of the call
1	Action temporarily not allowed
2	Wrong connection type
3	Specified data service profile invalid
4	PDP type or address is unknown
5	FDN Check was not successful; GPRS Attach and PDP Context Activation blocked
255	Undefined

2.4.8 SIEMENS release cause for PPP/IP-Stack

Number	Description
0	Regular call deactivation
1	LCP stopped
255	Undefined

2.5 ATS18 Extended call release report

Syntax

Read Command ATS18?	Response(s) <code><n></code> OK
Write Command ATS18=<n>	Response(s) OK

Reference(s)	PIN	USB					
V.25ter	○	●					

Command Description

This command enables or disables the presentation of extended call release reports for fax and data calls. The call release report is presented in numeric format and includes the following parameters:

+CAUSE: <locationID>,<reason>

If enabled the message will be reported every time a fax or data call is released or fails to be established.

Parameter Description

`<n>`^(num)&W&V)

An odd number enables the presentation of the extended call release report. An even number disables this feature.

0(&F)...255

`<locationID>`^(num)

Location ID as number code (see also `<locationID>` of AT+CEER). Location IDs are listed in section 2.4.1. Each ID is related to another table that contains a list of `<reason>`s.

`<reason>`^(num)

Reason for last call release as number code (see also `<reason>` of AT+CEER. `<reason>` numbers and the associated descriptions are listed in several tables, sorted by different categories in chapter AT+CEER. The tables can be found proceeding from the Location IDs listed in 2.4.1.

Note

- The command applies only to circuit switched data and fax calls. For voice calls extended call release reports can be retrieved using the command AT+CEER.

Examples

EXAMPLE 1

`ATS18=1`

Enables the presentation of extended call release reports.

OK

ATD03012345678	Now, a mobile originated data call fails.
+CAUSE: 8:17	An extended error report is output, followed by the result code BUSY.
BUSY	The Location ID 8 stated in section 2.4.1 points to section 2.4.4 , where 17 = "User busy".

EXAMPLE 2

ATS18=1	Enables the presentation of extended call release reports.
OK	
ATD03012345678	Now, a mobile originated data call is set up.
CONNECT 9600/RLP	
Hello,....	
+++	Call ends after remote party hung up.
+CAUSE: 8:16	Normal call release is reported, followed by the result code NO CARRIER.
NO CARRIER	The Location ID 8 stated in section 2.4.1 points to section 2.4.4 , where 16 = "Normal call clearing".

2.6 AT+CPAS Mobile equipment activity status

Syntax

Test Command AT+CPAS=?	Response(s) +CPAS: (list of supported<pas>s) OK
Exec Command AT+CPAS	Response(s) +CPAS: <pas> OK ERROR +CME ERROR: <err>

Reference(s)	PIN	USB					
GSM 07.07	○	●					

Command Description

TA returns the activity status of ME.

Parameter Description

<pas>^(num)

- 0 ready
- 3 incoming call (ringing)
- 4 call in progress or call hold

2.7 AT+WS46 Select wireless network

Syntax

Test Command AT+WS46=?	Response(s) +WS46: (list of supported<n>s) OK
---------------------------	---

Read Command AT+WS46?	Response(s) <n> OK
Write Command AT+WS46 = [<n>]	Response(s) OK

Reference(s)	PIN	USB					
GSM 07.07	○	●					

Parameter Description<n>^(num)

12 GSM digital cellular

3 SERIAL INTERFACE CONTROL COMMANDS

The AT commands described in this chapter allow the external application to determine various settings related to the SAMBA75's serial interface.

3.1 AT\Q Flowcontrol

Syntax

Exec Command AT\Q[<n>]	Response(s) OK If RTS/CTS flow control is not supported by interface and <n> is 2 or 3: ERROR
---------------------------	--

Reference(s)	PIN	USB					
V.25ter	○	●					

Parameter Description

<n>^(num)&W&V)

- | | |
|-------|---|
| [0]&F | disable flow control |
| 1 | XON/XOFF software flow control |
| 2 | only CTS by DCE |
| 3 | RTS/CTS hardware flow control Recommended for the following procedures: incoming or outgoing data calls, fax calls.

Often, the initialization routine of fax programs includes enabling RTS/CTS handshake, eliminating the need to issue AT\Q3 once again. |

Notes

- When using XON/XOFF flow control (AT\Q1) in online mode, +++ should not be used while the data transmission is paused with XOFF. Before entering the command mode with +++ the paused transmission should be resumed using the XON character.

3.2 AT&C Set circuit Data Carrier Detect (DCD) function mode

Syntax

Exec Command AT&C<value>	Response(s) OK
-----------------------------	-------------------

Reference(s)	PIN	USB					
V.25ter	○	●					

Command Description

This parameter determines how the state of circuit 109 (DCD) relates to the detection of received line signal from the distant end.

Parameter Description

<value>^(num)&W&V)

- [0] DCD line is always ON
- 1^(&F) DCD line is ON in the presence of data carrier only

3.3 AT&D Set circuit Data Terminal Ready (DTR) function mode

Syntax

Exec Command AT&D[<value>]	Response(s) OK
-------------------------------	-------------------

Reference(s)	PIN	USB					
V.25ter	○	●					

Command Description

This parameter determines how the TA responds when circuit 108/2 (DTR) is changed from ON to OFF during data mode.

Parameter Description

<value>^{(num)(&W)(&V)}

- [0] TA ignores status of DTR.
- 1 ON->OFF on DTR: Change to command mode while retaining the connected call.
- 2^(&F) ON->OFF on DTR: Disconnect data call, change to command mode. During state DTR = OFF is auto-answer off.

3.4 AT&S Set circuit Data Set Ready (DSR) function mode

Syntax

Exec Command AT&S[<value>]	Response(s) OK
-------------------------------	-------------------

Reference(s)	PIN	USB					
V.25ter	○	●					

Command Description

This parameter determines how the TA sets circuit 107 (DSR) depending on the communication state of the TA interfacing TE.

Parameter Description

<value>^{(num)(&W)(&V)}

- [0]^(&F) DSR line is always ON
- 1 TA in command mode: DSR is OFF. TA in data mode: DSR is ON.

3.5 ATE Enable command echo

Syntax

Exec Command ATE[<value>]	Response(s) OK
------------------------------	-------------------

Reference(s)	PIN	USB					
V.25ter	○	●					

Command Description

This setting determines whether or not the TA echoes characters received from TE during command state.

Parameter Description

<value>^{(num)(&W)(&V)}

- [0] Echo mode off
- [1 (&F)] Echo mode on

Note

- In case of using the command without parameter, <value> is set to 0.

3.6 AT+ICF Serial Interface Character Framing

The command **AT+ICF** controls the serial interface character framing format and parity used for receiving and transmitting.

The following settings are supported:

- 7 bits, even parity, 1 stop bit (**AT+ICF=5,1**)
- 7 bits, odd parity, 1 stop bit (**AT+ICF=5,0**)
- 8 bits, even parity, 1 stop bit (**AT+ICF=2,1**)
- 8 bits, no parity, 1 stop bit (**AT+ICF=3**)
- 8 bits, odd parity, 1 stop bit (**AT+ICF=2,0**)
- 8 bits, no parity, 2 stop bits (**AT+ICF=1**)

Syntax

Test Command AT+ICF=?	Response(s) + ICF: (list of supported <format>s), (list of supported <parity>s) OK
Read Command AT+ ICF?	Response(s) + ICF <format>[, <parity>] OK
Write Command AT+ ICF =[<format>][, <parity>]	Response(s) OK ERROR +CME ERROR

Reference(s)	PIN	USB					
V.25ter	○	●					

Parameter Description

<format>^{(num)(&W)(&V)}

Specifies the character format used for receiving and transmitting.

- 1 8 data, 0 parity, 2 stop
- 2 8 data, 1 parity, 1 stop
- [3] 8 data, 0 parity, 1 stop
- 5 7 data, 1 parity, 1 stop

<parity>^{(num)(&W)(&V)}

Specifies the method of calculating the parity bit, if a parity bit is supported by **<format>**.

If **<format>** does not support parity, this parameter has to be omitted.

0	odd
1	even

Notes

If **AT+ICF** modes 7E1 or 7O1 are set, the parity bit will by default not be transmitted over the air. If the remote party expects the parity bit to be transmitted, additional settings are required via **AT^STPB**.

When using a bit rate of 300 bps there must be a delay of 500ms before entering the next command. At bit rates of 1200 bps the delay must be 300ms. For higher bit rates use of the default delay is sufficient.

SAMBA75's autobaud feature detects the bit rate currently used by the TE. However, this detection suffers some limitations described in Section 4.9.1, **Autobausing**. If autobauding is enabled, the **AT+ICF** read command does not show the current character framing, but the character framing that will be used when autobauding is disabled.

If a **<format>** is selected without parity (e.g. **<format>**=3) and you try to activate a format with parity (e.g. **<format>**=2), you need to explicitly set the parameter **<parity>** (e.g. **AT+ICF**=2,1). Otherwise you will get '+CME ERROR: invalid index'. This is because for **<format>**=3, the parameter **<parity>** is set to the internal value 'no parity' which is not supported by **<format>**=2. (Remember that if an optional parameter is omitted for which no default is stated in this specification, the value of the parameter remains unchanged).

3.7 AT+IFC Set Flow Control separately for data directions

The command **AT+IFC** can be used to set or query the data flow control separately for each data direction. In contrast to this, flow control settings made with **AT\Q** are valid in both data directions.

Syntax

Test Command AT+ICF=?	Response(s) + ICF: (list of supported <TEflowcontrol> s), (list of supported <TAflowcontrol> s) OK
Read Command AT+ ICF?	Response(s) + ICF <TEflowcontrol>[, <TAflowcontrol>] OK
Write Command AT+ ICF =[<TEflowcontrol>][, <Aflowcontrol>]	Response(s) OK ERROR +CME ERROR

Reference(s)	PIN	USB					
V.25ter	○	●					

Parameter Description

<TEflowcontrol>^{(num)(&W)}

Specifies the method used by the TE when receiving data from the TA.

- [0] none
- 1 XON/XOFF, terminate flow control in the Cellular Engine
- 2 RTS line
- 3 XON/XOFF, evaluate flow control in the Cellular Engine and pass it through (over the air) to the opposite TE

<TAflowcontrol>(num)&W

Specifies the method used by the TA when receiving data from the TE.

- [0] none
- 1 XON/XOFF
- 2 CTS line

Notes

When using XON/XOFF flow control ([AT+IFC=1,x](#) or [AT+IFC=3,x](#)) in data mode, **+++** should not be used while the data transmission is paused with XOFF. Before entering the command mode with **+++** the paused transmission should be resumed using the XON character.

3.8 AT+ILRR Set TE-TA local rate reporting

The command [AT+ILRR](#) controls whether or not the intermediate result code "[+ILRR](#)" is transmitted from the DCE to the DTE.

Syntax

Test Command AT+ILRR=?	Response(s) + ILRR: (list of supported <value>s) OK
Read Command AT+ILRR?	Response(s) +ILRR: <value> OK
Write Command AT+ILRR=<value>	Response(s) OK ERROR +CME ERROR

Reference(s)	PIN	USB					
V.25ter	○	●					

Intermediate Result Code

+ILRR: <rate>

Indicates port rate setting on connection.

Command Description

The write command determines whether or not an intermediate result code of local rate is reported at connection setup. The rate is reported before the final result code of the connection is transmitted to the TE.

Parameter Description

<value>(num)&W&V

- 0(&F) Disables reporting of local port rate
- 1 Enables reporting of local port rate

<rate>(num)

0	port rate setting on connection (bps) Autobauding (see chapter 3.9.1).
300	
600	
1200	
2400	
4800	
9600	
14400	
19200	
28800	
38400	
57600	
115200	
230400	
460800	

3.9 AT+IPR Set fixed local rate

The command [AT+IPR](#) can be used to set or query the DTE-DCE interface bit rate.

Syntax

Test Command AT+IPR=?	Response(s) +IPR: (list of supported auto-detectable <rate>s) , (list of supported fixed-only <rate>s) OK
Read Command AT+IPR?	Response(s) +IPR: <rate> OK
Write Command AT+IPR=<rate>	Response(s) OK ERROR +CME ERROR

Reference(s)	PIN	USB					
V.25ter	○	●					

Command Description

The test command returns the values of the supported automatically detectable bit rates and the values of the supported fixed bit rates.

The read command returns the current bit rate of the interface.

The write command specifies the bit rate to be used for the interface. When you set a fixed-rate, make sure that both DTE (TE) and DCE (TA) are configured to the same rate. When you select autobauding, the DCE will automatically recognize the bit rate currently used by the DTE.

The setting is stored in the non-volatile memory and will be used whenever the engine is powered up again. However, in case of autobaud mode ([AT+IPR=0](#)) the detected DCE bit rate will not be saved and, therefore, needs to be resynchronized after restarting the GSM engine (see chapter [3.9.1](#)).

Parameter Description

<rate>{num}{&V}

bit rate per second (bps)

- 0(D) Activate autobauding (see chapter [3.9.1](#)).
- 300
- 600
- 1200
- 2400
- 4800
- 9600
- 14400
- 19200
- 28800
- 38400
- 57600
- 115200
- 230400
- 460800

Notes

- The factory default is autobauding enabled ([AT+IPR=0](#)) on USB. It will not be restored with [AT&F](#).
- The current setting of [AT+IPR](#) will be preserved when you download firmware (i.e. a firmware update does not restore the factory setting) or in the event of power failure.
- Generally, [AT+IPR](#) should be used as a standalone command. If nevertheless combinations with other commands on the same command line cannot be avoided, there are several constraints to be considered:
 - Avoid combinations with the AT commands listed in chapter [0.4.2](#).
 - Take into account, that a delay of 100 ms is required between the response to the last command (e.g. OK) and the next command on the same line.
 - When you enter [AT+IPR=0](#), autobauding will be activated after the response to the last command is received.
 - When local echo is active ([ATE1](#)) and you enter [AT+IPR=x](#) with other commands you may encounter the following problem: if switching to the new bit rate takes effect while a response is being transmitted, the last bytes may be sent with the new bit rate and thus, not properly transmitted. The following commands will be correctly sent at the new bit rate.
- In order to account for greater amounts of data it is recommended to choose a minimum bit rate of 2400 bps.
- A selected bit rate takes effect after the write commands returns OK.

[3.9.1 Autobauding](#)

To take advantage of autobaud mode specific attention must be paid to the following requirements:

- Synchronization between DTE and DCE

Ensure that DTE and DCE are correctly synchronized and the bit rate used by the DTE is detected by the DCE (ME). To allow the bit rate to be synchronized simply use an "AT" or "at" string. This is necessary

- after you have activated autobauding
- when you start up the GSM engine while autobauding is enabled. It is recommended to wait 3 to 5 seconds before sending the first AT character. Otherwise undefined characters might be returned.

If you want to use autobauding and autoanswer at the same time, you can easily enable the DTE-DCE synchronization, when you activate autobauding first and then configure the autoanswer mode (**ATSO#0**).

- Restrictions on autobauding operation
 - The serial interface shall be used with 8 data bits, no parity and 1 stop bit (factory setting), e.g. 2 stop bits are not supported for autobaud mode.
 - The command **A/** cannot be used.
 - Only the strings "AT" or "at" can be detected (neither "At" nor "aT").
 - URCs that may be issued before the ME detects a new bit rate (by receiving the first AT character) will be sent at the previously detected bit rate or, after ME restart, at 57600 bps.
 - It is not recommended to switch to autobauding from a bit rate that cannot be detected by the the autobaud mechanism (e.g. 300 bps). Responses to **AT+IPR=0** and any commands on the same line might be corrupted.
- Autobauding and bit rate after restart

The most recently detected bit rate is stored when the ME is powered down (with [Table 2.3](#)). Therefore, each time the module is restarted the correct bit rate must be found as described above. Unless the bit rate is determined, the following constraints apply:

- An incoming CSD call or a network initiated GPRS request cannot be accepted. This must be taken into account when autobauding and autoanswer mode (**ATSO#0**) are enabled at the same time, especially if SIM PIN 1 authentication is done automatically and the setting **ATSO#0** is stored to the user profile with **AT&W**.
- Until the bit rate is found, URCs generated after restart will be output at 57600 bps. This applies only to user defined URCs, such as "+CREG", "CCWA", "^SCKS" etc. The URCs "^SYSSTART", "^SYSSTART ALARM MODE" and "^SYSSTART CHARGE-ONLY MODE" will not be indicated when autobauding is enabled.

Note: To avoid any problems caused by undetermined bit rates in the direction from DCE to DTE we strongly recommend to configure a fixed bit rate rather than autobauding.

3.10 AT^STPB Transmit Parity Bit (for 7E1 and 7O1 only)

This command is intended only for use with 7E1 and 7O1. In addition to the 7E1 or 7O1 settings made with **AT+ICF** the command **AT^STPB** specifies whether or not to transmit the parity bit over the air.

Syntax

Test Command	Response(s)
AT^STPB=?	^STPB: (list of supported <n>s) OK

Read Command AT^STPB?	Response(s) ^STPB: <n> OK
Write Command AT^STPB=<n>	Response(s) OK ERROR +CME ERROR

Reference(s)	PIN	USB					
V.25ter	○	●					

Command Description

The test command returns the supported values of the parameter <n>.

The read command returns the current value of the parameter <n>.

The write command can be used to control the handling of the parity bit. If command fails, "+CME ERROR: unknown" will be returned.

Parameter Description

<n>^{(num)&(W)}

0(&F) The parity bit will not be transmitted over the air and will be replaced with 0.

This mode is the default setting if 7E1 or 7O1 is activated with **AT+ICF**.

1 In a data connection 8 bits will be transmitted, including the parity bit, i.e. the parity bit will be properly transmitted over the air. The setting shall be used if problems are encountered when SAMBA75 is running in the default 7E1 or 7O1 mode enabled with **AT+ICF**. In this case, **AT^STPB=1** shall be set in addition to the 7E1 or 7O1 settings selected with **AT+ICF**.

4 SECURITY COMMANDS

The AT commands described in this chapter allow the external application to determine various security related settings.

4.1 AT+CPIN Enter PIN

Syntax

Test Command AT+CPIN=?	Response(s) OK
Read Command AT+CPIN?	Response(s) +CPIN: <code> OK ERROR +CME ERROR: <err>
Write Command AT+CPIN=<pin>[,<new pin>]	Response(s) OK ERROR +CME ERROR: <err>

Reference(s)	PIN	USB					
GSM 07.07	○	●					

Command Description

The read command returns an alphanumeric string indicating whether or not a password is required.

The write command lets the ME store the entered password. This may be for example the SIM PIN1 to register to the GSM network, or the SIM PUK1 to replace a disabled PIN with a new one, or the PH-SIM PIN if the client has taken precautions for preventing damage in the event of loss or theft etc. See above for the list of passwords.

If no PIN request is pending (for example if PIN authentication has been done and the same PIN is entered again) ME responds + CME ERROR: operation not allowed. No action is required from your part.

Parameter Description

<pin>^(str)

Password (string type), usually SIM PIN1.

If the requested password was a PUK, such as SIM PUK1 or PH-SIM PUK or PH-FSIM PUK or another password, then <pin> must be followed by <new pin>.

<new pin>^(text)

If the requested code was a PUK: specify a new password or restore the former disabled password. See [4.1.1](#) for more information about when you may need to enter the PUK.

<code>^(text)

SIM PIN authentication

READY

PIN has already been entered. No further entry needed.

SIM PIN

ME is waiting for SIM PIN1.

SIM PUK	ME is waiting for SIM PUK1 if PIN1 was disabled after three failed attempts to enter PIN1.
SIM PIN2	ME is waiting for PIN2, when the attempt to access PIN2 requiring features was acknowledged with +CME ERROR:17 (e.g. if client attempts to edit the FD phone book). This is only applicable if the AT+CPIN read command also prompts for SIM PIN2. Normally, the AT+CPIN2 command is intended for SIM PIN2.
SIM PUK2	ME is waiting for PUK2 to unblock a disabled PIN2. Necessary if preceding command was acknowledged with error + CME ERROR:18 and only if the AT+CPIN read command also prompts for SIM PUK2. Normally, the AT+CPIN2 command is intended for SIM PUK2.

Phone security locks set by client or factory

PH-SIM PIN	ME is waiting for phone-to-SIM card password if "PS" lock is active and user inserts other SIM card than the one used for the lock. ("PS" lock is also referred to as phone or antitheft lock).
PH-SIM PUK	ME is waiting for Master Phone Code, if the above "PS" lock password was incorrectly entered three times.
PH-FSIM PIN	ME is waiting for phone-to-very-first-SIM card. Necessary when "PF" lock was set. When powered up the first time, ME locks itself to the first SIM card put into the card holder. As a result, operation of the mobile is restricted to this one SIM card (unless the PH-FSIM PUK is used as described below).
PH-FSIM PUK	ME is waiting for phone-to-very-first-SIM card unblocking password to be given. Necessary when "PF" lock is active and other than first SIM card is inserted.
PH-NET PIN	ME is waiting for network personalisation password
PH-NET PUK	ME is waiting for network personalisation unblocking password
PH-NS PIN	ME is waiting for network subset personalisation password
PH-NS PUK	ME is waiting for network subset unblocking password
PH-SP PIN	ME is waiting for service provider personalisation password
PH-SP PUK	ME is waiting for service provider personalisation unblocking password
PH-C PIN	ME is waiting for corporate personalisation password
PH-C PUK	ME is waiting for corporate personalisation unblocking password

Notes

- Caution: After entering a password with **AT+CPIN** all other commands that need access to data on the SIM card may be blocked for up to 20 seconds!
- Successful PIN authentication only confirms that the entered PIN was recognized and correct. The output of the result code OK does not necessarily imply that the mobile is registered to the desired network. Typical example: PIN was entered and accepted with OK, but the ME fails to register to the network. This may due to missing network coverage, denied network access with currently used SIM card, no valid roaming agreement between home network and currently available operators etc.
- ME offers various options to verify the present status of network registration: For example, the **AT+COPS** command indicates the currently used network. With **AT+CREG** you can also check the current status and activate an unsolicited result code which appears whenever the status of the network registration changes (e.g. when the ME is powered up, or when the network cell changes).
- Wait 10 seconds after PIN input before using SMS related commands.
 - **<pin>** and **<new pin>** can also be entered in quotation marks (e.g. "1234").
 - To check the number of remaining attempts to enter the passwords use the **AT&SPIC** command.
 - See **AT+CPWD** and **AT&SPWD** for information on passwords.
 - See **AT+CLCK** and **AT&SLCK** for information on lock types.

4.1.1 What to do if PIN or password authentication fails?

PIN1/PUK1:

After three failures to enter PIN 1, the SIM card is blocked (except for emergency calls). + CME ERROR: 12 will prompt the client to unblock the SIM card by entering the associated PUK (= PIN Unblocking Key/Personal Unblocking Key). After ten failed attempts to enter the PUK, the SIM card will be invalidated and no longer operable. In such a case, the card needs to be replaced. PIN1 consists of 4 to 8 digits, PUK1 is an 8-digit code only. To unblock a disabled PIN1 you have two options:

- You can enter **AT+CPIN=PUK1,new PIN1**.
- You can use the **ATD** command followed by the GSM code ****05*PUK*newPIN*newPIN#;**

PIN2/PUK2:

PIN2 prevents unauthorized access to the features listed in **AT+CPIN2**. The handling of PIN2 varies with the provider. PIN2 may either be a specific code supplied along with an associated PUK2, or a default code such as 0000. In either case, the client is advised to replace it with an individual code. Incorrect input of PUK2 will permanently block the additional features subject to PIN2 authentication, but usually has no effect on PIN1. PIN2 consists of 4 digits, PUK2 is an 8-digit code only. To unblock a disabled PIN2 you have two options:

- You can enter **AT+CPIN2=PUK2,new PIN2**.
- You can use the **ATD** command followed by the GSM code ****052*PUK2*newPIN2*newPIN2#;**

Phone lock:

If the mobile was locked to a specific SIM card (= "PS" lock or phone lock), the PUK that came with the SIM card cannot be used to remove the lock. After three failed attempts to enter the correct password, ME returns +CPIN: PH-SIM PUK (= response to read command [AT+CPIN?](#)), i.e. it is now waiting for the Master Phone Code. This is an 8-digit device code associated to the IMEI number of the mobile which can only be obtained from the manufacturer or provider. When needed, contact Siemens AG and request the Master Phone Code of the specific module. There are two ways to enter the Master Phone code:

- You can enter AT+CPIN=Master Phone Code,new password.
- You can use the [ATD](#) command followed by the GSM code *#0003*Master Phone Code#;.

Usually, the Master Phone Code will be supplied by mail or e-mail. If the received number is enclosed in the *# codes typically used for the [ATD](#) option, it is important to crop the preceding *#0003* characters and the appended #.

Example: You may be given the string *#0003*12345678#. When prompted for the PH-SIM PUK simply enter 12345678.

If incorrectly input, the Master Phone Code is governed by a specific timing algorithm: (n-1)*256 seconds (see table below). The timing should be considered by system integrators when designing an individual MMI.

Number of failed attempts	Time to wait before next input is allowed
1st failed attempt	No time to wait
2nd failed attempt	4 seconds
3rd failed attempt	3* 256 seconds
4th failed attempt	4* 256 seconds
5th failed attempt	5* 256 seconds
6th failed attempt	6* 256 seconds and so forth

SIM locks:

These are factory set locks, such as "PF", "PN", "PU", "PP", "PC". An 8-digit unlocking code is required to operate the mobile with a different SIM card, or to lift the lock. The code can only be obtained from the provider.

Failure to enter the password is subject to the same timing algorithm as the Master Phone Code (see table above).

Call barring:

Supported modes are "AO", "OI", "OX", "AI", "IR", "AB", "AG", "AC". If the call barring password is entered incorrectly three times, the client will need to contact the service provider to obtain a new one.

Summary of related chapters:

Related +CME errors are listed in chapter [1.12.1](#). For further instructions and examples see [AT+CLK](#), [AT&SLCK](#), [AT+CPWD](#) and [AT&SPWD](#). A complete list of *# codes is provided in [List of *# Codes](#).

4.2 AT+CPIN2 Enter PIN2

Syntax

Test Command AT+CPIN2=?	Response(s) OK
Read Command AT+CPIN2?	Response(s) +CPIN2: <code> OK ERROR +CME ERROR: <err>

Write Command AT+CPIN2 = <pin>[,<new pin>]	Response(s) OK ERROR +CME ERROR: <err>
---	---

Reference(s)	PIN	USB					
GSM 07.07	•	•					

Command Description

The read command returns an alphanumeric string indicating whether some password is required or not.

The write command lets the ME store the entered password. This may be for example the SIM PIN2 to benefit from the features listed below, or the SIM PUK2 to replace a disabled PIN2 with a new one. Note that PIN2 can only be entered if PIN1 authentication was done.

If the ME is requesting SIM PUK2, use <pin> to enter the PUK2, followed by <new pin> to specify your new PIN2.

Parameter Description

<pin>^(str)

Password (string type), usually SIM PIN2 or, if requested, SIM PUK2.

<new pin>^(str)

If the requested code was SIM PUK2: new password (PIN2).

See Chapter [4.1.1](#) for more information about when you may need to enter the PUK.

<code>^(text)

READY ME is not pending for any password.

SIM PUK2 ME is waiting for SIM PIN2. This <code> is returned only when PIN2 authentication has not yet been done or has failed (+CME ERROR:"!7).

SIMPIN2 ME is waiting for SIM PUK2.

This <code> is returned only when PIN2 authentication has failed and ME is pending for SIM PUK2 (i.e. +CME ERROR:18).

Note

- Functions accessible only after PIN2 authentication:

[AT+CACM](#): Accumulated call meter (ACM) reset or query

[AT+CAMM](#): Accumulated call meter maximum (ACMmax) set or query

[AT+CLCK](#): Facility lock to "FD" (Fixed dialing phone book)

[AT^SLCK](#): Facility lock to "FD" (Fixed dialing phone book)

[AT+CPWD](#): Change "P2"password

[AT^SPWD](#): Change "P2"password

[AT+CPUC](#): Price per unit and currency table

[AT+CPIN2](#): Enter SIM PIN2 or SIM PUK2 if requested.

For example, SIM PIN2 will be needed when you attempt to edit the "FD" phone book and ME returns +CME Error17 or +CPIN:SIM PIN2.

Once the required <pin> has been entered correctly, PIN2 authentication code changes to READY. After 300 s, a repetition of the authentication process is required (PIN2 authentication code changes from READY to SIM PIN2).

Examples

EXAMPLE 1

To change PIN2:

AT+CPWD="P2","0000", "8888" (where "0000" = old PIN2 and "8888" = new PIN2)

OK

EXAMPLE 2

To unblock a disabled PIN2:

AT+CPIN2?

+CPIN2: SIM PUK2

PIN2 has been disabled, PUK2 must be entered to define a new PIN2,

OK

AT+CPIN2=123456 78,8 888

where "12345678" is the PUK2, and "8888" the new PIN2.

EXAMPLE 3

To write to "FD" phone book:

AT+CPBS="FD"

OK

AT+CPBW=2,"+4 93012345678",145,"Charly"

+CME ERROR 17

access denied due to missing PIN2 authentication

AT+CPIN2=8888

OK

AT+CPBW=2,"+4 93012345678",145,"Charly"

OK

4.3 AT^SPIC Display PIN counter

Syntax

Test Command AT^SPIC=?	Response(s) OK
Read Command AT^SPIC?	Response(s) ^SPIC: <code> OK
Exec Command AT^SPIC	Response(s) ^SPIC: <counter> OK
Write Command AT^SPIC=<facility>	Response(s) ^SPIC: <counter> OK

Reference(s)	PIN	USB					
SIEMENS	○	●					

Command Description

The read command returns an identification of the currently required password, e.g. the PIN, PUK, PH-SIM PUK etc. The <counter> returned by the execute command refers to this password. In case there is no currently required password (the responses to "AT+CPIN?" and "AT+CPIN2?" both read "READY"), the read

command nevertheless identifies the password to which the execute command response refers.

The execute command returns the number of attempts still available for entering the currently required password, e.g. the PIN, PUK, PH-SIM PUK etc. To check whether or not you need to enter a password use commands [AT+CPIN?](#), Read command [AT^SPIC?](#) and [AT+CPIN2?](#).

If the responses to "[AT+CPIN?](#)" and "[AT+CPIN2?](#)" both read "READY", there is no currently required password, and the referrer of the execute command "[AT^SPIC](#)" is explicitly undefined.

In these cases, the read command "[AT^SPIC?](#)" may be used to determine, which password the response of the execute command actually refers to. Also, the write command may be used in order to retrieve the counter for a specific password.

The write command returns the number of attempts still available for entering the password identified by [`<facility>`](#), e.g. the PIN, PIN 2, PH-SIM PIN etc.

Parameter Description

[`<counter>`](#)^(num)

Number of attempts for the currently required password. This number will be counted down after each failure.

[`<facility>`](#)^(str)

Password for which the corresponding PIN counter is to be displayed

"SC"	SIM PIN or SIM PUK. If the SIM PIN has been deactivated after three failed attempts, the counter for SIM PUK will be returned instead.
------	--

"PS"	"phone code" or "device code" (cf. AT+CLK and AT+CPWD). If incorrectly entered three times, the Master Phone Code is required to lift the lock and the number of remaining attempts for the master phonecode will be returned.
------	---

"P2"	SIM PIN 2 or SIM PUK 2. If the SIM PIN 2 has been deactivated after three failed attempts, the counter for SIM PUK 2 will be returned instead.
------	--

"PN"	Network Personalisation
------	-------------------------

[`<code>`](#)^(text)

Identification of the currently required password.

SIM PIN	ME is waiting for SIM PIN1.
---------	-----------------------------

SIM PUK	ME is waiting for SIM PUK1 if PIN1 was disabled after three failed attempts to enter PIN1.
---------	--

SIM PIN2	ME is waiting for PIN2, when the attempt to access PIN2 requiring features was acknowledged with +CME ERROR:17 (e.g. if client attempts to edit the FD phone book).
----------	---

SIM PUK2	ME is waiting for PUK2 to unblock a disabled PIN2. Necessary if preceding command was acknowledged with error+CME ERROR: 18.
----------	--

PH-SIM PIN	ME is waiting for phone-to-SIM card password if "PS" lock is active and user inserts other SIM card than the one used for the lock. ("PS" lock is also referred to as phone or antitheft lock).
------------	---

PH-SIM PUK	ME is waiting for Master Phone Code, if the above "PS" lock password was incorrectly entered three times.
------------	---

PH-NET PIN	ME is waiting for network personalisation password
PH-NET PUK	ME is waiting for network personalisation unblocking password

Notes

- Whenever the required password changes, <counter> changes to reflect that change. Please refer to the examples below.
- Use the read commands "[AT+CPIN?](#)" and "[AT+CPIN2?](#)" to check which password is currently required. If the responses to "[AT+CPIN?](#)" and "[AT+CPIN2?](#)" both read "READY", there is no currently required password, and the referrer of the execute command "[AT^SPIC](#)" is explicitly undefined.
- In these cases, the read command "[AT^SPIC?](#)" may be used to determine, which password the response of the execute command actually refers to. Also, the write command may be used in order to retrieve the counter for a specific password.
- For passwords associated to the phone lock ("PS" lock set by client or factory) or other factory set locks, such as "PF", "PN", "PU", "PP", "PC" the number of attempts is subject to a timing algorithm explained in [AT+CPIN](#). If these passwords are incorrectly entered the counter first returns 3, 2 and 1 remaining attempt(s), but then gives the total number of attempts which amounts to 63 (see example below).
- See also chapters [AT+CLCK](#), [AT+CPIN](#), [AT+CPIN2](#), [AT+CPWD](#), [AT^SLCK](#) for further information on locks and passwords.

Examples

EXAMPLE 1

The client fails to provide a correct SIM PIN three times. The counter decreases each time. After the counter reaches zero, the SIM PUK is required. After failure to enter a correct SIM PUK, the counter decreases.

```

at+cpin?
+CPIN: SIM PIN      (currently required password is
PIN1)

OK
at^spic
^SPIC: 3           (3 attempts left)
OK
at+cpin=9999
+CME ERROR:        incorrect password
at^spic
^SPiC: 2           (2 attempts left)
OK
at+cpin=9999
+CME ERROR:        incorrect password
OK
At^spic
OK
at+cpin=9999
+CME ERROR:        incorrect password
at+cpin?
+CPIN: SIM PUK     (now required password is PUK 1)

```

```

OK
at^spic
^SPIC: 10          (10 attempts left for PUK 1)
OK
at+cpin=0123456 7,12 34
+CME ERROR:        incorrect password
at^spic "SPIC: 9  (9 attempts left for PUK1)
OK

```

EXAMPLE 2

Though a mobile is locked to a specific SIM card (phone lock), the client attempts to operate it with another SIM card. The client correctly enters the SIM PIN of the SIM card currently inserted, but then fails to give the "PS" lock password (PH-SIM PUK):

```

at+cpin=9999
OK
at+cpin?
+CPIN: PH-SIM PIN      ME is waiting for the phone lock
                        password
OK
at spic
^SPIC: 3 OK
at+cpin=4711
+CME ERROR: PH-SIM PIN required
at+cpin=4712
+CME ERROR:        incorrect password
at^spic
^SPIC: 1
OK
at^spic?
^SPIC: PH-SIM PIN      The counter displayed refers to the
                        phone lock password
OK
at+cpin=4713
+CME ERROR:        incorrect password
at^spic
^SPIC: 63
OK
at^spic?
^SPIC: PH-SIM PUK      The counter displayed refers to the
                        master phone code
OK
at+cpin=4714
+CME ERROR: incorrect password
at^spic
^SPIC: 63
OK

```

4.4 AT+CLCK Facility lock

Syntax

Test Command AT+CLCK=?	Response(s) +CLCK: list of supported <facility>s
Write Command AT+CLCK=<facility>,<mode>[,<password>][,<class>]]	Response(s) if <mode> is not equal 2 and command successful: OK if <mode>= 2 and command successful: +CLCK: <status>,<class> [+CLCK: <status>,<class>] [+CLCK: ...] OK If error is related to ME functionality +CME ERROR

Reference(s)	PIN	USB					
GSM 03.88, GSM 04.88	●	●					

Command Description

The Test command returns the supported parameters.

Use this command to lock, unlock or interrogate a network or ME <facility>. The command can be aborted when network facilities are being set or interrogated.

Parameter Description

<facility>^(str)

Phone security locks set by client or factory

Primarily intended for the client to take safety precautions, "SC", "PS" and "FD" can be configured individually.

"PS" may also be factory set.

Parameter <class> is not applicable to security locks.

See examples below for further details.

"SC" SIM (lock SIM cards). SIM requests password upon ME power-up and when this lock command is issued.
<password>: SIM PIN1.

"PS" Phone locked to SIM card. ME requests password when other than current SIM card is inserted.

"PS" lock is frequently referred to as "phone lock", or "device lock". Accordingly, the password may be called "phone code" or "device code". The "PS" password is not associated with the PUK of the SIM card. If incorrectly entered three times, the Master Phone Code is required to lift the lock. This is an 8-digit device code associated to the IMEI number of the mobile which can only be obtained from the manufacturer of the module. Once the Master Phone Code has been accepted, the mobile is operational, and the "PS" lock is no longer active. If needed it must be set once again.

<password>: User defined password. It is needed before the first use of <facility> "PS" and, therefore, must first be specified with AT+CPWD or AT&SPWD, if it

has not been predefined by factory settings. If set by factory (e.g. for a prepaid mobile), the password is supplied by the provider or operator.

"FD"

SIM fixed dialling memory: If the mobile is locked to "FD", only the phone numbers stored to the "FD" memory can be dialled. (Capacity of FD phone book depending on the SIM card.) <password>: SIM PIN 2. If a lock on the SIM fixed dialing memory is active, the following applies:

- ✓ Outgoing voice, data or fax calls can be made only to numbers stored in "FD" phone book.
Result code depends on the type of the call:
for voice calls, indication is "+CME Error 257: Call barred".
For data and fax calls, indication is "NO CARRIER".
- ✓ Access to defined Supplementary Services such as call barring, call waiting, call forwarding, call hold and Multiparty is possible only if the exact corresponding public MMI *# code for the desired service is stored in the fixed dialing number phone book, and used with **ATD**.
AT commands for supplementary service control are barred while "FD" lock is active.
Indication is "+CME Error 257: Call barred".
- ✓ Access to Unstructured Supplementary Services ("USSD") is possible only if the exact desired USSD string is stored in the fixed dialling number phone book, and used with **ATD**.
AT commands for USSD are barred while "FD" lock is active.
Indication is "+CME Error 257: Call barred".
- ✓ SMS can be sent only to phone numbers which are stored in the "fixed dialling numbers" phone book "FD".
Indication is "+CMS Error 302: operation not allowed".
- ✓ GPRS commands can be used only if the "fixed dialling numbers" phone book "FD" contains an entry with phone number "*99#". This single entry enables all GPRS commands, including AT commands and modem compatibility commands like "ATD*99***1#" or "ATD*98***1#". Indication is "+CME Error 257: Call barred".

Factory defined SIM locks:

Typical examples of factory set SIM locks are prepaid phones or network locks, used to restrict the operation of a mobile to a specific provider or operator. The client should be aware that each of these lock types can only be unlocked if the associated password is available. For example, a mobile can be locked to accept only SIM cards from the respective provider, or even one single SIM card. Once a different SIM card is inserted the ME will prompt the client to enter a specific code. This is not the PUK of the SIM card, but usually an 8-digit code which needs to be requested from the provider.

The locks can only be set by the manufacturer and need to be agreed upon between the parties concerned, e.g. provider, operator, distributor etc. on the one side and the manufacturer on the other side. For details contact your local dealer or Siemens AG.

Parameter <class> is not applicable to SIM locks.

<password> and instructions for unlocking must be obtained from the network provider.

"PF"	lock Phone to the very First SIM card
"PN"	Network Personalisation
"PU"	Network subset Personalisation
"PP"	Service Provider Personalisation
"PC"	Corporate Personalisation

Supplementary Service Call Barring:

Supplementary Service "Call Barring" allows to specify conditions under which calls will be disallowed by the network.

The availability of the Supplementary Services varies with the network. To benefit from call barring the client will need to subscribe them, though a limited number of call barring types may be included in the basic tariff package.

When you attempt to set a <facility> or <class> which is not provisioned, not yet subscribed to, or not supported by the module, the setting will not take effect regardless of the response returned. The responses in these cases vary with the network (for example "OK", "+CME ERROR: Operation not allowed", "+CME ERROR: Operation not supported" etc.). To make sure check the extended error response with AT+CEER and the lock status with <mode>=2.

<password>: Network password supplied from the provider or operator. Usually there is one password which applies to all call barring options. For details contact your provider.

"AO"	BAOC (Bar All Outgoing Calls)
"OI"	BOIC (Bar Outgoing International Calls)
"OX"	BOIC-exHC (Bar Outgoing International Calls except to Home Country)
"AI"	BAIC (Bar All Incoming Calls)
"IR"	BIC-Roam (Bar Incoming Calls when Roaming outside the home country)
"AB"	All Barring services (applicable only for <mode>=0)
"AG"	All outGoing barring services (applicable only for <mode>=0)
"AC"	All inComing barring services (applicable only for <mode>=0)

<mode>^(num)

0	unlock
1	lock
2	query status

<status>^(num)

0	lock is inactive
1	lock is active

<password>^(str)

Password string used to lock and to unlock a <facility>. Length and authority for passwords depend on the <facility> in question and are therefore listed in the section on parameter <facility>. Passwords can be modified with AT+CPWD or AT^SPWD.

<class>^(num)

Integer or sum of integers each representing a class of information, i.e. a bearer service, telecommunication service or bearer service group as defined in "GSM 02.04".

1	voice
2	class 2 ("data") comprises all those individual data classes between 16 and 128, that are supported both by the network and the MS. This means, a setting made for class 2 applies to all individual data classes (if supported). In addition, you can assign a different setting to a specific class. For example, you can activate Call Forwarding for all data classes, but deactivate it for data class 64, "dedicated packet access".
4	fax
8	SMS
16	data circuit sync
32	data circuit async
64	dedicated packet access
128	dedicated PAD access
1...[7]...255	combination of some of the above classes. For example, the default setting 7 represents the sum of the integers 1, 2 and 4 (voice, data and fax). The value 255 covers all classes. If parameter "class" is omitted, the default value 7 is used.

Notes

- The **AT+CLCK** command offers the full range of **<class>** parameters according to the GSM specifications. However, when you attempt to use a service option which is not provisioned or not yet subscribed to, the setting will not take effect regardless of the response returned.
- The responses in these cases vary with the network (for example "OK", "Operation not allowed", "Operation not supported" etc.). To make sure check the extended error response with AT+CEER and the lock status with **<mode>=2**.
- The command has been implemented with the full set of **<class>** parameters according to GSM 07.07. For actual applicability of a desired Call barring service to a specific service or service group (a specific **<class>** value) please consumable A.1 of GSM 02.04.
- If an outgoing Fax or Data Call is rejected due to an active "call barring" supplementary service, the call will be terminated with result code NO CARRIER.
- Under the same conditions, an outgoing Voice call will be terminated with result code NO DIALTONE.

Examples

EXAMPLE 1

Lock SIM card (**<facility>**= "SC")

AT+CLCK="SC", 1, "9999"

The "SC" parameter enables or disables the SIM PIN authentication (PIN 1) when you power up the GSM engine SIM card locked. As a result, SIM PIN 1 must be

entered to enable ME to register to the GSM network.

OK

AT+CLCK="SC",0, "9999"

Unlocks SIM card.

When powered up, ME registers to the GSM network without requesting SIM PIN1. Note: Depending on the services offered by the provider, this feature is not supported by all SIM card types. If so, the command returns ERROR when you attempt to unlock the card.

OK

To query the status of the SIM card lock:

AT+CLCK="SC",2

Query the status of SIM card lock.

SIM card is locked. SIM PIN1 must be entered to enable ME to register to the GSM network.

+CLCK: 1

OK

EXAMPLE 2

Phone lock (<facility>="PS")

AT+CPIN?

Make sure that PIN1 authentication is valid.

OK

To lock the ME to the currently inserted SIM card, first specify a password for <facility> "PS":

AT+CPWD="PS",,"1234"

If "PS" lock has not been set before: enter new password.

OK

Optionally, if "PS" password was defined before, change existing password:

AT+CPWD="PS",,"1234",,"3333" To replace existing "PS" password: Enter old and new password.

OK

Then, activate the Phone Lock:

AT+CLCK="PS",1, "333 3"

Locks the mobile to the current SIM card.

OK

To operate the mobile with the SIM card for which "PS" lock was activated:

AT+CPIN?

+CPIN: SIM PIN

OK

AT+CPIN="9999"

No additional password is required for operation (SIM recognized by mobile).

OK

To operate the mobile with other SIM card than the one used for the "PS" lock: Enter SIM PIN of present card, followed by "PS" lock password.

AT+CPIN?

```
+CPIN: SIM PIN
OK
AT+CPIN="1111"
OK
PIN authentication accepted.

AT+CPIN?
+CPIN: PH-SIM PIN
OK
"PS" lock password is required.

AT+CPIN="3333"
OK
"PS" Lock password has been accepted.
ME is fully operational now.
```

To deactivate the Phone Lock:

AT+CLCK="PS",0,"333 3"	Phone Lock password has to be provided again.
OK	Now the mobile can be used with any SIM card, without the need of the phone lock password.

4.5 AT^SLCK Facility lock

AT command [AT^SLCK](#) provides the "Facility lock" function as described for AT command [AT+CLCK](#) defined in GSM 07.07.

It is identical in every respect to [AT+CLCK](#), except that the command syntax and response prefix is "^SLCK" instead of "+CLCK".

Syntax

Test Command AT^SLCK=?	Response(s) ^SLCK: list of supported <facility>s OK
Write Command AT^SLCK=<facility>,<mode>[,<password>][,<class>]	Response(s) if <mode> is not equal 2 and command successful: OK if <mode>= 2 and command successful: ^SLCK: <status>,<class> [^SLCK: <status>,<class>] [^SLCK: ...] OK If error is related to ME functionality +CME ERROR

Reference(s)	PIN	USB					
SIEMENS, GSM 07.07, GSM 02.04, GSM 02.88, GSM 03.88, GSM 04.88	●	●					

Command Description

The test command returns the supported parameters.

Use this command to lock, unlock or interrogate a network or ME <facility>. The command can be aborted when network facilities are being set or interrogated.

Note

- For further details please refer to AT+CLCK.

4.6 AT+CPWD Change Password

Use this command when you want to change the passwords defined for the "facility lock" functions available from [AT+CLCK](#). A password consists of a string of numeric digits with a length in the range specified by <password length>.

Specifically the command can be used to change PIN1 orPIN2, change the password supplied from your provider for the "call barring" supplementary service, set individual phone security passwords, enter the unblocking key (Master Phone Code) to restore a disabled "PS" password.

See AT commands [AT+CLCK](#) and [AT^SLCK](#) for more information on the various lock features.

Syntax

Test Command AT+CPWD=?	Response(s) + CPWD: (list of supported (<facility>,<password length>) OK
Write Command AT+CPWD=<facility>,<old password>[,<new password>]	Response(s) New password has been registered for the facility lock function. OK If parameter <old password> was not correct: +CME ERROR 16 (+CME ERROR: incorrect password) If the password for the selected <facility> has been invalidated due to too many failed attempts: +CME ERROR ... If error is related to ME functionality: +CME ERROR

Reference(s)	PIN	USB					
GSM 07.07	●	●					

Command Description

The test command returns a list of pairs which represent the available facilities and the maximum length of the associated password.

The write command allows to define a new password for a password protected <facility> lock function. Each password is a string of digits, the length of which varies with the associated <facility>.

Parameter Description

<facility> (str)

Phone security locks set by client or factory:

Primarily intended for the client to take safety precautions, passwords "SC" (SIM PIN) and "P2" (SIM PIN2) are usually predefined, but can be configured individually. The password for lock facility "PS" may also be factory set.

"SC" SIM PIN. SIM requests password upon ME power-up and when this lock command is issued.

If incorrectly entered three times, the SIM PUK is required to perform authentication. Input of the SIM PUK password is possible only with AT command [AT+CPIN](#) or [ATD](#). For further details please refer to chapter [4.1.1. <password length>](#): 4 to 8 digits.

"PS" Phone locked to SIM card. ME requests password when other than current SIM card is inserted.

"PS" lock is frequently referred to as "phone lock", or "device lock". Accordingly, the password may be

called "phone code" or "device code". The "PS" password is not associated with the PUK of the SIM card. It must be defined before the first use of <facility> "PS" with **AT+CLCK**. <password length>: 4 digits.

If incorrectly entered three times, the Master Phone Code is required to lift the lock. This unblocking procedure is performed with **AT+CPWD** using the following parameters: <facility>="PS",<old password>= Master Phone Code (to be obtained from the module manufacturer), and <new password>= the new phone code ("PS" password for lock facility), if desired. Mind that successful PIN authentication is a prerequisite for use of AT command **AT+CPWD**. If Pin authentication has not been completed, input of the Master Phone code password is possible only with AT command **AT+CPIN** or **ATD**. For further detail please refer to chapter 4.1.1.

Once the Master Phone Code has been accepted, the mobile is operational, and the "PS" lock is no longer active. If needed it must be set once again with **AT+CLCK**.

"P2" SIM PIN 2, e.g. required for authentication with q facility lock "FD" (cf. **AT+CLCK**).

If incorrectly entered three times, the SIM PUK 2 is required to perform authentication. Input of the SIM PUK 2 password is possible only with AT command **AT+CPIN2** or **ATD**. For further detail please refer to chapter 4.1.1. <password length>: 4 to 8 digits.

Factory defined SIM locks:

Typical examples of factory set SIM locks are prepaid phones or network locks, used to restrict the operation of a mobile to a specific provider or operator. The client should be aware that each of these lock types can only be unlocked if the associated password is available. For example, a mobile can be locked to accept only SIM cards from the respective provider, or even one single SIM card. Once a different SIM card is inserted the ME will prompt the client to enter a specific code. This is not the PUK of the SIM card, but usually an 8-digit code which needs to be requested from the provider.

The locks can only be set by the manufacturer and need to be agreed upon between the parties concerned, e.g. provider, operator, distributor etc. on the one side and the manufacturer on the other side. For details contact your local dealer or Siemens AG.

"PF"	lock Phone to the very First SIM card
"PN"	Network Personalisation
"PU"	Network subset Personalisation
"PP"	Service Provider Personalisation
"PC"	Corporate Personalisation

Supplementary Service Call Barring:

Supplementary Service "Call Barring" allows to specify conditions under which calls will be disallowed by the network.

The availability of the Supplementary Services varies with the network. To benefit from call barring the client will need to subscribe them, though a limited number of call barring types may be included in the basic tariff package.

<password length>: The Network Password needs to be supplied from the network provider or network operator. Usually there is one 4 digit password which applies to all call barring options. For details contact your provider.

"AO"	BAOC (Bar All Outgoing Calls)
"OI"	BOIC (Bar Outgoing International Calls)
"OX"	BOIC-exHC (Bar Outgoing International Calls except to Home Country)
"AI"	BAIC (Bar All Incoming Calls)
"IR"	BIC-Roam (Bar Incoming Calls when Roaming outside the home country)
"AB"	All Barring services
"AG"	All outGoing barring services
"AC"	All inComing barring services

<password length>^(num)

4...8 length of password. The range of permitted length for a password depends on the associated **<facility>**. It is available from the test command response, or in the description of parameter **<facility>**.

<old password>^(str)

Password specified for the facility.

Parameter **<old password>** can be ignored if no old password was allocated to the facility. Take into account that a password may have already been set by factory, or that the service is subject to a password issued by the provider. See notes above or contact provider.

<new password>^(str)

New password. Mandatory, if **<old password>** was an unblocking key (such as the Master Phone Code).

Note

- To delete a password use the following syntax:
at+cpwd=<facility>,<old password>

Examples

EXAMPLE 1

To change PIN2

AT+CPWD="P2","0000", "8888"

(where "0000" = old PIN2 and "8888" = new PIN2) PIN2 password has been changed to "8888"

OK

EXAMPLE 2

To set password used to enable or disable barring of all outgoing calls:

AT+CPWD="AO","0000","3333"

Requests the network to change the password for supplementary service "call barring". Usually this request will affect all barring services, even though the request is issued for

Supplementary Service BAOC ("Barring of all outgoing calls") only. Refer to the respective network provider for detail.

OK

EXAMPLE 3

Handling of the "PS" lock password

AT+CMEE=2

Enable text output of CME Error information

AT+CPWD="PS","1111","2222"

(where "1111" = old password and "2222" = new password)

OK

AT+CPWD="PS","1111","2222"

Password for facility "PS" is now "2222"

Repeat command to provoke error "incorrect password"

+CME ERROR: incorrect password ("1111" is no longer the correct password)

EXAMPLE 4

To specify a new "PS" lock password, after the old password was disabled (e.g. after three failed attempts to change the "PS" password): use the master phone code.

CAUTION: THIS TEST SHOULD BE PERFORMED ONLY IF THE CORRECT MASTER PHONE CODE FOR THE INDIVIDUAL ME USED IS DEFINITELY AVAILABLE! Otherwise the module used will be rendered useless until the correct master phone code is entered!:

AT+CPWD="PS","12345678","1111" where 12345678 is the Master Phone Code and 1111 is the new password. You may also use <new password> to restore the former disabled password.

OK

Alternatively, without giving a new password:

AT+CPWD="PS","12345678" (where 12345678 is the Master Phone Code). Deactivates the present phone lock.

OK

4.7 AT^SPWD Change Password

Use this command when you want to change the passwords defined for the "facility lock" functions available from [AT+CLCK](#). Specifically the command can be used to change PIN1 orPIN2, change the password supplied from your provider for the "call barring" supplementary service, set individual phone security passwords, enter the unblocking key (Master Phone Code) to restore a disabled "PS" password.

See AT commands [AT+CLCK](#) and [AT^SLCK](#) for more information on the various lock features.

AT command [AT^SPWD](#) is identical in every respect to [AT+CPWD](#), except that the command syntax and response prefix is "^SPWD" instead of "+CPWD".

Syntax

Test Command	Response(s)
AT^SPWD=?	^SPWD: (list of supported (<facility>,<password length>) OK

<p>Write Command</p> <pre>AT^SPWD=<facility><old password>[,<new password>]</pre>	<p>Response(s)</p> <p>New password has been registered for the facility lock function.</p> <p>OK</p> <p>If parameter <old password> was not correct: +CME ERROR 16 (+CME ERROR: incorrect password)</p> <p>If the password for the selected <facility> has been invalidated due to too many failed attempts: +CME ERROR ...</p> <p>If error is related to ME functionality: +CME ERROR</p>
--	---

PIN	USB				
○	●				

Command Description

The test command returns a list of pairs which represent the available facilities and the maximum length of the associated password.

The write command allows to define a new password for a password protected <facility> lock function. Each password is a string of digits, the length of which varies with the associated <facility>.

Note

- For further description please refer to [AT+CPWD](#).

5 IDENTIFICATION COMMANDS

The AT commands described in this chapter allow the external application to obtain various identification information related to the SAMBA75 and linked entities.

5.1 ATI Display product identification information

Syntax

Exec Command ATI	Response(s) SAMBA75 REVISION xx.yy OK
Exec Command ATI [<value>]	Response(s) [SIEMENS Gipsy Soft Protocolstack V2.550] OK

Reference(s)	PIN	USB				
V.25ter	•	•				

Command Description

ME issues product information text.

Explanation of 'Revision' parameter: Version xx and variant yy of software release.

ME issues additional identification information, after using with optional parameter. ATI9 delivers the information above. Other values are not supported and only return OK.

Parameter Description

<value>^(num)

SIEMENS Gipsy Soft Protocol stack V2.550

5.2 AT+CGMI Request manufacturer identification

Syntax

Test Command AT+CGMI=?	Response(s) OK
Exec Command AT+CGMI	Response(s) OK

Reference(s)	PIN	USB				
GSM 07.07	○	●				

Command Description

TA returns manufacturer identification text.

Note

- See also: [AT+GMI](#).

5.3 AT+GMI Request manufacturer identification

Syntax

Test Command AT+GMI=?	Response(s) OK
Exec Command AT+GMI	Response(s) SIEMENS OK

Reference(s)	PIN	USB					
V.25ter	○	●					

Command Description

TA reports information to identify the manufacturer.

Note

- See also: [AT+CGMI](#)

5.4 AT+CGMM Request model identification

Syntax

Test Command AT+CGMM=?	Response(s) OK
Exec Command AT+CGMM	Response(s) SAMBA75 OK

Reference(s)	PIN	USB					
GSM 07.07	○	●					

Command Description

TA returns product model identification text.

Note

- See also: [AT+GMM](#).

5.5 AT+GMM Request TA model identification

Syntax

Test Command AT+GMM=?	Response(s) OK
Exec Command AT+GMM	Response(s) SAMBA75 OK

Reference(s)	PIN	USB					
V.25ter	○	●					

Command Description

TA reports one or more lines of information text which permit the user to identify the specific model of device.

Note

- See also: [AT+CGMM](#)

5.6 AT+CGMR Request revision identification of software status

Syntax

Test Command AT+CGMR=?	Response(s) OK
Exec Command AT+CGMR	Response(s) REVISION <xx.yy>

Reference(s)	PIN	USB					
GSM 07.07	○	●					

Command Description

TA returns product firmware version identification text.

Parameter Description

Version xx and variant yy of software release.

Note

- See also: [AT+GMR](#).

5.7 AT+GMR Request TA revision identification of software status

Syntax

Test Command AT+GMR=?	Response(s) OK
Exec Command AT+GMR	Response(s) REVISION <xx.yy> OK

Reference(s)	PIN	USB					
V.25ter	○	●					

Command Description

TA returns product software version identification text.

Parameter Description

<xx.yy>^(text)

Version xx and variant yy of software release.

Note

- See also: [AT+CGMR](#)

5.8 AT+CGSN Request product serial number identification (IMEI) identical to GSN

Syntax

Test Command AT+CGSN=?	Response(s) OK
---------------------------	-------------------

Exec Command AT+CGSN	Response(s) <sn> OK
-------------------------	---------------------------

Reference(s)	PIN	USB					
GSM 07.07	○	●					

Command Description

TA returns identification text for determination of the individual ME.

Parameter Description<sn>^(str)

IMEI of the telephone (International Mobile station Equipment Identity)

Note

- See also: [AT+GSN](#).

5.9 AT+GSN Request TA serial number identification (IMEI)

Syntax

Test Command AT+GSN=?	Response(s) OK
Exec Command AT+GSN	Response(s) <sn> OK

Reference(s)	PIN	USB					
V.25ter	○	●					

Command Description

TA reports one or more lines of information text which permit the user to identify the individual device.

Parameter Description<sn>^(str)

IMEI of the telephone (International Mobile station Equipment Identity)

Note

- The serial number (IMEI) varies for every individual ME device.

5.10 AT+CIMI Request international mobile subscriber identity

Syntax

Test Command AT+CIMI=?	Response(s) OK
Exec Command AT+CIMI	Response(s) OK ERROR +CME ERROR: <err>

Reference(s)	PIN	USB					

GSM 07.07	•	•						
-----------	---	---	--	--	--	--	--	--

Command Description

TA returns IMSI for identifying the individual SIM which is attached to ME.

Parameter Description

<imsi>^(str)

International Mobile Subscriber Identity (string without quotes).

6 CALL RELATED COMMANDS

The AT commands described in this chapter are related to Mobile Originated (MOC, i.e. outgoing) Calls and Mobile Terminated (MTC, i.e. incoming) Calls.

NOTE: NO AUDIO CHANNELS ARE PROVIDED BY THE SAMBA75 !!!!.

6.1 Call Status Information

For circuit switched calls, including voice, fax and data calls, call status information is available with URC "+CIEV": call" (configurable via AT commands **AT+CIND** and **AT+CMER**) or - in more detail - from the list of current calls. This list can be displayed on request via AT commands **AT+CLCC** and **AT\SLCC**. It can also be issued by the ME in the form of an unsolicited result code "**\\$SLCC**" if configured with **AT\SLCC** and **AT+CMER**. URC "+CIEV": call" and URC "\\$SLCC" can be configured using AT command **AT\SCFG**. An overview of the possible configurations and their consequences for the availability of call status information will be given here.

Generally speaking, the call status values recognized by the ME are as follows:

- active
- held
- dialing (MOC)
- alerting (MOC)
- incoming (MTC)
- waiting (MTC)
- terminating: The call is not active anymore, but inband information is still available.
- dropped: The call has been suspended by the network, but may be resumed later.

The values "terminating" and "dropped" are not standardized for AT command **AT+CLCC**, and therefore only available for command **AT\SLCC**. A call in any of these two states will not appear in the list of current calls as displayed with **AT+CLCC**.

A call that is not recognized by the ME is considered to be in "unknown" state. Some networks may schedule a traffic channel for a call that is not yet in the "active" state. This is reflected in parameter <traffic channel assigned> of AT command **AT\SLCC** and the corresponding URC.

Depending on the value of **AT\SCFG** setting <succ>, Indicator "+CIEV" will be issued (if configured with **AT+CIND** and **AT+CMER**) when a state transition ends in state "active" or in state "unknown" (if **AT\SCFG** setting <suco="restricted">).

When any state transition (including transitions beginning or ending in state "unknown") occurs in the list of active calls, or when a traffic channel is established (if **AT\SCFG** setting <suco="verbose">).

The indicator value for indicator "+ciEV":call" will be "1" if at least one call is in states "held" or "active", and "0" otherwise.

Depending on the value of **AT\SCFG** setting <sucs>, indicator "\\$SLCC" will be issued (if configured with write command **AT\SLCC** and **AT+CMER**) when a state transition ends in state "active" or in state "unknown" (if **AT\SCFG** setting <sucs>="restricted") when any state transition (including transitions beginning or ending in state "unknown") occurs in the list of active calls, or when a voice channel is established (if **AT\SCFG** setting <sucs>="verbose").

Due to compatibility considerations, the power up default for **AT\SCFG** setting <succ> is "restricted", offering compatibility to the standard behaviour of indicator "+CIEV": call", while the default for setting <sucs> is "verbose".

In order to see the URCs, event reporting for both indicators must be explicitly configured with the appropriate AT commands.

6.2 ATA Answer a call

Syntax

Exec Command ATA	Response(s) In case of data call, if successfully connected: CONNECT <text> TA switches to data mode. In case of voice call, if successfully connected: OK When TA returns to command mode after call release: OK If no connection: NO CARRIER
---------------------	---

Reference(s)	PIN	USB					
V.25ter	•	•					

Command Description

TA causes remote station to go off-hook (e.g. answer call).

Parameter Description

<text>^(str)

Connection status

<text> output only if **ATX** parameter setting with value greater 0.

Notes

- Any additional commands on the same command line are ignored.
- The command may be aborted generally by receiving a character during execution. It can't be aborted in some connection setup states, such as handshaking.
- If **AT+FCLASS** setting is 1 or 2, all incoming calls will be answered as fax calls.
- It is possible to change the setting for **AT+FCLASS** to 0 while the call is ringing, and accept the call normally afterwards with **ATA**.
- The **ATA** command may be used also to accept a network request for a PDP context activation (see **ATA**).
- See also **ATX** for <text>.

6.3 ATD Mobile originated call to dial a number

Syntax

Exec Command ATD<n>[<mgsm>][:]	Response(s) If no dialtone (parameter setting ATX2 or ATX4): NO DIALTONE If busy (parameter setting ATX3 or ATX4): BUSY If a connection cannot be set up: NO CARRIER OK If successfully connected and non-voice call (TA switches to online data mode): CONNECT <text> When TA returns to command mode after call release: OK If successfully connected and voice call: OK
-----------------------------------	--

Reference(s)	PIN	USB					
V.25ter	●	●					

Command Description

This command can be used to set up outgoing voice, data or fax calls. It also serves to control Supplementary Services. The termination character ";" is mandatory to set up voice calls or to send *# codes for Supplementary Services. It must not be used for data and fax calls.

Additional notes on the responses returned after dialing with **ATD**:

- For voice calls, you have the choice of two different response modes that can be selected with **AT^SM2 0: AT^SM2 0=1** (factory default) causes the ME to respond once the call setup is completed either successfully ("OK") or unsuccessfully ("NO CARRIER", "NO DIAL TONE", "BUSY").
- **AT^SM2 0=0** causes the ME to return "OK" immediately after dialing was completed (i.e. before call setup terminates successfully or unsuccessfully).
- For data connections, call setup always terminates when the call has been established (indicated by the result code "CONNECT <text>"), or when it fails (indicated by "NO CARRIER"). The settings of **AT^SM20** do not apply.

Different call release indications:

- Upon termination, an outgoing fax or data call may show a different result code than a voice call would show under identical conditions. In order to track down the actual reason for call termination,

[AT+CEER](#) or [ATS18](#) should be used for all applicable connections.

Using [ATD](#) during an active call:

- When a user originates a second voice call while there is already an active voice call, the first call will automatically put on hold. The second call attempt is acknowledged with "OK" immediately after dialing with [ATD](#) has completed, without relation to a successful call setup. In case of failure, the additional result codes "NO CARRIER", "NO DIAL TONE", "NO CARRIER" will be presented afterwards (see example below).

Parameter Description

[**<n>**](#)^(text)

String of dialing digits and optional V.25ter modifiers: 0-9, *, #, +, A, B, C. The following V.25ter modifiers are ignored: ,(comma), T, P, !, W ,@ Emergency call: <n> = 112 , 911 or 08, standardized GSM emergency number (no SIM needed).

[**<mgsm>**](#)^(str)

String of GSM modifiers:

- | | |
|---|---|
| I | Activates CLIR (disables presentation of own phone number to called party) |
| i | Deactivates CLIR (enables presentation of own phone number to called party) |
| G | Activate Closed User Group explicit invocation for this call only. |
| g | Deactivate Closed User Group explicit invocation for this call only. |

Notes

- The command may be aborted generally when receiving an [ATH](#) command during execution. It cannot be aborted in some connection setup states, such as handshaking.
- Parameter "I" and "i" only if no *#-code is within the dial string.
- [**<mgsm>**](#) is not supported for data calls.
- [**<n>**](#) is default for last number that can be dialled by [ATDL](#).
- See also [ATX](#) for [**<text>**](#).
- If [ATD](#) is used with a USSD command (e.g. ATD*100#;) an AT+CUSD=1 is executed implicitly (see [AT+CUSD](#)).
- Parameter 'G' or 'g' will be ignored if Closed User Group was already activated, respectively deactivated with [AT+CCUG](#) command before. Call by call invocation of CUG uses the settings provisioned by the provider or, if available, the settings of the parameters [**<index>**](#) and [**<info>**](#) made with [AT+CCUG](#).
- The ME is equipped with a "Blacklist" function according to GSM02.07 Annex A:

After a predefined number of failed call attempts, the dialed number is entered into a read-only phone book called "blacklist" (phone book "BL"). Call attempts to numbers contained in the blacklist will be barred by ME and not signalled to the network.

An attempt to start a voice call to a barred phone number will be stopped with a CME ERROR 257 "Call Barred".

An attempt to start a data or fax call to a barred phone number will be answered immediately with result code "NO CARRIER".

The barred numbers are automatically removed from the blacklist according to the timing conditions specified in GSM02.07 Annex A.

Example

The following example shows the call setup procedure when a call is already active and a second call attempt fails because the line of the called party is busy:

atd03012345678	Dialing out the first party's number.
OK	The first call is established.
ATD03022222222	The number of the second party is dialed.
OK	The response "OK" is issued immediately though no call is established (same behavior as is you had chosen AT&SM2 0=0 .)
BUSY	Line of the second called party is busy.

6.4 ATD><mem><n> Originate call to phone number in memory

Syntax

Exec Command ATD><mem><n>[<mgsm>];	Response(s) ERROR +CME ERROR: <err> If no dialtone (parameter ATX2 or ATX4): NO DIALTONE If busy (parameter setting ATX3 or ATX4): BUSY If connection cannot be set up: NO CARRIER When TA returns to command mode after call release: OK If successfully connected: OK
---------------------------------------	---

Reference(s)	PIN	USB				
V.25ter	•	•				

Command Description

TA attempts to set up an outgoing call to the specified number. The termination character ";" is mandatory since dialing from a phone book is only supported for voice calls and for sending *# codes of Supplementary Services or other functions.

Parameter Description

<mem>^(str)

Phone book storage:

For detailed description of storages see [AT+CPBS](#).

"FD"	Fixed dialing phone book
"SM"(&F)	SIM phone book
"ON"	MSISDN list
"ME"	Mobile Equipment Phone book
"LD"	Last number dialed phone book
"MC"	Missed (unanswered received) calls list
"RC"	Received calls list

<n>^(num)

Integer type memory location in the range of locations available in the selected memory, i.e. the index number returned by [AT+CPBR](#).

<mgsm>^(str)

String of GSM modifiers:

- I Activates CLIR (disables presentation of own phone number to called party)
- i Deactivates CLIR (enables presentation of own phone number to called party)

Notes

- This command may be aborted generally by receiving a character during execution. Abortion is not possible during some states of connection setup such as handshaking.
- There is no <mem> for emergency call ("EN").
- The command is not applicable to data calls. Any attempt to dial a data call number from <mem> causes the result code "NO CARRIER" to appear.
- Parameter <mgsm> only if no *# code is within the dialing string.
- See [ATX](#) for setting result code and call monitoring parameters.

Examples

EXAMPLE 1

To query the location number of the phone book entry:

AT+CPBR=1,xx

TA returns the entries available in the active phone book.

EXAMPLE 2

To dial a number from the SIM phone book, for example the number stored to location 15:

ATD>SM15;

OK

EXAMPLE 3

To dial a phone number stored in the last dial memory on the SIM card:

ATD>LD9;

OK

6.5 ATD><n> Originate call to phone number selected from active memory

Syntax

Exec Command	Response(s)
ATDxn>[<mgsm>];	<p>ERROR +CME ERROR: <err> If no dialtone (parameter ATX2 or ATX4): NO DIALTONE If busy (parameter setting ATX3 or ATX4): BUSY If connection cannot be set up: NO CARRIER When TA returns to command mode after call release: OK If successfully connected: OK</p>

Reference(s)	PIN	USB					
V.25ter	•	•					

Command Description

TA attempts to set up an outgoing call to the stored number. The termination character ";" is mandatory since dialing from a phone book is only supported for voice calls and for sending *# codes of Supplementary Services or other functions.

Parameter Description

<n>^(num)

Integer type memory location in the range of locations available in the selected memory, i.e. the index number returned by [AT+CPBR](#).

<mgsm>^(str)

String of GSM modifiers:

- | | |
|---|---|
| I | Activates CLIR (disables presentation of own phone number to called party) |
| i | Deactivates CLIR (enables presentation of own phone number to called party) |

Notes

- This command may be aborted generally by receiving a character during execution. Abortion is not possible during some states of connection setup such as handshaking.
- The command is not applicable to data calls. Any attempt to dial a data call number from <n> causes the result code "NO CARRIER" to appear.
- Parameter <mgsm> only if no *# code is within the dialing string.

6.6 ATD><str> Originate call to phone number in memory with corresponding field

Syntax

Exec Command ATDxstr>[<mgsm>];	Response(s) ERROR +CME ERROR: <err> If no dialtone (parameter ATX2 or ATX4): NO DIALTONE If busy (parameter setting ATX3 or ATX4): BUSY If connection cannot be set up: NO CARRIER When TA returns to command mode after call release: If successfully connected: OK
-----------------------------------	---

Reference(s)	PIN	USB					
V.25ter	•	•					

Command Description

This command searches the active phone book for a given string <str> and dials the assigned phone number. The termination character ";" is mandatory since

dialing from a phone book is only supported for voice calls and for sending *# codes of Supplementary Services or other functions.

Parameter Description

<str>^{(str)(+CSCS)}

String type value ("x"), which should equal an alphanumeric field in at least one phone book entry in the searched memories; used character set should be the one selected with **AT+CSCS**. **<str>** can contain escape sequences as described in chapter "Supported character sets".

<str> must be wrapped in quotation marks (" "), if escape sequences or parameter **<mgsm>** are used or if the alphanumeric strings contains a blank. If not, quotation marks are optional.

If **AT+CSCS** is set to "UCS2", with respect to the coding of UCS2-characters only phone book entries that contain an alphanumeric string with assize less than the half of the paramter **<tlength>** from **AT+CPBW** can be dialed.

<mgsm>^(str)

String of GSM modifiers:

- | | |
|---|---|
| I | Activates CLIR (disables presentation of own phone number to called party) |
| i | Deactivates CLIR (enables presentation of own phone number to called party) |

Notes

- This command may be aborted generally by receiving a character during execution. Abortion is not possible during some states of connection setup such as handshaking.
- The command is not applicable to data calls. Any attempt to dial **<str>** without semicolon ";" causes the result code "NO CARRIER" to appear.
- Parameter **<mgsm>** only if no *# code is within the dialing string.

6.7 ATDI Mobile originated call to dialable ISDN number <n>

Syntax

Exec Command ATDI<n>[<; >]	Response(s) If no dialtone (parameter ATX2 or ATX4): NO DIALTONE BUSY If connection cannot be set up: NO CARRIER All other error reasons: +CME ERROR If successfully connected and non-voice call (TA switches to data state): CONNECT <text> When TA returns to command mode after call release: OK If successfully connected and voice call: OK
--	---

Reference(s)	PIN	USB					
V.25ter	•	•					

Command Description

TA attempts to set up an outgoing call to ISDN number.

Parameter Description

<n>^(str)

ISDN number [+]<d>

String with maximum length of 20 characters. Allowed characters:

+: international dialing format

<d>: 0-9, A, B, C

<;>^(str)

voice call.

Note

- This command may be aborted generally by receiving a character during execution. Abortion is not possible during some states of connection setup such as handshaking.

6.8 ATDL Redial last telephone number used

Syntax

Exec Command ATDL[:]	If there is no last number or number is not valid: +CME ERROR If no dialtone (parameter ATX2 or ATX4): NO DIALTONE If busy (parameter setting ATX3 or ATX4): BUSY If connection cannot be set up: NO CARRIER If successfully connected and non-voice call (TA switches to online data mode): CONNECT <text> When TA returns to command mode after call release: OK If successfully connected and voice call: OK
-------------------------	--

Reference(s)	PIN	USB				
	●	●				

Command Description

This command redials the last voice and data call number used in the [ATD](#) command. If terminated with semicolon ";" [ATDL](#) dials the last voice call number stored in the "LD" phone book. Otherwise, the last dialed data or fax number will be used (not contained in the "LD" phone book).

Notes

- This command may be aborted generally by receiving a character during execution. Abortion is not possible during some states of connection setup such as handshaking.
- Parameter "l" and "i" only if no *#-code is within the dial string.

6.9 ATH Disconnect existing connection

Syntax

This confidential document is the property of FALCOM GmbH and may not be copied or circulated without permission.

Exec Command ATH[<n>]	Response(s) OK
--------------------------	-------------------

Reference(s)	PIN	USB					
	○	●					

Command Description

Disconnect existing call from command line by local TE and terminate call.

Parameter Description

<n>^(num)

[0] disconnect from line and terminate call

Notes

- OK is issued after circuit 109 (DCD) is turned off, if it was previously on.
- **ATH** terminates every circuit switched call (voice, data or fax), even if it is issued via another interface. This behavior is in accordance with ITU-T V.25ter; (07/97, "Hook control": "**ATH** is terminating any call in progress.").
- **ATH** clears any active PDP context or terminates any existing PPP connection, but only if issued on the same interface where GPRS is used and if there is no pending network request for PDP context activation. It does not affect PDP contexts and PPP connections on other interfaces (see also chapter "**ATH** Manual rejection of a network request for PDP context activation").

6.10 AT+CHUP Hang up call

Syntax

Test Command AT+CHUP=?	OK
Exec Command AT+CHUP	OK ERROR +CME ERROR

Reference(s)	PIN						
	●						

Command Description

Cancels all active and held calls.

Note

- AT+CHUP implements the same behaviour as **ath**.

6.11 ATSO Set number of rings before automatically answering the call

Syntax

Read Command ATSO?	Response(s) <n> OK
-----------------------	--------------------------

Write Command ATSO=<n>	OK
---------------------------	----

Reference(s)	PIN						
V.25ter	●	●					

Command Description

This parameter setting determines the number of rings before automatic answering.

Parameter Description

<n>^{(num)&W&V}

- 000(&F) automatic answering is disabled
- 001-255 enable automatic answering on the specified ring number

Notes

- This command works for MT data and fax calls.
- Autoanswering of CSD data and fax calls is supported on USB.
- A CSD call will not be answered automatically if the module is in GPRS online mode. However, this is possible in GPRS command mode. The application can detect a call by evaluating the RING line and distinguish to change into GPRS command mode or stay in GPRS online mode until GPRS is available again. To answer, to reject or to wait for automatic answering the incoming call the application has to switch into GPRS command mode.
- If <n> is set to higher values, the calling party may terminate the call establishment before the call can be automatically answered.
- The correlation between **ATS7** and **ATSO** is important.
- Example: **ATS7**=30 and **ATSO**=20 may not allow call establishment.
- Setting is local to the interface. It is allowed to have different settings on different interfaces. In such cases the interface 'wins', which is idle and uses the smallest <n> value.
- **ATSO** write command is PIN protected.
- The command **ATSO** is also used as GPRS compatibility command to answer automatically to a network request for PDP context activation (for details see **ATSO** for GPRS). So using **ATSO=<n>** with n > 0, will perform a GPRS attach, if the ME is not already GPRS attached and if ME is configured to do this (see **AT&SCFG**, parameter <gaa>). If the GPRS attach fails (e.g. the network rejects the attach request), the write command returns with error, but the value of <n> is changed anyway.

The GPRS attach will not be performed on recalling a stored user profile with **ATZ** or on power up, if a n > 0 setting was stored in the user profile with **AT&W**.

6.12 ATS6 Set pause before blind dialing

Syntax

Read Command ATS6?	Response(s)
	OK

Write Command ATS6=<n>	Response(s)
---------------------------	-------------

Reference(s)	PIN	USB					
V.25ter		●					

Command Description

No effect for GSM.

Parameter Description

$<n>$ ^{(num)(&W)(&V)}

000...255

6.13 ATS7 Set number of seconds to wait for connection completion

Syntax

Read Command ATS7?	$<n>$	OK					
ATS7=<n>		Response(s) OK					

Reference(s)	PIN	USB					
V.25ter	○	●					

Command Description

This parameter setting determines the amount of time to wait for the connection completion when answering or originating a call.

Parameter Description

$<n>$ ^{(num)(&W)(&V)}

no. of seconds to wait for connection completion 000...060(&F)

Notes

- Values bigger than 60 cause no error, but $<n>$ will be set down to maximum value of 60.
- In $<n>$ of **ATSO** of the called party is set to higher values the call establishment may not be successful.
- The correlation between **ATS7** and **ATSO** is important.
Example: **ATS7**=30 and **ATSO**=20 may not allow call establishment.

6.14 ATS8 Set number of seconds to wait for comma dialing modifier

Syntax

Read Command ATS8?	Response(s) $<n>$						
Write Command ATS8=<n>	Response(s) OK						

Reference(s)	PIN						
--------------	-----	--	--	--	--	--	--

V.25ter	<input type="radio"/>	<input checked="" type="radio"/>					
---------	-----------------------	----------------------------------	--	--	--	--	--

Command Description

No effect for GSM.

Parameter Description

<n>^{(num)(&W)(&V)}

6.15 ATS10 Set disconnect delay after indicating the absence of data carrier

Syntax

ATS10?	Response(s)						
	OK						
Write Command	OK						

Reference(s)	PIN						
V.25ter	O						

Command Description

This parameter setting determines the amount of time, that the TA remains connected in absence of a data carrier. If the data carrier is detected before disconnect, the TA remains connected.

Parameter Description

<n>^{(num)(&W)(&V)}

number of tenths of seconds of delay
001...2^(&F)...255

6.16 ATP Select pulse dialing

Syntax

Exec Command							
ATP	OK						

Reference(s)							
V.25ter	O						

Note

- No effect for GSM.

6.17 ATO Switch from command mode to data mode/PPP online mode

Syntax

Exec Command ATO[<n>]	Response(s)
	NO CARRIER
	CONNECT <text>

Reference(s)	PIN	USB					
V.25ter	○						

Command Description

ATO is the corresponding command to the **+++** escape sequence: When you have established a CSD call or a GPRS connection and TA is in command mode, **ATO** causes the TA to resume the data or GPRS connection and takes you back to data mode or PPP online mode.

Parameter Description

<n>^(num)

[0] Switch from command mode to data mode

6.18+++ Switch from data mode to command mode

Syntax

Exec Command +++	Response(s)
	OK

Reference(s)	PIN	USB					
V.25ter	○	●					

Command Description

This command is only available during a CSD call or a GPRS connection. The **+++** character sequence causes the TA to cancel the data flow over the AT interface and switch to command mode. This allows you to enter AT commands while maintaining the data connection to the remote device or, accordingly, the GPRS connection. To prevent the **+++** escape sequence from being misinterpreted as data, it must be preceded and followed by a pause of at least 1000 ms. The **+++** characters must be entered in quick succession, all within 1000 ms.

Note

- To return from command mode to data or PPP online mode: Enter **ATO**.

6.19ATT Select tone dialing

Syntax

Exec Command ATT	Response(s)
	OK

Reference(s)	PIN	USB					
V.25ter	○	●					

Note

- No effect for GSM.

6.20 AT+CBST Select bearer service type

Syntax

Test Command AT+CBST=?	Response(s) +CBST: (list of supported <speed>s), (list of supported <name>s), (list of supported <ce>s) OK
AT+CBST?	Response(s) OK
Write Command	Response(s) OK ERROR +CME ERROR: <err>

Reference(s)	PIN	USB					
GSM 07.07	○	●					

Command Description

The write command selects the bearer service <name>, the data rate <speed> and the connection element <ce> to be used when data calls are originated. The settings also apply to mobile terminated data calls, especially when single numbering scheme calls or calls from analog devices are received (see also: [AT+CSNS](#)).

Parameter Description

<speed>^{(num)(&W)&V}

0	auto bauding
4	2400 bps (V.22bis)
6	4800 bps (V.32)
[7] ^(&F)	9600 bps (V.32)
14	14400 bps(V. 34)
68	2400 bps(V. 110)
70	4800 bps(V. 110)
71	9600 bps(V. 110)
75	14400 bps(V. 110)

<name>^{(num)(&W)}

0^(&F) asynchronous modem

<ce>^{(num)(&W)}

Transparent mode is not supported.

1^(&F) non-transparent

Note

- GSM 02.02[1]: List of allowed combinations of subparameters.

6.21 AT+CRLP Select radio link protocol param. for orig. non-transparent data call

Syntax

Test Command AT+CRLP=?	Response(s) +CRLP: (list of supported <iws>s), (list of supported <mws>s), (list of supported <Ti>s), (list of supported <N2>s) OK
Read Command AT+CRLP?	Response(s) + CRLP: <iws>, <mws>, <T1>, <N2>[,<verx>] OK
Write Command AT+CRLP=[<iws>[,<mws>[,<T1>[,<N2>[,<verx>]]]]]	Response(s) OK ERROR +CME ERROR: <err>

Reference(s)	PIN	USB					
GSM 07.07	○	●					

Command Description

Read command returns current settings for the supported RLP version 0.

The Write command sets radio link protocol (RLP) parameters used when non-transparent data calls are originated.

Parameter Description

<iws>^{(num)&W)&V}

Interworking window size (IWF to MS)

<mws>^{(num)&W)&V}

Mobile window size (MS to IWF)

<T1>^{(num)&W)&V}

Acknowledgement timer (T1 in 10 ms units)

48...[78]&F...255

<N2>^{(num)&W)&V}

Re-transmission attempts N2

1...[6]&F...255

<verx>^(num)

0 RLP version number in integer format; when version indication is not present it shall equal 0.

Notes

- RLP version 0: single-link basic version;
- RLP version 1: single-link extended version (e.g. extended by data compression);
- RLP version 2: multi-link version.
- Compression and multi-link are not supported.

6.22 AT+CLCC List current calls of ME

Syntax

Test Command AT+CLCC=?	Response(s) OK
---------------------------	-------------------

Exec Command AT+CLCC	Response(s) [+CLCC: <idx>,<dir>,<stat>,<mode>,<mpty>[,<number>,<type>[,<alpha>]]] [+CLCC: <idx>,<dir>,<stat>,<mode>,<mpty>[,<number>,<type>[,<alpha>]]] [+CLCC: ...] OK ERROR +CME ERROR
-------------------------	--

Reference(s)	PIN	USB					
	●	●					

Command Description

The exec command returns a list of current calls of ME. If command is successful, but no calls are available, no information response is sent to TE.

Parameter Description

<idx>^(num)

call identification number as described in GSM02.30 subclause 4.5.5.1;
this number can be used in [AT+CHLD](#) command operations

<dir>^(num)

- 0 mobile originated call (MOC)
- 1 mobile terminated call (MTC)

<stat>^(num)

state of the call

- 0 active
- 1 held
- 2 dialing (MOC)
- 3 alerting (MOC)
- 4 incoming (MTC)
- 5 waiting (MTC)

<mode>^(num)

bearer/teleservice

- 0 voice
- 1 data
- 2 fax
- 3 voice followed by data, voice mode (only in connection with
4 single numbering scheme [AT+CSNS](#))
- 4 alternating voice/data, voice mode (only in connection with
single numbering scheme [AT+CSNS](#))
- 5 alternating voice/fax, voice mode (only in connection with
single numbering scheme [AT+CSNS](#))
- 6 voice followed by data, data mode (only in connection with
single numbering scheme [AT+CSNS](#))
- 7 alternating voice/data, data mode (only in connection with
single numbering scheme [AT+CSNS](#))
- 8 alternating voice/fax, fax mode (only in connection with
single numbering scheme [AT+CSNS](#))
- 9 unknown

<mpty>^(num)

0 call is not one of multiparty (conference) call parties call is one of
 1 multiparty (conference) call parties
<number>^(str)
 phone number in format specified by **<type>**
<type>^(num)
 type of address octect
 145 dialling string **<number>** includes international access code
 129 character '+' otherwise
<alpha>^{(str)(+cscs)}
 Alphanumeric representation of **<number>** corresponding to the entry found in phone book; used character set should be the one selected with command [AT+CSCS](#) (Select TE Character Set).
 The maximum displayed length of **<alpha>** is 16 characters. If the **<alpha>** has more than 16 characters, only the first 15 characters will be displayed. To indicate an overflow, a special character will be used as the 16th character. This will be a space if the character set selected with [AT+CSCS](#) is 'GSM', or 'E400' if the character set is 'UCS2'.
 Due to time constraints on the necessary evaluation of the phone book, this parameter may show a default value during early call phases (e.g. for **<stat>**= "dialling", "incoming" or "alerting"), even if a phone book entry is present for the number concerned.

Note

- Teleservices other than voice, data, fax are not fully supported by ME. They are used only in connection with the handling for [AT+CSNS](#), and may therefore occur in parameter **<mode>** for mobile terminated calls.

6.23 AT^SLCC Siemens defined command to list the current calls of the ME

Command ^SLCC covers essentially the same information as GSM 07.07 command [AT+CLCC](#), with the following additions:

- The execute command response contains an additional parameter **<traffic channel assigned>** indicating whether the call has been assigned a traffic channel by the network (transmission of data or inband information is possible).
- The additional write command allows to activate event reporting for the list of current calls. If event reporting is active for an interface, a call status transition (see [6.1](#)) and (if desired) the assignment of a traffic channel will generate an event report indication to this interface. In order to receive this event report as an URC, the URC presentation mode for this interface has to be configured with [AT+CMER](#).
- The frequency of event report generation can be configured with AT command [AT^SCFG](#). Refer to [Call Status Information](#) for further detail on the configuration options.
- The additional read command allows to determine the event reporting mode **<n>** which indicates whether the interface receives event report indications for the list of current calls. Mind that the URC will be displayed only if the URC presentation mode for the interface concerned has been configured with [AT+CMER](#).

Syntax

Test Command AT^SLCC=?	Response(s) OK
Read Command AT^SLCC?	Response(s) ^SLCC: <n> OK
Exec Command AT^SLCC	Response(s) ^PSLCC: <idx>,<dir>,<stat>,<mode>,<mpty>,<traffic channel assigned>[,<number>,<type>[,<alpha>]]] ^PSLCC: <idx>,<dir>,<stat>,<mode>,<mpty>,<traffic channel assigned>[,<number>,<type>[,<alpha>]]] OK ERROR +CME ERROR
Write Command AT^SLCC=[<n>]	Response(s) OK ERROR +CME ERROR: <err>

Reference(s)	PIN						
SIEMENS	●	●					

Unsolicited Result Code

Unsolicited Call Status information

if the list of current calls is empty:

^SLCC:

if one or more calls are currently in the list:

^SLCC: <idx>,<dir>,<stat>,<mode>,<mpty>,<traffic assigned>[,<number>,<type>[,<alpha>]] channel
[^SLCC: <idx>,<dir>,<stat>,<mode>,<mpty>,<traffic assigned>[,<number>,<type>[,<alpha>]]] channel

[...]

^SLCC:

URC "**^SLCC**" displays the list of current calls as displayed with the execute command **AT^SLCC**. The list is displayed in the state it has at the time of display, not in the state it had when the signal was generated. The URC's occurrence indicates call status changes for any of the calls in the list of current calls. Please refer to [6.1](#) and [AT^SCFG](#) for further information about the configuration of this URC.

Event reporting can be enabled separately for each interface. Interface settings are saved with [AT&W](#) and can be displayed with [AT&V](#). Additionally, the URC presentation mode for the interface must be configured with [AT+CMER](#).

Depending on the value of [AT^SCFG](#) setting <sucs>, Indicator "**^SLCC**" will be issued (if configured with write command [AT^SLCC](#) and [AT+CMER](#))

- ✓ when a state transition ends in state "active" or in state "unknown" (if [AT^SCFG](#) setting <sucs>="restricted")
- ✓ when any state transition (including transitions beginning or ending in state "unknown") occurs in the list of active calls, or when a traffic channel is established (if [AT^SCFG](#) setting <sucs>="verbose").

If multiple displays of identical list configurations occur, this happens because of short intermediate states of the list, that have already been overridden by new transitions and states. Thus, it is guaranteed that the configuration displayed is always the current configuration at the time of the last display.

The list of active calls displayed with this URC will always be terminated with an empty line preceded by prefix "^SLCC:", in order to indicate the end of the list.

Command Description

The read command returns an indication whether event reporting is active for the current interface.

The exec command returns a list of current calls of ME. If command is successful, but no calls are available, no information response is sent to TE.

Use the write command to activate or deactivate event reporting for URC "**^SLCC**". Event reporting can be enabled separately for each interface. Interface settings are saved with **AT&W** and can be displayed with **AT&V**.

Parameter Description

<idx>^(num)

call identification number as described in GSM02.30 subclause 4.5.5.1;
this number can be used in **AT+CHLD** command operations

<n>^{(num)&W&V}

- 0 presentation of URC "**^SLCC**" disabled
- 1 presentation of URC "**^SLCC**" enabled

<dir>^(num)

- 0 mobile originated call (MOC)
- 1 mobile terminated call (MTC)

<stat>^(num)

state of the call

- 0 active
- 1 held
- 2 dialing (MOC)
- 3 alerting (MOC)
- 4 incoming (MTC)
- 5 waiting (MTC)
- 6 terminating: The call is not active anymore, but inband information is still available.
- 7 dropped: The call has been suspended by the network, but may be resumed later.

<mode>^(num)

bearer/teleservice

- 0 voice
- 1 data
- 2 fax
- 3 voice followed by data, voice mode (only in connection with single numbering scheme **AT+CSNS**)
- 4 alternating voice/data, voice mode (only in connection with single numbering scheme **AT+CSNS**)
- 5 alternating voice/fax, voice mode (only in connection with single numbering scheme **AT+CSNS**)
- 6 voice followed by data, data mode (only in connection with single numbering scheme **AT+CSNS**)
- 7 alternating voice/data, data mode (only in connection with single numbering scheme **AT+CSNS**)

8	alternating voice/fax, fax mode (only in connection with single numbering scheme AT+CSNS)
9	unknown
<mpty> ^(num)	
0	call is not one of multiparty (conference) call parties
1	call is one of multiparty (conference) call parties
<traffic channel assigned> ^(num)	
0	No traffic channel is available to the call
1	mobile has been assigned a traffic channel. It is now possible to send or receive inband information, e.g. to send DTMF tones (cf. AT+VTS), or to receive network announcements.
<number> ^(str)	phone number in format specified by <type>
<type> ^(num)	
145	type of address octect dialing string <number> includes international access code character '+'
129	otherwise
<alpha> ^(str)	Alphanumeric representation of <number> corresponding to the entry found in phone book; used character set should be the one selected with command AT+CSCS (Select TE Character Set).
	The maximum displayed length of <alpha> is 16 characters. If <alpha> has more than 16 characters, only the first 15 characters will be displayed. To indicate an overflow, a special character will be used as the 16th character. This will be a space if the character set selected with AT+CSCS is 'GSM', or 'E400' if the character set is 'UCS2'.
	Due to time constraints on the necessary evaluation of the phone book, this parameter may show a default value during early call phases (e.g. for <stat>= "dialing", "incoming" or "alerting"), even if a phone book entry is present for the number concerned.

Notes

- Teleservices other than voice, data, fax are not fully supported by ME. They are used only in connection with the handling for [AT+CSNS](#), and may therefore occur in parameter [**<mode>**](#) for mobile terminated calls.
- If a URC "[^SLCC](#)" in verbose mode (see [AT+SCFG](#)) has been buffered while the interface was in dedicated mode (depending on the settings of [AT+CMER](#) parameter [**<bfr>**](#)), each buffered event indicator will be output as a separate URC after the interface returns to idle mode.
- However, the output will deliver the list of current calls in the "current" state (at the time when the output is generated), possibly leading to multiple displays of identical list configurations.
- Some parameters of AT command [AT+CHLD](#), as well as some situations where the call status in the network changes very quickly (e.g. the transition between [**<stat>=**](#) "unknown", "dialing" and "alerting" for a call to a reachable subscriber within the registered network) may lead to quasi-simultaneous changes to the states of one or several calls in the list, possibly leading to multiple displays of identical list configurations.
- If multiple displays of identical list configurations occur, this happens because of intermediate states of the list, that have already been

overridden by new transitions and states. Thus, it is guaranteed that the configuration displayed in such cases is the current configuration at the time of the last display.

- It is adviseable to receive URC "**^SLCC**" on an interface that is not used for call initiation, if verbose output is configured. If only voice calls are expected, a setting of **AT^SM20=0** may be used alternatively in order to keep the call from blocking the interface.

Examples

EXAMPLE 1

```

^SYSSTART
at+cpin=9999
OK
+CREG: 2
+ CREG: 1, '0145', '0016'
at^sm20=0

We are now registered command
"ATD" for an outgoing voice call will
terminate immediately with response
"OK"

OK
atd"1234567" ;
We start a voice call.
OK
"OK" response is issued immediately
because of setting "^SM20=0"
^SLCC:
MO call starts, paging B-party
1,0,2,0,0,0,"1234567",129,"Called
Party"
^SLCC: End of current list
^SLCC: Traffic channel established,
1,0,2,0,0,1,"1234567",129,"Called network may now transmit network
Party" announcements, ME may now transmit
DTMF tones.
^SLCC: End of current list
^SLCC: Call is now ringing at B-Party
1,0,3,0,0,1,"1234567",129,"Called
Party"
^SLCC: End of current list
^SLCC: B-Party has accepted the call,
connection established
1,0,0,0,0,1,"1234567",129,"Called
Party"
^SLCC: End of current list
atd23456;
We start a second voice call.
OK
"OK" response is issued immediately
because another call is already active
(cf. ATD)
SLCC: The active call is automatically put on
hold, triggering the display of the list
1,0,1,0,0,0,"1234567",129, "Called
Party"

```

^SLCC: 2,0,2,0,0,1,"23456",129	The second call has already started before the indication for the held call could be displayed
^SLCC:	End of current list
^SLCC:	The identical list is displayed again, triggered by the start of the second voice call
1,0,1,0,0,0,"1234567",129,"Called Party"	
^SLCC: 2,0,2,0,0,1,"23456",129	The status of the second list entry has already been displayed with the previous URC
^SLCC:	End of current list
^SLCC:	The held call doesn't change status right now
1,0,1,0,0,0,"1234567",129,"Called Party"	
^SLCC: 2,0,3,0,0,1,"23456",129	The second call is now alerting the B-Party
^SLCC:	End of current list
^SLCC:	The held call doesn't change status right now
1,0,0,0,0,1,"1234567",129,"Called Party"	
^SLCC:	End of current list: the B-Party of the second call has not accepted the call in time, the second call has ended.
NO CARRIER	The second call has ended
^SLCC:	list is now empty: B-Party has ended the first call
NO CARRIER	The second call has ended
EXAMPLE 2	
^SLCC: 1,1,4,0,0,1,"1234567",129	Incoming call is signalled. Display is triggered by the incoming call, but the current status of the call at the time of display already comprises an active traffic channel.
^SLCC:	End of current list
RING	Incoming call is signalled.
^SLCC: 1,1,4,0,0,1,"1234567",129	The incoming call had a traffic channel assigned from the start. This second identical display is triggered by the traffic channel assignment.
	Since the traffic channel was already indicated in the previous URC, both instances of the URC contain identical information.
^SLCC:	End of current list
RING	Incoming call is signalled.

ata	Incoming call is accepted,
OK	call is established.
^SLCC: 1,1,0,0,0,1,'1234567',12 9	The call is now active.
^SLCC:	End of current list
ATH	Hang up the call.
OK	Hang up complete.
^SLCC :	The list of current calls is empty again

6.24 AT+CR Service reporting control

Syntax

Test Command AT+CR=?	Response(s) +CR: (list of supported<mode>s) OK ERROR
Read Command AT+CR?	Response(s) +CR: <mode> ERROR +CME ERROR
Write Command AT+CR=<mode>	Response(s) OK ERROR +CME ERROR

Reference(s)	PIN	USB					
GSM 07.07	●	●					

Intermediate Result Code

If enabled, an intermediate result code is transmitted at the point during connect negotiation when the TA has determined the speed and quality of service to be used, before any error control or data compression reports are transmitted, and before any final result code (e.g. CONNECT) appears.

+CR: <serv>

Command Description

Configures the TA whether or not to transmit an intermediate result code+CR: <serv> to TE when a call is being set up.

Parameter Description

<mode>^{(num)(&W)(&V)}

0(&F)	disable
1	enable

<serv>^(str)

"REL ASYNC" "GPRS- asynchronous non-transparent GPRS »

Notes

- The PLMN influences the second air interface (to the terminator), therefore another mode may be established from the network.
- Setting the value of <mode> to 1 may lead to connection failure, if the application (e.g. WinFax) waits for default result code/URC.

6.25 AT+CRC Set Cellular Result Codes for incoming call indication

Syntax

Test Command AT+CRC=?	Response(s) +CRC: (list of supported <mode>s) OK ERROR +CME ERROR
Read Command AT+CRC?	Response(s) +CRC: <mode> OK ERROR +CME ERROR
Write Command AT+CRC=[<mode>]	Response(s) OK ERROR +CME ERROR

Reference(s)	PIN	USB				
GSM 07.07	○	●				

Unsolicited Result Code

When enabled, an incoming call is indicated to the TE with unsolicited result code + CRING: <type> instead of the normal RING.

+CRING: <type>

Command Description

The command controls whether or not the extended format of incoming call indication is used.

Parameter Description

<mode>^{(num)&W&V}

[0]^(&F) disable extended format

1 enable extended format

<type>^(str)

“REL ASYNC” asynchronous non-transparent

“FAX” facsimile

“VOICE” voice

“GPRS” <PDP_type>, <PDP_addr>[, [<L2P>][,<APN>]] GPRS network request for PDP context activation

Note

- Setting the value of <mode> to 1 may lead to connection failure, if the application (e.g. WinFax) waits for default result code/URC.

6.26 AT+CSNS Single Numbering Scheme

Syntax

Test Command AT+CSNS=?	Response(s) +CSNS: (list of supported <mode>s) OK
---------------------------	---

Read Command AT+CSNS?	Response(s) +CSNS: <mode>
Write Command AT+CSNS=<mode>	Response(s) OK ERROR +CME ERROR

Reference(s)	PIN	USB					
GSM 07.07	○	●					

Command Description

The **AT+CSNS** command enables the ME to accept incoming calls when no bearer capability information is provided with the call, e.g. single numbering scheme calls or calls originating from analog devices.

Parameter Description

<mode>^(num)

- | | |
|--------------------|--|
| [0] ^(D) | Voice: Each call received without bearer element is assumed to be speech. |
| 2 | Fax: Each call received without bearer element is assumed to be an incoming fax. |
| 4 | Data: Each call received without bearer element is assumed to be a data call.

Please take into account that the bearer service parameters set with AT+CBST apply to all data calls including those received without bearer capability. |

Notes

- The command must be set before the call comes. By default, when you do not modify the settings, all calls received without bearer element are assumed to be voice.
- The setting will be automatically saved when you power down the GSM engine with **Table 2.3**, provided that PIN authentication has been done. This value will be restored when PIN authentication is done again.

6.27 AT^SCNI List Call Number Information

Syntax

Test Command AT^SCNI=?	Response(s) OK
Exec Command AT^SCNI	Response(s) <id>_<cs>_<number>_<type>]] [...] OK ERROR +CME ERROR: <err>

Reference(s)	PIN	USB					
SIEMENS	●	●					

Command Description

TA returns a list of current calls of ME.

Parameter Description

<id>^(num)

call identification number as described in GSM 02.30 [19] subclause 4.5.5.1; this number can be used in **AT+CHLD** command operations

1...7

<cs>^(num)

call status of respective call number (first parameter)

0 call hold

1 call in progress

2 waiting call

<number>^(str)

string type phone number in format specified by **<type>**

<type>^(num)

type of address octet in integer format; 145 when dialling string includes international access code character "+", otherwise 129

Note

- See also GSM 07.07: AT+CLCC

6.28 AT^SLCD Display Last Call Duration

Syntax

Test Command AT^SLCD=?	Response(s) OK ERROR +CME ERROR
Exec Command AT^SLCD	Response(s) ^SLCD: <time> OK ERROR +CME ERROR

Reference(s)	PIN	USB					
SIEMENS	●						

Command Description

TA returns last call duration or current call duration.

Parameter Description

<time>^(str)

Format is "hh:mm:ss", where characters indicate hours, minutes, seconds; E.g. 22:10:00 "22:10:00" Max value is 9999:59:59

6.29 AT^STCD Display Total Call Duration

Syntax

Test Command AT^STCD=?	Response(s) OK +CME ERROR
---------------------------	---------------------------------

Exec Command AT^STCD	Response(s) ^STCD: <time> OK +CME ERROR
-------------------------	--

	PIN	USB					
SIEMENS	●	●					

Command Description

TA returns total call duration (accumulated duration of all calls).

Parameter Description

<time>^(str)

Format is "hh:mm:ss", where characters indicate hours, minutes, seconds;
E.g. 22:10:00 "22:10:00" Max value is 9999:59:59

Note

- The Total Call Duration will not be reset by power off or other means.

7 NETWORK SERVICE COMMANDS

The AT commands described in this chapter are related to various network services. More commands related to this area can be found in chapter Supplementary Service Commands.

7.1 AT+COPN Read operator names

Syntax

Test Command	Response(s) OK
Exec Command AT+COPN	Response(s) + COPN: <numerichn>,<alphan> + COPN: ... OK

Reference(s)	PIN	USB					
GSM 07.07	●	●					

Command Description

TA returns the list of operator names from the ME. Each operator code **<numerichn>** that has an alphanumeric equivalent **<alphan>** in the ME memory is returned. See also: [AT+SPLM](#).

Parameter Description

<nuraericn>^(str)

Operator in numeric form; GSM location area identification number.

<alphan>^(str)

Operator in long alphanumeric format; can contain up to 16 characters.

7.2 AT+COPS Operator selection

This command can be used to query the present status of the ME's network registration and to determine whether automatic or manual network selection shall be used.

Automatic mode:

Lets the ME automatically search for the home operator. If successful the ME registers to the home network and enters the IDLE mode. If the home network is not found, ME goes on searching. If then a permitted operator is found, ME registers to this operator. If no operator is found the ME remains unregistered. Manual mode: Desired operator can be manually entered, using the [AT+COPS](#) write command syntax. If operator is found, ME registers to this operator immediately. If the selected operator is forbidden, the ME remains unregistered.

Manual/automatic:

In this mode, the ME first tries to find the operator that was manually entered. If the ME fails to register to this operator, then it starts to select automatically another network.

Syntax

Test Command AT+COPS=?	Response(s) +COPS:[list of supported:(<stat>, long alphanumeric <oper>, , numeric <oper>)][, list of supported <mode>s, list of supported <format>s] OK ERROR +CME ERROR
Read Command AT+COPS?	Response(s) + COPS : <mode>[,<format>[,<oper>]] OK ERROR +CME ERROR
Write Command	OK ERROR +CME ERROR

	PIN	USB				
	O					

Command Description

The test command returns a list of quadruplets, each representing an operator present in the network. Any of the formats may be unavailable and will then be an empty field (,,). The list of operators comes in the following order: Home network, networks referenced in SIM, and other networks.

The read command returns the current <mode> and the currently selected operator. If no operator is selected, <format> and <oper> are omitted.

The write command forces an attempt to select and register the GSM network operator. If the selected operator is not available, no other operator will be selected (except <mode>=4). The selected operator name format will apply to further read commands (+COPS?), too.

Parameter Description

<stat>^(num)

Status

- 0 unknown
- 1 operator available
- 2 operator current
- 3 operator forbidden

<oper>^(&v)

Operator

Parameter is stored non-volatile to the SIM. Operator as per <format>. The numeric format is the GSM Location Area Identification number which consists of a 3-digit country code plus a 2- or 3-digit network code.

<mode>^{(num)&V}

Parameter values 0 and 1 are stored non-volatile in the ME

0^(D) automatic mode; <oper> field is ignored

1 manual operator selection

Write command requires <oper>.<format> value shall be 2.

Read command returns the current `<mode>` and the currently selected `<oper>`. If no operator is selected, `<format>` and `<oper>` are omitted.

2 manual deregister from network and remain unregistered until `<mode>=0,1,4` is selected

3 set only `<format>` (for read command +COPS?)

4 automatic, manual selected; if manual selection fails, automatic mode (`<mode>=0`) is entered (`<oper>` field will be present)

`<format> (num)(&W)(&V)`

parameter can be stored non-volatile in the user profile using `AT&W`

0(&F) long format alphanumeric `<oper>`; up to 16 characters

2 numeric `<oper>`; GSM Location Area Identification number

Notes

- `AT+COPS` settings are effective over all interfaces of the SAMBA75.
- When using the `AT+COPS=?` command during an ongoing GPRS transfer, the transfer will be interrupted for up to 1 minute.

7.3 AT+CREG Network registration

Syntax

Test Command <code>AT+CREG=?</code>	Response(s) <code>+CREG: (list of supported <n>s)</code> OK
Read Command <code>AT+CREG?</code>	Response(s) <code>+CREG: <n>,<stat>[,<lac>,<ci>]</code> OK ERROR <code>+CME ERROR: <err></code>
Write Command <code>AT+CREG=[<n>]</code>	Response(s) OK ERROR <code>+CME ERROR: <err></code>

Reference(s)	PIN	USB					
GSM 07.07	○	●					

Unsolicited Result Codes

URC1

If `<n>=1` and there is a change in the ME network registration status:

`+CREG: <stat>`

URC2

If `<n>=2` and there is a change in the ME network registration status or a change of the network cell:

`+CREG: <stat>[, <lac>, <ci>]`

Command Description

Read command returns the URC presentation mode `<n>` and an integer `<stat>` that shows the registration status of the ME. The location information elements `<lac>` and `<ci>` are returned only when `<n>=2` and ME is registered to the network.

Use the write command to select the type of URC. Two types of URCs are available:

```
<n>=1: +CREG:<stat>
<n>=2: +CREG:<stat>[,<lac>,<ci>]
```

Parameter Description

<n>^{(num)(&W)(&V)(&F)}

- | | |
|-------|---|
| 0(&F) | disable URCs |
| 1 | enable URC +CREG:<stat> to report status of network registration |
| 2 | enable URC +CREG:<stat>[,<lac>,<ci>] to report status of network registration including location information. Please note that optional parameters will not be displayed during call. |

<stat>^{(num)(&V)}

- | | |
|---|--|
| 0 | Not registered, ME is currently not searching for new operator
There is a technical problem. User intervention is required. Yet, emergency calls can be made if any network is available.
Probable causes: |
|---|--|

- No SIM-card available
- No PIN entered
- No valid Home PLMN-Entry found on the SIM

- | | |
|---|----------------------------|
| 1 | Registered to home network |
|---|----------------------------|

- | | |
|---|---|
| 2 | Not registered, but ME is currently searching for a new operator. |
|---|---|

The ME searches for an available network. Failure to log in until after more than a minute may be due to one of the following causes:

- No network available or insufficient Rx level.
- The ME has no access rights to the networks available.
- Networks from the SIM list of allowed networks are around, but login fails due to one of the following reasons:
 - #11 ... PLMN not allowed
 - #12 ... Location area not allowed
 - #13 ... Roaming not allowed in this location area

After this, the search will be resumed (if automatic network search is enabled).

- The Home PLMN or an allowed PLMN is available, but login is rejected by the cell (reasons: Access Class or LAC).

If at least one network is available, emergency calls can be made.

- | | |
|---|---------------------|
| 3 | Registration denied |
|---|---------------------|

- If automatic network search is enabled:

Authentication or registration fails after Location Update Reject due to one of the following causes:

- #2 ... IMSI unknown at HLR
- #3 ... Illegal MS
- #6 ... Illegal ME

Either the SIM or the MS or the ME are unable to log into any network. User intervention is required. Emergency calls can be made, if any network is available.

- Only if manual network search is enabled:

Manual registration fails after Location Update Reject due to the following causes:

- #2 ... IMSI unknown at HLR
- #3 ... Illegal MS
- #6 ... Illegal ME
- #11 ... PLMN not allowed
- #12 ... Location area not allowed
- #13 ... Roaming not allowed in this location area

No further attempt is made to search or log into a net-work. Emergency calls can be made if any network is available.

4

Unknown

(not used)

5

Registered, roaming

The ME is registered at a foreign network (national or international network)

<lac>^(str)

Two byte location area code in hexadecimal format (e.g. "00C3" equals 193 in decimal).

<ci>^(str)

Two byte cell ID in hexadecimal format.

Note

- Optional parameters will not be displayed during a call.

Example

at+creg=2	Activates extended URC mode.
OK	
at+cops=0	Forces ME to automatically search network operator
OK	
+CREG: 2	URC reports that ME is currently searching.
+CREG: 1, "0145", "291A"	URC reports that operator has been found.

7.4 AT+CSQ Signal quality

Syntax

Test Command AT+CSQ=?	Response(s) +CSQ: (list of supported <rssi>s), (list of supported <ber>s) OK
Exec Command	Response(s) + CSQ: <rssi>,<ber> OK

Reference(s)	PIN	USB					
GSM 07.07	○	●					

Command Description

TA returns received signal strength indication **<rss>** and channel bit error rate **<ber>** from the ME.

Parameter Description

<rss>^(num)

0	-113dBm or less
1	-111 dBm
2..30	-109...-53 dBm
31	-51 dBm or greater
99	not known or not detectable

<ber>^(num)

To check the bit error rate there must be a call in progress to obtain realistic values. If no call is set up, there is no BER to be determined. In this case the indicated value may be 0 or 99, depending on the SIM card.

0..7	as RXQUAL values in the table in GSM 05.08 section 8.2.4.
99	not known or not detectable

Note

- After using network related commands such as AT+CCWA, AT+CCFC, AT+CLCK, users are advised to wait 3s before entering AT+CSQ. This is recommended to be sure that any network access required for the preceding command has finished.

7.5 AT^SMONC Cell Monitoring

Syntax

Test Command AT^SMONC=?	Response(s) OK
Exec Command AT^SMONC	Response(s) ^SMONC: <MCC>1,<MNC>1,<LAC>1,<cell>1,<BSIC>1,<chann>1,<RSSI>1,<C 1>1,<C2>1,<MCC>2,<MNC>2,<LAC>2,<cell>2,<BSIC>2,<chann>2,< RSSI>2,<C1>2,<C2>2, ... OK CME ERROR

Reference(s)	PIN	USB					
SIEMENS, 3GPPTS 05.08	●	●					

Command Description

The output of the exec command contains 9 values from a maximum of 7 base stations. The first base station is the serving cell.

Parameter Description

<MCC>^(num)

Mobile country code
3 digits, e.g. 232
000 not decoded

<MNC>^(num)

Mobile network code

3 digits, e.g.

003 000 not decoded

<LAC>^(num)

Location area code

4 digits, e.g. 3010

0000 not decoded

<cell>^(num)

Cell identifier

4 hexadecimal digits, e.g. 4EAF

0000 not decoded

<BSIC>^(num)

Base station identity code

2 digits, e.g. 32

00 not decoded

<chann>^(num)

ARFCN (Absolute Frequency Channel Number)

0 not decoded. In this case, all remaining parameters related to the same channel are neither decoded. For example, a non-existing cell appears as follows:
000,000,0000,0000,00,0,--

<RSSI>^(num)

Received signal level of the BCCH carrier (0..63). The indicated value is composed of the measured value in dBm plus an offset. This is in accordance with a formula specified in 3GPP TS 05.08

<C1>^(num)

Coefficient for base station reselection, e.g. 30. In dedicated mode, under certain conditions the parameter cannot be updated. In such cases a '-' is presented.

<C2>^(num)

Coefficient for base station reselection, e.g. 30. In dedicated mode, under certain conditions the parameter cannot be updated. In such cases a '-' is presented.

Note

- To some extent, the cell monitoring commands AT^MONI, AT^MONP and AT^MONC cover the same parameters. The receiving level, for example, can be queried with all three commands. Yet the resulting values may be slightly different, even though obtained over a time period of a few seconds. This is quite normal and nothing to worry about, as the cell information is permanently updated.

7.6 AT^MONI Monitor idle mode and dedicated mode

Syntax

Test Command AT^MONI=?	Response(s) ^MONI : (list of supported <period>s) OK
---------------------------	--

Exec Command AT^MONI	Response(s) See: 7.6.1 OK
Write Command AT^MONI=<period>	Response(s) See: 7.6.1 OK

Reference(s)	PIN	USB					
SIEMENS	○	●					

Command Description

The execute command can be used to retrieve the cell parameters of the serving/dedicated cell on request.

The write command can be used to retrieve information of the serving/dedicated cell automatically every <period> seconds. To stop the presentation type "AT" or "at".

Parameter Description

<period>^(num)

Display period in seconds

1...254

Notes

- The two header lines (see [7.6.1](#)) are output after every ten data lines.
- The length of following output lines exceeds 80 characters. Therefore a terminal program may draw a carriage return on a screen. However, this is not part of the response.

7.6.1 AT^MONI responses

ME is not connected:

- ME is camping on a cell and registered to the network:

Serving Cell	Dedicated channel
chann rs dBm PLMN LAC cell NCC BCC PWR RXLev C1	chann TS timAdv PWR
	dBm Q ChMod
1013 21 -71 00101 1001 0103 7 7 33 -105 33	No connection
- ME is camping on a cell but not registered to the network (only emergency call allowed):

Serving Cell	Dedicated channel
chann rs dBm PLMN LAC cell NCC BCC PWR RXLev C1	chann TS timAdv PWR
	dBm Q ChMod
1013 21 -71 00101 1001 0103 7 7 33 -105 33	Limited Service
- ME camping on a cell, but searching for a better cell (cell reselection):

Serving Cell	Dedicated channel
chann rs dBm PLMN LAC cell NCC BCC PWR RXLev C1	chann TS timAdv PWR
	dBm Q ChMod
1013 21 -71 00101 1001 0103 7 7 33 -105 33	Cell Reselection
- ME is searching and could not (yet) find a suitable cell:

Serving Cell	Dedicated channel
--------------	-------------------

chann rs dBm PLMN LAC cell NCC BCC PWR RXLev C1

I chann TS timAdv PWR
dBm Q ChMod

Searching

- e) ME is connected (Call in progress):

Serving Cell

I Dedicated channel

chann rs dBm PLMN LAC cell NCC BCC PWR RXLev C1

I chann TS timAdv PWR
dBm Q ChMod

1013 19 -76 00101 1001 0103 7 7 33 -105 33 I 1015 1 0 5 -76 0 S_HR

Columns for Serving Cell:

Column	Description
chann	ARFCN (Absolute Frequency Channel Number) of the BCCH carrier
rs	RSSI value 0 - 63 (RSSI = Received signal strength indication)
dBm	receiving level of the BCCH carrier in dBm
PLMN	PLMN ID code
LAC	location area code, see note below
cell	cell ID, see note below
NCC	PLMN colour code
BCC	base station colour code
PWR	maximal power level used on RACH channel in dBm
RXLev	minimal receiving level (in dBm) to allow registration
C1	coefficient for base station selection

Columns for Dedicated channel:

Column	Description
chann	ARFCN (Absolute Frequency Channel Number) of the TCH carrier Note: <chann> = h indicates frequency hopping.
TS	timeslot number
timAdv	timing advance in bits
PWR	current power level
dBm	receiving level of the traffic channel carrier in dBm
Q	receiving quality (0-7)
ChMod	channel mode (S_HR: Half rate, S_FR: Full rate, S_EFR: Enhanced Full Rate)

7.6.2 Service states

Depending on the service state, an additional textual output is generated (refer also to the response examples):

- 'Searching' - The MS is searching, but could not (yet) find a suitable cell. This output appears after restart of the MS or after loss of coverage.
- 'No connection' - The MS is camping on a cell and registered to the network. The service state is 'idle', i.e. there is no connection established or a dedicated channel in use.
- 'Cell Reselection' - The MS has not yet lost coverage but is searching for a better cell, since the cell reselection criterion is fulfilled.
- 'Limited Service' - The MS is camping on a cell but not registered to the network. Only emergency calls are allowed. The MS enters this state, for example, when
 - no SIM card is inserted, or PIN has not been given,
 - neither Home PLMN nor any other allowed PLMN are found,

- registration request was not answered or denied by the network (use command [AT+CREG](#) to query the registration status),
- authentication failed.

7.6.3 Notes

- The parameters LAC and cell are presented as hexadecimal digits, the remaining parameters are composed of decimal digits.
- If the radio cell changes during a connection, the parameters PWR, RXLev and C1 of the 'Serving Cell' part cannot be updated under certain conditions and therefore, are displayed as "-" (for conditions see also [AT+CREG](#)). This is because the MS does not update the cell selection and reselection parameters since, in this mode, they are not relevant for operation. When the connection ends, and the mobile is back to IDLE mode, correct values will be given.
- If the radio cell changes during a connection, it normally takes 1 or 2 seconds to update the parameters cell, NCC and BCC. Until the information is received from the new base station, the default values will be shown instead: cell="0000", NCC="-", BCC="-".

If the BS supports frequency hopping during a connection, the dedicated channel (parameter chann) is not stable. This mode is indicated by chann = 'h'.

- To some extent, the cell monitoring command [AT^SMONC](#) covers the same parameters. The receiving level, for example, can be queried with both commands. Yet the resulting values may be slightly different, even though obtained over a time period of a few seconds. This is quite normal and nothing to worry about, as the cell information is permanently updated.

7.7 AT^MONP Monitor neighbour cells

Syntax

Test Command AT^MONP=?	Response(s) ^MONP: (list of supported <period>s) OK
Exec Command AT^MONP	Response(s) See: 7.7.1 OK
Write Command AT^MONP=<period>	Response(s) See: 7.7.1 OK

Reference(s)	PIN	USB				
SIEMENS	○	●				

Command Description

This command can be used to obtain information of up to six neighbour cells on request.

This command can be used to retrieve information of up to six neighbour cells automatically every n seconds. To stop the presentation type "at" or "AT".

Parameter Description

<period>^(num)

Display period in seconds

1...254

Note

- Due to the fact that not all necessary information of the neighbour cells can be decoded during a connection, there are several constraints to be considered:
 - Only neighbour cells that have already been visible in IDLE mode will be further updated, as long as they are still included in the list.
 - Though new neighbour cells can be added to the list (e.g. due to handover), their C1 and C2 parameters cannot be displayed until the connection is released. In this case "-" is presented for C1 and C2.
 - To some extent, the cell monitoring command **AT^SMONC** covers the same parameters. The receiving level, for example, can be queried with both commands. Yet the resulting values may be slightly different, even though obtained over a time period of a few seconds. This is quite normal and nothing to worry about, as the cell information is permanently updated.

7.7.1 **AT^MONP** responses

Response of **AT^MONP** (Example):

Chann	rs	dBm	MCC	MNC	BCC	C1	C2
653	26	-84	262	07	0	22	22
660	20	-90	262	07	3	16	16
687	19	-91	262	07	1	15	15
678	14	-96	262	07	3	10	10
671	14	-96	262	07	1	10	10
643	10	-100	262	07	7	6	6

Column	Description
chann	ARFCN (Absolute Radio Frequency Channel Number) of the BCCH carrier RSSI value 0 - 63
rs	RSSI value 0 - 63 (RSSI = Received signal strength indication)
dBm	receiving level in dBm
MCC	Mobile Country Code (first part of the PLMN code)
MNC	Mobile Network Code (second part of the PLMN code)
BCC	Base Station colour code
C1	cell selection criterion
C2	cell reselection criterion

7.8 AT^SMONG GPRS Monitor

Syntax

Test Command AT^SMONG=?	Response(s) ^SMONG: (list of supported <table>s), (list of supported <period>s) OK
Exec Command AT^SMONG	Response(s) GPRS Monitor Cell Info Table (see: 7.7.1) OK

Write Command AT^SMONG=<table>[,<period>]	Response(s) ^SMONG: GPRS Monitor Cell Info Table (see: 7.7.1) OK +CME ERROR
--	---

Reference(s)	PIN	USB					
	•						

Command Description

The execute command can be used to retrieve GPRS specific cell information directly on request. The cell data will be output only once on a single line.

The write command can be used to retrieve GPRS specific cell information directly on request or automatically every n seconds. To stop the presentation type "at" or "AT".

Parameter Description

<table>^(num)

1 Cell Info Table

<period>^(num)

Display period in seconds

If <period> is omitted the cell data will be presented only once on a single line (as if Execute command was issued).

If <period> is given, the cell data will be listed repeatedly on 10 data lines. Every 10th data line is followed by the header, simply to repeat the column titles.

1...100

Note

- For compatibility with earlier products and to support legacy applications, often any input character will stop the periodic output of the write command. But since this applies only in certain cases (depending on the settings of chapter [3.9](#) it is recommended to always use "at" or "AT".

7.8.1 AT^SMONG Cell Info Table

Example output for [AT^SMONG](#):

GPRS Monitor

BCCH	G	PBCCH	PAT	MCC	MNC	NOM	TA	RAC #	Cell #
0637	1	-	4	234	05	2	00	OB	

Columns of the cell info table:

Column	Description
BCCH	ARFCN of BCCH carrier
G	GPRS supported ("1") or not supported "-"
PBCCH	If PBCCH is present, indication of ARFCN, else "-" or if Frequency Hopping is used "H"
PAT	Priority Access Threshold (GSM Rec. 04.08 /10.5.2.37b)
0	Packet access is not allowed in the cell
1	Spare, shall be interpreted as "000" (packet access not allowed)
2	Spare, shall be interpreted as "000" (packet access not allowed)
3	Packet access is allowed for priority level 1
4	Packet access is allowed for priority level 1 to 2
MCC	Mobile Country Code
MNC	Mobile Network Code

NOM	Network Operation Mode (1 ...3)
TA	Timing Advance Value
RAC	Routing Area Code (as hexadecimal value)

7.9 AT^SALS Alternate Line Service

The **AT^SALS** command is designed to support Alternate Line Service. This allows the subscriber to use two voice numbers on the same SIM card (service requires a dual line SIM card).

Syntax

Test Command AT^SALS=?	Response(s) ^SALS: (list of supported <^SALS>s), (list of supported <line>s) OK
Read Command AT^SALS?	Response(s) ^SALS: <^SALS>,<line> OK ERROR
Write Command AT^SALS=<^SALS>[,<line>]	Response(s) OK ERROR

Reference(s)	PIN	USB					
SIEMENS	●	●					

Unsolicited Result Code

If switched on with <^SALS>=1:

Indicates the line used by an incoming call.

Command Description

The read command returns the presentation mode of <^SALS> and the currently selected <line>. The write command enables or disables the presentation mode of <^SALS> and selects the preferred <line>.

Parameter Description

<^SALS>^(num)

view

Controls the presentation mode of the URC "^\\$ALS" which indicates the line number used by an incoming call:

0(&F) Disables indication of the called line

1 Enables indication of the called line

<line>^(num)

Selects the line to be used for outgoing calls.

[1] ALSLine1

2 ALS Line 2

Notes

- The selected <line> will be saved at non-volatile Flash memory and thus retained after Power Down.
- The <line> will be reset by **AT&F** and **ATZ** and afterwards saved at non-volatile memory too.

- The `<^sals>` will be reset after Power Down as well as by `ATZ` or `AT&F`.
- If a non ALS SIM is inserted, the `<line>` will be reset to line 1 as well.

Example

<code>at^sals=1, 1</code>	Line 1 has been selected for outgoing calls. " <code>^SALS</code> " URC is enabled.
<code>ring</code>	You receive a notification that you have an incoming call on line 2.
<code>^SALS: 2</code>	

7.10 AT^SHOM Display Homezone

Syntax

Test Command <code>AT^SHOM=?</code>	Response(s)
Exec Command <code>AT^SHOM</code>	Response(s) <code>^SHOM: <homezonestate></code> OK ERROR

Reference(s)	PIN	USB					
SIEMENS	○	●					

Command Description

TA returns homezone state. Result is valid only, if network registration state `<stat>` is 1 (registered) (see [AT+CREG](#)).

Feature is available only for supported network operators (Viag, One2One, Orange and LCI) and requires a suitable SIM card. If the homezone feature is not supported by the network operator or SIM card, result is always 0.

Parameter Description

`<homezonestate>`^(num)

- | | |
|---|---------------------------|
| 0 | ME is out of Homezone |
| 1 | ME is within the Homezone |

7.11 AT^SPLM Read the PLMN list

Syntax

Test Command <code>AT^SPLM=?</code>	Response(s) OK ERROR +CME ERROR: <err>
Exec Command <code>AT^SPLM</code>	Response(s) <code>^SPLM: <numeric>, long <alpha>[...]</code> OK ERROR +CME ERROR

Reference(s)	PIN	USB					
SIEMENS	●	●					

Command Description

TA returns the list of operator names from the ME. Each operator code <numeric> that has an alphanumeric equivalent <alpha> in the ME memory is returned.

Parameter Description

<numeric>^(str)

Operator in numeric form; GSM location area identification number

<alpha>^(str)

Operator in long alphanumeric format; can contain up to 16 characters

Note

- See also GSM 07.07: [AT+COPN](#), [AT+COPS](#)

7.12 AT^SPLR Read entry from the preferred operators list

Syntax

Test Command AT^SPLR=?	Response(s) ^SPLR: (list of supported) <indexa>s OK ERROR +CME ERROR: <err>
Write Command AT^SPLR=<index1>[,<index2>]	Response(s) R: <index1><oper> : <index2><oper> OK ERROR +CME ERROR: <err>

Reference(s)	PIN	USB					
SIEMENS	●	●					

Command Description

The test command returns the whole index range supported by the SIM.

The write command returns used entries from the SIM list of preferred operators with <indexa> between <index1> and <index2>. If <index2> is not given, only entry at <index1> is returned.

Parameter Description

<index1>^(num)

Location number to start reading from

<index2>^(num)

Location number where to stop reading

<indexa>^(num)

Index range supported by the SIM card (between <index1> and <index2>)

<oper>^(str)

Operator in numeric form; GSM location area identification number

Note

- See also GSM 07.07: [AT+CPOL](#)

7.13 AT^SPLW Write an entry to the preferred operators list

Syntax

Test Command AT^SPLW=?	Response(s) ^SPLW: (list of supported) <index>s OK ERROR +CME ERROR:
Write Command AT^SPLW=<index>[,<oper>]	Response(s) OK ERROR +CME ERROR: <err>

Reference(s)	PIN	USB				
SIEMENS	•	•				

Command Description

Test command returns the whole index range supported by the SIM

Write command writes an entry to the SIM list of preferred operators at location number <index>. If <index> is given but <oper> is left out, the entry is deleted. If <oper> is given but <index> is left out, <oper> is inserted in the next free location.

Parameter Description

<index>^(num)

location number

<oper>^(str)

Operator in numeric format (GSM Location Area Identification number which consists of a 3-digit country code plus a 2- or 3-digit network code).

Note

- See also GSM 07.07: AT+CPOL

8 SUPPLEMENTARY SERVICE COMMANDS

The AT commands described in this chapter are related to the Supplementary Services offered by the GSM network.

8.1 AT+CACM Accumulated call meter (ACM) reset or query

Syntax

Test Command AT+CACM=?	Response(s) OK
Read Command AT+CACM?	Response(s) +CACM: <acm> OK ERROR +CME ERROR: <err>
Write Command AT+CACM=[<passwd>]	Response(s) OK ERROR +CME ERROR: <err>

Reference(s)	PIN	USB					
GSM 07.07	•	•					

Command Description

The read command returns the current ACM value.

The write command resets the Advice of Charge related to the accumulated call meter (ACM) value in SIM file EF(ACM). ACM contains the total number of home units for both the current and preceding calls.

Parameter Description

<acm>^(str)

Three bytes of the current ACM value in hexadecimal format (e.g. "00001E" indicates decimal value 30) 000000 - FFFFFF.

<passwd>^(str)

SIM PIN2

8.2 AT^SACM Advice of charge and query of ACM and ACMmax

Syntax

Test Command AT^SACM=?	Response(s) ^SACM:(list of supported <n>s) OK
Exec Command AT^SACM	Response(s) ^SACM: <n>,<acm>,<acmMax> OK ERROR +CME ERROR: <err>

Write Command AT^SACM=<n>	Response(s) OK ERROR +CME ERROR: <err>
------------------------------	---

Reference(s)	PIN	USB					
SIEMENS	•	•					

Unsolicited Result Code

+CCCM: <ccm>

When activated, an unsolicited result code is sent when the CCM value changes, but not more often than every 10 seconds.

Command Description

The execute command can be used to query the current mode of the Advice of Charge supplementary service, the SIM values of the accumulated call meter (ACM) and accumulated call meter maximum (ACMmax).

The write command enables or disables the presentation of unsolicited result codes to report the call charges.

Parameter Description<n>^{(num)(&W)(&V)}[0]^(&F) suppress unsolicited result code

1 display unsolicited result code

<acm>^{(str)(W)}

Three bytes of the current ACM value in hexadecimal format FFFFFF (e.g. "00001E" indicates decimal value 30) 000000-

<acnmax>^{(str)(SV)}

Three bytes of the max. ACM value in hexadecimal format disable ACMmax feature 000001-FFFFFF (e.g. "00001E" indicates decimal value 30) 000000

<ccm>^(str)

Three bytes of the current CCM value in hexadecimal format (e.g. "00001E" indicates decimal value 30); bytes are coded in the same way as ACMmax value in the SIM 000000-FFFFFF

Notes

- When you power down or reset the ME with **AT+CFUN=1,1** the URC presentation mode will be reset to its default. To benefit from the URC it is recommended to have the setting included in the user profile saved with **AT&W**, or to select <n>=1 every time you reboot the ME.
- See also GSM07.07: **AT+CACM**, **AT+CAMM**, **AT+CAOC**.

8.3 AT+CAMM Accumulated call meter maximum (ACMmax) set or query

Syntax

Test Command AT+CAMM=?	Response(s) OK
---------------------------	-------------------

Read Command AT+CAMM?	Response(s) +CAMM: <acmmmax> OK ERROR +CME ERROR: <err>
Write Command AT+CAMM=[<acmmmax>[,<passwd>]]	Response(s) OK ERROR +CME ERROR: <err>

Reference(s)	PIN	USB					
GSM 07.07	●	●					

Command Description

The read command returns the current ACMmax value.

The write command sets the Advice of Charge related to the accumulated call meter maximum value in SIM file EF (ACMmax). ACMmax contains the maximum number of home units allowed to be consumed by the subscriber.

Parameter Description

<acmmmax>^(str)

Three bytes of the max. ACM value in hexadecimal format (e.g. "00001E" indicates decimal value 30) 000000 disable ACMmax feature 000001-FFFFF.

<passwd>^(str)

SIMPIN2

8.4 AT+CAOC Advice of Charge information

Syntax

Test Command AT+CAOC=?	Response(s) +CAOC: (list of supported <mode>s) OK
Read Command AT+CAOC?	Response(s) +CAOC: <mode> OK
Exec Command	Response(s) ERROR +CME ERROR: <err> If <mode>=0, TA returns the current call meter value: +CAOC: <ccm> OK
Write Command AT+CAOC=[<mode>]	Response(s) ERROR +CME ERROR: <err> If <mode>=0, TA returns the current call meter value. OK

Reference(s)	PIN	USB					
GSM 07.07	●	●					

Command Description

Execute command returns the current call meter value.

The write command sets the Advice of Charge supplementary service function mode.

Parameter Description

<mode>^{(num)&(V)}

0 query CCM value

<ccm>^(str)

Three bytes of the current CCM value in hexadecimal format (e.g. "00001E" indicates decimal value 30); bytes are similarly coded as ACMmax value in the SIM 000000-FFFFF.

8.5 AT+CCUG Closed User Group

Syntax

Test Command AT+CCUG=?	Response(s) +CCUG: list of supported <n>, range of supported <index>, range of supported <info> OK ERROR +CME ERROR
Read Command AT+CCUG?	Response(s) +CCUG: <n>,<index>,<info> OK ERROR +CME ERROR
Write Command AT+CCUG=[[<n>][,<index>][,<info>]]	Response(s) OK ERROR +CME ERROR

Reference(s)	PIN	USB					
GSM 07.07, GSM 02.85, GSM 03.85, GSM 04.85	●	●					

Command Description

The Test command returns the supported parameters.

The Read command returns if the Explicit CUG invocation is activated (in parameter <n>), which CUG <index> is chosen, and if Preferential Group or Outgoing Access is suppressed (in parameter <info>).

The write command serves to activate or deactivate the explicit CUG invocation, to set the desired index, and to specify if Preferential Group or Outgoing Access shall be suppressed.

Parameter Description

<n>^(num)

explicit CUG invocation options

0^(D) Deactivate explicit CUG invocation

1 Activate explicit CUG invocation

<index>^(num)

0-9 explicit selection of CUG index

10^(D) No index (preferred CUG taken from subscriber data)

<info>^(num)

state of the call

- 0(D) no information
- 1 suppress outgoing access
- 2 suppress preferential CUG
- 3 Suppress preferential CUG and Outgoing Access.

Notes

- The active settings for omitted parameters are retained without changes.
- Explicit CUG invocation means that at each call setup, CUG information is added to the called number.
- Upon delivery, settings are predefined with
 $\langle n \rangle = 0$,
 $\langle index \rangle = 10$,
 $\langle info \rangle = 0$.
- These delivery defaults cannot be recalled automatically.
- When starting a call with **ATD**, Parameter 'G' or 'g' of command **ATD** will have no effect if the option selected for this single call is identical to the option already selected with **AT+CCUG**.
- Current settings are saved in the ME automatically.
- ATZ or AT&F do not influence the current settings.
- Some combinations of parameters may lead to rejection of CUG calls by the network. For more information, please consult GSM 04.85

8.6 AT+CCFC Call forwarding number and conditions control

Syntax

Test Command AT+CCFC=?	Response(s) +CCFC: (list/range of supported <reason> s) OK
Write Command AT+CCFC= reason , <mode> [, <number> [, <type> [, <class> [, <time>]]]]	Response(s) if <mode> is not equal 2 and command successful: OK if <mode> = 2, <reason> is not equal 2 and command successful: + CCFC: <status> , <class> [, <number> , <type>] if <mode> = 2, <reason> = 2 and command successful: + CCFC: <status> , <class> [, <number> , <type> , <time>] OK If error is related to ME functionality +CME ERROR

Reference(s)	PIN	USB				
GSM 07.07, GSM 02.04, GSM 02.82, GSM 03.82, GSM 04.82	○	●				

Command Description

The Test command returns the supported parameters.

The write command controls the call forwarding supplementary service. Registration, erasure, activation, deactivation and status query are supported.

Parameter Description

<reason>^(num)

reason for call forwarding

- 0 unconditional
- 1 mobile busy
- 2 no reply
- 3 not reachable
- 4 all call forwarding (includes reasons 0,1,2 and 3)
- 5 all conditional call forwarding (includes reasons 1, 2 and 3)

<mode>^(num)

network operation to be performed for Supplementary service "call forwarding"

- 0 disable call forwarding (disable service)
- 1 enable call forwarding (enable service)
- 2 query status of call forwarding (query service status)
- 3 register <number> and activate call forwarding (register service)
- 4 erase <number> and deactivate call forwarding (erase service)

<number>^(str)

string type phone number of forwarding address in format specified by <type>. If you select <mode> = 3, the phone <number> will be registered in the network. This allows you to disable/enable CF to the same destination without the need to enter the phone number once again. Depending on the services offered by the provider the registration may be mandatory before CF can be used. The number remains registered in the network until you register another number or erase it using <mode> = 4.

<type>^(num)

type of address octect

- 145 dialling string <number> includes international access code character '+'
- 129 otherwise

<class>^(num)

integer or sum of integers each representing a class of information, i.e. a bearer service, telecommunication service or bearer service group as defined in "GSM 02.04"

- | | |
|---|-----------------------------|
| 1 | voice |
| 2 | data |
| <class> 2 (data) comprises all those <class> values between 16 and 128, that are supported both by the network and the MS. This means, a setting made for <class> 2 applies to all remaining data classes (if supported). In addition, you can assign a different setting to a specific class. For example, you can activate Call Forwarding for all data classes, but deactivate it for a specific data class. | |
| 4 | fax |
| [7] | voice, data and fax (1+2+4) |
| 8 | SMS |
| 16 | data circuit sync |
| 32 | data circuit async |
| 64 | dedicated packet access |

128	dedicated PAD access
1...[7]...255	combination of some of the above classes. For example, the default setting 7 represents the sum of the integers 1, 2 and 4 (CF for voice, data and fax). The value 255 covers all classes. If the <class> parameter is omitted, the default value 7 is used.
<time> ^(num)	
5...[20]...30	time to wait before call is forwarded, rounded to a multiple of 5 sec. (only for <reason>=no reply)
<status> ^(num)	
0	Call Forwarding not active
1	Call Forwarding active

Notes

- You can register, disable, enable and erase <reason> 4 and 5 as described above. However, querying the status of <reason> 4 and 5 with **AT+CCFC** will result in an error ("CME error: Operation not supported"). As an alternative, you may use the **ATD** command followed by *'# codes to check the status of these two reasons. See [List of *# Codes](#) for a complete list of *# GSM codes. See also examples below.
- Most networks will not permit registration of new parameters for conditional call forwarding (reasons 1,2,3,5) while unconditional call forwarding is enabled.
- The **AT+CCFC** command offers a broad range of call forwarding options according to the GSM specifications. However, when you attempt to set a call forwarding option which is not provisioned or not yet subscribed to, the setting will not take effect regardless of the response returned. The responses in these cases vary with the network (for example "OK", "Operation not allowed", "Operation not supported" etc.). To make sure check the call forwarding status with <mode>=2.
- Some networks may choose to have certain call forwarding conditions permanently enabled (e.g. forwarding to a mailbox if the mobile is not reachable). In this case, erasure or deactivation of call forwarding for these conditions will not be successful, even if the CCFC request is answered with response "OK".
- The command has been implemented with the full set of <class> parameters according to GSM 07.07. For actual applicability of SS "call forwarding" to a specific service or service group (a specific <class> value) please consult table A.1 of GSM 02.04.
- There is currently no release of GSM standard "GSM 02.04", in which the "Call Forwarding" Supplementary Service is defined as applicable to SMS services.

Example

Please note that when you configure or query call forwarding without specifying any classes, the settings will refer to classes 1, 2 and 4 only (=default). The handling of classes is equivalent to **AT+CLCK**.

- To register the destination number for unconditional call forwarding (CFU):

```
at+ccfc=0,3,"+4 93012345678",145
```

```
OK
```

The destination number will be registered for voice, data and fax services (default <class> 7).

In most networks, the registration will also cause call forwarding to be activated for these `<class>` values.

- To query the status of CFU without specifying `<class>`:

```
at+ccfc=0,2
+CCFC: 1,1,"+493012345678",145
+CCFC: 1,2,"+493012345678",145
+CCFC: 1,4,"+493012345678",145
OK
```

- To deactivate CFU without specifying `<class>`:

```
at+ccfc=0,0
OK
```

To check whether CFU was successfully deactivated (note that the destination number remains registered in the network when you disable CFU):

```
at+ccfc=0,2
+CCFC: 0,1,"+493012345678",145
+CCFC: 0,2,"+493012345678",145
+CCFC: 0,4,"+493012345678",145
OK
```

- To erase the registered CFU destination number:

```
at+ccfc=0,4
OK
```

Now, when you check the status, no destination number will be indicated:

```
at+ccfc=0,2
+CCFC: 0,1
+CCFC: 0,2
+CCFC: 0,4
OK
```

To query the status of CFU for all classes:

```
at + ccfc = 0,2,, ,255
```

```
+CCFC:0,1
+CCFC:0,2
+CCFC:0,4
+CCFC:0,8
+CCFC:0,16
+CCFC:0,32
+CCFC:0,64
+CCFC:0,128
OK
```

- `<reason>` 4 or 5 cannot be used to query the status of all call forwarding reasons (see also notes above):

```
at+ccfc=4,2
+CME error: operation not supported
at+ccfc=5,2
+CME error: operation not supported
```

8.7 AT+CCWA Call Waiting

This command controls the "Call Waiting" supplementary service according to GSM 02.83. Activation, deactivation and status query are supported.

Syntax

Test Command AT+CCWA=?	Response(s) +ccwa:(list of supported <n>s) OK
AT+CCWA?	+CCWA:<n> OK
AT+CCWA=[[<n>][,<mode>][,<class>]]	if <mode> is not equal 2 and command successful: OK if <mode>= 2 and command successful: +CCWA: <status>,<class> [+CCWA: <status>,<class>] [+CCWA: ...] OK If error is related to ME functionality +CME ERROR

Reference(s)	PIN	USB					
GSM 07.07, GSM 02.04, GSM 02.83, GSM 03.83, GSM 04.83	●	●					

Unsolicited Result Codes

URC1

Indication of a call that is currently waiting and can be accepted.

+CCWA: <calling number>,<type of number>,<class>,<CLI validity>

If <n>=1 and the call waiting supplementary service is enabled in the network, URC "+CCWA" indicates a waiting call to the TE. It appears while the waiting call is still ringing.

URC 2

Indication of a call that has been waiting.

If <n>=1 and the call waiting supplementary service is enabled in the network, this URC indicates that a waiting call rang when the ME was in online mode during a CSD call, but the calling party hung up before the ME went back to command mode.

Command Description

The test command returns the list of supported "<n>"s.

The read command returns the current value of parameter <n>.

The write command controls the call waiting supplementary service. Activation, deactivation and status query are supported.

Parameter Description

<n>^(num)

Switch URCs "+CCWA" and "ASCWA" for call waiting on/off

0 Disable display of URCs "+CCWA" and

1 Enable display of URCs "+CCWA" and "

<mode>^(num)

Network operation to be performed for Supplementary service call waiting

0 Disable call waiting (disable service)

- 1 Enable call waiting (enable service)
- 2 Query status of call waiting (query service status)

<class>^(num)

Integer or sum of integers each representing a class of information, i.e. a bearer service, telecommunication service or bearer service group as defined in "GSM 02.04".

In the write command, parameter **<class>** specifies the class of the active call during which an incoming call of any class is to be regarded as a waiting call.

In URC "+CCWA: <calling number>,<type of number>,<class>,<CLI validity>", parameter **<class>** specifies the class of the waiting call.

1	voice	<p><class> 2 (data) comprises all those <class> values between 16 and 128, that are supported both by the network and the MS. This means, a setting made for <class> 2 applies to all remaining data classes (if supported). In addition, you can assign a different setting to a specific class. For example, you can activate call waiting for all data classes, but deactivate it for a specific data class.</p>
2	data	
4	fax	
8	SMS	
16	data circuit sync	
32	data circuit async	
64	dedicated packet access	
128	dedicated PAD access	
1...[7]...255	Combination of some of the above classes. For example, the default setting 7 represents the sum of the integers 1, 2 and 4 (CF for voice, data and fax). The value 255 covers all classes. If parameter "class" is omitted, the default value 7 is used.	

<status>^(num)

- 0 Call waiting service is not active
- 1 Call waiting service is active

<calling number>^(str)

Phone number of waiting caller in the format specified by parameter **<type of number>**.

<type of number>^(num)

Type of address octet in integer format (refer to GSM 04.08, subclause 10.5.4.7)

- 145 **<calling number>** includes international access code character '+'
- 129 Otherwise

<CLIvalidity>^(num)

- 0 CLI valid
- 1 CLI has been withheld
- 2 CLI is not available

Notes

- If the active call is a CSD call, and a waiting call is received, then the ME produces a BREAK while still in online mode, and displays
 - the +CCWA URC (as above) when the ME goes back to command mode while the waiting call is still active and can be accepted;
 - or the ^SCWA URC (as above) when the ME goes back to command mode after the waiting call has ended.
- With the **AT+CHLD** command, it is possible to establish a multiparty call or to set the active voice call on hold and then accept a waiting voice call (not possible with fax and data call). See also **AT+CHLD**
- Users should be aware that if call waiting is activated (**<mode>=1**), the presentation of URCs needs to be enabled, too (**<n>=1**).
 - Otherwise, on the one hand, awaiting caller would be kept waiting due to lack of BUSY signals, while, on the other hand, the waiting call would not be indicated to the called party.
 - The **AT+CCWA** command offers a broad range of options according to the GSM specifications. However, when you attempt to enable call waiting for a **<class>** for which the service is not provisioned or not supported, the setting will not take effect regardless of the response returned. The responses in these cases vary with the network (for example "OK", "Operation not allowed", "Operation not supported" etc.). To make sure check the current call waiting settings with **<mode>=2**.
 - The **AT+CCWA** command has been implemented with the full set of **<class>** parameters according to GSM 07.07. For actual applicability of SS call waiting to a specific service or service group (a specific **<class>** value) please consult table A.1 of GSM 02.04.
 - Despite the specifications stated in GSM 02.04 call waiting is not handled uniformly among all networks: GSM 02.04, Annex A, provides the following specification:
 - "The applicability of call waiting refers to the telecommunication service of the active call and not of the waiting call. The incoming, waiting, call may be of any kind." Nevertheless, networks do differ on the actual implementation of the service. For example, the activation of call waiting for **<class> 4**, "fax", causes some networks to send a call waiting indication if a call "of any kind" comes in during an active fax call, but others may (with the same settings active) indicate a waiting fax call during any kind of active call. Thus, the only reliable way to receive or prevent a call waiting indication under any circumstances and in any network, is to activate or deactivate call waiting for all tele- and bearer services (**<class> 255**).

Examples

EXAMPLE 1

Parameter **<n>**

at+ccwa=1	To enable the presentation of the URC
OK	

EXAMPLE 2

Parameter **<mode>**

at+ccwa=1	To activate the supplementary service in the network for voice, data, and fax calls (default classes). Note that parameter <n> is left out. In this case, the current value of <n> will be retained.
OK	

at+ccwa=,2	To query the network status of call waiting for default classes.
at+ccwa=1,1	Call Waiting is activated during voice calls.
at+ccwa=1,2	Call Waiting is activated during data calls.
at+ccwa=1,4	Call Waiting is activated during fax calls.
OK	

EXAMPLE 3Parameter **<class>**

AT+CCWA=,0,1	To deactivate call waiting for voice calls.
OK	

8.8 AT+CHLD Call Hold and Multiparty**Syntax**

Test Command AT+CHLD=?	Response(s) OK
Write Command AT+CHLD=[<n>]	Response(s) OK ERROR +CME ERROR: <err>

Reference(s)	PIN	USB					
	●	●					

Command Description

TA controls the Supplementary Services Call Hold and Multiparty. Calls can be put on hold, recovered, released, and added to a conversation.

Like for all Supplementary Services, the availability and detailed functionality of Call Hold and Multiparty services depends on the configuration of the GSM network. The SAMBA75 can only request the service, but the network decides whether and how the request will be answered.

Parameter Description<n>^(num)

- 0 Release all held calls or set User Determined User Busy (UDUB) for a waiting call:
 - If a call is waiting, release the waiting call. The calling party will receive a "BUSY" indication (Supplementary Service User Determined User Busy "UDUB")
 - Otherwise, terminate all held calls (if any).
- 1 Terminate all active calls (if any) and accept "the other call" as the active call:
 - If a call is waiting, the waiting call will be accepted.
 - Otherwise, if a held call is present, the held call becomes active.
- 1X Terminate a specific call X (X= 1-7). The call may be active, held or waiting. The remote party of the terminated call will receive a "NO CARRIER" indication. Parameter X is the call number <idx> of the targeted call in the list of current calls available with AT command **AT+CLCC**.

- 2 Place all active calls on hold (if any) and accept "the other call" as the active call:
 - If a call is waiting, the waiting call will be accepted.
 - Otherwise, if a held call is present, the held call becomes active.
- 2X Place all active calls except call X (X= 1-7) on hold. Parameter X is the call number <idx> of the targeted call in the list of current calls available with AT command [AT+CLCC](#).
- 3 Add a held call to the active calls in order to set up a conference (multiparty) call.

Notes

- The [AT+CHLD](#) command offers a broad range of options according to the GSM specifications. However, if you attempt to invoke an option which is not provisioned by the network, or not subscribed to, invocation of this option will fail. The responses in these cases may vary with the network (for example "Operation not allowed", "Operation not supported" etc.).
- This Supplementary Service is only applicable to Teleservice 11 (Speech telephony), that is, voice calls can be put on hold, while data or fax calls cannot. For example, with [AT+CHLD=2](#) you can simultaneously place a voice call on hold and accept another waiting voice call. But it is possible to place a voice call on hold in order to accept a waiting data or fax call, and afterwards recover the voice call. In this case, the only difference over speech telephony is that the data or fax call needs to be manually accepted via [ATA](#) (see example below).
- In conflict situations, e.g. when a waiting call comes while there are already held calls, the above procedures apply to the waiting call only. For example, <n>=0 rejects the waiting call, but does not affect the held calls.
- See also the [AT+CCWA](#) command for details on how to display waiting calls.

Example

```

^SYSSTART
at+cpin="9999"
OK
+CREG: 2

at+ccwa=1,1,1           You activate the indication of waiting
                        calls during voice calls.

OK
atd"1234567";          You make a voice call.
OK
+CCWA: "+491791292364",145,32,,0   You receive a URC indicating a
                        waiting data call.

RING                     You now receive the RING of the data call.
OK

RING                     You accept the data call.
ATA
CONNECT 9600/RLP

```

```

hello
OK
"+++"
at+clcc           With "+++"
                    You interrogate the status of all established
                    calls.
+CLCC: 1,0,1,0,0,"03038639268",129
+ CLCC: 2,1,0,1,0,"+491791292364",145
OK

held voice call becomes active.

OK
at+clcc
+CLCC: 1,0,0,0,0,"03038639268",129
OK

```

8.9 AT+CLIP Calling line identification presentation

Syntax

Test Command AT+CLIP=?	Response(s) +CLIP: (list of supported <n>s) OK
Read Command AT+CLIP?	Response(s) + CLIP: <n>,<m> OK ERROR +CME ERROR: <err>
Write Command AT+CLIP=<n>	Response(s) OK ERROR +CME ERROR: <err>

Reference(s)	PIN	USB					
GSM 07.07	●	●					

Unsolicited Result Codes

URC1

Voice call response format:

+CLIP: <number>,<type>,,,<CLI validity>

URC2

Data/FAX call response format:

+CLIP: <number>,<type>

When CLIP is enabled at the TE (and is permitted by the calling subscriber), an unsolicited result code is returned after every RING (or +CRING: <type>) at a mobile terminating call.

Command Description

This command refers to the GSM supplementary service CLIP (Calling Line Identification Presentation) that enables a called subscriber to get the calling line identity (CLI) of the calling party when receiving a mobile terminated call.

Write command enables or disables the presentation of the CLI at the TE. It has no effect on the execution of the supplementary service CLIP in the network.

Parameter Description

<n>^(num)&W&V)

- | | |
|--------|-----------------------------------|
| [0]&F) | suppress unsolicited result codes |
| 1 | display unsolicited result codes |

<m>^(num)&V)

- | | |
|---|----------------------|
| 0 | CLIP not provisioned |
| 1 | CLIP provisioned |
| 2 | unknown |

<number>^(str)

string type phone number of calling address in format specified by

<type>

<type>^(num)

type of address octet in integer format; 145 when dialling string includes international access code character "+", otherwise 129.

<CLIvalidity>^(num)

- | | |
|---|---|
| 0 | CLI valid |
| 1 | CLI has been withheld by the originator. |
| 2 | CLI is not available due to interworking problems or limitations of originating network. <number> shall be an empty string ("") and <type> value will not be significant. |

When CLI is not available (**<CLIvalidity>=2**), **<number>** shall be an empty string ("") and **<type>** value will not be significant. Nevertheless, TA shall return the recommended value 128 for **<type>** (TON/NPI unknown in accordance with GSM 04.08 subclause 10.5.4.7).

When CLI has been withheld by the originator, (**<CLIvalidity>=1**) and the CLIP is provisioned with the "override category" option (refer GSM 02.81 and GSM 03.81), **<number>** and **<type>** is provided. Otherwise, TA shall return the same setting for **<number>** and **<type>** as if the CLI was not available.

8.10 AT+CLIR Calling line identification restriction

Syntax

Test Command AT+CLIR=?	Response(s) +CLIR: (list of supported <n> s) OK
Read Command AT+CLIR?	Response(s) + CLIR <n> , <m> OK ERROR +CME ERROR: <err>
Write Command AT+CLIR=[<n>]	Response(s) OK ERROR +CME ERROR: <err>

Reference(s)	PIN	USB					
GSM 07.07	●	●					

Command Description

This command refers to the GSM supplementary service CLIR (Calling Line Identification Restriction).

Parameter Description

<n>^(num)

Parameter shows the settings for outgoing calls:

- [0]^(P) Presentation indicator is used according to the subscription of the CLIR service
- 2 LIR invocation
- 3 LIR suppression

<m>^(num)

Parameter shows the subscriber CLIR service status in the network:

- 0 IR not provisioned
- 1 IR provisioned in permanent mode
- 2 known (e.g. no network, etc.)
- 3 IR temporary mode presentation restricted
- 4 IR temporary mode presentation allowed

Note

- The settings made with **AT+CLIR=1** or **AT+CLIR=2** are used for all outgoing calls until the ME is switched off or **AT+CLIR=0** is used.

8.11 AT+CPUC Price per unit and currency table

Syntax

Test Command AT+CPUC=?	Response(s) OK
Read Command AT+CPUC?	Response(s) + CPUC: <currency>,<ppu> OK ERROR +CME ERROR: <err>
Write Command AT+CPUC=<currency>,<ppu>[,<passwd>]	Response(s) OK ERROR +CME ERROR: <err>

Reference(s)	PIN	USB				
GSM 07.07	●					

Command Description

Read command returns the current parameters of PUC.

Write command sets the parameters of Advice of Charge related price per unit and currency table. SIM PIN2 is usually required to set the parameters.

Parameter Description

<currency>^{(str)+CSCS}

Three-character currency code (e.g. "GBP", "EUR"). If the currency name is longer than three characters, all characters will be cut off after the third position. Before they are written to the SIM card, these characters are converted to the standard GSM alphabet.

<ppu>^(str)

Price per unit; dot is used as a decimal separator (e.g. "2.66"). The length is limited to 20 characters. If the string length is exceeded, the command is terminated with an error. This string may only contain digits and a dot. Leading zeros are removed from the string. The minimum and maximum value are determined by the structure of the SIM-PUCT file. The maximum price per unit value is 999 999 999.00. When successfully entered, this value is rounded to maximum accuracy. Note: Due to storage in mantisse (range 0-4095) and exponent (-7 to 7) it is possible that rounding errors occur.

<passwd>^(str)

SIM PIN2. String parameter which can contain any combination of characters. The maximum string length is limited to 8 characters. If this value is exceeded, the command terminates with an error message. If the PIN2 is incorrect, a CME error (+CME ERROR: incorrect password) is output.

Example

To change currency and/or price per unit you have two ways:

You can enter PIN2 along with the [AT+CPUC](#) command:

AT+CPUC="EUR","0.10","8888" (where "8888" = PIN2)

OK

Alternatively, you can first use the [AT+CPIN2](#) command to enter PIN2. When you execute the [AT+CPUC](#) command, subsequently, take into account that PIN2 authentication expires after 300 ms (see notes in [AT+CPIN2](#)).

AT+CPUC="EUR","0.10"

OK

successful

AT+CPUC="EUR","0.10"

+CME ERROR: SIM PIN2 required

Attempt not successful. PIN2 authentication has expired.

8.12 AT+CSSN Supplementary service notifications

Syntax

Test Command AT+CSSN=?	Response(s) +CSSN: (list of supported <n>s), (list of supported <m>s) OK
Read Command	Response(s) + CSSN: <n>,<m> OK
Write Command AT+CSSN=<n>[,<m>]	Response(s) OK ERROR +CME ERROR

Reference(s)

PIN

GSM 07.07	●	●					
-----------	---	---	--	--	--	--	--

Unsolicited Result Codes

URC 1

+CSSI: <code 1>

When $<n>=1$ and a supplementary service notification is received after a mobile originated call setup, intermediate result code "+CSSI": <code 1> is sent to TE before any other MO call setup result codes

URC 2

+CSSU: <code 2>

When $<m>=1$ and a supplementary service notification is received during a mobile terminated call setup or during a call, unsolicited result code "+CSSU": <code 2> is sent to TE.

Command Description

The write command enables or disables the presentation of URCs for supplementary services.

Parameter Description

<n>^(num)

0(&F)	Suppress "+CSSI" URCs
1	Activate "+CSSI" URCs

<m>^(num)

0(&F)	Suppress "+CSSU" URCs
1	Activate "+CSSU" URCs

<code 1>^(num)

3	Waiting call is pending
---	-------------------------

<code 2>^(num)

0	The incoming call is a forwarded call.
5	Held call was terminated

Note

- The URCs will be displayed only if the call concerned is a voice call.

8.13 AT+CUSD Supplementary service notifications

This command allows control of the Unstructured Supplementary Service Data (USSD) according to GSM 02.90. Both network and mobile initiated operations are supported.

Syntax

Test Command AT+CUSD=?	Response(s) +CUSD: (list of supported <n>s)
Read Command AT+CUSD?	Response(s) +CUSD: <n> OK
AT+CUSD=<n>[,<str>[,<dcs>]]	Response(s) OK +CME ERROR

Reference(s)	PIN	USB				
--------------	-----	-----	--	--	--	--

GSM 07.07, GSM 02.90, GSM 03.90, GSM 04.90	●	●					
---	---	---	--	--	--	--	--

Unsolicited Result Code

+ CUSD: <m>[<str>[<dcs>]]

URC "+CUSD" indicates an USSD response from the network, or network initiated operation

Command Description

The read command returns the current <n> value

Write command parameter <n> is used to disable/enable the presentation of an unsolicited result code (USSD response from the network, or network initiated operation) "+CUSD: <m>[<str>[<dcs>]]" to the TE.

When <str> is given, a mobile initiated USSD string or a response USSD string to a network initiated operation is sent to the network. The response USSD string from the network is returned in a subsequent unsolicited result code "+CUSD".

The interaction of this command with other commands based on other GSM supplementary services is described in the GSM standard.

Parameter Description

<n>^(num)

0(&F) Disable the result code presentation in the TA

1 Enable the result code presentation in the TA

2 Cancel session (not applicable to read command response)

<str>^(str)

Stringtype USSD-string (when <str> parameter is not given, network is not interrogated).

If <dcs> indicates that GSM 03.38 default alphabet is used TA converts GSM alphabet into current TE character set according to rules of GSM 07.05 Annex A.

<dcs>^(num)

GSM 03.38 Cell Broadcast Data Coding Scheme in integer format (default 15)

<m>^(num)

0 No further user action required (network initiated USSD-Notify, or no further information needed after mobile initiated operation)

1 Further user action required (network initiated USSD-Request, or further information needed after mobile initiated operation).

If <m>=1, then the URC ends with ">" to prompt the user for input. The user action is finished with <CTRL-Z> or aborted with <ESC>.

2 USSD terminated by network.

Notes

- For the write command, only <dcs>= 15 is supported.
- When a USSD string is sent via ATD, a "AT+CUSD=1" is executed implicitly.

9 INTERNET SERVICE COMMANDS

This chapter provides a reference of AT commands and responses which allow the host application to easily access the Internet. The advantage of this solution is that it eliminates the need for the application manufacturer to implement own TCP/IP and PPP stacks, thus minimizing cost and time to integrate Internet connectivity into a new or existing host application.

Access is provided to the following Internet Services:

1. Socket Client and Server for TCP, Client for UDP
2. FTP Client
3. HTTP Client
4. SMTP Client
5. POP3 Client

9.1 AT^SICS Internet Connection Setup Profile

AT^SICS serves to setup the parameters related to an Internet connection profile. Any connection profile can then be used to select a connection in conjunction with Section 10.2, **AT^SISS**, parameter `<srvParmTag>` value "conld".

The read command serves to request the current settings of all Internet connection profiles. One line is issued for every possible parameter of a given `<conParmTag>` "conType" value. **AT^SICS** write command specifies the parameters for a connection profile identified by `<conProfileId>`. At first the type of Internet connection needs to be selected via `<conParmTag>` value "conType"; this determines the applicability of the other `<conParmTag>` values and resets them to their default values. Optional `<con-ParmTag>` value "alphabet" determines the applicable character set for all string parameters supplied with this command. Its value is used by all profiles and connection types; hence, it is not reset by setting `<conParmTag>` value "conType".

<code><conParmTag></code> value	CSD	GPRS
"conType"		mandatory
"user"	optional	optional
"passwd"	optional	optional
"apn"	Ø	mandatory
"inactTO"	optional	optional
"calledNum"	mandatory	Ø
"dataRate"	mandatory	Ø
"dataType"	mandatory	Ø
"authMode"	mandatory	mandatory
"dns1"	optional	optional
"dns2"	optional	optional
	optional	optional

Table 10.1: **AT^SICS** `<conParmTag>` value applicability

Syntax

Test Command AT^SICS=?	Response(s) OK
Read Command AT^SICS?	Response(s) ^SICS: <code><conProfileId></code> , <code><conParmTag></code> , <code><conParmValue></code>
Write Command AT^SICS <code>=<conProfileId></code> , <code><conParmTag></code> , <code><conParmValue></code>	Response(s) OK ERROR +CME ERROR: <code><err></code>

Reference(s)	PIN	USB				
--------------	-----	-----	--	--	--	--

GSM 07.07	<input type="radio"/>	<input checked="" type="radio"/>						
-----------	-----------------------	----------------------------------	--	--	--	--	--	--

Parameter Description**<conProfileId>(num)**

Internet connection profile identifier.

0...5

<conParmTag>(str)

Internet connection parameter.

“conType” Type of Internet connection to be configured with consecutive usage of [AT^SICS](#).

For supported values of [<conParmValue>](#) refer to [<conParmValue-con-Type>](#).

“alphabet” Character set selection for string parameter of this command.

For supported values of [<conParmValue>](#) refer to [<conParmValuealphabet>](#).

“user” User name string.

“passwd” Password string.

“apn” Access point name string value.

“inactTO” Inactivity timeout value in seconds, “0”: no timeout.

“calledNum” Called BCD number.

“dataRate” Data rate.

For supported values of [<conParmValue>](#) refer to [<conParmValue-dataRate>](#).

“dataType” Data call type.

For supported values of [<conParmValue>](#) refer to [<conParmValuedataType>](#).

“authMode” Authentication mode.

For supported values of [<conParmValue>](#) refer to [<conParmValue-auth-Mode>](#).

“locAddr” Local address (IP address in dotted-four-byte format).

“remAddr” Remote address (IP address in dotted-four-byte format).

“dns1” Primary DNS server address (IP address in dotted-four-byte format).

“dns2” Secondary DNS server address (IP address in dotted-four-byte format).

<conParmValue>(str)

Parameter value; type and supported content depend on related [<conParmTag>](#).

<conParmValue-conType>(str)

Supported connection type values in [<conParmValue>](#) for [<conParmTag>](#) value “conType”.

“CSD” Circuit-switched data call.

“GPRS0” First GPRS connection.

Settings of GPRS related commands are not used, e.g. [AT+CGDCONT](#).

"GPRS1" Second GPRS connection.

Settings of GPRS related commands are not used, e.g. [AT+CGDCONT](#).

[`<conParmValue-alphabet>\(str\)`](#)

Supported string parameter character set selections in [`<conParmValue>`](#) for [`<conParmTag>`](#) value "alphabet".

"0" Applicable character set is determined by current setting of [AT+CSCS](#).

"1" International Reference Alphabet (IRA, seven bit ASCII).

[`<conParmValue-dataRate>\(str\)`](#)

Supported data rate values in [`<conParmValue>`](#) for [`<conParmTag>`](#) value "dataRate".

"0" 14.4 Kbaud

[“1”] 9.6 Kbaud

[`<conParmValue-dataType>\(str\)`](#)

Supported data type values in [`<conParmValue>`](#) for [`<conParmTag>`](#) value "dataType".

"0" ISDN

[“1”] analog

[`<conParmValue-authMode>\(str\)`](#)

Supported authentication mode values in [`<conParmValue>`](#) for [`<conParmTag>`](#) value "authMode".

"none"

"PAP"

"CHAP"

"MsChapV1"

9.2 AT^{SISS} Internet Service Setup Profile

[AT^{SISS}](#) serves to set up the necessary parameters in the Internet service profiles. Any service profile can then be used to control a data link in conjunction with [AT^{SISO}](#), [AT^{SISC}](#), [AT^{SISR}](#) and [AT^{SISW}](#).

The read command serves to request the current settings of all Internet service profiles. One line is issued for every possible parameter of a given [`<srvParmTag>`](#) "srvType" value. [AT^{SISS}](#) write command specifies the parameters for a service profile identified by [`<srvProfileId>`](#). At first the type of Internet service needs to be selected via [`<srvParmTag>`](#) value "srvType". Configure "srvType" determines the applicability of the other [`<srvParmTag>`](#) values and resets them to their default values. The following overview lists the [`<srvParmTag>`](#) applicability for certain Internet services. However, optional [`<srvParmTag>`](#) value "alphabet" determines the applicable character set for all string parameters supplied by this command. Its value is used for all profiles and services; hence, it is not reset by setting [`<srvParmTag>`](#) value "srvType".

1. "Socket"

"address"

"conld" (mandatory)

Internet connection profile.

2. "FTP"

"address"
 "conId" (mandatory)
 Internet connection profile.

3. "HTTP"

"user"
 "passwd"
 "address"
 "conId" (mandatory)
 Internet connection profile.
 "hcContent"
 "hcContLen"
 "hcUsrAgent"
 "hcMethod"
 "hcProp"
 "hcRedir"
 "hcAuth"

4. "SMTP"

"user" (optional)
 User name to be used for SMTP authentication.
 "passwd" (optional)
 Password to be used for SMTP authentication.
 "address" (mandatory)
 SMTP server address.
 "tcpPort" (optional)
 TCP port number of SMTP Server.
 "conId" (mandatory)
 Internet connection profile.
 "smFrom" (mandatory)
 eMail sender ("MAIL FROM") Address.
 "smRcpt" (mandatory)
 Recipient ("RCPT TO") address.
 "smCC" (optional)
 CC Address of the eMail..
 "smSubj" (optional)
 Subject content of the eMail.
 "smAuth" (optional)
 SMTP authentication control flag.

5. "POP3"

"user" (mandatory)
 "passwd" (mandatory)
 "address" (mandatory)
 POP3 Server address.
 "tcpPort" (optional)
 POP3 Server TCP Port Number.
 "conId" (mandatory)

Internet connection profile.
 "pCmd" (optional)
 POP3 User Command.
 "pNumber" (optional)
 Message number argument.
 "pLength" (optional)
 Maximum message length.
 "pDelFlag" (optional)
 Delete message on server flag.

Syntax

Test Command AT^SISS=?	Response(s) OK
Read Command AT^SISS?	Response(s) ^SISS: <srvProfileId>,<srvParmTag>,<srvParmValue> OK
Write Command =<srvProfileId>,<srvParmTag>,<srvParmValue>	Response(s) OK ERROR +CME ERROR: <err>

Reference(s)	PIN	USB					
GSM 07.07	○	●					

Parameter Description

<srvProfileId>(num)

Internet service profile identifier.

<srvParmTag>(str)

Internet service profile parameter.

"srvType" Type of Internet service to be configured with consecutive usage of AT^SISS.

For supported values of <srvParmValue> refer to <srvParmValue-srv-Type>.

"alphabet" Character set selection for string parameter of this command.

For supported values of <srvParmValue> refer to <srvParmValuealphabet>.

"user" User name string

1. Socket

Not applicable; set within "address" parameter.

2. FTP

Not applicable; set within "address" parameter.

3. HTTP

User name for the HTTP authentication mechanism. Currently only HTTP simple authentication is supported.

4. SMTP

User name to be used for SMTP authentication.
If SMTP authentication is disabled, i.e. "smAuth" flag not set, user name parameter will be ignored.

5. POP3

User name identifying a mailbox (i.e. mailbox name) which will be used to perform authentication with a POP3 server, e.g. "john.smith".

"passwd" Password string

1. Socket

Not applicable; set within "address" parameter.

2. FTP

Not applicable; set within "address" parameter.

3. HTTP

Password for the HTTP authentication mechanism. Currently only HTTP simple authentication is supported.

4. SMTP

Password to be used for SMTP authentication.
If SMTP authentication is disabled, i.e. "smAuth" flag not set, password parameter will be ignored.

5. POP3

Server/mailbox password which will be used to perform authentication with a POP3 server.

"conld" Internet connection profile to be used, for details refer [AT^SICS](#).

"tcpPort" TCP Port Number

1. Socket

Not applicable; set within "address" parameter.

2. FTP

Not applicable; set within "address" parameter.

3. HTTP

Not applicable; set within "address" parameter.

If parameter is omitted the service connects to HTTP default port 80.

4. SMTP

SMTP Server TCP Port Number

If this parameter is not set, SMTP default port number 25 is used.

5. POP3

POP3 Server TCP Port Number

If this parameter is not set, POP3 default port number 110 is used.

“address“ The string value is used as URL scheme, which provides a compact way to access different services.

The Internet Service commands use the following URL schemes to specify an appropriate service. However, some services need additional parameters which must be supplied with **AT^SISO**, **AT^SISC**, **AT^SISR** and **AT^SISW**.

Address formats versus Internet Services:

1. Socket

- Socket type TCP client URL
"socktcp://host':remote
tcpPort'[;disnagle='0 | 1']"
"disnagle" is optional for disabling the TCP Nagle algorithm.
0: (default) Nagle algorithm is enabled.
1: Nagle algorithm is disabled.
- Socket type TCP server URL
"socktcp://listener':local tcpPort' "
- Socket type UDP client URL
"sockudp://host':remote
udpPort'[;size='byte']"
Parameter "size" (optional):
0: PDU size is variable.
1-1500: Fixed PDU size in bytes.

2. FTP

- FTP client URL (get)
"ftp://user':password'@host':tcpPort'/'url-path' [;type='a | i | d']"
Refer "IETF-RFC 1738".
- FTP client URL (put)
"ftpput://user':password'@host':tcpPort'/'url-path'/'element name'
[;type='a | i'][;size='length'][;mode='u | a | d']"
Used parameters:
"type": [a]scii | i)mage | d)irectory
"mode": [u]nique | a)ppend | d)elete]
If "mode" is omitted "replace mode" is default setting. "d)elete" clears given 'element name'.
If "user" is omitted the string "anonymous" is selected for "user" and "password".
If "password" is omitted no server password request can be served.
If "tcpPort" is omitted the service connects to the FTP default port 21.
If "url-path" does not contain any character a detailed directory listing is requested.
If "url-path" ends with '/' a detailed directory listing is requested.

3. HTTP

- HTTP client URL
 "http://server'/'path':tcpPort"
 "server": FQDN or IP-address
 "path": path of file or directory
 "tcpPort": If parameter is omitted the service connects to HTTP default port 80.
 Refer "IETF-RFC 2616".

4. SMTP

- SMTP server URL.
 Server address must be provided as IP address in standard dot-format (e.g. "192.168.1.2") or as server address name resolvable by a DNSserver (e.g. "smtp.myserver.de").

5. POP3

- POP3 server address.
 Server address must be provided as IP address in standard dot-format (e.g. "192.168.1.2") or as server address name resolvable by a DNS server (e.g. "pop3.myserver.de").

"hcContent" Data for short post message with HTTP "Post" method.

If parameter is given no write is possible. If "write" is used for larger data this arameter needs to be empty.

"hcContLen" Content length mandatory for HTTP "Post" requests, which send data from client to HTTP server (Upload). The content length must be set in the header of the HTTP "Post" request, before the data part is transferred.

This parameter shall only be set for the "Post" method.

"hcUsrAgent" The user agent string must be set by the application to identify the mobile. Usually operation system and software version info is set with thisbrowser identifier.

"hcMethod" HTTP method specification: 0=GET, 1=POST, 2=HEAD.

"hcProp" Parameter for several HTTP settings.

The general format is 'key': <space> 'value' "\0d\0a".

Multiple settings can be given separated by "\0d\0a" sequences within the string.

Possible 'key' values are defined at HTTP/1.1 Standard RFC 2616.

"hcRedir" This flag controls the redirection mechanism of the SAMBA75 acting as HTTP client.

If the flag is set (1) the client automatically sends a new HTTP request if the server answers with a redirect code (range 30x).

"hcAuth" I set (1) this flag determines that the HTTP client will automatically answer on authentication requests from the server

with the current "passwd" and "user" parameter settings. If these parameter are not specified the SAMBA75 will terminate the HTTP connection and send an indication to the TA.

"smFrom" eMail sender address ("MAIL FROM" address).

A valid address parameter consists of local part and domain name delimited by a '@' character, e.g. "john.smith@somedomain.de".

"smRcpt" Recipient address of the eMail ("RCPT TO" address).

If multiple recipient addresses are to be supplied the comma character is used as delimiter to separate individual address values, e.g. "john.smith@somedomain.de, tom.meier@somedomain.de".

"smCC" CC recipient address of the eMail. If multiple CC recipient addresses are to be supplied the comma character is used as delimiter to separate individual address values, e.g. "john.smith@somedomain.de,tom.meier@somedomain.de".

"smSubj" Subject content of the email. If no subject is supplied the eMail an will be sent with an empty subject.

"smAuth" SMTP authentication control flag.

If disabled ([`<srvParmValue>`](#) "0") or not set SAMBA75 performs action without authentication.

If enabled ([`<srvParmValue>`](#) "1") authentication procedure with the SMTP server will be performed by means of supported authentication methods, using values of "user" and "passwd" parameters. If SAMBA75 and SMTP server are not able to negotiate an authentication mechanism supported by both parties, the SAMBA75 continues action without authentication.

"pCmd" POP3 user command.

For supported values of [`<srvParmValue>`](#) refer to [`<srvParmValue-pCmd>`](#).

"pNumber" Optional message number argument used by POP3 commands "List", "Retrieve" and "Delete", refer [`<srvParmTag>`](#) value "pCmd".

[`<srvParmValue>`](#) default value "0" determines that no additional argument is sent, i.e. all messages are referenced.

"pLength" Maximum length a message can have so that the service will retrieve/delete certain messages from the POP3 server. A warning is issued if the TA tries to retrieve a longer message from the server explicitly (i.e using the "retrieve (message_number)" user command).

If this parameter is not set, default value "0" is used which indicates that there is no limit of the message size.

"pDelFlag" Delete on server command flag (optional).

For supported values of [`<srvParmValue>`](#) refer to [`<srvParmValuepDelFlag>`](#).

[`<srvParmValue>\(str\)`](#)

Parameter value; type and supported content depend on related [`<srvParmTag>`](#).

<srvParmValue-srvType>(str)

Supported Internet service type values in <srvParmValue> for <srvParmTag> value "srvType".

"Socket" SAMBA75 acting as client or server for TCP, or as client for UDP.

"FTP" SAMBA75 acting as FTP client.

"HTTP" SAMBA75 acting as HTTP client.

"SMTP" SAMBA75 acting as SMTP client.

"POP3" SAMBA75 acting as POP3 client.

"none" Reset Internet service profile settings. Operation is not allowed if profile is in use, i.e. it was activated via [AT^SISO](#).

<srvParmValue-alphabet>(str)

Supported string parameter character set selections in <srvParmValue> for <srvParmTag> value "alphabet".

[“0”] Applicable character set is determined by current setting of [AT+CSCS](#).

"1" International Reference Alphabet (IRA, seven bit ASCII).

<srvParmValue-pCmd>(str)

Supported POP3 user command values in <srvParmValue> for <srvParmTag> value "pCmd".

"1" Status command.

This command retrieves the "drop listing" of a POP3 server. A "drop listing" consists of a single line containing the number of messages in the maildrop list followed by the total size of the maildrop list in bytes.

"2" List command.

If <srvParmTag> value "pNumber" is provided the command returns the "scan listing", consisting of a single line which contains the message number and the message size in bytes if the specified message exists in the maildrop list on the POP3 server. If no such message exists on the server than the POP3 service issues an error response to the user. If no argument was given with the "List" command the POP3 service returns a multi-line "scan listing". For each message on the maildrop list of the server the POP3 service returns a line containing the message number and its size in bytes. A final "dotline" will be printed at the end of the "scan listing". If there are no messages on the maildrop list of the server, the POP3 service returns with a positive response, i.e. it doesn't issue an error response, but the "scan listing" will be empty.

"3" Retrieve command.

If <srvParmTag> value "pNumber" is set to a non-zero value this command retrieves the related message from the POP3 servers maildrop list. If no such message exists on the server the POP3 service issues an error response to the user. It depends on the parameter "pDelFlag" if the message will be deleted from the POP3 server upon successful retrieval. If no argument was given to the "Retrieve" command the POP3 service returns all messages pending in the POP3 servers maildrop. If there are no messages on the maildrop list of the server the POP3 service returns with a

positive response, i.e. it doesn't issue an error response, but the returned list will be empty.

“4“ Delete command

If [`<srvParmTag>`](#) value "pNumber" is set to a non-zero value the command deletes the related message from the POP3 servers maildrop list. In fact, the message is marked as deleted on the server and will be deleted permanently if the POP3 service command executes successfully. In case an error has occurred, e.g. network loss, the message will not be deleted on the server even though the POP3 service command has been finished. If no message number argument was given to the "Delete" command the POP3 service deletes all message from the POP3 servers maildrop list. In fact, the messages are marked as deleted on the server and will be deleted permanently if the POP3 service command executes successfully. In case an error has occurred, the messages will not be deleted on the server even though the POP3 service command has been finished.

[`<srvParmValue>`](#)[`pDelFlag`](#)(str)

Supported flag values in [`<srvParmValue>`](#) for [`<srvParmTag>`](#) value "pDelFlag".

[“0“] Messages will not be deleted on the server.

“1“ Delete messages on the server, which have been retrieved successfully.

9.3 AT^SISO Internet Service Open

Syntax

Test Command AT^SISO=?	Response(s) OK
Read Command AT^SISO?	Response(s) ^SISO: <code><srvProfileId></code> , <code><srvParmTag></code> ,value"srvType[,<srvState>,<socketState>,<rxCount>,<txCount>,<locAddr>,<remAddr>] OK
Write Command AT^SISO = <code><srvProfileId></code>	Response(s) OK ERROR +CME ERROR: <err>

Reference(s)	PIN	USB				
GSM 07.07	●					

Unsolicited Result Code

Internet service status indication.

This URC may be issued after successful [`AT^SISO`](#) write command.

[`^SIS: <srvProfileId>,<urcCause>\[, \[<urcInfoId> \] , <urcInfoText> \] \]`](#)

Parameter Description

The read command serves to request the status of all Internet service profiles. One line is issued for every Internet service profile. Information following [`<srvParmTag>`](#) value "srvType" is issued only, if "srvType" was given a valid value via [`AT^SISS`](#).

AT^SISS write command performs all necessary action to enable data transmission using **AT^SISR** or **AT^SISW**

Parameter Description

<srvState>(num)

Internet service state identifier.

- 2 Engaged: Profile resources allocated, possibly parameter set via **AT^SISS**.
- 3 Connecting: Socket connection ongoing.
- 4 Connected: Socket connection valid.
- 5 Closing: Socket connection releasing.

<socketState>(num)

Socket state identifier.

- 1 Socket not assigned, i.e. no TCP/UDP connection active.
- 2 Socket assigned as CLIENT.
- 3 Socket assigned as LISTENER.
- 4 Socket assigned as SERVER.

<rxCount>(num)

Number of bytes received via **AT^SISR** since last successful **AT^SISO** write command.

<txCount>(num)

Number of bytes sent via **AT^SISW** since last successful **AT^SISO** write command.

<locAddr>(str)

Local IP address in dotted-four-byte format and TCP port, separated by colon, e.g. "192.60.10.10:80".

<remAddr>(str)

Remote IP address in dotted-four-byte format or evaluated DNS name and TCP port, separated by colon, e.g. "192.60.10.10:80" or "www.siemens.com:80".

<urcCause>(num)

URC cause identifier.

- 0 Internet service error indication.

Error number is presented via **<urcInfoId>**, optionally additional information may be supplied via **<urcInfoText>**.

- 1 Indication of successful incoming Internet service client connection.

Connection is dynamically assigned to Internet service profile identifier issued in **<urcInfoId>**. The connection needs to be accepted via **AT^SISO** or rejected via **AT^SISC**.

Details regarding the connection may be requested via **AT^SISO** read command.

- 2 Indication of failed incoming Internet service client connection.

Client request was rejected automatically because no free Internet service profile was available.

<urcInfoId>(num)

Information identifier related to <urcCause>.
<urcInfoText>(str)
 Information text related to <urcCause>.

9.4 AT^SISC Internet Service Close

Syntax

Test Command AT^SISC=?	Response(s)
Read Command	Response(s) ^SISC: <srvProfileId>[,<closeMode>] OK
Write Command AT^SISC =<srvProfileId >	Response(s) OK ERROR +CME ERROR: <err>

Reference(s)	PIN	USB					
GSM 07.07	●	●					

Command Description

AT^SISC write command performs all necessary action to release all properties activated by **AT^SISO**.

Parameter Description

<closeMode>(num)

Close Internet Service profile mode

- | | |
|---|-----------|
| 0 | Graceful |
| 1 | Immediate |

9.5 AT^SISR Internet Service Read Data

AT^SISR write command triggers reading data via the Internet service configured in **<srvProfileId>**.

SAMBA75 returns the amount of data which can be transferred:

- **<cnfReadLength>** value equal 0 indicates that the SAMBA75 failed to enter online data mode. Details about the cause of failure is available using **AT+CEER**.
- **<cnfReadLength>** value greater than 0 indicates that the SAMBA75 switches into online data mode to transfer the given number of bytes.

A URC "**^SISR: <srvProfileId>, <urcCauseId>**" will be issued if

- data is available after opening an Internet service or
- less data was confirmed (in **<cnfReadLength>**) than requested (with **<reqReadLength>**) and new data is available.

This mechanism intends to avoid polling for fresh data by the TA.

Syntax

Test Command AT^SISR=?	OK
Write Command AT^SISR=<srvProfileId>,<reqReadLength>	Response(s) ^SISR: <srvProfileId>, <cnfReadLength> Number of data bytes are sent as specified by <cnfReadLength> OK ERROR +CME ERROR: <err>

Reference(s)	PIN	USB					
GSM 07.07	●	●					

Unsolicited Result Code

^SISR: <srvProfileId>, <urcCauseId>

Data availability status of Internet service configured in **<srvProfileId>** has changed.

Parameter Description

<reqReadLength>(num)

Requested number of data bytes to be read via the Internet service configured in **<srvProfileId>**.

1...1500

<cnfReadLength>(num)

Confirmed number of data bytes to be read via the Internet service configured in **<srvProfileId>**. This number may be less or equal to the value requested with **<reqReadLength>**. 0 value indicates that no data can be read.

<urcCauseId>(num)

Data availability status change indication.

1 New data is available via **AT^SISR**.

2 Data transfer has been finished and Internet service can be closed via **AT^SISC**.

9.6 AT^SISW Internet Service Write Data

AT^SISW write command triggers writing data via the Internet service configured in **<srvProfileId>**.

SAMBA75 returns the amount of data which can be written:

- **<cnfWriteLength>** value equal 0 indicates that the SAMBA75 failed to enter online data mode. Details about the cause of failure is available using **AT+CEER**.
- **<cnfWriteLength>** value greater than 0 indicates that the SAMBA75 switches into online data mode to transfer the given number of bytes.

A URC "**^SISW: <srvProfileId>, <urcCauseId>**" will be issued if

- the SAMBA75 is capable to send data after opening the Internet service or
- less transmission buffer space was confirmed (in **<cnfWriteLength>**) than requested (with **<reqWriteLength>**) and contained data has been sent via the Internet service.

This mechanism intends to avoid polling for free transmission buffer space by the TA.

Syntax

Test Command AT ^S ISW=?	Response(s) OK
Write Command AT ^S ISW=<srvProfileId>, <reqWriteLength>	Response(s) ^SISW: <srvProfileId>, <cnfWriteLength>Number of data bytes are expected as specified by <cnfWriteLength> OK ERROR +CME ERROR: <err>

Reference(s)	PIN	USB					
	●						

Unsolicited Result Code

^SISW: <srvProfileId>, <urcCauseId>

Data availability status of Internet service configured in **<srvProfileId>** has changed.

Parameter Description

<reqWriteLength>(num)

Requested number of data bytes to be transmitted via the Internet service configured in **<srvProfileId>**.

1...1500

<cnfWriteLength>(num)

Confirmed number of data bytes to be transmitted via the Internet service configured in **<srvProfileId>**. This number may be less or equal to the value requested with **<reqWriteLength>**. 0 value indicates that no data can be written.

<urcCauseId>(num)

Data availability status change indication.

1 New data can be written via **AT^SISW**.

2 Data transfer has been finished and Internet service can be closed via **AT^SISC**.

10 GPRS COMMANDS

This chapter describes AT commands that a TE (Terminal Equipment, e.g. an application running on a controlling PC) may use to control the SAMBA75 acting as GPRS Mobile Termination (MT). Please use chapter "[Using GPRS AT commands \(Examples\)](#)" as a first guidance.

10.1 AT+CGACT PDP context activate or deactivate

Syntax

Test Command AT+CGACT=?	Response(s) +CGACT: (list of supported <state>s) OK
Read Command AT+CGACT?	Response(s) + CGACT: <cid>,<state> [+CGACT: <cid>,<state>] OK
Write Command AT+CGACT=[<state>[,<cid>[,<cid>[,...]]]]	Response(s) OK ERROR +CME ERROR

Reference(s)	PIN	USB					
GSM 07.07	●	●					

Command Description

The test command is used for requesting information on the supported PDP context activation states. The read command returns the current activation states for all the defined PDP contexts.

The write command is used to activate or deactivate the specified PDP context(s). After the command has completed, the MT remains in V.25ter command state. If any PDP context is already in the requested state, the state for that context remains unchanged. If the MT is not GPRS attached when the activation form of the command is executed, the MT first performs a GPRS attach and then attempts to activate the specified contexts. If no <cid>s are specified the activation/deactivation form of the command activates/deactivates all defined contexts. If the MT is not able to activate a context because of a failed attach, command returns with "ERROR" or with "+CME ERROR: unknown" after 385 seconds (timer T3310 expired).

If the MT is attached but is not able to activate a context for more than 160 seconds (timer T3380 expired), command returns with "ERROR" or with "+CME ERROR: unspecified GPRS error. In this case AT+CEER, returns "+CEER:51,3,0".

Parameter Description

<state>^(num)

Indicates the state of PDP context activation.

0 detached

[1] attached

<cid>^(num)

PDP Context Identifier is a numeric parameter which specifies a particular PDP context definition. The parameter is local to the TE-MT interface and is used in other PDP context-related commands.

1...2

Notes

- ATH will deactivate any PDP context.
- If the MT is in dedicated mode, write command returns with "+CME ERROR: operation temporary not allowed."
- A maximum of 2 contexts can be activated at the same time, no matter on which interface. Trying to activate more than 2 contexts will cause "+CME ERROR: operation temporary not allowed. Note that, depending on the provider, the number of activated contexts may be further restricted. In such cases "+CME ERROR: unspecified GPRS error" will be returned and

AT+CEER returns "+CEER: 50,26,0".

Remember that contexts may be activated implicitly by using the **ATD*98#** or **ATD*99#** GPRS compatibility commands without specifying a <cid>.

10.2 AT+CGANS Manual response to a network request for PDP context activation

Syntax

Test Command AT+CGANS=?	Response(s) +CGANS: (list of supported <response>s), (list of supported <L2P>s) OK
Write Command AT+CGANS=[<response>[,<L2P>[,<cid>]]]	Response(s) OK ERROR +CME ERROR

Reference(s)	PIN	USB					
GSM 07.07	•	•					

Command Description

The write command requests the MT to respond to a network request for GPRS PDP context activation which has been signaled to the TE by the RING or CRING unsolicited result code. The <response> parameter allows the TE to accept or reject the request.

Parameter Description

<response>^(num)

- [0] the request is rejected and the MT returns OK to the TE
- 1 accept and request that the PDP context be activated

<L2P>^(str)

a string parameter which indicates the layer 2 protocol to be used (see **AT+CGDATA** command)

<cid>^(num)

a numeric parameter which specifies a particular PDP context definition (see **AT+CGDCONT** command).

Note

- If <response> is 1, the following procedure is followed by the MT:
- If the <L2P> parameter value is unacceptable to the MT, the MT will return an ERROR or +CME ERROR response. Otherwise, the MT issues the intermediate result code CONNECT and enters V.25ter online data state.
- A <cid> may be specified for use in the context activation request.

During the PDP startup procedure the MT has the PDP type and the PDP address provided by the network in the Request PDP context activation message. If this is in conflict with the information provided by a specified <cid>, the command will fail. There will be no conflict, if the PDP type matches exactly and the PDP address given by the context definition for <cid> is empty or matches exactly with the address specified with the network PDP context activation message.

The context will be activated using the values for PDP type and address provided by the network, together with all other information found in the PDP context definition. An APN may or may not be required, depending on the application.

If no **<cid>** is given or if there is no matching context definition, the MT will attempt to activate the context using the values for PDP type and address provided by the network. The other parameters will be set to their default values (see [AT+CGDCONT](#)). If activation is successful, data transfer may proceed.

After data transfer is completed, and the layer 2 protocol termination procedure has completed successfully, the V.25ter command state is reentered and the MT returns the final result code OK. In the event of an erroneous termination or a failure to start up, the V.25ter command state is reentered and the MT returns the final result code NO CARRIER, or if enabled, +CME ERROR. Attach, activate and other errors may be reported. It is also an error to issue the [AT+CGANS](#) command when there is no pending network request. The command may be used in both normal and modem compatibility modes.

10.3 AT+CGATT GPRS attach or detach

Syntax

Test Command AT+CGATT=?	Response(s) +CGATT: (list of supported <state>s) OK
Read Command AT+CGATT?	+CGATT: <state>
Write Command AT+CGATT=[<state>]	Response(s) OK ERROR +CME ERROR

Reference(s)	PIN	USB					
GSM 07.07	●	●					

Command Description

The test command is used for requesting information on the supported GPRS service states. The read command returns the current GPRS service state.

The write command is used to attach the MT to, or detach the MT from the GPRS service. After the command has completed, the MT remains in V.25ter command state. If the MT is already in the requested state, the command is ignored and the OK response is returned. Any active PDP contexts will be automatically deactivated when the attachment state changes to detached.

If the MT is not able to attach for more than 5 minutes, command returns with "ERROR" or "+CME ERROR: unknown", but MT is still trying to attach.

If the MT is not able to detach for more than 1 minute, command returns with "ERROR" or "+CME ERROR: unknown", but MT is still trying to detach. If an attach is issued during a running detach, command returns with "ERROR" or "+CME ERROR: unspecified GPRS error.

Parameter Description**<state>**^(num)

Indicates the state of GPRS attachment.

0^(P) detached

[1] attached

Notes

- If the MT is in dedicated mode, write command returns with "+CME ERROR: operation temporary not allowed."
- When the module is GPRS attached and a PLMN reselection occurs to a non-GPRS capable network or to a network where the SIM is not subscribed to for using GPRS, the resulting GMM (GPRS mobility management) state according to GSM 24.008 is REGISTERED/NO CELL, meaning that the read command will still show <state>=1.

10.4 AT+CGAUTO Automatic response to a network request for PDP context activation

Syntax

Test Command AT+CGAUTO=?	Response(s) +CGAUTO : (list of supported <n>s) OK
Read Command AT+CGAUTO?	Response(s) +CGAUTO: <n> OK
Write Command AT+CGAUTO=[<n>]	Response(s) OK ERROR +CME ERROR

Reference(s)	PIN	USB				
GSM 07.07	•	•				

Command Description

The test command returns the values of <n> supported by the MT as a compound value.

The write command disables or enables an automatic positive response (auto-answer) to the receipt of a Request PDP Context Activation message from the network. It also provides control over the use of the V.25ter basic commands [ATSO](#), [ATA](#) and [ATH](#) for handling network requests for PDP context activation.

Parameter Description**<n>**^(num)

- | | |
|------------------|---|
| 0 | Disable automatic response for network requests for GPRS PDP context activation. GPRS network requests are manually accepted or rejected by the AT+CGANS command. |
| 1 | Enable automatic response for network requests for GPRS PDP context activation. GPRS requests are automatically accepted according to the description below. |
| 3 ^(P) | Modem compatibility mode. The automatic acceptance of both GPRS and incoming CSD calls is |

controlled by the [ATSO](#) command. Manual control uses the [ATA](#) and [ATH](#) commands, respectively, to accept or reject GPRS network requests or incoming CSD calls.

Notes

- It is allowed to have different [AT+CGAUTO](#) settings on different interfaces.
- When the [AT+CGAUTO=0](#) command is received, the MT will not perform a GPRS detach if it is attached. Subsequently, when the MT announces a network request for PDP context activation by issuing the URC RING or CRING, the TE may manually accept or reject the request by issuing the [AT+CGANS](#) command or may simply ignore the network request.
- When the [AT+CGAUTO=1](#) command is received, the MT will attempt to perform a GPRS attach if it is not yet attached. Failure will result in ERROR or, if enabled +CME ERROR being returned to the TE. Subsequently, the MT announces a network request for PDP context activation by issuing the URC RING to the TE, followed by the intermediate result code CONNECT. The MT then enters V.25ter online data state and follows the same procedure as it would after having received a +CGANS=1 with no <L2P> or <cid> values specified.
- If a GPRS attach will be initiated by this command and the MT is not able to attach for more than 385 seconds (timer T3310 expired), command returns with "ERROR" or "+CME ERROR: unknown", but MT is still trying to attach and the requested automatic mode <n> is in use.
- If a network request for PDP context activation is answered automatically and if another AT command is issued at the same time on the same interface, then this AT command is not executed. Any response belongs to the automatic context activation procedure. If the AT command which caused the collision was a circuit switched data call, the CONNECT response does not belong to this data call but to the GPRS. This can be detected if [ATX](#) is not set to 0. CS data call will issue CONNECT <text>, GPRS will issue CONNECT only.

10.5 AT+CGDATA Enter data state

Syntax

Test Command AT+CGDATA=?	Response(s) +CGDATA: (list of supported <L2P>s) OK
Write Command AT+CGDATA=[<L2P>[,<cid>[,<cid>[,...]]]]	Response(s) CONNECT NO CARRIER ERROR +CME ERROR

Reference(s)	PIN	USB				
GSM 07.07	●	●				

Command Description

The test command is used for requesting information on the supported layer 2 protocols to be used between the TE and MT.

The write command causes the MT to perform all actions which are necessary to establish communication between the TE and the network using one or more GPRS PDP types. This may include performing a GPRS attach and one or more

PDP context activations. Commands following the [AT+CGDATA](#) command in the AT command line will not be processed by the MT.

If no [`<cid>`](#) is given or if there is no matching context definition, the MT will attempt to activate the context with PDP type IP and all other context parameters set to their default values (see [AT+CGDCONT](#), [AT+CGQREQ](#), [AT+CGQMIN](#)).

If the [`<L2P>`](#) parameter is omitted, the layer 2 protocol is unspecified and PPP will be used.

If the write command is successful, the MT issues the intermediate result code CONNECT and enters V.25ter online data state.

After data transfer is complete, and the layer 2 protocol termination procedure has completed successfully, the command state is reentered and the MT returns the final result code OK.

If the [`<L2P>`](#) parameter value is unacceptable to the MT, the MT returns ERROR or +CME ERROR.

In the event of erroneous termination or a failure to start up, the command state is reentered and the MT returns NO CARRIER, or if enabled +CME ERROR.

Parameter Description

[`<L2P>`](#)^(str)

Layer 2 protocol to be used between the TE and MT.

"PPP" layer 2 protocol PPP

"1" layer 2 protocol PPP

[`<cid>`](#)^(num)

Parameter specifies a particular PDP context definition. The parameter is local to the TE-MT interface and is used in other PDP context-related commands.

1...2

Notes

- If the MT is in dedicated mode, write command returns with "+CME ERROR: operation temporary not allowed".
- It is possible to leave the GPRS data mode and enter the command mode by using the V.25ter command **+++**. By using the command [AT+CGDATA](#) again, the data mode is reentered. Which context is used to return to data mode, depends on the supplied parameter [`<cid>`](#).
- If no [`<cid>`](#) is specified, this is equivalent to using the V.25ter command [ATO](#), which is usable for GPRS connections too. In this case the first context is used, which is active and which was already in data mode since it was activated (the internal context, which is used for GPRS connection without explicitly specifying a context identifier, has the highest priority).
- It is possible, to use [AT+CGDATA](#) to enter the data mode for a context, which was not in data mode since it was activated. With [ATO](#) this is not possible.

10.6 AT+CGDCONT Define PDP Context

Syntax

Test Command AT+CGDCONT=?	Response(s) +CGDCONT: (range of supported <cid>s),<PDP_type>,,,(list of supported <d_comp>s), (list of supported <h_comp>s) OK ERROR +CME ERROR
Read Command AT+CGDCONT?	Response(s) +CGDCONT:<cid>,<PDP_type>,<APN>,<PDP_addr>,<d_comp>,<h_comp> OK ERROR +CME ERROR
Write Command AT+CGDCONT=[<cid>[,<PDP_type>[,<APN>[,<PDP_addr>]]]]	Response(s) OK ERROR +CME ERROR

Reference(s)	PIN	USB					
GSM 07.07	●	●					

Command Description

The test command returns supported values as a compound value.

The read command returns the current settings for each defined PDP context.

The write command specifies the parameters for a PDP context identified by the context identifier <cid>. The number of contexts that may be in a defined state at the same time is given by the range returned by the test command. A special form of the write command (AT+CGDCONT=<cid>) causes the values for context <cid> to become undefined.

Parameter Description

<cid>^(num)

PDP Context Identifier

Parameter specifies a particular PDP context definition. The parameter is local to the TE-MT interface and is used in other PDP context-related commands.

1...2

<PDP_type>^(str)

Packet Data Protocol type

Specifies the type of the packet data protocol.

"IP" Internet Protocol (IETF STD 5)

<APN>^(str)

Access Point Name

The logical name that is used to select the GGSN or the external packet data network. If the value is null or omitted, then the subscription value will be requested.

<PDP_addr>^(str)

Packet Data Protocol address

Identifies the MT in the address space applicable to PDP (e.g. IP V4 address for PDP type IP). If the value is null or omitted, then a value

may be provided by the TE during the PDP startup procedure or, failing that, a dynamic address will be requested. The read command will continue to return the null string even if an address has been allocated during the PDP startup procedure. The allocated address may be read using **AT+CGPADDR**.

<d_comp>^(num) Data Compression

Controls the PDP data compression (applicable for Subnetwork Dependent Convergence Protocol (SNDCP) only) 3GPP TS 44.065

[0] off

<h_comp>^(num)

Header Compression

Controls the PDP header compression 3GPP TS 44.065, 3GPP TS 25.323

[0] off

Notes

- The MT supports PDP type IP only.
- AT&F and ATZ will undefine every context which is not active or not online.

10.7 AT+CGPADDR Show PDP address

Syntax

Test Command AT+CGPADDR=?	Response(s) +CGPADDR: (list of supported <cid>s) OK
Write Command AT+CGPADDR=[<cid>[<cid>[...]]]	Response(s) + CGPADDR: <cid>,<PDP_address> + CGPADDR: ... OK ERROR +CME ERROR

Reference(s)	PIN	USB					
GSM 07.07	●	●					

Command Description

The test command returns a list of defined <cid>s.

The write command returns a list of PDP addresses for the specified context identifiers.

Parameter Description

<cid>^(num)

a numeric parameter which specifies a particular PDP context definition (see **AT+CGDCONT** command).

<PDP address>^(str)

a string that identifies the MT in the address space applicable to the PDP. The address may be static or dynamic.

Note

- If no <cid> is specified, the write command will return a list of all defined contexts.

10.8 AT+CGQMIN Quality of Service Profile (Minimum acceptable)

Syntax

Test Command AT+CGQMIN=?	Response(s) +CGQMIN: <PDP_type>, (list of supported <precedence>s), (list of supported <delay>s), (list of supported <reliability>s), (list of supported <peak>s), (list of supported <mean>s) OK ERROR +CME ERROR
Read Command AT+CGQMIN?	Response(s) + CGQMIN: <cid>,<precedence>,<delay>,<reliability>,<peak>,<mean> OK ERROR +CME ERROR
Write Command AT+CGQMIN=[<cid>[,<precedence>[,<delay>[,<reliability>[,<peak> [,<mean>]]]]]]]	Response(s) OK ERROR +CME ERROR

Reference(s)	PIN	USB					
GSM 07.07	●	●					

Command Description

The test command returns values supported as a compound value. If the MT supports several PDP types, the parameter value ranges for each PDP type are returned on a separate line.

The read command returns the current settings for each defined context. If no minimum profile was explicitly specified for a context, simply OK will be returned, but default values will be used for that context.

This command allows the TE to specify a minimum acceptable profile which is checked by the MT against the negotiated profile returned in the Activate PDP Context Accept message.

The set command specifies a profile for the context identified by the (local) context identification parameter, a special form of the set command, **AT+CGQMIN=<cid>** causes the minimum acceptable profile for context number **<cid>** to become undefined. In this case no check is made against the negotiated profile. **AT&F** and **ATZ** will undefine the minimum QoS profiles of every context which is not active or not online.

Parameter Description

<cid>^(num)

Parameter specifies a particular PDP context definition. The parameter is local to the TE-MT interface and is used in other PDP context-related commands.

1...2

<precedence>^(num)

Precedence class

[0] network subscribed value

- | | |
|---|--|
| 1 | High Priority
Service commitments shall be maintained ahead of precedence classes 2 and 3 |
| 2 | Normal priority
Service commitments shall be maintained ahead of precedence class 3 |
| 3 | Low priority
Service commitments shall be maintained |

<delay>^(num)

Delay class

The delay parameter defines the end-to-end transfer delay incurred in the transmission of SDUs through the GPRS network(s).

[0] network subscribed value

1..4 SDU size: 128 octets:

Delay Class	Mean Transfer Delay	95 percentile
1 (Predictive)	<0.5	<1.5
2 (Predictive)	<5	<25
3 (Predictive)	<50	<250
4 (Best Effort)	Unspecified	

SDU size: 1024 octets:

Delay Class	Mean Transfer Delay	95 percentile
1 (Predictive)	<0.5	<1.5
2 (Predictive)	<5	<25
3 (Predictive)	<50	<250
4 (Best Effort)	Unspecified	

<reliability>^(num)

Reliability class

- | | |
|-----|--|
| [0] | network subscribed value |
| 1 | Non real-time traffic, error-sensitive application that cannot cope with data loss |
| 2 | Non real-time traffic, error-sensitive application that can cope with infrequent data loss |
| 3 | Non real-time traffic, error-sensitive application that can cope with data loss, GMM/SM, and SMS |
| 4 | Real-time traffic, error-sensitive application that can cope with data loss |
| 5 | Real-time traffic, error non-sensitive application that can cope with data loss |

<peak>^(num)

Peak throughput class (in octets per second).

- | | |
|-----|----------------------------|
| [0] | network subscribed value |
| 1 | Up to 1 000 (8 kbit/s). |
| 2 | Up to 2 000 (16 kbit/s). |
| 3 | Up to 4 000 (32 kbit/s). |
| 4 | Up to 8 000 (64 kbit/s). |
| 5 | Up to 16 000 (128 kbit/s). |

- 6 Up to 32 000 (256 kbit/s).
- 7 Up to 64 000 (512 kbit/s).
- 8 Up to 128 000 (1024 kbit/s).
- 9 Up to 256 000 (2048 kbit/s).

<mean>^(num)

Mean throughput class (in octets per hour).

- [0] network subscribed value
- 1 (-0.22 bit/s)
- 2 200 (-0.44 bit/s)
- 3 500 (-1.11 bit/s)
- 4 000 (-2.2 bit/s)
- 5 000 (-4.4 bit/s)
- 6 000 (-11.1 bit/s)
- 7 000 (-22 bit/s)
- 8 000 (-44 bit/s)
- 9 000 (-111 bit/s)
- 10 000 (-0.22 kbit/s)
- 11 200 000 (~0.44 kbit/s)
- 12 500 000 (~1.11 kbit/s)
- 13 000 000 (-2.2 kbit/s)
- 14 000 000 (-4.4 kbit/s)
- 15 000 000 (-11.1 kbit/s)
- 16 000 000 (-22 kbit/s)
- 17 000 000 (-44 kbit/s)
- 18 000 000 (-111 kbit/s)
- 31 best effort

<PDP_type>^(str)

Packet Data Protocol Type

"IP"

Notes

- If parameters are not defined, the parameter default values depend on the HLR-stored subscribed default values.
- Definitions of parameters in GSM 02.60 and GSM 03.60 paragraph 15.2 "Quality of Service Profile".

Example

If some of the QoS parameters are omitted, they will keep their current value (or the default value if not specified so far), e.g.:

AT+CGDCONT=1,"ip"

OK

AT+CGQMIN=

OK

AT+CGQMIN?

OK

AT+CGQMIN=1,0

OK

AT+CGQMIN?

```
+CGQMIN:1,0,0,0,0,0
OK
AT+CGQMIN=1,0,0,0,1
OK
AT+CGQMIN?
+CGQMIN:1,0,0,0,1,0
OK
AT+CGQMIN=1,1
OK
AT+CGQMIN?
+CGQMIN:1,1,0,0,1,0
OK
```

10.9 AT+CGQREQ Quality of Service Profile (Requested)

Syntax

Test Command AT+CGQREQ=?	Response(s) +CGQREQ: <PDP_type>, (list of supported <precedence>s), (list of supported <delay>s), (list of supported <reliability>s), (list of supported <peak>s), (list of supported <mean>s) OK +CME ERROR
Read Command AT+CGQREQ?	Response(s) + CGQREQ: <cid>,<precedence>,<delay>,<reliability>,<peak>,<mean> [+CGQREQ: <cid>,<precedence>,<delay>,<reliability>,<peak>,<mean>] ...
Write Command AT+CGQREQ=[<cid>[,<precedence>[,<delay>[,<reliability>[,<peak>[,<mean>]]]]]	Response(s) OK ERROR +CME ERROR

Reference(s)	PIN	USB					
GSM 07.07	•	•					

Command Description

The test command returns values supported as a compound value. If the MT supports several PDP types, the parameter value ranges for each PDP type are returned on a separate line.

The read command returns the current settings for each defined context. If no requested profile was explicitly specified for a context, simply OK will be returned, but default values will be used for that context.

This command allows the TE to specify a Quality of Service Profile that is used when the MT sends an Activate PDP Context Request message to the network.

The set command specifies a profile for the context identified by the (local) context identification parameter <cid>.

A special form of the set command, +CGQREQ=<cid> causes the requested profile for context number <cid> to become undefined.

AT&F and ATZ will undefine the QoS profiles of every context which is not active or not online.

Parameter Description

<cid>^(num)

Parameter specifies a particular PDP context definition. The parameter is local to the TE-MT interface and is used in other PDP context-related commands.

1...2

<precedence>^(num)

Precedence class

[0] network subscribed value

1 High Priority

Service commitments shall be maintained ahead of precedence classes 2 and 3

2 Normal priority

Service commitments shall be maintained ahead of precedence class 3

3 Low priority

Service commitments shall be maintained

<delay>^(num)

Delay class

This parameter defines the end-to-end transfer delay incurred in the transmission of SDUs through the GPRS network(s).

[0] network subscribed value

1 ..4 with SDU size = 128 octets:

Delay Class	Mean Transfer Delay	95 percentile
1 (Predictive)	<0.5	<1.5
2 (Predictive)	<5	<25
3 (Predictive)	<50	<250
4 (Best Effort)	Unspecified	

with SDU size = 1024 octets:

Delay Class	Mean Transfer Delay	95 percentile
1 (Predictive)	<0.5	<1.5
	<5	<25
3 (Predictive)	<50	<250
	Unspecified	-

<reliability>^(num)

Reliability class

[0] network subscribed value

1 Non real-time traffic, error-sensitive application that cannot cope with data loss

2 Non real-time traffic, error-sensitive application that can cope with infrequent data loss

3 Non real-time traffic, error-sensitive application that can cope with data loss, GMM/SM, and SMS

4	Real-time traffic, error-sensitive application that can cope with data loss Real-time traffic, error non-sensitive application that can cope with data loss
---	--

<peak>^(num)

Peak throughput class
in octets per second

- [0] network subscribed value
- 1 Up to 1 000 (8 kbit/s)
- 2 Up to 2 000 (16 kbit/s)
- 3 Up to 4 000 (32 kbit/s)
- 4 Up to 8 000 (64 kbit/s)
- 5 Up to 16 000 (128 kbit/s)
- 6 Up to 32 000 (256 kbit/s)
- 7 Up to 64 000 (512 kbit/s)
- 8 Up to 128 000 (1024 kbit/s)
- 9 Up to 256 000 (2048 kbit/s)

<mean>^(num)

Mean throughput class
in octets per hour

- [0] network subscribed value
- 1 100 (~0.22 bit/s)
- 2 200 (~0.44 bit/s)
- 3 500 (~1.11 bit/s)
- 4 1 000 (~2.2 bit/s)
- 5 2 000 (~4.4 bit/s)
- 6 5 000 (~11.1 bit/s)
- 7 10 000 (~22 bit/s)
- 8 20 000 (~44 bit/s)
- 9 50 000 (~111 bit/s)
- 10 100 000 (~0.22 kbit/s)
- 11 200 000 (~0.44 kbit/s)
- 12 500 000 (~1.11 kbit/s)
- 13 1 000 000 (~2.2 kbit/s)
- 14 2 000 000 (~4.4 kbit/s)

<PDP_type>^(str)

Packet Data Protocol type
"IP"

Notes

- If parameters are not defined, the parameter default values depend on the HLR-stored subscribed default values.
- Definitions of parameters in GSM 02.60 and GSM 03.60 paragraph 15.2 "Quality of Service Profile".

Example

If some of the QoS parameters are omitted, they will keep their current value (or the default value if not specified so far), e.g.:

```
AT+CGDCONT=1,"ip"
OK
```

```

AT+CGQREQ=
OK
AT+CGQREQ?
OK
AT+CGQREQ=1,0
OK
AT+CGQMIN?
+CGQREQ:1,0,0,0,0,0
OK
AT+CGQREQ=1,0,0,0,1
OK
AT+CGQREQ?
+CGQREQ:1,0,0,0,1,0
OK
AT+CGQREQ=1,1
OK
AT+CGQREQ?
+CGQREQ:1,1,0,0,1,0
OK

```

10.10 AT+CGREG GPRS network registration status

Syntax

Test Command AT+CGREG=?	Response(s) +CGREG: (list of supported <n>s) OK
Read Command AT+CGREG?	Response(s) +CGREG: <n>,<stat> OK
Write Command AT+CGREG=[<n>]	Response(s) OK ERROR +CME ERROR

Reference(s)	PIN	USB					
GSM 07.07	●	●					

Unsolicited Result Code

+CGREG: <stat>

Indicates a change in the MT's GPRS network registration status.

Command Description

The read command returns the status of result code presentation and an integer <stat> which shows whether the network has currently indicated the registration of the MT.

The write command controls the presentation of an unsolicited result code "+CGREG" when <n>=1 and there is a change in the MT's GPRS network registration status.

Parameter Description

<n>^(num)

<code><stat></code> ^(num)	0(P) 1 2 3 4 5	disable network registration unsolicited result code enable network registration unsolicited result code "+CGREG" 1 not registered, ME is not currently searching an operator to register to the MS is in GMM state GMM-NULL or GMM-DEREGISTERED-INITIATED. The GPRS service is disabled, the MS is allowed to attach for GPRS if requested by the user. 2 registered, home network. The MS is in GMM state GMM-REGISTERED or GMM-ROUTING-AREA-UPDATING-INITIATED initiated on the home PLMN. 3 not registered, but ME is currently trying to attach or searching an operator to register to. The MS is in GMM state GMM-DEREGISTERED or GMM-REGISTERED-INITIATED. The GPRS service is enabled, but an allowable PLMN is currently not available. The MS will start a GPRS attach as soon as an allowable PLMN is available. 4 registration denied. The MS is in GMM state GMM-NULL. The GPRS service is disabled, the MS is not allowed to attach for GPRS if requested by the user unknown. 5 registered, roaming. The MS is in GMM state GMM-REGISTERED or GMM-ROUTING-AREA-UPDATING-INITIATED on a visited PLMN.
--	-------------------------------	---

Note

- When the module is GPRS attached and a PLMN reselection occurs to a non-GPRS capable network or to a network where the SIM is not subscribed to for using GPRS, the resulting GMM (GPRS mobility management) state according to GSM 24.008 is REGISTERED/NO CELL, meaning that the read command will still show `<stat>=1` or `<stat>=5`.

10.11 AT+CGSMS Select service for MO SMS messages

Syntax

Test Command <code>AT+CGSMS=?</code>	Response(s) +CGSMS: (list of supported <code><service></code> s) OK
Read Command <code>AT+CGSMS?</code>	Response(s) +CGSMS: <code><service></code> OK
Write Command <code>AT+CGSMS=[<service>]</code>	Response(s) OK ERROR +CME ERROR

Reference(s)	PIN	USB					
GSM 07.07	○	●					

Command Description

The test command is used for requesting information on which services and service preferences can be set by using the [AT+CGSMS](#) write command.

The read command returns the currently selected service or service preference.

The write command is used to specify the service or service preference that the MT will use to send MO SMS messages. If parameter <service> is not given, the current value remains unchanged.

Parameter Description

<service>^(num)

A numeric parameter which indicates the service or service preference to be used

- | | |
|-----|--|
| 0 | GPRS |
| 1 | circuit switched |
| 2 | GPRS prefered (use circuit switched if mobile is not GPRS attached) |
| [3] | circuit switched preferred (use GPRS if circuit switched is not available) |

Note

- Parameter cannot be stored using [AT&W](#)

10.12 AT^SGAUTH Set type of authentication for PPP connection

Syntax

Test Command AT^SGAUTH=?	Response(s) ^SGAUTH: (list of supported <auth>s) OK ERROR +CME ERROR
Read Command AT^SGAUTH?	Response(s) ^SGAUTH: <auth> OK ERROR +CME ERROR
Write Command AT^SGAUTH=<auth>	Response(s) OK ERROR +CME ERROR

Reference(s)	PIN	USB					
SIEMENS	●	●					

Parameter Description

<auth>^(num)

Indicates types of supported authentication.

- | | |
|------------------|--------------|
| 0 | none |
| 1 | PAP |
| 2 | CHAP |
| 3 ^(P) | PAP and CHAP |

10.13 AT[^]SGCONF Configuration of GPRS related Parameters

Syntax

Test Command AT [^] SGCONF=?	Response(s) ^SGCONF: (list of supported <llc_pdu_length>s), (list of supported <class>es) OK
Read Command AT [^] SGCONF?	Response(s) ^SGCONF: <llc_pdu_length>,<class> OK
Write Command AT [^] SGCONF=[<llc_pdu_length>][,<class>]	Response(s) OK ERROR +CME ERROR

Reference(s)	PIN	USB					
SIEMENS	○	●					

Parameter Description

<llc_pdu_length>^(num)

LLC-PDU-length

- 0 no negotiation with network (500 will be used)
- 140...1520^(P) lower values diminish performance

<class>^(num)

GPRS Multislot Class. The parameter can be changed only when the MT is detached, otherwise "CME ERROR: operation temporary not allowed" will be returned. The value can be one of the classes indicated with the test command.

Notes

- +CME ERROR: invalid index: Parameter is out of range.
- +CME ERROR: operation temporary not allowed: The command is blocked as long as GPRS is already in use (as long as mobile is GPRS attached).
- Writing to user profile with AT&W and restoring with AT&F are not supported.

10.14 ATA Manual response to a network request for PDP context activation

Syntax

Exec Command ATA	CONNECT NO CARRIER
---------------------	-----------------------

Reference(s)	PIN	USB					
GSM 07.07	●	●					

Command Description

The V.25ter **ATA** command may be used to accept a network request for a PDP context activation announced by the unsolicited result codes RING or "+CRING: GPRS". The MT responds with CONNECT, enters V.25ter online data state and

follows the same procedure as it would after having received a [AT+CGANS=1](#) with no <L2P> or <cid> values specified.

If you try to answer a request which is no longer present or which is already answered by another instance, NO CARRIER is returned.

10.15 ATD*99# Request GPRS service

Syntax

Exec Command ATD*99[* [<called_address>][* [<L2P>][* [<cid>]]]]#	Response(s) CONNECT NO CARRIER
---	--------------------------------------

Reference(s)	PIN	USB				
GSM 07.07	●	●				

Command Description

This command causes the MT to perform whatever actions are necessary to establish communication between the TE and the external PDN.

The V.25ter 'D' (Dial) command causes the MT to enter the V.25ter online data state and, with the TE, to start the specified layer 2 protocol. No further commands may follow on the AT command line. GPRS attachment and PDP context activation procedures may take place prior to or during the PDP startup if they have not already been performed using the [AT+CGATT](#) and [AT+CGACT](#) commands. If the context to be used is already activated, it will be deactivated first. This ensures that the right context parameters will be used (e.g. QoS changes since the last context activation or the called address specified by [ATD*99#](#)).

Examples on how to use this command are provided in chapter "[using GPRS AT commands \(Examples\)](#)".

To confirm acceptance of the command before entering the V.25ter online data state command will respond with CONNECT.

When the layer 2 protocol has terminated, either as a result of an orderly shutdown of the PDP or an error, the MT enters V.25ter command state and returns NO CARRIER.

Parameter Description

<called_address>^(str)

IP V4 address in the form w.x.y.z, which identifies the called party; if it is provided, the MT will automatically set up a virtual call to the specified address after the context has been activated. This parameter is currently not used and needs not to be specified.

<L2P>^(str)

Layer 2 protocol to be used between the TE and MT.

"PPP" layer 2 protocol PPP

"1" layer 2 protocol PPP

<cid>^(num)

Parameter specifies a particular PDP context definition (see [AT+CGDCONT](#) command). If no context is specified, an internal context 0 with default properties is used (see [AT+CGDCONT](#), [AT+CGQREQ](#) and [AT+CGQMIN](#)).

1...2

Notes

- If SAMBA75 is in dedicated mode, command returns with "+CME ERROR: phone busy".
- ATD is used as a standard V.25ter AT command, too.

10.16 ATD*98# Request GPRS IP service**Syntax**

Exec Command ATD*98[* <cid>]#	Response(s) CONNECT NO CARRIER
Reference(s)	PIN USB
GSM 07.07	● ●

Command Description

This command causes the MT to perform whatever actions are necessary to establish a communication between the TE and the external PDN.

The V.25ter 'D' (Dial) command causes the MT to enter the V.25ter online data state and, with the TE, to start the layer 2 protocol.

GPRS attachment and PDP context activation procedures may take place prior to or during the PDP startup if they have not already been performed using the [AT+CGATT](#) and [AT+CGACT](#) commands. If the context to be used is already activated, it will be deactivated first. This ensures that the right context parameters will be used (e.g. QoS changes since the last context activation).

To confirm acceptance of the command before entering the V.25ter online data state command will respond with CONNECT.

When the layer 2 protocol has terminated, either as a result of an orderly shutdown of the PDP or an error, the MT enters V.25ter command state and returns NO CARRIER.

Parameter Description

<cid>^(num)

Parameter specifies a particular PDP context definition (see [AT+CGDCONT](#) command). If no context is specified, an internal context 0 with default properties is used (see [AT+CGDCONT](#), [AT+CGQREQ](#) and [AT+CGQMIN](#)).

1...2

Notes

- If SAMBA75 is in dedicated mode, command returns with "+CME ERROR: phone busy".
- ATD is used as a standard V.25ter AT command, too.

10.17 ATH Manual rejection of a network request for PDP context activation**Syntax**

Exec Command ATH	Response(s) OK
---------------------	-------------------

Reference(s)	PIN	USB				
GSM 07.07	●	●				

Command Description

The V.25ter **ATH** command may be used to deactivate all PDP contexts which are active or online on the same interface.

The **ATH** command may also be used to reject a network request for PDP context activation announced by the unsolicited result codes "RING" or "+CRING:GPRS".

Notes

- In contrast to GSM 07.07 it is possible to cancel a connection with **ATH** after a break. This is done for compatibility reasons due to the "dial-up network" drivers of Microsoft Windows.
- **ATH** is used as a standard V.25ter AT command, too.
- If **ATH** is used to reject a network request for PDP context activation, then other PDP contexts on the same interface which are active or online will not be deactivated.

10.18 ATSO Automatic response to a network request for PDP context activation

Syntax

Read Command ATSO?	Response(s) <n> OK
Write Command ATSO=<n>	Response(s) OK

Reference(s)	PIN	USB				
GSM 07.07	●	●				

Command Description

The V.25ter **ATSO=<n>** (Automatic answer) command may be used to turn off ($n=0$) and on ($n>0$) the automatic response to a network request for a PDP context activation.

When the **ATSO=<n>** ($<n> > 0$) command is received, the MT will attempt to perform a GPRS attach if it is not yet attached and if ME is configured to do this (see **AT&SCFG**, parameter **<gaa>**). Failure will result in **ERROR** being returned to the TE. Subsequently, the MT will announce a network request for PDP context activation by issuing the URC RING or CRING to the TE, followed by the intermediate result code CONNECT. The MT then enters V.25ter online data state and follows the same procedure as it would after having received a **AT+CGANS=1** command with no **<L2P>** or **<cid>** values specified. **ATSO=0** does not perform an automatic GPRS detach.

Parameter Description

<n>^{(num)(&W)(&V)}

000(&F)automatic answering is disabled

001-255 enable automatic answering on the specified ring number

Notes

- If different settings are used on each interface, and a request for PDP context activation is received, the interface 'wins' which is idle and uses the smallest **ATSO** value.
- If a network request for PDP context activation is answered automatically and another AT command is issued at the same time on the same interface then this AT command will not be executed. Any response belongs to the automatic context activation procedure. If the AT command which caused the collision was a CS data call, the CONNECT response does not belong to this data call but to the GPRS. This can be detected if **ATX** is not set to 0. CS data call will issue CONNECT <text>, GPRS will issue CONNECT only.
- A network request for PDP context activation has a maximum duration of approximately 40 seconds (for details see GSM 04.08). A RING/CRING URC is issued every 5 seconds, so setting parameter <n> to values greater than 7 will not allow a successful context activation and is not recommended.
- The automatic GPRS attach will not be performed on recalling a stored user profile with **ATZ** or on power up, if an > 0 setting was stored in the user profile with **AT&W**.
- If the automatic GPRS attach fails (e.g. the network rejects the attach request), the write command returns with error, but the value of <n> is changed anyway. This is necessary because ATSO is used for circuit switched calls too (see **ATSO**).
- ATSO write command is PIN protected.

10.19 Using GPRS AT commands (Examples)

Examples:

EXAMPLE 1

Defining and using a Context Definition ID (CID):

Every time a CID is used as a parameter for a GPRS command the CID has to be defined before by using the **AT+CGDCONT** command. To get the parameter of a CID use the **AT+CGDCONT** read option. If the response of '**AT+CGDCONT?**' is OK only, there is no CID defined.

AT+CGDCONT?

OK

There is no CID defined.

All parameters of the CID are initiated by NULL or not present values, and the CID itself is set to be undefined. To define a CID use the **AT+CGDCONT** command with at least one CID parameter. At the moment the mobile supports CID 1 and CID 2 by using the **AT+CGDCONT** command.

Define CID 1 and set the PDP type to IP, access point name and IP address are not set:

AT + CGDCONT=1, "IP"

OK

Define CID 2 and sets PDP type, APN and IP addr:

AT+CGDCONT=2,"IP","internet.t-d1.gprs",111.222.123 . 234

OK

A following read command will respond:

AT+CGDCONT?

+ CGDCONT:1,"IP","","","",0,0

+CGDCONT:2,"IP","internet.t-d1.gprs",111.222.123 . 234

OK

Set the CID 1 to be undefined:

AT+CGDCONT=1

OK

A following read command will respond:

AT+CGDCONT?

+CGDCONT:2,"IP","internet.t-d1.gprs",111.222.123.234

OK

EXAMPLE 2

Quality of Service (QoS) is a special parameter of a CID which consists of several parameters itself. The QoS consists of

- the precedence class
- the delay class
- the reliability class
- the peak throughput class
- the mean throughput class

and is divided in "requested QoS" and "minimum acceptable QoS".

All parameters of the QoS are initiated by default to the "network subscribed value (= 0)" but the QoS itself is set to be undefined. To define a QoS use the [AT+CGQREQ](#) or [AT+CGQMIN](#) command.

Overwrite the precedence class of QoS of CID 1 and set the QoS of CID 1 to be present:

AT+CGQREQ=1,2

OK

A following read command will respond:

AT+CGQREQ?

+CGQREQ: 1,2,0,0,0,0

OK

All QoS values of CID 1 are set to network subscribed now, except precedence class which is set to 2. Now set the QoS of CID 1 to not present:

AT+CGQREQ=1

OK

Once defined, the CID it can be activated. To activate CID 2 use:

AT+CGACT=1,2

OK

If the CID is already active, the mobile responds OK at once.

If no CID and no STATE is given, all defined CIDs will be activated by:

AT+CGACT=

OK

If no CID is defined the mobile responds +CME ERROR: invalid index

Remark: If the mobile is NOT attached by [AT+CGATT=1](#) before activating, the attach is automatically done by the [AT+CGACT](#) command.

After defining and activating a CID it may be used to get online by:

AT + CGDATA="PPP" ,1

CONNECT The mobile is connected using the parameters of CID 1.

AT+CGDATA=

CONNECT The mobile is connected using default parameters (<L2P>="PPP" and <cid> as described for command [AT+CGDATA](#)).

The mobile supports Layer 2 Protocol (L2P) PPP only.

Remark: If the mobile is NOT attached by [AT+CGATT=1](#) and the CID is NOT activated before connecting, attaching and activating is automatically done by the [AT+CGDATA](#) command.

Some providers (e.g. D2 or E-Plus) require to use an APN to establish a GPRS connection. So if you use the Microsoft Windows Dial-Up Network and ATD*9... to connect to GPRS you must provide the context definition as part of the modem definition (Modem properties/Connection/Advanced.../Extra settings). As an alternative, you can define and activate the context in a terminal program (e.g. Microsoft Hyperterminal) and then use the Dial-Up Network to send only the [ATD](#) command.

10.20 Using the GPRS dial command ATD

Example

In addition to the GPRS AT commands you can use the "D" command to dial into to the GPRS network.

There are two GPRS Service Codes for the [ATD](#) command: Values 98 and 99. Examples:

```
ATD*99#
CONNECT
ATD*99*123.124.12 5.12 6*PPP*1#
CONNECT
```

Establish a connection by service code 99.

Establish a connection by service code 99, IP address 123 and L2P = PPP and using CID 1. The CID has to be defined by [AT+CGDCONT](#).

```
ATD*99**PPP#
CONNECT
ATD*99***1#
CONNECT
ATD*99**PPP*1#
CONNECT
```

Establish a connection by service code 99 and L2P = PPP.

Establish a connection by service code 99 and using CID 1.

Establish a connection by service code 99 and L2P = PPP and using CID 1. The CID has to be defined by [AT+CGDCONT](#).

```
ATD*98#
CONNECT
ATD*98*1#
CONNECT
```

Establish a connection by service code 98.

Establish an IP connection by service code 98 using CID 1. The CID has to be defined by [AT+CGDCONT](#).

11 FAX COMMANDS

The following commands can be used for FAX transmission. If the ME is acting as a Fax-Modem to a PC-based application (e.g. "WinFax") it is necessary to select the proper Service Class (Fax Class) provided by the ME. The ME reports its Service Class capabilities, both the current setting and the range of services available. This is provided by the **AT+FCLASS** command. Service Classes supported by ME:

AT+FCLASS Parameter	Service class	
0		e.g. TIA/EIA-602 or ITU V.25ter
1	Service Class 1	
2	manufacture specific	this document and EIA PN-2388 (draft)

The following AT commands are dummy commands:

AT+FAA	Auto Answer mode
AT+FECM	Error Correction Mode control
AT+FLNFC	Page Length format conversion
AT+FLPL	Indicate document available for polling
AT+FMINSP	Minimum Phase C speed
AT+FRBC	Phase C data receive byte count
AT+FREL	Phase C received EOL alignment
AT+FSPL	Enable polling
AT+FTBC	Phase C data transmit byte count
AT+FWDFC	Page width format conversion

Invoking these commands will not cause ERROR result codes, but these commands have no functionality.

11.1 FAX parameters

Parameter Description

<bf>^(num)

Binary File Transfer Mode

Note: Only the default value needs to be implemented. Use test command to check which parameter values are really possible!

- [0] disable BFT
- 1 enable BFT

**
^(num)**

Bit Rate

- 0 2400 bit/s, V.27ter
- 1 4800 bit/s, V.27ter
- 2 7200 bit/s, V.29
- [3] 9600 bit/s, V.29

<df>^(num)

Data Compression Format

Note: Only the default value needs to be implemented. Use test command to check which parameter values are really possible!

- [0] 1-D modified Huffman
- 1 2-D modified read
- 2 2-D uncompressed mode

<ec>^(num)

Error Correction Mode

Note: Only the default value needs to be implemented. Use test command to check which parameter values are really possible!

- [0] disable ECM
- 1 enable ECM, 64 bytes/frame
- 2 enable ECM, 256 bytes/frame

<ln>^(num)

Page Length

- 0 A4, 297 mm
- 1 B4, 364 mm
- [2] unlimited length

<mod>^(num)

modulation mode

- 3 V21 Ch2 - 300 bps
- 24 V.27ter - 2400 bps
- 27 V.27ter-4800 bps
- 48 V.27ter - 7200 bps
- 72 V.29 - 7200 bps
- 96 V.29 - 9600 bps

<st>^(num)

Scan Time/Line

Note: Only the default value needs to be implemented. Use test command to check which parameter values are really possible![0] 0 ms (at VR= normal)

- 1 5 ms
- 2 10 ms
- 3 10 ms
- 4 20 ms
- 5 20 ms
- 6 40 ms
- 7 40 ms

<vr>^(num)

Vertical Resolution

- 0 normal, 98 lpi
- [1] fine, 196 lpi

<wd>^(num)

Page Width

- [0] 1728 pixels in 215mm
- 1 2048 pixels in 255 mm
- 2 2432 pixels in 303 mm
- 3 1216 pixels in 151 mm
- 4 864 pixels in 107 mm

Note

- Only the default value needs to be implemented. Use test command to check which parameter values are really possible.

11.2 AT+FBADLIN Bad Line Threshold

Syntax

Read Command AT+FBADLIN?	Response(s) <badlin> OK
Write Command AT+FBADLIN=<badlin>	Response(s) If error is related to ME functionality ERROR

Reference(s)	PIN	USB					
		●					

Command Description

This command defines the Copy-Quality-OK-threshold. If <badlin> consecutive lines have pixel count errors in normal resolution (98 dpi) mode, then the copy quality is unacceptable. If <badlin> * 2 consecutive lines have pixel count errors in fine resolution (196 dpi) mode, then the copy quality is unacceptable. "Copy Quality Not OK" occurs if either the error percentage is too high or too many consecutive lines contain errors. A value of 0 implies that error checking is not present or disabled.

Parameter Description

<badlin>^(num)

bad lines

0...10^(P)...255

Note

- Used for Fax Class 2 only

11.3 AT+FBADMUL Error Threshold Multiplier

Syntax

Read Command AT+FBADMUL?	Response(s) <badmul> OK
Write Command AT+FBADMUL=<badmul>	OK If error is related to ME functionality:

Reference(s)	PIN	USB					
		●					

Command Description

This command defines the "Copy-Quality-OK" multiplier. The number of lines received with a bad pixel count is multiplied by this number. If the result exceeds the total number of lines on the page the error rate is considered too high. A threshold multiplier value of 20 corresponds to a 5 per cent error rate. A value of 0 implies that error checking is not present or disabled.

Parameter Description

<badmul>^(num)

0...20^(P)...255**Note**

- Used for Fax Class 2 only

11.4 AT+FBOR Query data bit order

Syntax

Test Command AT+FBOR=?	Response(s) (list of supported <bor>s) OK
Read Command AT+FBOR?	Response(s) <bor> OK
Write Command AT+FBOR=<bor>	Response(s)

Reference(s)	PIN	USB					
EIA PN-2388	O						

Command Description

Query the bit order for receive-mode. The mode is set by the ME depending on the selected Service Class, see "["AT+FCLASS](#) Fax: Select, read or test service class".

Parameter Description<bor>^(num)

bit order modes

- 0 Direct bit order for both Phase C and for Phase B/D data.
- [1] Reversed bit order for Phase C data, direct Bit Order for Phase B/D data.

Note

- Used for Fax Class 2 only

11.5 AT+FCIG Query or set the Local Polling ID

Syntax

Test Command AT+FCIG=?	Response(s) (max. length of Local Polling ID string) (range of supported ASCII character values) OK
Read Command AT+FCIG?	Response(s) <id> OK
Write Command AT+FCIG=<id>	Response(s)

Reference(s)	PIN						
EIA PN-2388	O	●					

Parameter Description<id>^(num)

Local Polling ID string, max. length and possible content as reported by test command. Default value is empty string ("").

Notes

- Used for Fax Class 2 only.
- See also [AT+FLID](#) Query or set the Local Id setting capabilities.

11.6 AT+FCLASS Fax: Select, read or test service class

Syntax

Test Command AT+FCLASS=?	Response(s) OK
Read Command AT+FCLASS?	Response(s) OK
Write Command AT+FCLASS=<n>	Response(s) OK

	PIN	USB					
EIA/TIA-592-A	○	●					

Command Description

The ME is set to a particular mode of operation (data, fax). This causes the MA to process information in a manner suitable for that type of information.

Parameter Description

<n>^{(num)(&W)(&V)}

[0](&F)	data (e.g. EIA/TIA-602 or ITU V.25ter)
1	Fax class 1 (EIA/TIA-578-A, Service class 1)
2	Fax class 2 (EIA/TIA SP-2388, an early draft version of EIA/TIA-592-A - Service class 2.1)

Notes

- Using Error Correcting Mode (ECM) when sending FAXes over GSM should be avoided.
- If <n> is set to 1 or 2, all incoming calls will be answered as fax calls with [ATA](#).
- It is possible to change the setting of <n> to 0 while the call is ringing, and accept the call normally afterwards with [ATA](#).

11.7 AT+FCQ Copy Quality Checking

Syntax

Test Command AT+FCQ=?	Response(s) (list of supported copy quality checking <cq>s) OK
Read Command AT+FCQ?	Response(s) <cq> OK
Write Command AT+FCQ=<cq>	Response(s) OK

Reference(s)	PIN	USB				
EIA PN-2388		●				

Command Description

This command controls Copy Quality checking when receiving a fax.

Parameter Description

`<cq>(num)`

- | | |
|-----|--|
| 0 | No copy quality checking. The ME will generate Copy Quality OK (MCF) responses to complete pages. |
| [1] | ME can check 1-D phase data. The connected application must check copy quality for 2-D phase C data. |

Note

- Used for Fax Class 2 only

11.8 AT+FCR Capability to receive

Write Command	Response(s)		
AT+FCR=<cr>	OK		

Reference(s)	PIN	USB				
EIA PN-2388	○	●				

Parameter Description

`<cr>(num)`

- | | |
|-----|---|
| [0] | ME will not receive message data. This can be used when the application has insufficient storage. The ME can send and can be polled for a file. |
| 1 | ME can receive message data. |

Note

- Used for Fax Class 2 only

11.9 AT+FDCC Query or set capabilities

Syntax

Test Command	Response(s)
	<df>s, (list of <ec>s), (list of <bf>s), (list of <st>s) OK
Write Command AT+FDCC=<vr>, ,<wd>,<ln>,<df>,<ec>,<bf>,<st>	Response(s) OK

Reference(s)	PIN	USB				
EIA PN-2388	○					

Command Description

This command allows the connected application to sense and constrain the capabilities of the facsimile DCE (=ME), from the choices defined in CCITT T.30 table 2.

Notes

- For further information see [AT+FDIS](#).
- Used for Fax Class 2 only.

11.10 AT+FDFFC Data Compression Format Conversion

Syntax

Test Command AT+FDFFC=?	Response(s) (list of <df>s) OK
Read Command AT+FDFFC?	Response(s) <df> OK
Write Command	Response(s) OK

Reference(s)	PIN	USB					
EIA PN-2388	O						

Command Description

This parameter determines the ME response to a mismatch between the data format negotiated for the fax session, reported by the <df> subparameter, and the Phase C data desired by the controlling application, indicated by the optional [AT+FDT <df>](#) subparameter, or the [AT+FDIS <df>](#) subparameter for [AT+FDR](#) operation.

Parameter Description

<df>^(num)

- | | |
|-----|--|
| [0] | Mismatch checking is always disabled. The controlling application has to check the <df> subparameter and transfer matching data. |
|-----|--|

Notes

- For further information see [AT+FDIS](#).
- Used for Fax Class 2 only.

11.11 AT+FDIS Query or set session parameters

Syntax

Test Command AT+FDIS=?	Response(s) (list of <vr>s), (list of s), (list of <wd>s), (list of <ln>s), (list of <df>s), (list of <ec>s), (list of <bf>s), (list of <st>s) OK
Read Command AT+FDIS?	Response(s) <vr>, ,<wd>,<ln>,<df>,<ec>,<bf>,<st> OK
Write Command AT+FDIS=<vr>, ,<wd>,<ln>,<df>,<ec>,<bf>,<st>	Response(s) OK

Reference(s)	PIN	USB				
EIA PN-2388	○	●				

Command Description

This command allows the controlling application to sense and constrain the capabilities used for the current session. It uses **AT+FDIS** to generate DIS or DTC messages directly, and uses **AT+FDIS** and received DIS messages to generate DCS messages.

Note

- Used for Fax Class 2 only.

11.12 AT+FDR Begin or continue phase C data reception

Syntax

Exec Command AT+FDR	Response(s) CONNECT or OK If error related to ME functionality
------------------------	--

Reference(s)	PIN	USB				
EIA PN-2388	○	●				

Command Description

The command initiates transition to Phase C data reception.

Note

- Used for Fax Class 2 only.

11.13 AT+FDT Data Transmission

Syntax

Exec Command AT+FDT	Response(s) CONNECT
Write Command AT+FDT=<df>,<vr>,<wd>,<ln>	Response(s) CONNECT

Reference(s)	PIN	USB				
EIA PN-2388	○	●				

Command Description

This command requests the ME to transmit a Phase C page. When the ME is ready to accept Phase C data, it issues the negotiation responses and the CONNECT result code to the application.

In Phase B, the **AT+FDT** command releases the ME to proceed with negotiation, and releases the DCS message to the remote station. In Phase C, the **AT+FDT** command resumes transmission after the end of a data stream transmitted before.

Note

- Used for Fax Class 2 only.

11.14 AT+FET End a page or document

Syntax

Write Command AT+FET=<ppm>	Response(s) OK
-------------------------------	-------------------

Reference(s)	PIN	USB				
EIA PN-2388	○	●				

Command Description

This command indicates that the current page or partial page is complete. An ERROR response code results if this command is issued while the mode is on-hook.

Parameter Description<ppm>^(num)

Post Page Message Codes

1	another document next
2	no more pages or documents
3	another page, procedure interrupt
4	another document, procedure interrupt

Note

- Used for Fax Class 2 only

11.15 AT+FK Kill operation, orderly FAX abort

Syntax

Exec Command AT+FK	Response(s) OK
-----------------------	-------------------

PIN	USB				
○	●				

Command Description

This command causes the TA to terminate the session in an orderly manner.

Note

- Used for Fax Class 2 only

11.16 AT+FLID Query or set the Local Id setting capabilities

Syntax

Test Command AT+FLID=?	Response(s) (max. character length of Local ID string) (range of supported ASCII character values) OK
---------------------------	---

Read Command AT+FLID?	Response(s) <lid> OK
Write Command AT+FLID=<lid>	Response(s)

Reference(s)	PIN	USB					
EIA PN-2388	○	●					

Parameter Description<lid>^(num)

Local ID string

max. length and possible content as reported by test command.
Default value is empty string ("").**Notes**

- Used for Fax Class 2 only.
- See also [AT+FCIG](#) Query or set the Local polling id.

11.17 AT+FMDL Identify Product Model

Syntax

Read Command AT+FMDL?	Gipsy Soft Protocolstack OK
--------------------------	-----------------------------

Reference(s)	PIN						
SIEMENS	○	●					

Command Description

Send the model identification to the TA.

Note

- Used for Fax Class 2 only.

11.18 AT+FMFR Request Manufacturer Identification

Syntax

Read Command AT+FMFR?	Response(s) SIEMENS OK
--------------------------	------------------------------

Reference(s)	PIN	USB					
SIEMENS	○	●					

Command Description

Send the manufacturer identification to the TA.

Note

- Used for Fax Class 2 only.

11.19 AT+FOPT Set bit order independently

Syntax

Write Command AT+FOPT=<opt>	Response(s) OK
--------------------------------	-------------------

Reference(s)	PIN	USB					
SIEMENS	○	●					

Command Description

Model specific command to set bitorder independently of the understanding which is "mirrored" and which is direct.

Parameter Description

<opt>^(num)

- 0 non-standard
- 1 standard

Note

- Used for Fax Class 2 only.

11.20 AT+FPHCTO DTE Phase C Response Timeout

Syntax

Read Command AT+FPHCTO?	Response(s) <tout> OK
Write Command AT+FPHCTO=<tout>	Response(s) OK If error is related to ME functionality ERROR

Reference(s)	PIN	USB					
EIA PN-2388	○	●					

Command Description

The time-out value <tout> determines how long the DCE will wait for a command after reaching the end of data when transmitting in Phase C. When time-out is reached, the DCE assumes that there are no more pages or documents to send.

Parameter Description

<tout>^(num)

- Timeout
- Value in 100ms units
- 0...30^(P)...255

Note

- Used for Fax Class 2 only.

11.21 AT+FREV Identify Product Revision

Syntax

Read Command AT+FRREV?	Response(s) V2.550 OK
---------------------------	-----------------------------

Reference(s)	PIN	USB					
SIEMENS	○	●					

Command Description

Sends the revision identification to the TA.

Note

- Used for Fax Class 2 only.

11.22 AT+FRH Receive Data Using HDLC Framing

Syntax

Write Command AT+FRH=<mod>	Response(s) CONNECT If error related to ME functionality: ERROR
-------------------------------	--

Reference(s)	PIN	USB					
TIA/EIA-578	○	●					

Command Description

This command causes the TA to receive frames using the HDLC protocol and the modulation defined below. An ERROR response code results if this command is issued while the modem is on-hook.

Note

- Used for Fax Class 1 only

11.23 AT+FRM Receive Data

Syntax

Test Command AT+FRM=?	Response(s) (list of <mod>s) OK
Write Command AT+FRM=<mod>	Response(s) CONNECT If error is related to ME functionality: ERROR

Reference(s)	PIN	USB					
TIA/EIA-578	○	●					

Command Description

This command causes the TA to enter the receiver-mode using the modulation defined below. An ERROR response code results if this command is issued while the modem is on-hook.

Notes

- Used for Fax Class 1 only

- <mod>= 3 is not possible

11.24 AT+FRS Receive Silence

Syntax

Write Command AT+FRS=<time>	Response(s) OK If error related to ME functionality ERROR
--------------------------------	--

Reference(s)	PIN	USB					
TIA/EIA-578	○	●					

Command Description

<time>=n causes the TA to report an OK result code to the TE after <time> 10 millisecond intervals of silence have been detected on the line. This command is aborted if any character is received by the DTE. The modem discards the aborting character and issues an OK result code. An ERROR response code results if this command is issued while the mode is on-hook.

Parameter Description

<time>^(num)

no. of 10 millisecond intervals
0...255

Note

- Used for Fax Class 1 only

11.25 AT+FTH Transmit Data Using HDLC Framing

Syntax

Write Command AT+FTH=<mod>	Response(s) CONNECT
-------------------------------	------------------------

Reference(s)	PIN	USB					
TIA/EIA-578	○	●					

Command Description

This command causes the TA to transmit data using HDLC protocol and the modulation mode defined below. An ERROR response code results if this command is issued while the modem is on-hook.

Notes

- Used for Fax Class 1 only
- Only <mod>= 3 is possible

11.26 AT+FTM Transmit Data

Syntax

Test Command AT+FTM=?	Response(s) (list of <mod>s)
--------------------------	---------------------------------

Write Command AT+FTM=<mod>	Response(s) CONNECT If error is related to ME functionality ERROR
-------------------------------	--

Reference(s)	PIN	USB					
TIA/EIA-578	○	●					

Command Description

This command causes the TA to transmit data using the modulation mode defined below. An ERROR response code results if this command is issued while the modem is on-hook.

Notes

- Used for Fax Class 1 only
- <mod>= 3 is not possible

11.27 AT+FTS Stop Transmission and Wait

Syntax

Write Command AT+FTS=<time>	Response(s) An ERROR response code results if this command is issued while the modem is on-hook.
--------------------------------	---

Reference(s)	PIN	USB					
TIA/EIA-578	○	●					

Command Description

This command causes the TA to terminate a transmission and wait for <time> 10 millisecond intervals before responding with the OK result code to the DTE.

Parameter Description

<time>^(num)

no. of 10 millisecond intervals
0...85

Note

- Used for Fax Class 1 only

11.28 AT+FVRFC Vertical resolution format conversion

Syntax

Test Command AT+FVRFC=?	Response(s) (list of supported <vrfc>s)
Read Command AT+FVRFC?	Response(s) OK
Write Command AT+FVRFC=<vrfc>	Response(s)

Reference(s)	PIN	USB					

EIA PN-2388	<input type="radio"/>	<input checked="" type="radio"/>						
-------------	-----------------------	----------------------------------	--	--	--	--	--	--

Command Description

This command determines the DCE response to a mismatch between the vertical resolution negotiated for the facsimile session and the Phase C data desired by the DTE.

Parameter Description

<vrfo>^(num)

- | | |
|-----|---|
| 0 | Disable mismatch checking. |
| [2] | Enable mismatch checking, with resolution conversion of 1-D data in the DCE, and an implied AT+FK command executed on 2-D mismatch detection. |

Note

- Used for Fax Class 2 only

12 SHORT MESSAGE SERVICE (SMS) COMMANDS

The AT commands described in this chapter allow an external application to use the Short Message Service with the SAMBA75.

12.1 SMS parameters

Parameter Description

<ackpdu>^(num)

Format is same for **<pdu>** in case of SMS, but without GSM 24.11 SC address field and parameter shall be bounded by double quote characters like a normal string type parameter

<alpha>^{(str)(+CSCS)}

String type alphanumeric representation of **<da>** or **<oa>** corresponding to the entry found in phone book; implementation of this feature is manufacturer specific

<cdata>^(num) Command Data

GSM 03.40 TP-Command-Data in text mode responses; ME/TA converts each 8-bit octet into two IRA character long hexadecimal numbers (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65))

<ct>^(num)

Command Type

GSM 03.40 TP-Command-Type in integer format

[0]...255

<da>^{(num)(+CSCS)}

Destination Address

GSM 03.40 TP - Destination-Address Address-Value field in string format; BCD numbers (or GSM default alphabet characters) are converted into characters; type of address given by **<toda>**

<data>^{(num)(+CSCS)}

User Data

In case of SMS: GSM 03.40 TP-User-Data in text mode responses; format:

- If **<dcs>** indicates that GSM 03.38 default alphabet is used and **<fo>** indicates that GSM 03.40 TP-User-Data-Header-Indication is not set: ME/TA converts GSM alphabet into current TE character set according to rules covered in Annex A.
- If **<dcs>** indicates that 8-bit or UCS2 data coding scheme is used, or **<fo>** indicates that GSM 03.40 TP-User-Data-Header-Indication is set: ME/TA converts each 8-bit octet into hexadecimal numbers containing two IRA characters (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)).
- In case of CBS: GSM 03.41 CBM Content of Message in text mode responses; format:
- If **<dcs>** indicates that GSM 03.38 default alphabet is used: ME/TA converts GSM alphabet into current TE character set according to rules covered in Annex A.

- If **<dcs>** indicates that 8-bit or UCS2 data coding scheme is used: ME/TA converts each 8-bit octet into hexadecimal numbers containing two IRA characters.

<dt>^(num)

Discharge Time

GSM 03.40 TP-Discharge-Time in time-string format: "yy/MM/dd,hh:mm:ss+zz", where characters indicate year (two last digits), month, day, hour, minutes, seconds and time zone. For example, 6th of May 1994, 22:10:00 GMT+2 hours equals "94/05/06,22:10:00+08"

<index>^(num)

Integer type; value in the range of location numbers supported by the associated memory

<length>^(num)

Message Length

Integer type value indicating in the text mode (**AT+CMGF=1**) the length of the message body **<data>** (or **<cdata>**) in characters; or in PDU mode (**AT+CMGF=0**), the length of the actual TP data unit in octets (i.e. the RP layer SMSC address octets are not counted in the length) In text mode, the maximum length of an SMS depends on the used coding scheme: It is 160 characters if the 7 bit GSM coding scheme is used, and 140 characters according to the 8 bit GSM coding scheme.

If the SMS message format is "text mode" (**AT+CMGF=1**) and the character set is set to "UCS2" with **AT+CSCS** and the SMS is also coded as "UCS2" (see **<dcs>** of **AT+CSMP**), then the length is in octets instead of characters.

<mem1>^(str)

Memory to be used when listing, reading and deleting messages:

"SM"	SIM message storage
"ME"	Mobile Equipment message storage
"MT" ^(D)	Sum of "SM" and "ME" storages

<mem2>^(str)

Memory to be used when writing and sending messages:

"SM"	SIM message storage
"ME"	Mobile Equipment message storage
"MT" ^(D)	Sum of "SM" and "ME" storages

<mem3>^(str)

Received messages will be placed in this memory storage if routing to TE is not set. See command **AT+CNMI** with parameter **<mt>=2**.

"SM"	SIM message storage
"MT" ^(D)	Sum of "SM" and "ME" storages

<mid>^(num)

Message Identifier

GSM 03.41 CBM Message Identifier in integer format

<mn>^(num)

Message Number

GSM 03.40 TP-Message-Number in integer format

<mr>^(num)

Message Reference

GSM 03.40 TP-Message-Reference in integer format

<oa>^{(num)+CSCS}

Originating Address

GSM 03.40 TP-Originating-Address Address-Value field in string format; BCD numbers (or GSM default alphabet characters) are converted into characters; type of address given by **<tooa>**

<page>^(num)

Page Parameter

GSM 03.41 CBM Page Parameter bits 4-7 in integer format

<pages>^(num)

Page Parameter

GSM 03.41 CBM Page Parameter bits 0-3 in integer format

<pdu>^(num)

In the case of SMS: GSM 04.11 SC address followed by GSM 03.40 TPDU in hexadecimal format: ME/TA converts each octet of TP data unit into hexadecimal numbers containing two IRA characters (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)). In the case of CBS: **<ra>** GSM 03.40 TP-Recipient-Address Ad-dress-Value field in string format; BCD numbers (or GSM default alphabet characters) are converted into characters; type of address given by **<tora>**.

<ra>^{(num)+CSCS}

Recipient Address

GSM 03.40 TP-Recipient-Address Address-Value field in string format; BCD numbers (or GSM default alphabet characters) are converted to characters of the currently selected TE character set (refer to command **AT+CSCS.**); type of address given by **<tora>**.

<sca>^{(num)+CSCS}

Service Center Address

GSM 04.11 RP SC address Address-Value field in string format; BCD numbers (or GSM default alphabet characters) are converted to characters of the currently selected TE character set (refer to command **AT+CSCS**); type of address given by **<tosca>**.

<scts>^(num)

Service Centre Time Stamp

GSM 03.40 TP-Service-Centre-Time-Stamp in time-string format (refer **<dt>**)

<sn>^(num)

Serial Number

GSM 03.41 CBM Serial Number in integer format

<st>^(num)

Status

GSM 03.40 TP-Status in integer format

0...255

<stat>^(str)

Message status

3GPP 27.005 Interface of SMS and CB. Indicates the status of message in memory.

Description	text mode (<mode>=1)	(<mode>=0)	Default
-------------	--	---------------------------	---------

Received unread messages	"REC UNREAD"	0	for SMS reading commands
Received read messages	"REC READ"	1	
Stored unsent messages	"STO UNSENT"	2	for SMS writing commands
Stored sent messages	"STO SENT"	3	
All messages	"ALL"	4	

<toda>^(num)

Type of Destination Address

GSM 04.11 TP-Destination-Address Type-of-Address octet in integer format (when first character of <da> is + (IRA 43) default is 145, otherwise default is 129)

0...255

<tooa>^(num)

Type of Originating Address

GSM 04.11 TP-Originating-Address Type-of-Address octet in integer format (default refer <toda>)

<tora>^(num)

Type of Recipient Address

GSM 04.11 TP-Recipient-Address Type-of-Address octet in integer format (default refer <toda>)

<tosca>^(num)

Type of Service Center Address

GSM 04.11 RP SC address Type-of-Address octet in integer format (default refer <toda>)

12.2 AT+CMGC Send an SMS command

Syntax

Test Command AT+CMGC=?	Response(s) OK
Write Command If text mode (see AT+CMGF=1) AT+CMGC=<fo>,<ct>[,<pid>[,<mn>[,<da>[,<toda>]]]]<CR>.Text can be entered <CTRL-Z>/<ESC>	Response(s) + CMGC: <mr>[,<scts>] If sending fails ERROR +CMS ERROR
Write Command If PDU mode (see AT+CMGF=0) AT+CMGC=<length><CR> PDU can be entered <CTRL-Z>/<ESC>	Response(s) + CMGC: <mr>[,<ackpdu>] OK If sending fails ERROR +CMS ERROR

Reference(s)	PIN	USB					
GSM 07.05	●	●					

Notes

- After invoking the commands AT+CMGW, AT+CMGS or AT+CMGC it is necessary to wait for the prompt ">" before entering text or PDU. After the prompt a timer will be started to observe the input.
- At baudrates below 19200 it is recommended to use the line termination character only (refer to ATS3, default <CR>) before entering the text or PDU. Use of the line termination character followed by the response formatting character (refer to ATS4, default <LF>) can cause problems.

12.3 AT+CMGD Delete SMS message

Syntax

Test Command AT+CMGD=?	Response(s) OK
Write Command AT+CMGD=<index>	Response(s) OK ERROR +CMS ERROR

Reference(s)	PIN	USB					
GSM 07.05	●	●					

Command Description

Write command deletes message from preferred message storage <mem1> location <index>.

Note

- If there is no SMS stored at the selected index, the response is OK too.

12.4 AT+CMGF Select SMS message format

Syntax

Test Command AT+CMGF=?	Response(s) +CMGF : (list of supported <mode>s) OK
Read Command AT+CMGF?	Response(s) +CMGF: <mode> OK
AT+CMGF=<mode>	Response(s) OK

Reference(s)	PIN	USB					
GSM 07.05	○	●					

Command Description

The write command specifies the input and output format of the short messages.

Parameter Description

<mode>^{(num)(&W)(&V)}

[0] ^(&F)	PDU mode
1	Text mode

12.5 AT+CMGL List SMS messages from preferred store

Syntax

Test Command AT+CMGL=?	Response(s) +CMGL: (list of supported <stat>s) OK
Exec Command AT+CMGL	Response(s) +CMGL: (see write command for default of <stat>) OK

<p>Write Command AT+CMGL=<stat></p>	<p>Response(s)</p> <p>and/or SMS-DELIVERS +CMGL:<index>,<stat>,<oa>/<da>,[<alpha>],[<scts>][,<tooa>/<toda>,<length>] <data> [...] OK</p> <p>For SMS-STATUS-REPORTS + CMGL: <index>,<stat>,<fo>,<mr>,[<ra>],[<tora>],<scts>,<dt>,<st> [...] OK</p> <p>For SMS-Commands + CMGL: <index>,<stat>,<fo>,<ct> [...] OK</p> <p>Output if PDU mode AT+CMGF=0 and command successful: For SMS-SUBMITS and/or SMS-DELIVERS + CMGL: <index>,<stat>,[<alpha>],<length> <pdu> [...] OK</p> <p>If error is related to ME functionality ERROR +CMS ERROR</p>
--	---

Reference(s)	PIN	USB					
GSM 07.05	●	●					

Command Description

The execute command is the same as the write command with the given default for <stat>.

The write command returns messages with status value <stat> from message storage <mem1> to the TE. If status of the message is 'received unread', status in the storage changes to 'received read'.

Notes

- The selected <mem1> can contain different types of SMs (e.g. SMS-DELIVERS, SMS-SUBMITS, SMS-STA-TUS-REPORTs and SMS-COMMANDs), the response may be a mix of the responses of different SM types. TE application can recognize the response format by examining the third response parameter.
- The parameters <ra> and <tora> will only be displayed if parameter <ra> of the **AT&SSCONF** command is set to 1.
- This command can be used only after the SMS data from the SIM have been read successfully for the first time. Reading starts after successful SIM authentication has been performed, and may take up to 30 seconds depending on the SIM used. While the read process is in progress, an attempt to use any of the SMS read commands will result in "+CME Error: 14" (SIM busy).

12.6 AT+CMGR Read SMS messages

Syntax

<p>Test Command AT+CMGR=?</p>	<p>Response(s)</p> <p>OK</p>
--	-------------------------------------

Write Command AT+CMGR=<index>	Response(s) Output if text mode (AT+CMGF=1) and command successful: For SMS-DELIVER + CMGR: <stat>,<oa>,[<alpha>],<scts>[,<tooa>,<fo>,<pid>,<dcs>,<sca>,<tosca>,<length>]<data> [...] OK For SMS-SUBMIT + CMGR: <stat>,<da>,[<alpha>][,<toda>,<fo>,<pid>,<dcs>,[<vp>],<sca>,<tosca>,<length>]<data> [...] OK For SMS-STATUS-REPORT + CMGR: <stat>,<fo>,<mr>,[<ra>],[<tora>],<scts>,<dt>,<st> <data> [...] OK For SMS-Commands +CMGR:<stat>,<fo>,<ct>[,<pid>,[<mn>],[<da>],[<toda>],<length>] <data> [...] OK Output if PDU mode (AT+CMGF=0) and command successful: For SMS-SUBMITS and/or SMS-DELIVERS + CMGR: <stat>,[<alpha>],<length> <pdu> OK ERROR +CMS ERROR
----------------------------------	--

Reference(s)	PIN	USB				
GSM 07.05	●	●				

Command Description

The write command returns SMS message with location value <index> from message storage <mem1> to the TE. If status of the message is 'received unread', status in the storage changes to 'received read'.

Notes

- Response if AT+CMGR is used to read an empty record index: +CMGR: 0,,0
- Response if AT+CMGR is used to read a non-existent record index: +CMS ERROR: invalid memory index
- The parameters <ra> and <tora> will only be displayed if parameter <ra> of the AT^SSCONF command is set to 1.
- This command can be used only after the SMS data from the SIM have been read successfully for the first time. Reading starts after successful SIM authentication has been performed, and may take up to 30 seconds depending on the SIM used. While the read process is in progress, an attempt to use any of the SMS read commands will result in "+CME Error: 14" (SIM busy).

12.7 AT+CMGS Send SMS message

Syntax

Test Command AT+CMGS=?	Response(s) OK
---------------------------	-------------------

Write Command If text mode (see AT+CMGF=1) AT+CMGS=<da>[,<toda>]<CR> Text can be entered. <CTRL-Z>/<ESC>	Response(s) + CMGS: <mr>[,<scts>] OK If sending fails see notes below.
Write Command If PDU mode (see AT+CMGF=0) AT+CMGS=<length><CR> PDU can be entered. <CTRL-Z>/<ESC>	Response(s) + CMGS: <mr>[,<ackpdu>] OK If sending fails see notes below

Reference(s)	PIN	USB					
GSM 07.05	●	●					

Command Description

The write command transmits a short message from TE to network (SMS-SUBMIT).

After invoking the write command wait for the prompt ">" and then start to write the message. To send the message simply enter <CTRL-Z>. After the prompt a timer will be started to observe the input. To abort sending use <ESC>. Abortion is acknowledged with "OK", though the message will not be sent. The message reference <mr> is returned to the TE on successful message delivery. The value can be used to identify the message in a delivery status report provided as an unsolicited result code.

Notes

- If sending fails, for example, if a message is too long, the result code depends on the current setting of the [AT^SM20](#) command:
If the [AT^SM20 <CmgwMode>](#) equals 1 (factory default) any failure to send a message is responded with "OK". Users should be aware, that despite the "OK" response, the message will not be sent to the subscriber. If the [AT^SM20 <CmgwMode>](#) equals 0 any failure to send a message is responded with "ERROR".
- If sending fails due to timeout, then
[AT^SM20 <CmgwMode>=1](#) causes "+CMS ERROR: Unknown error" to be returned;
[AT^SM20 <CmgwMode>=0](#) causes "+CMS ERROR: timer expired" to be returned.
- Note that some providers do not recognize an @ symbol used in a short message. A widely used alternative is typing "*" as defined in GSM 03.40 (GPP TS 23.40).
- All characters entered behind the prompt ">" will be recognized as GSM characters. For example, "Backspace" (ASCII character 8) does not delete a character, but will be inserted into the short message as an additional physical character. As a result, the character you wanted to delete still appears in the text, plus the GSM code equivalent of the backspace key.
- In text mode, the maximum length of an SMS depends on the used coding scheme: It is 160 characters if the 7 bit GSM coding scheme is used, and 140 characters according to the 8 bit GSM coding scheme.
- At baudrates lower than 19200 it is recommended to use the line termination character only (refer to <n> of [ATS3](#), default <CR>) before entering text or PDU. Use of the line termination character followed by the response formatting character (see <n> of [ATS4](#), default <LF>) can cause problems.

12.8 AT+CMGW Write SMS messages to memory

Syntax

Test Command AT+CMGW=?	Response(s) OK
Exec Command If text mode (see AT+CMGF=1): AT+CMGW	Response(s) <CR> Text can be entered. <CTRL-Z>/<ESC> +CMGW: <index> OK If writing fails ERROR +CMS ERROR
Write Command If text mode (see AT+CMGF=1): AT+CMGW=<oa>/<da>[, [<tooa>/<toda>][,<stat>]]<CR> Text can be entered. <CTRL-Z>/<ESC>	Response(s) +CMGW: <index> OK If writing fails see notes below.
Write Command If PDU mode (see AT+CMGF=0): AT+CMGW=<length>[,<stat>]<CR> PDU can be entered. <CTRL-Z>/<ESC>	Response(s) +CMGW: <index> OK If writing fails see notes below.

Reference(s)	PIN	USB					
GSM 07.05	●	●					

Command Description

The execute and write commands transmit SMS (either SMS-DELIVER or SMS-SUBMIT) from TE to memory storage <mem2>. Memory location <index> of the stored message is returned. Message status will be set to 'stored unsent' unless otherwise given in parameter <stat>.

After invoking the execute or write command wait for the prompt ">" and then start to write the message. To save the message simply enter <CTRL-Z>. After the prompt a timer will be started to observe the input.

To abort writing use <ESC>. Abortion is acknowledged with "OK", though the message will not be saved.

Notes

- If writing fails, for example, if a message is too long, the result code depends on the current setting of the [AT^SM20](#) command:
- If the [AT^SM20 <CmgwMode>=1](#) (factory default) any failure to send a message is responded with "OK". Users should be aware, that despite the "OK" response, the message will not be written to the selected SMS storage. If the [AT^SM20 <CmgwMode>](#) equals 0 any failure to write a message is responded with "ERROR".
- If writing fails due to timeout, then
- [AT^SM20 <CmgwMode>=1](#) causes "+CMS ERROR: Unknown error" to be returned; [AT^SM20 <CmgwMode>=0](#) causes "+CMS ERROR: timer expired" to be returned.
- Note that some providers do not recognize an @ symbol used in a short message. A widely used alternative is typing "*" as defined in GSM 03.40 (GPP TS 23.40).
- For baudrates lower than 19200 it is recommended to use the line termination character only (refer to [ATS3=<n>](#), default <CR>) before entering the text or PDU. Use of the line termination character followed by the response formating character (see [ATS4=<n>](#), default <LF>) may cause problems.

- SMS-COMMANDs and SMS-STATUS-REPORTs cannot be stored in text mode.
- All characters entered behind the ">" prompt will be recognized as GSM characters. For example, "Backspace" (ASCII character 8) does not delete a character, but will be inserted into the short message as an additional physical character. As a result, the character you wanted to delete still appears in the text, plus the GSM code equivalent of the backspace key.
- In text mode, the maximum length of an SMS depends on the used coding scheme: It is 160 characters if the 7 bit GSM coding scheme is used, and 140 characters according to the 8 bit GSM coding scheme.
- The length of 8-bit data coded short messages has to be greater than 0.

12.9 AT+CMSS Send SMS messages from storage

Syntax

Test Command AT+CMSS=?	Response(s) OK
Write Command If text mode (AT+CMGF=1): AT+CMSS=<index>[,<da>[,<toda>]]	Response(s) + CMSS: <mr>[,<scts>] OK If sending fails ERROR +CMS ERROR
Write Command If PDU mode (AT+CMGF=0): AT+CMSS=<index>[,<da>[,<toda>]]	Response(s) + CMSS: <mr>[,<ackpdu>] OK If sending fails ERROR +CMS ERROR

Reference(s)	PIN	USB					
GSM 07.05	●	●					

Command Description

The write command sends message with location value <index> from message storage <mem2> to the network (SMS-SUBMIT or SMS-COMMAND). If new recipient address <da> is given for SMS-SUBMIT, it shall be used instead of the one stored with the message. Reference value <mr> is returned to the TE on successful message delivery. Value can be used to identify message upon unsolicited delivery status report result code. If the optional parameter <da> is given, the old status of the short message at <index> remains unchanged (see <stat>).

12.10 AT+CNMA New SMS message acknowledge to ME/TE, only phase 2+

Syntax

Test Command AT+CNMA=?	Response(s) +CNMA: (list of supported <n>s) OK
Exec Command AT+CNMA	Response(s) OK ERROR +CMS ERROR
Write Command AT+CNMA=<n>	Response(s) OK ERROR +CMS ERROR

Reference(s)	PIN	USB				
GSM 07.05	●	●				

Command Description

The write/execute command confirms successful receipt of a new message (SMS-DELIVER or SMS-STATUS-REPORT) routed directly to the TE. TA shall not send another +CMT or +CDS result code to TE until previous one is acknowledged. If ME does not receive acknowledgment within required time (network time-out), ME sends RP-ERROR to the network. TA shall automatically disable routing to TE by setting both <mt> and <ds> values of AT+CNMI to zero.

Parameter Description

<n>^(num)

0	Parameter is only required for PDU mode. Command operates similarly as in text mode
---	---

Notes

- The execute/write command shall only be used when AT+CSMS parameter <service> equals 1 (= phase 2+).
- Both the execute and the write command can be used no matter whether text mode or PDU mode is activated.

12.11 AT+CNMI New SMS message indications

Syntax

Test Command AT+CNMI=?	Response(s) +CNMI : (list of supported <mode>s), (list of supported <mt>s), (list of supported <bm>s), (list of supported <ds>s), (list of supported <bfr>s) OK
Read Command AT+CNMI?	Response(s) + CNMI: <mode>, <mt>, <bm>, <ds>, <bfr> OK
Write Command AT+CNMI = [<mode>][,<mt>][,<mb>] [<ds>][,<bfr>]	Response(s) OK ERROR

Reference(s)	PIN	USB				
		●				

Unsolicited Result Codes

URC1

	<code><mt>=1:</code> +CMTI: <code><mem3>,<index></code> Indicates that new message has been received
URC2	<code><mt>=2 (PDU mode enabled):</code> + CMT: <code><length><CR><LF><pdu></code> Indicates that new message has been received
URC3	<code><mt>=2 (text mode enabled):</code> +CMT: <code><oa>,<scts>[,<tooa>,<fo>,<pid>,<dcs>,<sca>,<tosca>,<length>] <CR><LF><data></code> Indicates that new message has been received
URC4	<code><bm>=2 (PDU mode enabled):</code> + CBM: <code><length><CR><LF><pdu></code> Indicates that new cell broadcast message has been received
URC5	<code><bm>=2 (text mode enabled):</code> +CBM: <code><sn>,<mid>,<dcs>,<page>,<pages><CR><LF><data></code> Indicates that new cell broadcast message has been received
URC6	<code><ds>=1 (PDU mode enabled):</code> + CDS: <code><length><CR><LF><pdu></code> Indicates that new SMS status report has been received
URC7	<code><ds>=1 (text mode enabled):</code> +CDS: <code><fo>,<mr>[,<ra>] [,<tora>],<scts>,<dt>,<st></code> Indicates that new SMS status report has been received
URC8	<code><ds>=2:</code> +CDSI: <code><mem3>,<index></code> Indicates that new SMS status report has been received

Command Description

The write command selects the procedure how the receipt of new SMS messages from the network is indicated to the TE when TE is active, e.g. DTR signal is ON. If TE is inactive (e.g. DTR signal is OFF), message receiving should be done as specified in GSM 03.38. If the DTR signal is not available or the state of the signal is ignored (V.25ter command **AT&DO**, reliable message transfer can be assured by using **AT+CNMA** acknowledgment procedure. The rules `<mt>=2` and `<mt>=3` for storing received SM are possible only if phase 2+ compatibility is activated with **AT+CSMS=1**. The parameter `<ds>=1` is only available in phase 2+.

Parameter Description

`<mode>(num)&W`

`[0](&F)` Buffer unsolicited result codes in the TA. If TA result code buffer is full, indications can be buffered in some other place or the oldest indications may be discarded and replaced with the new received indications.

- 1 Discard indication and reject new received message unsolicited result codes when TA-TE link is reserved (e.g. in on-line data mode). Otherwise forward them directly to the TE.
- 2 Buffer unsolicited result codes in the TA when TA-TE link is reserved (e.g. in on-line data mode) and flush them to the TE after reservation. Otherwise forward them directly to the TE.
- 3 Forward unsolicited result codes directly to the TE. TA-TE link specific in-band technique used to embed result codes and data when TA is in on-line data mode.

<mt>^{(num)(&W)(&V)}

Rules for storing received SMS depend on the relevant data coding method (refer to GSM 03.38), preferred memory storage ([AT+CPMS](#)) setting and this value.

Note: If AT command interface is acting as the only display device, the ME must support storage of class 0 messages and messages in the message waiting indication group (discard message).

- [0]^(&F) No SMS-DELIVER indications are routed to the TE.
- 1 If SMS-DELIVER is stored in ME/TA, indication of the memory location is routed to the TE using unsolicited result code:
- 2 SMS-DELIVERs, except class 2 messages and messages in the message waiting indication group (store message) are routed directly to the TE using unsolicited result code:
- 3 Class 3 SMS-DELIVERs are routed directly to the TE using unsolicited result codes defined in [**<mt>=2**](#). Messages of other data coding schemes result in indication as defined in [**<mt>=1**](#).

<bm>^{(num)(&W)(&V)}

Rules for storing received CBMs depend on the relevant data coding method (refer to GSM 03.38), the setting of Select CBM Types ([AT+CSCB](#)) and this value:

- [0]^(&F) No CBM indications are routed to the TE.
- 2 New CBMs are routed directly to the TE using unsolicited result code:
- 3 Class 3 CBMs are routed directly to TE using unsolicited result codes defined in [**<bm>=2**](#).

<ds>^{(num)(&W)(&V)}

- [0]^(&F) No SMS-STATUS-REPORTs are routed to the TE.
- 1 SMS-STATUS-REPORTs are routed to the TE using unsolicited result code:
- 2 If SMS-STATUS-REPORT is routed into ME/TA, indication of the memory location is routed to the TE using unsolicited result code:

<bfr>^{(num)(&W)(&V)}

- [1]^(&F) TA buffer of unsolicited result codes defined within this command is cleared when [**<mode> 1...3**](#) is entered.

<index>^(num)

integer type; value in the range of location numbers supported by the associated memory

Notes

- Each time an SMS or Cell Broadcast Message is received, the Ring Line goes Logic "1" for one second.
- Parameters $<\text{mt}>=2,3$ and $<\text{ds}>=1$ are only available with GSM phase 2+ (see [AT+CSMS=1](#)). Incoming SMS or Status Reports have to be acknowledged with [AT+CNMA=0](#) when using these phase 2+ parameters.
- Due to GSM 03.38 the ME treats short messages with message class 0 as though there was no message class, i.e. it will ignore bits 0 and 1 in the TP-DCS and normal rules for memory capacity exceeded shall apply.
- To allow SMS overflow presentation during data transfers via Break, use [AT+CNMI=3,1](#) (see [AT^SMGO](#)).

12.12 AT+CPMS Preferred SMS message storage

Syntax

Test Command AT+CPMS=?	Response(s) +CPMS: (list of supported $<\text{mem1}>$ s), (list of supported $<\text{mem2}>$ s), (list of supported $<\text{mem3}>$ s) OK
Read Command AT+CPMS?	Response(s) + CPMS: $<\text{mem1}>$, $<\text{used1}>$, $<\text{total1}>$, $<\text{mem2}>$, $<\text{used2}>$, $<\text{total2}>$, $<\text{mem3}>$, $<\text{used3}>$, $<\text{total3}>$ OK ERROR +CMS ERROR
Write Command AT+CPMS= $<\text{mem1}>$ [, $<\text{mem2}>$ [, $<\text{mem3}>$]]	Response(s) +CPMS: $<\text{used1}>$, $<\text{total1}>$, $<\text{used2}>$, $<\text{total2}>$, $<\text{used3}>$, $<\text{total3}>$ OK ERROR +CMS ERROR

Reference(s)	PIN	USB					
GSM 07.05	●	●					

Command Description

The write command selects memory storages $<\text{mem1}>$, $<\text{mem2}>$, $<\text{mem3}>$ to be used for reading, writing, etc.

Parameter Description

$<\text{used1}>$ ^(num)

Number of messages currently in $<\text{mem1}>$

$<\text{used2}>$ ^(num)

Number of messages currently in $<\text{mem2}>$

$<\text{used3}>$ ^(num)

Number of messages currently in $<\text{mem3}>$

$<\text{total1}>$ ^(num)

Number of messages storable in $<\text{mem1}>$

$<\text{total2}>$ ^(num)

Number of messages storable in $<\text{mem2}>$

<total3>^(num)

Number of messages storables in <mem3>

Notes

- The Mobile Equipment storage "ME" offers space for 25 short messages, see <mem1>.
- "MT" is the sum of "ME" (= 25 locations) and "SM" (capacity varies with SIM card). The indices <index> of the "MT" storage are dependent on the order selected with [AT^SSMSS](#).
- The <mem1>, <mem2> and <mem3> parameter will be stored in non-volatile memory.
- The user should be aware that the setting "MT" involves "ME" and "SM", with "ME" being filled up first. If the "ME" storage is full, SAMBA75 will proceed with the "SM" storage.
- Incoming Class 1 short messages (ME specific) will be preferably stored to "ME" and may be transferred to the "SM" storage if "ME" is used up.
- Incoming Class 2 messages (SIM specific) will be stored to the SIM card only, no matter whether or not there is free "ME" space. As a result, the ^SMGO: 2 indication (see [AT^SMGO](#)) may be presented without prior indication of ^SMGO: 1. For more information regarding SIM and ME specific message classes refer to <dcs> and the following specifications: GSM 03.38 and 3GPP TS23038.
- When <mem3> is switched over from "MT" to "SM" all free "ME" locations will be filled with dummy short messages. This procedure can take up to 35 seconds, until all the 25 records are written.
- If switching from "MT" to "SM" was not finished due to error or user break, the value of <mem3> remains "MT", but some of the dummy records remain in the "ME" storage. These records have to be deleted manually. When <mem3> equals "SM", do not delete the dummy messages in the "ME" storage. They will be automatically deleted when you switch back from "SM" to "MT". Again, this may take up to 35 seconds. If switching from "SM" to "MT" was not finished due to an error or user break, the value of <mem3> remains "SM", but the "ME" storage will no longer be filled with dummy records. New incoming short messages may now be written to the "ME" storage, if "SM" is already full. To avoid this, repeat the [AT+CPMS](#) command as soon as possible to switch <mem3> back to "MT". As an alternative, you can manually delete the dummy records and issue [AT+CPMS=MT,MT,MT](#).
- While <mem3> equals "SM" and <mem1> equals "ME" it is possible that, after deleting short messages from "ME", the freed space on "ME" is reclaimed for new incoming short messages, when there is no space left on the "SM" storage. As it is often the clients concern to have received short messages stored only to the SIM card, inconsistent settings should be generally avoided. This can be achieved simply by using the same parameter for all memory indices.
- The indices <index> of the storage are dependent on the order selected with [AT^SSMSS](#).

12.13 AT+CSCA SMS service centre address

Syntax

Test Command AT+CSCA=?	Response(s) OK
---------------------------	-------------------

Read Command AT+CSCA?	Response(s) +CSCA: <sca>,<tosca> OK
Write Command AT+CSCA=<sca>[,<tosca>]	Response(s) OK

Reference(s)	PIN	USB				
GSM 07.05	•	•				

Command Description

Write command updates the SMSC address, through which mobile originated SMS are transmitted. In text mode, setting is used by send and write commands. In PDU mode, setting is used by the same commands, but only when the length of the SMSC address coded into **<pdu>** parameter equals zero.

Notes

- In case of using no parameter after AT+CSCA= the content of **<sca>** will be deleted.
- This command writes the service centre address to non-volatile memo.
- The SMS service centre address should be entered as specified by the service provider.

12.14 AT+CSCB Select Cell Broadcast Message Indication

Syntax

Test Command AT+CSCB=?	Response(s) +CSCB: (list of supported <mode>s) OK
Read Command AT+CSCB?	Response(s) + CSCB: <mode>,<mids>,<dcss> OK
Write Command AT+CSCB=[<mode>[,<mids>[,<dcss>]]]	Response(s) OK

Reference(s)	PIN	USB				
GSM 07.05	•	•				

Command Description

Test command returns supported modes as a compound value.

Write command selects which types of CBMs are to be received by the ME.

Parameter Description

<mode>^(num)

Message mode

- | | |
|-----|---|
| [0] | Accept messages that are defined in <mids> and <dcss> |
| 1 | Forbid messages that are defined in <mids> and <dcss> |

<mids>^(str)

Cell Broadcast Message ID specification

- ❖ For `<mode>=0`: Six different possible combinations of CBM IDs (e.g. "0,1,5,320-478,922,2000-3000"), default is empty string.
- ❖ In certain configurations, e.g. if using SIMs that contain data in Elementary File EF-CBMID (Cell Broadcast Message Identifier for Data download) less than six combinations may be available. To access a SIMs Elementary File data refer to command [AT+CRSM](#).
- ❖ For `<mode>=1`: One CBM ID or range of IDs (e.g. "320-478"), default is empty string.

<dcss>^(str)

CBM data coding scheme specification

All different possible combinations of CBM data coding schemes (e.g. "0-3,5"). Using default empty string leads to get all CBMs independent of their dcss.

A given `<dcss>` replaces any former value and is used for consecutive requests.

12.15 AT+CSDH Show SMS text mode parameters

Syntax

Test Command AT+CSDH=?	Response(s) +CSDH: (list of supported <code><show></code> s) OK
Read Command AT+CSDH?	Response(s) +CSDH:<show> OK
Write Command AT+CSDH=<show>	Response(s) +CSDH: <show> OK

Reference(s)	PIN	USB					
GSM 07.05	•	•					

Command Description

Write command sets whether or not detailed header information is shown in text mode result codes.

Parameter Description

<show>^{(num)&W}

- | | |
|-------------------------|---|
| [0] ^(&F) | Do not show header values defined in commands AT+CSKA and AT+CSMP (<code><sca>,<tosca>,<fo>,<vp>,<pid></code> and <code><dcs></code>) nor <code><length>,<toda></code> or <code><tooa></code> in "+CMTI", AT+CMGL , AT+CMGR result codes for SMS-DELIVERS and SMS-SUBMITs in text mode; for SMS-COMMANDs in +CMGR result code, do not show <code><pid>,<mn>,<da>,<toda>,<length></code> or <code><cdata></code> . |
| 1 | Show the values in result codes. |

12.16 AT+CSMP Set SMS text mode parameters

Syntax

Test Command AT+CSMP=?	Response(s) OK
Read Command AT+CSMP?	Response(s) + CSMP:<fo>,<vp>/<scts>,<pid>,<dcs> OK
Write Command AT+CSMP=<fo>[,<vp>/<scts>[,<pid>[,<dcs>]]]	Response(s) +CSMP: <index> OK If sending fails ERROR +CMS ERROR

Reference(s)	PIN	USB					
GSM 07.05	●	●					

Command Description

The write command selects values for additional parameters needed when SM is sent to the network or placed in a storage when text format message mode is selected.

It is possible to set the validity period starting from when the SM is received by the SMSC (<vp> is in range 0... 255) or define the absolute time of the validity period termination (<vp> is a string). The format of <vp> is given by <f o>. If TA supports the enhanced validity period format, see GSM 03.40), it shall be given as a hexadecimal coded string (e.g. <pdu>) with quotes.

Parameter Description

<fo>^(num)

First Octet

depending on the command or result code: first octet of GSM 03.40 SMS-DELIVER, SMS-SUBMIT (default 17), SMS-STATUS-REPORT, or SMS-COMMAND (default 2) in integer format

0...17(&F)...255

<vp>^(num)

Depending on SMS-SUBMIT <fo> setting: GSM 03.40 TP-Validity-Period either in integer format or in time-string format (refer <dtt>)

0...167(&F)...255

<dcs>^(num)

Data Coding Scheme

GSM 03.38 SMS Data Coding Scheme, or Cell Broadcast Data Coding Scheme in integer format

0(&F)...247

<pid>^(num)

Protocol Identifier

GSM 03.40 TP-Protocol-Identifier in integer format

0<&F>...255

Notes

- When storing a SMS DELIVER from the TE to the preferred memory storage in text mode (using the AT+CMGW write command), <vp> field can be used for <scts>.
- The command writes the parameters to the non-volatile memory.

12.17 AT+CSMS Select Message Service

Syntax

Test Command AT+CSMS=?	Response(s) +CSMS: (list of supported <service>s) OK
Read Command AT+CSMS?	Response(s) + CSMS: <service>,<mt>,<mo>,<bm> OK
Write Command AT+CSMS=<service>	Response(s) + CSMS: <mt>,<mo>,<bm> OK ERROR +CMS ERROR

Reference(s)	PIN	USB					
GSM 07.05	●	●					

Parameter Description

<service>^(num)

- | | |
|---|---|
| 0 | GSM 03.40 and GSM 03.41 (the syntax of SMS AT commands is compatible with GSM 07.05 Phase 2 version 4.7.0; Phase 2+ features which do not require new command syntax may be supported, e.g. correct routing of messages with new Phase 2+ data coding schemes). |
| 1 | GSM 03.40 and GSM 03.41 (the syntax of SMS AT commands is compatible with GSM 07.05 Phase 2+ version; the requirement of <service> setting 1 is mentioned under corresponding command descriptions). |

<mt>^(num)

Mobile Terminated Messages:

- | | |
|---|--------------------|
| 0 | Type not supported |
| 1 | Type supported |

<mo>^(num)

Mobile Originated Messages:

- | | |
|---|--------------------|
| 0 | Type not supported |
| 1 | Type supported |

<bm>^(num)

Broadcast Type Messages:

- | | |
|---|--------------------|
| 0 | Type not supported |
| 1 | Type supported |

Notes

- If CSMS mode is switched from Phase 2+ to Phase 2 and one or more **AT+CNMI** parameter are Phase 2+ specific a '+CMS ERROR: unknown error' will appear. It is recommended to switch the **AT+CNMI** parameters to Phase 2 specific values before entering Phase 2.
- Phase 2+ (<service>=1) must be set before the following features can be used:
 - Configuring procedures for indicating received short messages with the **AT+CNMI** parameters <mt>=2 or <mt>=3 and <ds>=1.
 - Acknowledging incoming short messages with **AT+CNMA**.

- Receiving Status Reports and acknowledging them with [AT+CNMA](#).

12.18 AT^SLMS List SMS Memory Storage

Syntax

Test Command AT^CLMS=?	Response(s) OK
Exec Command AT^SLMS	Response(s) ^SLMS: "MT"<total3>,<used3> ^SLMS: "SM",<total1>,<used1> ^SLMS: "ME",<total2>,<used2> OK ERROR +CMS ERROR

Reference(s)	PIN	USB					
SIEMENS	•	•					

Command Description

The execute command indicates the maximum capacity of each SMS storage type and the number of locations currently used.

Parameter Description

<total1>^(num)

Maximum number of messages storable in the SMS memory of the SIM (physical storage "SM")

<total2>^(num)

Maximum number of messages storable in the SMS memory of the Mobile Equipment (physical storage "ME")

<total3>^(num)

Sum of "SM" and "ME", indicated as "MT". Maximum number of all messages storable in the SIM memory and the Mobile Equipment memory.

<used1>^(num)

Number of messages currently stored in the SMS memory of the SIM (physical storage "SM")

<used2>^(num)

Number of messages currently stored in the SMS memory of the Mobile Equipment (physical storage "ME")

<used3>^(num)

Concatenated logical SMS storages of SIM ("SM") and Mobile Equipment ("ME"). Sum of all messages currently stored, indicated as "MT".

12.19 AT^SMGL List SMS messages from preferred store without setting status to REC READ

Syntax

Test Command AT^SMGL=?	Response(s) same as AT+CMGL
---------------------------	--

Exec Command AT^SMGL	Response(s) ^SMGL: (For default values of <stat>, see Chapter "SMS parameters".) OK
AT^SMGL=<stat>	Response(s) same as AT+CMGL

Reference(s)	PIN	USB					
SIEMENS	●	●					

Command Description

The execute command is the same as the write command, but uses the given default of <stat>.

The write command allows to select a status type and lists, from the message storage <memi>, all messages that currently have the specified <stat>. The major difference over the standard command AT+CMGL is that the status of the listed messages remains unchanged (unread remains unread).

Notes

- The selected <mem1> can contain different types of SMs (e.g. SMS-DELIVERs, SMS-SUBMITs, SMS-STA-TUS-REPORTs and SMS-COMMANDs), the response may be a mix of the responses of different SM types. TE application can recognize the response format by examining the third response parameter.
- This command can be used only after the SMS data from the SIM have been read successfully for the first time. Reading starts after successful SIM authentication has been performed, and may take up to 30 seconds depending on the SIM used. While the read process is in progress, an attempt to use any of the SMS read commands will result in "+CME Error: 14" (SIM busy)

12.20 AT^SMGO Set or query SMS overflow presentation mode or query SMS overflow

Syntax

Test Command AT^SMGO=?	Response(s) ^SMGO: (list of supported <n>s) OK
Read Command AT^SMGO?	Response(s) ^SMGO: <n>,<mode> OK ERROR +CMS ERROR
Write Command AT^SMGO=<n>	Response(s) OK ERROR CME ERROR

Reference(s)	PIN	USB					
SIEMENS	●	●					

Unsolicited Result Code

SMS buffer change:

^SMGO: <mode>

Status of SMS buffer has changed.

Command Description

The read command returns overflow presentation mode and SMS overflow status. The write command sets overflow presentation mode.

Parameter Description

<n>^{(num)(&W)(&V)}

SMS overflow presentation mode

[0]^(&F) disable

1 enable

<mode>^{(num)(&V)}

SMS overflow status

0 space available

1 SMS buffer full (The buffer for received short messages is <mem3>. See [AT+CPMS](#).)

2 Buffer full and new message waiting in SC for delivery to phone

Notes

- Incoming short messages with message class 1 (ME specific short messages) or class 2 (SM specific short messages), see [<dcs>](#) in GSM 03.38, will be stored either in "ME" or in "SM" storage. Therefore the "[^SMGO:2](#)" indication could occur, without issuing the indication "[^SMGO:1](#)" before. The indication "[^SMGO:1](#)" means that both buffers ("ME" and "SM") are full.
- For more information regarding SIM and ME specific message classes refer to [<dcs>](#) and the following specifications: GSM 03.38 and 3GPP TS 23.038 .

12.21 AT[^]SMGR Read SMS message without setting status to REC READ

Syntax

Test Command AT [^] SMGR=?	Response(s) ^SMGR: OK
Write Command AT [^] SMGR=<index>	Response(s) see AT+CMGR

Reference(s)	PIN	USB					
SIEMENS	●	●					

Notes

- The [AT[^]SMGR](#) command is a specific Siemens command with the same syntax as [AT+CMGR](#) Read SMS message. The only difference is that the status "REC UNREAD" of a short message is not overwritten to "REC READ".
- This command can be used only after the SMS data from the SIM have been read successfully for the first time. Reading starts after successful SIM authentication has been performed, and may take up to 30 seconds depending on the SIM used. While the read process is in progress, an attempt to use any of the SMS read commands will result in "+CME Error: 14" (SIM busy).

12.22 AT^ASSCONF SMS Command Configuration

AT^ASSCONF controls details of some SMS related commands. Please note that **AT^ASSCONF** settings are stored volatile, i.e. after restart or reset the default values will be restored.

Syntax

Test Command AT ^A SSCONF=?	Response(s) ^SSCONF: list of supported <ra>s OK
Read Command AT ^A SSCONF?	Response(s) ^SSCONF:<ra> OK
Write Command AT ^A SSCONF=<ra>	Response(s) OK

PIN	USB					
○	●					

Parameter Description

<ra>^(num)

Display recipient address

[0]^(&F) SAMBA75 does not display <ra> and <tora>. These parameters are used with the result codes of **AT+CMGL**, **AT^ASMGL**, **AT+CGMR**, **AT^ASMGR** and the URC "+CDS".

1 SAMBA75 displays <ra> and <tora>.

12.23 AT^ASSDA Set SMS Display Availability

This command allows to notify the SAMBA75 of its controlling application's capability to immediately display incoming SMS on a display.

If the application is able to display incoming SMS, class 0 SMS shall be displayed immediately. However, if it does not, class 0 SMS shall be treated as if no message class is determined (GSM 03.38[14]).

The effect of this command if <da>=1 is to determine the behavior of parameter <mt> of **AT+CNMI**:

If <da>=1 and <mt>=1 incoming class 0 SMS need to be acknowledged with **AT+CNMA** (see also **AT+CNMI** and **AT+CSMS**).

Syntax

Test Command AT ^A SSDA=?	Response(s) ^SSDA:list of supported <da>s OK
Read Command AT ^A SSDA?	Response(s) ^SSDA:<da> OK
Write Command AT ^A SSDA=<da>	Response(s)

Reference(s)	PIN	USB					
SIEMENS	○	●					

Command Description

The read command returns ME's current capability setting.

Parameter Description

<da>^(num)

Display Availability

- | | |
|-------|---|
| 0(&F) | Application is not able to display incoming SMS |
| 1 | Application is able to display incoming SMS |

12.24 AT[^]SSMSS Set Short Message Storage Sequence

Syntax

Test Command AT [^] SSMSS=?	Response(s) ^SSMSS: (list of supported) <seq>s
AT [^] SCKS?	^SCKS: <mode>,<SimStatus> OK ERROR +CME ERROR: <err>
Write Command AT [^] SSMSS=<seq>	OK

Reference(s)	PIN						
SIEMENS	<input type="radio"/>	<input checked="" type="radio"/>					

Command Description

The short message storage "MT" (see [AT+CPMS](#)) is a logical storage. It consists of two physical storages "ME" and "SM". This command allows to select the sequence of addressing this storage.

Parameter Description

<seq>^(num)

MT sequence

- | | |
|-------|--------------------------------|
| 0(&F) | "MT" storage is "ME" then "SM" |
| 1 | "MT" storage is "SM" then "ME" |

Note

- Access to the SIM storage is faster. For compatibility with previous software releases, the "MT" sequence <seq>=0 is the factory default.

13 SIM RELATED COMMANDS

The AT commands described in this chapter are related to the Subscriber Identity Modul (SIM) connected to the SAMBA75.

13.1 AT+CRSM Restricted SIM Access

Syntax

Test Command AT+CRSM=?	Response(s) OK
Write Command AT+CRSM=<command>[,<fileID>[,<P1>,<P2>,<P3>[,<data>]]]	Response(s) OK ERROR

Reference(s)	PIN	USB					
GSM 07.07	●	●					

Command Description

By using this command the TE has access to Elementary Files on the SIM. Access to the SIM database is restricted to the commands which are listed at <command>.

As response to the command the ME sends the current SIM information parameters and response data. ME error result code +CME ERROR may be returned if the command cannot be passed to the SIM, e.g. if the SIM is not inserted. However, errors related to SIM data are reported in <sw1> and <sw2> parameters as defined in GSM 11.11.

Parameter Description

<command>^(num)

All values not listed below are reserved; refer GSM 11.11.

- 176 READ BINARY
- 178 READ RECORD
- 192 GET RESPONSE
- 214 UPDATE BINARY
- 220 UPDATE RECORD
- 242 STATUS

<fileID>^(num)

This is the identifier for an elementary data file on SIM. Mandatory for every command except STATUS

<P1>^(num)

Parameter to be passed on by the ME to the SIM; refer GSM 11.11.

0...255

<P2>^(num)

Parameter to be passed on by the ME to the SIM; refer GSM 11.11.

0...255

<P3>^(num)

Parameter to be passed on by the ME to the SIM; refer GSM 11.11.

0...255

<data> ^(str)	Information which shall be written to the SIM (hexadecimal character format)
<sw1> ^(num)	Status information from the SIM about the execution of the actual command. These parameters are delivered to the TE in both cases, on successful or failed execution of the command; refer GSM 11.11. 0...255
<sw2> ^(num)	Status information from the SIM about the execution of the actual command. These parameters are delivered to the TE in both cases, on successful or failed execution of the command; refer GSM 11.11. 0...255
<response> ^(str)	Response of a successful completion of the previously issued command. STATUS and GET RESPONSE commands return data, which gives information about the current elementary data field. This information includes the type of file and its size (refer GSM 51.011). After READ BINARY or READ RECORD command the requested data will be returned. <response> is not returned after a successful UPDATE BINARY or UPDATE RECORD command.

13.2 AT^SCKS Query SIM and Chip Card Holder Status

This command controls the SIM connection presentation mode and queries the connection status of the SIM and the card holder tray of the SAMBA75.

Syntax

Test Command AT^SCKS=?	Response(s) ^SCKS:(list of supported <mode>s) OK
AT^SCKS?	^SCKS: <mode>,<SimStatus> OK +CME ERROR: <err>
Write Command AT^SCKS=<mode>	Response(s) ERROR +CME ERROR: <err>

Reference(s)	PIN	USB				
SIEMENS	O					

Unsolicited Result Code

^SCKS: <SimStatus>

During startup, and if the SAMBA75's SIM connection status has changed an unsolicited result code (URC) is issued.

Command Description

The read command returns the URC presentation mode and the status of the SIM card connection.

The write command enables or disables the presentation of URCs to report whether or not the SIM card is connected.

If the ME is powered down or reset ([AT+CFUN](#) or [Table 2.3](#)) the current presentation mode setting **<mode>** will not be retained. Therefore the setting **<mode>=1** needs to be restored after power on the SAMBA75 or may be saved in the user profile ([AT&W](#)).

Parameter Description

<mode>^(num)&W)&V)

- | | |
|-------|-----------------------------------|
| 0(&F) | Suppress unsolicited result codes |
| 1 | Output unsolicited result codes |

<SimStatus>^(num)&V)

- | | |
|---|---|
| 0 | Card holdertray removed or SIM connection error |
| 1 | SIM inserted (refer to note) |

Note

- **<SimStatus>** reflects the status of the SIM and the card holdertray. Therefore if an empty SIM card tray is inserted, two URCs will be presented, indicating the status 1 followed by 0, i.e. a SIM is inserted into the card holdertray but no SIM connection could be established.

Example:

AT^SCKS=1 Activates the presentation of unsolicited result codes
OK

Now, after inserting an empty card tray the following URCs appear:

^SCKS: 1 Tray connected
^SCKS : 0 No SIM card found

13.3 AT^SCID Display SIM card identification number

Syntax

Test Command AT^SCID=?	Response(s) OK
Exec Command AT^SCID	Response(s) ^SCID: <cid> ERROR +CME ERROR: <err>

Reference(s)	PIN	USB					
SIEMENS	○	●					

Command Description

TA returns the card identification number in SIM (SIM file EF|_{CARD}, see [GSM 11.11](#) Chap.10.1.1) as string type.

Parameter Description

<cid>^(str)

card identification number of SIM card

13.4 AT+CXXCID Display card ID

Syntax

Test Command AT+CXXCID=?	Response(s) OK
Exec Command AT+CXXCID	Response(s) +CXXCID: <cid> OK ERROR +CME ERROR: <err>

Reference(s)	PIN	USB					
SIEMENS	○	●					

Command Description

TA returns the card identification number in SIM (SIM file EF ICCID, see GSM 11.11 Chap.10.1.1) as string type.

Note

- See also: [AT^ACID](#)

14 PHONE BOOK COMMANDS

The AT commands described in this chapter allow the external application to access the phone books located in the SAMBA75's memory or on the attached Subscriber Identity Modul (SIM).

14.1 Sort Order for Phone books

Due to the support of UCS2 for the <text> part of phone book entries, the sort order for phone book records follows the algorithm published as Unicode Technical Standard #10, "Unicode Collation Algorithm". A memory-optimized version of the proposed collation tables "[AllKeys]" from Unicode Technical Standard #10 is used in order to determine collation weights for code points between 0000 and 06FF, and composed keys are used for code points from ranges 0700 to 33FF, A000 to D7FF and E000 to FFFD. Code Points not referenced in these tables will be assigned a default collation weight with their Unicode value as level 1 weight. Decomposition is not supported.

Phone book entries whose names contain only characters from the GSM07.07 default alphabet are converted internally into their UCS2 equivalents in order to achieve consistent sorting results.

For the user, this means that:

- Punctuation marks and other non-alphabetical characters from the common latin-based character sets, and from the standard GSM character set, will be sorted before any alphabetical characters. The ordering in which these marks appear as compared to other non-alphabetical characters from the same group is determined by their collation weights and does not reflect their code values in the UCS2 or GSM alphabet tables above. Please refer to www.unicode.org for detail.
- Alphabetical characters from the common latin-based character sets, and from the standard GSM character set, will be sorted according to their underlying base characters, plus the collation weights of their accent signs.
- Only collation levels 1 and 2 are regarded, so sorting is not case-sensitive.

Example: the european letters "A" (GSM 0EH, UCS2 00C5h), "ae" (GSM 1DH, UCS2 00E6h), "c" (GSM09h, UCS2 00E7h), "a" (GSM 61H, UCS2 0061 h) and "b" (GSM 62H, UCS2 0062h) will be sorted in order "a", "A", "as" "b","c" although their numerical values in GSM and UCS2 suggest a different ordering.

**Unicode Technical Standard #10,
"Unicode Collation Algorithm"**

14.2 AT+CPBR Read from Phone book

This command serves to read one or more entries from the phone book selected with AT command **AT+CPBS**. It can be used only after the phone book's data has been read from the SIM successfully. Reading starts after successful SIM authentication has been performed and may take up to 30 seconds depending on the SIM used. While this read process is in progress, an attempt to use any of the phone book commands will result in "+CME Error: SIM busy".

Syntax

Test Command AT+CPBR=?	Response(s) + CPBR: (1-<maxloc>),<nlength>,<tlength> OK +CME ERROR
Write Command AT+CPBR=<location1>[,<location2>]	Response(s) [+CPBR: <location1>,<number>,<type>,<text>] [+CPBR: <location2>,<number>,<type>,<text>] OK +CME ERROR

Reference(s)	PIN	USB					
GSM 07.05, GSM 11.11	●	●					

Command Description

The test command returns the location range supported by the current phone book storage, the maximum length of <number> field and the maximum length of <text> field. Note: Length information may not be available while SIM storage is selected. If storage does not offer format information, the format list contains empty parentheses.

The write command determines the phone book entry to be displayed with <location1> or a location range from <location1> to <location2>. Hence, if no <location2> is given only the entry at <location1> will be displayed. If no entries are found at the selected location "OK" will be returned.

Parameter Description

<location1>^(num)

The first (lowest) location number within phone book memory for which the corresponding entry is to be displayed. The supported range is given in the test command response.

If <location1> exceeds the upper bound <maxloc> (as indicated by the test command), command will respond with "+CME ERROR: INVALID INDEX".

<location2>^(num)

The last (highest) location number within phone book memory for which the corresponding entry is to be displayed. The supported range is given in the test command response.

If both <location1> and <location2> are in the range indicated by the test command with parameter <max-loo>, the list of entries will be output and terminated with "OK".

If <location2> exceeds the range indicated by the test command with parameter <maxloc>, the list of entries will be output but terminated with "+CME ERROR: INVALID INDEX".

<number>^(str)

Phone number in format specified by <type>, it may be an empty string.

<type>^(num)

Address type

145 dialling string <number> includes international access code character '+'

209 dialling string <number> contains printable non-alphabetic non-digit characters saved with the number string.

For phone book entries with this **<type>**, dialling from phone book with **ATD><mem><n>** is not possible. For further detail, check the parameter descriptions for at command **AT+CPBW**.

129 otherwise

<text>(str){+cscs}

Text assigned to a phone number. The maximum length for this parameter is given with test command response parameter **<tlength>**.

If using an ASCII terminal characters which are coded differently in ASCII and GSM have to be entered via escape sequences as described in chapter **0.5 Supported character sets**.

<maxloo>(num)

Maximum location number for the currently selected storage. For phone books located on the SIM this value depends on the SIM card type.

<nlength>(num)

Maximum length of phone number for "normal" locations. Depending on the storage a limited number of locations with extended memory is available per phone book. These locations allow storing numbers with twice the standard length, which is **2*<nlength>** digits for normal numbers, but only **<nlength>** digits for numbers saved with **<type>=209**.

<tlength>(num)

Maximum length of **<text>** assigned to the telephone number. The value indicated by the test command is given in octets. If **<text>** is given as GSM characters each character corresponds to one octet. If the **<text>** string is given in UCS2, the maximum number of characters depends on the coding scheme used for the alpha field of the SIM according to GSM 11.11, Annex B [16]. As a worst case the number of UCS2 characters is less than half the number of GSM characters. For a detailed description please refer to GSM 11.11, Annex B [15].

Examples:

EXAMPLE 1

First run the test command to find out the maximum range of entries stored in the active phone book

```
AT+CPBR=?  
+ CPBR: (1-100) ,20,17
```

SAMBA75 returns the supported values, where 100 is the supported range of location numbers, 20 is the length of the phone number and 17 is the maximum length of the associated text.

EXAMPLE 2

Then use the execute command to display the phone book entries sorted by location numbers

```
AT+CPBR =1,3  
+CPBR:1,"+999999",145,"Charlie"+CPBR:2," + 777777",145, "Bill"  
+CPBR:3,"+888888",145,"Arthur"
```

14.3 AT+CPBS Select phone book memory storage

This command is used to select the active phone book storage, i.e. the phone book storage that all subsequent phone book commands will be operating on.

The read command can be used only after the phone book data from the SIM have been read successfully for the first time. Reading starts after successful SIM authentication has been performed, and may take up to 30 seconds depending on the SIM used. While the read process is in progress, an attempt to use any of the phone book commands will result in "+CME Error: 14" (SIM busy).

Syntax

Test Command AT+CPBS=?	Response(s) +CPBS: (list of supported <storage>s) OK +CME ERROR
Read Command AT+CPBS?	Response(s) + CPBS: <storage>,<used>,<total> +CME ERROR
Write Command	Response(s) OK +CME ERROR:

Reference(s)	PIN						
GSM 07.05	●	●					

Command Description

The test command returns supported <storage>s as compound value.

The read command returns the currently selected <storage>, the number of <used> entries and the <total> number of entries available for this storage.

The write command selects the phone book memory <storage>, which is used by other phone book commands.

Parameter Description

<storage>^(str)

For phone books "MC", "RC" and "LD", automatic deletion of the entries stored in ME will be performed if the SIM card is changed. If the same SIM is removed and reinserted, no automatic deletion is performed. Calls made after last switch on will be lost from "MC", "RC" and "LD" phone book, if the SIM is removed and reinserted during normal operation

"FD"	Fixed dialling phone book capacity: depending on SIM card location: SIM
"SM" ^(&F)	IM phone book capacity: depending on SIM card location: SIM
"ON"	SISDN list capacity: depending on SIM card location: SIM
"ME"	Mobile Equipment Phone book capacity: max. 250 entries

	location: ME
"LD"	last number dialled phone book. Stores all voice call numbers dialed with ATD , but no data call numbers.
	capacity: max. 10 entries
	location: depending on SIM this phone book may reside partly or completely in ME
	AT command +CPBW is not applicable to this storage. The LD list can be deleted with AT^SDLD or with AT^SPBD .
"MC"	issed (unanswered received) calls list
	capacity: max. 10 entries
	location: ME
	+CPBW is not applicable to this storage. The MC list can be deleted with AT^SPBD .
"RC"	Received calls list
	capacity: max. 10 entries
	location: ME
	+CPBW is not applicable to this storage. The RC list can be deleted with AT^SPBD .
<used>(num)	value indicating-the-number of-used-locations-in selected-memory-storage.
<total>(num)	value indicating the maximum number of locations allowed in the selected memory storage.

14.4 AT+CPBW Write into Phonebook

This command serves to write onto an entry of the phone book selected with **AT+CPBS**. It can be used only after the phone book's data has been read successfully from the SIM. Reading starts after successful SIM authentication has been performed and may take up to 30 seconds depending on the SIM used. While the read process is in progress, an attempt to use any of the phone book commands will result in "+CME Error: SIM busy".

Syntax

Test Command AT+CPBW=?	Response(s) + CPBW: (1-<maxloc>),<nlength>, (list of supported <type>s),<tlength> OK ERROR +CME ERROR
Write Command]]	Response(s) OK ERROR +CME ERROR

Reference(s)	PIN	USB				
GSM 07.07		●				

Command Description

The test command returns the location range supported by the current storage, the maximum length of **<number>** field, the range of supported **<type>** values and the maximum length of **<text>** field. Note: The length may not be available while SIM storage is selected. If storage does not offer format information, the format list contains empty parentheses.

The write command fills a phone book entry at memory location **<location>** of the active storage selected with **AT+CPBS**.

If **<storage>="FD"** (SIM fixed dialling numbers) is selected, PIN2 authentication has to be performed prior to any write access.

If no **<location>** is given, the first free entry will be used.

If **<location>** is given as the only parameter, the phone book entry specified by **<location>** is deleted.

If write attempt fails "+CME ERROR" is indicated.

Parameter Description

<location>(num)

Location number within phone book-memory. The-supported-range-is given-with-the-test-command-response.

<number>(str)

Phone number with format specified by **<type>**. Parameter must be present, although it may be an empty string. However, alphabetic characters are not permitted.

<number> may contain printable non-alphabetic characters of the standard GSM alphabet as dialstring modifiers, including "*", "#" or "+". However, if **<number>** contains modifiers other than "*", "#" or "+" the following constraints shall be considered:

- If no **<type>** was specified explicitly, all accepted modifiers from the GSM alphabet will be saved in the number string. **<type>** will be set to 209 (ASCII). However, limitations as listed below for **<type>** 209 apply.
- A **<number>** saved with **<type>=209** requires double memory. In order to fit into a standard location, the number needs to be reduced to a maximum length of **<nlength>/2**, including all digits and dial string modifiers. Extended locations may be used as stated below for **<nlength>**.

<type>(num)

Type of address octet

If **<type>** is specified as 129 or 145, any non-digit characters other than "*", "#", or "+" will be removed from the number string. If the number string contains such characters, they can be saved with the number string by using **<type>** 209, see below.

145 dialling string **<number>** includes international access code character '+'

209 dialling string **<number>** contains printable non-alphabetic non-digit characters that should be saved with the number string. Remarks as under parameter **<number>** apply. For phone book entries with this type, dialling from phone book with **ATD><mem><n>** is not possible.

129 otherwise

<text>(str)(+cscs)

Text assigned to the phone number. The maximum length for this parameter is given in test command response <tlength>. When using an ASCII terminal, characters which are coded differently in ASCII and GSM have to be entered via escape sequences as described in chapter 0.5 "Supported character sets".

<maxloo>^(num)

Max. location for the currently selected storage. For phone books located on SIM, this value may vary between SIM cards. See [AT+CPBS](#) for typical values.

<nlength>^(num)

Max. length of phone number for "normal" locations. - Depending on the storage, a limited number of locations with extended memory is available per phone book. These locations allow storing numbers with twice the standard length, which is 2*<nlength> digits for normal numbers, but only <nlength> digits for numbers saved with parameter <type>= 209. If all extended locations of the selected phone book are used up, then any attempt to write a number which requires extended memory will be denied with CME ERROR 260: INVALID DIAL STRING.

<tlength>^(num)

Maximum length of <text> assigned to the telephone number. The value indicated by the test command is given in octets. If the <text> string is given in GSM characters, each character corresponds to one octet. If the <text> string is given in UCS2, the maximum number of characters depends on the coding scheme used for the alpha field of the SIM according to GSM 11.11, Annex B [16]. As a worst case the number of UCS2 characters is less than half the number of GSM characters. For a detailed description please refer to GSM 11.11, Annex B [15].

Examples:

EXAMPLE 1

Make a new phone book entry at the first free location.

AT+CPBW=1,"+431234567",145,"international"

Delete entry at location 1

AT+CPBW=1

EXAMPLE 2

The following examples are provided to illustrate the effect of writing phone book entries with different types of dial string modifiers in <number>

AT+CPBW=5,"12345678","","Arthur"

AT+CPBW=6,"432!+-765()&54*654#","John"

AT+CPBW=7,"432!+-765()&54*654#",129,"Eve"

AT+CPBW=8,"432!+-765()&54*654#",145,"Tom"

AT+CPBW=9,"432!+-765()&54*654#",209,"Richard"

EXAMPLE 3

Read phone book entries from locations 5 - 9 via [AT+CPBR](#)

+CPBR:5,"12345678",129,"Arthur"

+CPBR:6,"432!+-765()&54*654#",209,"John"

+CPBR:7,"432!+-76554*654#",129,"Eve"

+CPBR:8,"432!+-76554*654#",145,"Tom"

```
+CPBR:9,"432!+-765()&54*654#",20 9,"Richard"
```

14.5 AT^SPBC Search the first entry in the sorted telephone book

This command can be used to retrieve the index of the first entry starting with selected character <schar> in the sorted list of phone book records of the phone book currently selected with [AT+CPBS](#).

The sorted list of phone book records can be accessed with AT command [AT^SPBG](#). The sort order is described in chapter [14.1](#).

CAUTION: Please note that the sorted entries are assigned an index of their own which is not identical with the location numbers used in the various phone books. Therefore, the index retrieved with command [AT^SPBC](#) command can be used only as an index for [AT^SPBG](#). Do not use the listed index numbers to dial out or modify entries.

This command can be used only after the phone book data from the SIM have been read successfully for the first time. Reading starts after successful SIM authentication has been performed, and may take up to 30 seconds depending on the SIM used. While the read process is in progress, an attempt to use any of the phone book commands will result in "+CME Error: 14" (SIM busy).

Syntax

Test Command AT^SPBC=?	Response(s) "SPBC: "FD","SM","ME" OK ERROR +CME ERROR
Write Command AT^SPBC=<schar>	Response(s) spbc: <index> OK ERROR +CME ERROR

Reference(s)	PIN	USB					
SIMENS	●						

Command Description

The test command returns the list of phone books for which [AT^SPBC](#) is supported, in the syntax used for phone book selection in AT command [AT+CPBS](#)).

The write command retrieves the first (lowest) index in the list of sorted phone book entries beginning with character <schar>.

Parameter Description

<schar>(str)(+cscs)

The character to be searched in the sorted list of phone book entries. Character coding and formatting according to the settings made with [AT+CSGS](#). Search algorithms follow the sorting algorithms referenced in chapter [14.1](#).

<index>(num)

The first (lowest) index number within the phone book memory selected with [AT+CPBS](#) for which the corresponding <text> parameter starts with character <schar>. If no matching phone book entry is found, <index> =0 will be returned.

The index retrieved with [AT^SPBC](#) can be used only as an index for [AT^SPBG](#). Do not use the listed index numbers to dial out or modify entries.

14.6 AT^SPBD Purge phone book memory storage

This command is used to purge the selected phone book <storage> manually, i.e. all entries previously stored in the selected phone book storage will be deleted. CAUTION! The operation cannot be stopped nor reversed!

Automatic purging of phone books is performed when the SIM card is removed and replaced by a different SIM card. This affects the ME-based part of the "LD" storage, and storages "MC" and "RC". Storage "ME" is not affected.

This command can be used only after the phone book data from the SIM have been read successfully for the first time. Reading starts after successful SIM authentication has been performed, and may take up to 30 seconds depending on the SIM used. While the read process is in progress, an attempt to use any of the phone book commands will result in "+CME Error: 14" (SIM busy).

Syntax

Test Command AT^SPBD=?	Response(s) ^SPBD: list of supported <storage>s OK +CME ERROR
AT^SPBD=<storage>	Response(s) OK +CME ERROR

Reference(s)	PIN	USB					
SIEMENS	•	•					

Command Description

The test command returns a list of supported <storage>s.

The write command is used to select the phone book <storage> to be purged.

Parameter Description

<storage>^(str)

If test command: List of phone books which can be deleted by [AT^SPBD](#).

If write command: Phone book to be deleted.

For a detailed description of storages see [AT+CPBS](#).

"LD" Last number dialed phone book

"MC" Missed (unanswered received) calls list

"RC" Received calls list

14.7 AT^SPBG Read current Phone book entries

This command can be used to display the phone book records of the phone book currently selected with [AT+CPBS](#) in sorted order by name. The sort order is described in chapter [14.1](#), "Sort order for Phone books". There are two ways to use command [AT^SPBG](#):

- If the optional parameter <RealLocReq> is omitted: Please note that the sorted entries are assigned an index of their own which is

not identical with the location numbers used in the various phone books.

In this case, command **AT^SPBG** can be used for reading only. For example, it helps you find entries starting with matching characters. Do not use the listed index numbers to dial out or modify entries.

- To access an entry found with **AT^SPBG** for editing or dialing, enter **AT^SPBG** with the parameter **<RealLo-cReq>=1**.

Then extract the "real" location number of the entry from response parameter **<location>** and use this "real" location number with **ATD><mem><n>** or **AT+CPBW**.

This command can be used only after the phone book data from the SIM have been read successfully for the first time. Reading starts after successful SIM authentication has been performed, and may take up to 30 seconds depending on the SIM used. While the read process is in progress, an attempt to use any of the phone book commands will result in "+CME Error: 14" (SIM busy).

Syntax

Test Command AT^SPBG=?	Response(s) ^SPBG: (1-<used>),<nlength>,<tlength> OK ERROR
Write Command AT^SPBG=<index1>[,<index2>][,<RealLocReq>]	Response(s) [^SPBG:<index1>,<number>,<type>,<text>[,<location>]] [^SPBG: <index2>,<number>,<type>,<text>[,<location>]] OK +CME ERROR

Reference(s)	PIN	USB					
SIEMENS	●	●					

Command Description

The test command returns the index range for this command, the maximum length of **<number>** field, and the maximum length of **<text>** field.

Note: The length may not be available while SIM storage is selected. If storage does not offer format information, the format list should be empty parentheses.

The write command selects the index of the phone book entry, that is to be displayed, in the sorted list of phone book, or the range of indices to display.

If no **<index2>** is given, only the entry at **<index1>** will be displayed.

If parameter **<RealLocReq>=1**, the actual location of the entry displayed will be indicated in parameter **<location>**. If **<RealLocReq>** is omitted or **<RealLocReq>=0**, parameter **<location>** will not be displayed. The indices displayed in the first parameter of the write command response are indices in the sorted list of entries, and not related to the entries' location in the phone book. They may not be used for other phone book commands or **ATD><mem><n>**. Instead, parameter **<location>** must be used for these purposes.

Parameter Description

<index1>(num)

The first index number within the sorted list of phone book for which the corresponding entry is to be displayed.

The supported range is given in the test command response.

If <index1> exceeds the upper bound <used>, the AT command will return a CME ERROR 21.

<index2>^(num)

The last index number within the sorted list of phone book for which the corresponding entry is to be displayed.

The supported range is given in the test command response.

If both <index1> and <index2> are in the range indicated by the test command in parameter <used>, the list of entries will be output and terminated with OK.

If <index2> exceeds the range indicated by the test command in parameter <used>, the list of entries will be output but terminated with a +CME ERROR 21 "INVALID INDEX".

<RealLocReq>^(num)

Is a display of the "real" <location> of the entry required?

- [0] Do not display an entries "real" location number. Parameter <location> will not be displayed.
- 1 Display the "real" location number as parameter <location> at the end of the entry.

<number>^(str)

String type phone number in format specified by <type>. The number parameter may be an empty string.

<type>^(num)

type of address octet

- 145 dialling string <number> includes international access code character '+'
- 209 dialling string <number> contains printable non-alphabetic non-digit characters saved with the number string. For further detail, check the parameter descriptions for at command [AT+CPBW](#).
- 129 otherwise

<text>^{(str)(+cscs)}

Text assigned to the phone number. The maximum length for this parameter is given in test command response <tlength>.

<used>^(num)

Value indicating the number of used locations in selected memory storage.

<location>^(num)

The location within phone book memory at which the corresponding entry is located. This location may be used for other commands, (e.g. [AT+CPBR](#) or [ATD><mem><n>](#))

<tlength>^(num)

Max. length of phone number for "normal" locations. - Depending on the storage, a limited number of locations with extended memory is available per phone book. Please refer to AT command [AT+CPBW](#) for detail.

<tlength>^(num)

Max. length of <text> assigned to the telephone number. The value indicated by the test command is given in octets. If the <text> string is given in GSM characters, each character corresponds to one octet.

If the `<text>` string is given in UCS2, the maximum number of characters depends on the coding scheme used for the alpha field of the SIM according to GSM 11.11, Annex B. In the worst case, the number of UCS2 characters is less than half the number of GSM characters. For a detailed description see GSM 11.11, Annex B.

Notes

- The AT^SPBG feature is able to sort by the first 6 matching characters only. All following characters will be ignored.
- The command can be used for the phone books "SM", "FD", "ME" (cf. AT+CPBS).

Examples

EXAMPLE 1:

Using APSPBG without `<RealLocReq>`.

- a) First, run the test command to find out the range of phone book entries stored in the active phone book by using:

`AT^SPBG=?`

TA returns the number of entries in the format:

`^SPBG: (1-33),20,17`

where 33 is the number of used entries in the active phone book storage.

- b) Now, run the write command to display the phone book entries by alphabetical order. It is recommended to enter the full range to obtain best results.

`AT^SPBG=1,33`

TA returns phone book entries by alphabetical order:

`^SPBG:1,"+999999",145,"Arthur"`

`^SPBG:2,"+7777 77",145,"Bill"`

`^SPBG:3,"+888888",145,"Charlie"`

The numbers at the beginning of each line are not the memory locations in the phone book, but only serial numbers assigned to the entries' positions in the alphabetical list.

EXAMPLE 2:

Using AT^SPBG with `<RealLocReq>`

- a) First, run the test command to find out the range of phone book entries stored in the active phone book:

`AT^SPBG=?`

TA returns the number of entries in the format:

`^SPBG: (1-33),20,17`

where 33 is the total number of entries in the active phone book storage.

- b) Now, run the write command to display the phone book entries by alphabetical order. It is recommended to enter the full range to obtain best results.

Use parameter `<RealLocReq>=1` in order to obtain the entries' location numbers.

`AT^SPBG=1,33,1`

TA returns phone book entries by alphabetical order:

`^SPBG:1,"+999999",145,"Arthur",27`

`^SPBG:2,"+777777",145,"Bill",6`

`^SPBG:3,"+888888",145,"Charlie",15`

- c) The numbers at the end of each line are now the memory locations in the phone book and can be used for dialing or editing phone book entries:

`AT+CPBR=27`

Read out phone book location 27.

`+CPBR: 27," + 999 999",145,"Arthur"`

- d) This entry can now be edited with

`AT+CPBW.`

14.8 AT[^]PBS Step through the selected phone book alphabetically

This command can be used to scroll sequentially through the active phone book records in alphabetical order by name. Three entries will be displayed at a time.

This command can be used only after the phone book data from the SIM have been read successfully for the first time. Reading starts after successful SIM authentication has been performed, and may take up to 30 seconds depending on the SIM used. While the read process is in progress, an attempt to use any of the phone book commands will result in "+CME Error: 14" (SIM busy). This command can be used for the ME, SM and FD phone book.

Syntax

Test Command <code>AT[^]PBS=?</code>	Response(s) <code>^PBS: (list of supported <value>)</code> OK
Write Command <code>AT[^]PBS=<value>[,<RealLocReq>]</code>	Response(s) <code>^PBS:<index-a><number>,<type>,<text>[,<location>]</code> <code>^PBS:<index-b><number>,<type>,<text>[,<location>]</code> <code>^PBS:<index-c><number>,<type>,<text>[,<location>]</code> OK +CME ERROR

Reference(s)	PIN	USB					
SIEMENS	●	●					

Command Description

Test command returns a list of supported `<value>`.

Every time the write command is executed, 3 rows of phone book records are returned. Each triplet overlaps with the next one. The actual index depends on parameter `<value>`. This parameter determines whether the index will be increased or decreased.

If the index in one output line reaches the last index in the alphabetical list, the next output line will display the first list entry.

After the last record of the phone book has been reached (see parameter `<used>` for `AT^PBG`), the `<internalcounter>` switches over to the first. There are two ways to use command `AT^PBS`:

- If the optional parameter `<RealLocReq>` is omitted or (0): In this case, the sorted list is assigned an index of its own which is not identical with location numbers used in the various phone books. For example, it helps you find entries starting with matching characters. However, do not use the listed

index numbers to dial out with `ATD><mem><n>` or to modify entries with `AT+CPBW`.

- To access an entry found with `AT&SPBS` for editing or dialing, enter `AT&SPBS` with the parameter `<RealLo-cReq>=1`. Then extract the "real" location number of the entry from response parameter `<location>` and use this "real" location number with `ATD><mem><n>` or `AT+CPBW`.
- See examples below.

Parameter Description

`<value>(num)`

- 1 To make a step forward in the alphabetically sorted phone book.
- 2 To make a step backward in the alphabetically sorted phone book.

`<index-a>(num)`

1...maxindex The index in the sorted list of phone book entries that identifies the first entry displayed.

The value of `<index-a>` is determined by the value of the `<internalcounter>` and by parameter `<value>`.

After a write command has terminated successfully with "OK", the value from parameter `<index-a>` is saved and retained as the new `<internalcounter>` value.

`<index-b>(num)`

1...maxindex The index in the sorted list of phone book entries that identifies the third entry displayed.

`<index-b>=(<index-a>+1)`.

Mind after the last record of phone book, the first entry follows.

`<index-c>(num)`

1...maxindex The index in the sorted list of phone book entries that identifies the third entry displayed.

`<index-c>=(<index-b>+1)`.

Mind after the last record of phone book, the first entry follows.

`<number>(num)`

Mind after the last record of phone book, the first entry follows.

`<number>` (str) string type phone number in format specified by `<type>`. The number parameter may be an empty string.

`<type>(num)`

type of address octet

145 dialling string `<number>` includes international access code character '+'

209 dialling string `<number>` contains printable non-alphabetic non-digit characters saved with the number string.

For phone book entries with this `<type>`, dialling from phone book with `ATD><mem><n>` is not possible. For further detail, check the parameter descriptions for at command `AT+CPBW`.

129 otherwise

<text>(str)(+CSCS)

Text assigned to the phone number.

<RealLocReq>(num)

Is a display of the "real" **<location>** of the entry required?

[0] Do not display an entries "real" location number.
Parameter **<location>** will not be displayed.

1 Display the "real" location number as parameter
<location> at the end of the entry.

<location>(num)

The location within phone book memory at which the corresponding entry is located.

This location may be used for other phone book commands (e.g. **AT+CPBR**, **AT+CPBW**, **ATD><mem><n>**).

<internal-counter>(num)

0(&F)...maxindex This Parameter is only an internal parameter and cannot modified directly.

The internal counter will be reset to index 0 after a call to **ATZ** or **AT&F**.

Note

- The complete list of sorted entries can be retrieved using AT command **AT^SPBG**.

Example

How to use **AT^SPBS** to browse through the sorted list forward and backward.
Using **AT^SPBS** without **<RealLocReq>** or with **<RealLocReq>=0**.

- First, **AT&F** is issued to make sure that **AT^SPBS=1** starts from the first character in alphabetical order. The example illustrates how to search down and up again.

```
at&f
OK at^spbs=1
^SPBS:1,"+999999",145,"Arthur"
^SPBS:2,"+777777",145,"Bill"
^SPBS:3,"+888888",145,"Charlie"
OK
At^spbs=1
^SPBS:2,"+777777",145,"Bill"          ^SPBS:3,"+888888",145,"Charlie"
^SPBS:4,"0304444444",129,"Esther"
OK
at^spbs=1
^SPBS:3,"+888888",145,"Charlie"  ^SPBS:4,"0304444444",129,"Esther"
^SPBS:5,"0303333333",129,"Harry"
OK
At^spbs=2
^SPBS:2,"+777777",145,"Bill"          ^SPBS:3,"+888888",145,"Charlie"
^SPBS:4,"0304444444",129,"Esther"
OK
```

- If the last index in the sorted list has been reached, then the internal counter overflows to the first index:

```

at&          reset internal counter to 0
OK

At^spbs=2    step down 1 entry starting from (internal
              counter)=0 overflow occurs.

^SPBS:33,"+49301234567",145,"TomTailor"
^SPBS:1,"+999999",145,"Arthur" ^SPBS:2,"+777777",145,"Bill"
OK

```

Using AT^SPBS with <RealLocReq>=1 in order to obtain the entries' location numbers.

```

At^spbs=l,1
^SPBS:1,"+999999",145,"Arthur",27      ^SPBS:2,"+777777",145,"Bill",6
^SPBS:3,"+888888",145,"Charlie",15

```

The numbers at the end of each line are now the memory locations in the phone book and can be used for dialing or editing phone book entries:

This entry can now be read with **AT+CPBR** or edited with **AT+CPBW**.

AT+CPBR=27

Read out phone book location 27.

+CPBR:27,"+999999",145,"Arthur"

14.9 AT^SDLD Delete the "last number redial" memory

Reading starts after successful SIM authentication has been performed, and may take up to 30 seconds depending on the SIM used. While the read process is in progress, an attempt to use any of the phone book commands will result in "+CME Error: 14" (SIM busy).

Syntax

Test Command AT^SDLD=?	Response(s) OK
Exec Command AT^SDLD	Response(s) OK ERROR +CME ERROR: <err>

Reference(s)	PIN	USB					
SIEMENS	●	●					

Command Description

The execute command deletes all numbers stored in the LD memory.

15 AUDIO COMMANDS

NOTE: NO AUDIO CHANNELS ARE PROVIDED BY THE SAMBA75 !!!!.

15.1 ATL Set monitor speaker loudness

Syntax

Exec Command ATL[<val>]	Response(s) OK
----------------------------	-------------------

Reference(s)	PIN	USB					
V 25ter	○	●					

Parameter Description

<val>^(num)

Notes

- Commands **ATL** and **ATM** are implemented only for V.25ter compatibility reasons and have no effect.

15.2 ATM Set monitor speaker mode

Syntax

Exec Command ATM[<val>]	OK
----------------------------	----

Reference(s)	PIN	USB					
V.25ter	○	●					

Parameter Description

<val>^(num)

Notes

- Commands **ATL** and **ATM** are implemented only for V.25ter compatibility reasons and have no effect.

15.3 AT+CLVL Loudspeaker volume level

Syntax

Test Command AT+CLVL=?	Response(s) +CLVL: (list of supported <level>s) OK
AT+CLVL?	Response(s) +CLVL: <level> OK ERROR +CME ERROR: <err>
Write Command AT+CLVL=<level>	Response(s) OK ERROR +CME ERROR: <err>

Reference(s)	PIN	USB					
GSM 07.07	○	●					

Parameter Description**<level>**^(num)

Loudspeaker Volume Level

0...4(D)

Notes

- The write command can only be used in audio mode 2 - 6.
- The values of the volume steps are specified with the parameters **<outCalibrate>[0],...<outCalibrate>[4]** of the **ATASNFO** command.
- As an alternative to **AT+CLVL**, you can use **ATASNFO** and **ATASNFV**. The parameter **<level>** is identical with **<outStep>** used by both commands.
- Any change to **<level>** (or **<outstep>**) takes effect in audio modes 2 to 6. The only exception is audio mode 1 which is fixed to **<level>=4** (or accordingly **<outstep>=4**).
- <level>** (or **<outstep>**) is stored non-volatile when the ME is powered down with Table 2.3 or reset with **AT+CFUN=1,1**.

15.4 AT+CMUT Mute control

Syntax

Test Command AT+CMUT=?	Response(s) +CMUT: (list of supported<mute>s) OK
Read Command AT+CMUT?	Response(s) +CMUT: <mute> OK ERROR +CME ERROR: <err>
Write Command AT+CMUT=<mute>	Response(s) OK ERROR +CME ERROR: <err>

Reference(s)	PIN	USB					
		●					

Command Description

This command can be used in all audio modes (1 to 6) and during a voice call only. During an active call, users should be aware that when they switch back and forth between different audio modes (for example handsfree on/off) the value of **<mute>** does not change, i.e. the microphone mode is retained until explicitly changed.

Parameter Description**<mute>**^(num)

0(P) mute off

1 mute on

15.5 AT+VTD Tone duration

Syntax

Test Command AT+VTD=?	Response(s) +VTD: (list of supported <duration>s) OK
Read Command AT+VTD?	Response(s) <duration> OK
Write Command AT+VTD=<duration>	Response(s) OK

Reference(s)	PIN	USB					
GSM 07.07	○						

Command Description

This command refers to an integer <duration> that defines the length of tones transmitted with the **AT+VTS** command.

Parameter Description

<duration>^(num)

duration of the tone in 1/10 second

1(&F)...255

15.6 AT+VTS DTMF and tone generation

The Write command is intended to send ASCII characters or strings which cause the Mobile Switching Center (MSC) to transmit DTMF tones to a remote subscriber. It works during active voice calls only and offers the following variants:

AT+VTS=<dtmf String> allows to send a sequence of DTMF tones with a duration defined with **AT+VTD**.

AT+VTS=<dtmf>[,<duration>] allows to send a single DTMF tone. In this case, the duration can be individually determined during the call.

Syntax

Test Command AT+VTS=?	Response(s) +VTS: (list of supported <dtmf>s), (list of supported <duration>s) OK
Write Command AT+VTS=<dtmfString>	Response(s) OK
Write Command AT+VTS=<dtmf>[,<duration>]	Response(s) OK

Reference(s)	PIN	USB					
GSM 07.07	○	●					

Parameter Description

<dtmfString>^(str)

String of ASCII characters in the set 0-9,#,* ,A, B, C, D. Maximal length of the string is 29. The string must be enclosed in quotation marks ("...").

<dtmf>^(str)

ASCII character in the set 0...9,#,* , A, B, C, D.

<duration>^(num)

Tone duration in 1/10 second. If not specified current setting of **AT+VTD** is used.

1...255

15.7 AT^SNFD Set audio parameters to manufacturer default values

Syntax

Read Command AT^SNFA?	Response(s) ^SNFA: (list of supported <atten>s) OK
Exec Command AT^SNFD	Response(s) OK

Reference(s)	PIN	USB					
	O						

Command Description

TA sets the active audio parameters to manufacturer defined default values.

Notes

- Remember that the factory set audio mode 1 is fixed to **<outstep>=4**. Consequently, **AT^SNFD** restores **<audMode>** together with **<outstep>=4**, but does not affect the values of **<outStep>** currently selected in audio modes 2 - 6. This means, if **<audMode>=1**, the read commands **AT^SNFO**, **AT^SNFV** and **AT+CLVL** will always deliver **<outstep>=4**. In all other modes the **<outStep>** value is retained until explicitly changed.

15.8 AT^SNFI Set microphone path parameters

Syntax

Test Command AT^SNFI=?	Response(s) ^SNFI: (list of supported <inBbcGain>s), (list of supported <inCalibrate>s) OK
AT^SNFI?	Response(s) ^SNFI: (list of supported <inBbcGain>s), (list of supported <inCalibrate>s) OK
Write Command AT^SNFI = <inBbcGain>,<inCalibrate>	Response(s) OK

Reference(s)	PIN	USB					
SIEMENS	O	●					

Command Description

TA sets microphone path amplifying.

Parameter Description

<inBbcGain>^(num)(^SNFW)

ADC gain adjustable in eight 6 dB steps from 0 dB to 42 dB (0=0dB, 7=42dB, 8 steps of 6 dB).

0...7

`<inCalibrate>(num)(^SNFW)`

Multiplication factor for input samples. Formula to calculate the negative gain (attenuation) of the input signal: Gain in dB = 20 * log (`inCalibrate / 32768`)

0...32767

Notes

- Write command works only in audio modes 2 to 6!
- Read and write options of this command refer to the active audio mode.
- The range of `<inCalibrate>` is up to 65535 but will be suppressed to 32767. Values above `<inCalibrate>= 65535` will cause a failure.
- Changed values have to be stored with AT^{^SNFW}.
- Attention! When you adjust audio parameters avoid exceeding the maximum allowed level. Bear in mind that exposure to excessive levels of noise can cause physical damage to users!
- The default values are customer specific.

15.9 AT^{^SNFO} Set audio output (= loudspeaker path) parameter

Syntax

Test Command AT ^{^SNFO=?}	Response(s) ^SNFO: (list of supported <code><outBbcGain>s</code>) (list of supported <code><outCalibrate>s</code>) (list of supported <code><outStep>s</code>) (list of supported <code><sideTone>s</code>) OK
Read Command AT ^{^SNFO?}	Response(s) ^SNFO: <code><outBbcGain></code> , <code><outCalibrate>[0]</code> , <code><outCalibrate>[1]</code> , <code><outCalibrate>[2]</code> , <code><outCalibrate>[3]</code> , <code><outCalibrate>[4]</code> , <code><outStep></code> , <code><sideTone></code> OK
Write Command AT ^{^SNFO=<outBbcGain>,<outCalibrate>[0],<outCalibrate>[1],<outCalibrate>[2],<outCalibrate>[3],<outCalibrate>[4],<outStep>,<sideTone>}	Response(s) OK

Reference(s)	PIN	USB					
SIEMENS	○	●					

Command Description

TA sets earpiece path amplifying.

Parameter Description

`<outBbcGain>(num)(^SNFW)`

Negative DAC gain (attenuation) adjustable in four 6 dB steps from 0 dB to -18 dB (0=0 dB, 3=-18 dB)

0...3

`<outCalibrate>(num)(^SNFW)`

Formula to calculate the value of the 5 volume steps selectable with parameter `<outstep>`: Attenuation = $20 \log * (2 * \text{outCalibrate}[n] / 32768)$

0...32767

`<outStep>(num)`

Volume steps 0 - 4, each defined without Calibrate[n]

`<sideTone>(num)(^SNFW)`

Multiplication factor for the sidetone gain.

Formula to calculate how much of the original microphone signal is added to the earpiece signal:

Sidetone gain in dB = $20 * \log (\text{sideTone} / 32768)$.

0...32767

Notes

- The write command works only in audio modes 2 to 6.
- The read and write commands refer to the active audio mode.
- `<outCalibrate>` specifies the amount of volume of each `<outstep>`. The range of each `<outCalibrate>` is up to 65535, but will be suppressed to 32767. A value above `<outCalibrate>= 65535` will cause an error.
- The range of `<sideTone>` is up to 65535, but will be suppressed to 32767. A value above `<sideTone>=65535` will cause an error.
- Any change to `<outStep>` takes effect in audio modes 2 to 6. Nevertheless, the sound quality and the amount of volume are not necessarily the same, since all remaining audio parameters can use different values in either mode.
- Audio mode 1 is fixed to `<outStep>=4`. In this mode, any attempt to change `<outStep>` or other parameters returns an error.
- The value of `<outStep>` is stored non-volatile when the ME is powered down with Table 2.3 or reset with `AT+CFUN=x,1`. Any other parameters changed with `AT^SNFO` need to be saved with `AT^SNFW` for use after restart. See also `AT^SNFD` for details on restoring factory defaults.
- The values of `<outStep>` can also be changed with `AT^SNFV` and `AT+CLVL`.
- CAUTION!** When you adjust audio parameters avoid exceeding the maximum allowed level. Bear in mind that exposure to excessive levels of noise can cause physical damage to users!

15.10 AT^SNFPT Set progress tones

Syntax

Test Command <code>AT^SNFPT=?</code>	Response(s) <code>^SNFPT: (list of supported <pt>s)</code> OK
Read Command	Response(s) <code>^SNFPT: <pt></code> OK
Write Command <code>AT^SNFPT=<pt></code>	Response(s) OK

Reference(s)	PIN	USB				
	○	●				

Command Description

The write command controls the Call Progress Tones generated at the beginning of a mobile originated call setup.

Parameter Description

<pt>^(num)

- | | |
|------------------|---|
| 0 | Disables Call Progress Tones |
| 1 ^(P) | Enables Call Progress Tones (audible tones shortly heard on the phone when ME starts to set up a call.) |

Note

- Please note that the setting is stored volatile, i.e. after restart or reset, the default value 1 will be restored.

15.11 AT^SNFV Set loudspeaker volume

Syntax

Test Command AT^SNFV=?	Response(s) ^SNFV: (list of supported <outstep>s) OK
Read Command AT^SNFV?	Response(s) ^SNFV: <outStep> OK
Write Command AT^SNFV=<outStep>	Response(s) OK ERROR +CME ERROR

Reference(s)	PIN	USB					
SIEMENS	○	●					

Command Description

The test command returns the supported values of the parameter <outstep>. The read command returns the current value of parameter <outstep>.

The write command can be used to set the volume of the loudspeaker to the value <outCalibrate> addressed by <outstep>.

Parameter Description

<outStep>^(num)

The actual volume of each step is defined by the parameter <outCalibrate>, which can be set with [AT^SNFO](#).

0...4^(P)

Notes

- The read and write commands refer to the active audio mode.
- The write command works only in audio modes 2 to 6!
- Any change to <outStep> takes effect in audio modes 2 to 6. Nevertheless, the actual volume can be quite different, depending on the values of <outCalibrate> set in each mode. The only exception is audio mode 1 which is fixed to <outStep>=4.
- <outStep> is stored non-volatile when the ME is powered down with [Table 2.3](#) or reset with [AT+CFUN=1,1](#). <outStep> is not stored by [AT^SNFW](#).
- <outStep> can also be changed by [AT^SNFO](#) (chapter 15.9) and [AT+CLVL](#) (chapter 15.10).

15.12 AT^SNFW Write audio setting in non-volatile store

Syntax

Test Command AT^SNFW=?	Response(s) OK
Exec Command AT^SNFW	Response(s) OK ERROR CME ERROR: <err> OK

Reference(s)	PIN	USB					
SIEMENS	○	●					

Command Description

TA writes the active audio parameters in non-volatile store related to the active mode.

Notes

- Execute command works only in audio mode 2 to 6.
- TA writes the following audio parameter values in non-volatile store:
AT^SNFi: <inBbcGain>,<inCalibrate>
AT^SNFO: <outBbcGain>,<outCalibrate>[0 to 4],<sideTone>
<audMode><io>,<mic>,<ep>.

15.13 AT^SRTC Ring tone configuration

Syntax

Test Command AT^SRTC=?	Response(s) RTC: (list of supported) <type>s,(list of supported) <volume>s OK
Read Command AT^SRTC?	Response(s) ^SRTC: <type>,<volume>,<status> OK
Exec Command AT^SRTC	Response(s) OK
Write Command AT^SRTC=[<type>][,<volume>]	Response(s) ^SRTC: <type>,<volume> OK ERROR

Reference(s)	PIN	USB					
SIEMENS	○	●					

Command Description

The test command returns the current ring tone and volume.

The read command returns the current <type> and current <volume>. The read command can be used while test playback is off or on. In the latter case, see Execute command for details.

The execute command is intended for testing. It starts to play a melody from the audio output currently selected with the CORRESPONDING command. To deactivate test playback use AT^SRTC again.

During test playback, you can enter the Write command to select another melody and adjust the volume. Also, you can enter the read command to check the type and volume of the current ring tone, and to view the status of playback (on/off). The test ringing signal cannot be activated when an MTC is ringing (ERROR). Selecting <volume>=0 during the test, immediately stops playback. After this, ring tones will be muted until you change <volume> using the write command.

The write command chooses the type and volume of ring tones. The settings can be changed no matter whether or not the ME is ringing. The selected type and volume are saved in the non-volatile Flash memory and, thus, are retained after Power Down. An exception is <type>=0, that can be entered to quickly mute the tone or melody currently played to indicate an event. <type>=0 only stops immediately the audible ring tone, but does not terminate the URC that indicates the event (for example RING). No permanent settings are changed or saved. Before first using ring tones:

We have chosen to let you decide your own preferences when you start using ring tones. Therefore, factory setting is AT&STC=3,0,0 (ring tones are muted). To activate ring tones for the very first time, first enter the write command and simply change the volume. After applying a firmware update the volume and type selected before the firmware update will be preserved.

Parameter Description

<type>(num)

Type of ring tone. You have a choice of 7 different ring tones and melodies. All will be played from the audio output selected with the CORRESPONDING command. <type>=0 is only intended for muting.

0	Mutes the currently played tone immediately.
1	Sequence 1
2	Sequence 2
3(D)	Sequence 3
4	Sequence 4
5	Sequence 5
6	Sequence 6
7	Sequence 7

<volume>(num)

Volume of ring tone, varies from low to high

0(D)	Mute
1	Very low
2	Identical with 1
3	Low
4	Identical with 3
5	Middle
6	Identical with 5
7	High

<status>(num)

Status of test ringing. Indicates whether or not a melody is currently being played back for testing

0	Switched off
1	Switched on

Notes

- The test ringing signal cannot be activated while an MTC is ringing (ERROR).
- If an MTC arrives during test playback, test ringing will be deactivated and "normal" ringing reactivated (RING).
- If no optional parameter is entered, the old value will be kept.

16 HARDWARE RELATED COMMANDS

The AT commands described in this chapter are related to the SAMBA75's hardware interface. More information regarding this interface is available with the "SAMBA75 Hardware Interface Description"[1].

16.1 AT+CALA Set alarm time

Syntax

Test Command AT+CALA=?	Response(s) +CALA: (list of supported <n>s), (list of supported <type>s), (list of supported <length>s) OK ERROR +CME ERROR: <err>
Read Command AT+CALA?	Response(s) + CALA: <time>[,<n>[,<type>[,<text>]]] OK ERROR +CME ERROR: <err>
Write Command AT+CALA=<time>[,<n>[,<type>[,<text>]]]	Response(s) OK ERROR +CME ERROR

Reference(s)	PIN	USB					
GSM 07.07	○	●					

Unsolicited Result Codes

URC 1

+CALA: <text>

Indicates reminder message.

URC 2

^SYSSTART ALARM MODE

+CALA: <text>

Indicates ME wake-up into Alarm mode. If autobauding is active (AT+IPR=0) the line "^SYSSTART ALARM MODE" does not appear, but your individual <text> message will be displayed.

Command Description

Test command returns supported array index values <n>, alarm types <type>, and maximum length of the text <length> to be output.

Read command returns the list of current alarm settings in the ME.

The write command sets an alarm time in the ME. When the alarm is timed out and executed the ME returns an Unsolicited Result Code (URC) and the alarm time is reset to "00/01/01,00:00:00".

The alarm can adopt two functions, depending on whether or not you switch the GSM engine off after setting the alarm:

Reminder message: You can use the alarm function to generate reminder messages. For this purpose, set the alarm as described below and do not switch off or power down the ME. When executed the message comes as an Unsolicited Result Code.

Alarm mode: You can use the alarm function to restart the ME when powered down. For this purpose, set the alarm as described below. Then power down the ME by entering the [Table 2.3](#) command. When the alarm time is reached, the ME will wake up to Alarm mode. To prevent the ME from unintentionally logging into the GSM network, Alarm mode provides restricted operation. Upon wake-up, the ME indicates an Unsolicited Result Code which reads: ^SYSSTART ALARM MODE. A limited number of AT commands is available during Alarm mode, for details see table "[List of AT Commands Available in Alarm and Charge-only Mode](#)". The ME remains deregistered from the GSM network.

If you want the ME to return to full operation (normal operating mode) it is necessary to restart the ME by driving the ignition line (IGT pin of application interface) to ground.

If your ME is battery powered note that the battery can be charged while the ME stays in Alarm mode. For details please refer to [\[2\]](#).

Parameter Description

<time>(str)

Format is "yy/MM/dd,hh:mm:ss", where characters indicate year (two last digits), month, day, hour, minutes. E.g. 6th of May 2004, 22:10:00 hours equals to "04/05/06,22:10:00" (see also [AT+CCLK](#)).

Note: if **<time>** equals current date and time or is set to an earlier date, TA returns +CME ERROR: 21.

<n>(num)

Integer type value indicating the array index of the alarm.

The ME allows to set only one alarm at a time. Therefore, the list of supported alarm events indicated by the test command [AT+CALA=?](#) is **<n>=0**. If a second alarm time is set, the previous alarm will be deleted. Therefore, the read command [AT+CALA?](#) will always return **<n>=0**. This is also true if individual settings are made on USB, for details see notes below.

<type>(num)

Integer type value indicating the type of the alarm.

0 Alarm indication: text message via serial interface

<text>(str)

String type value indicating the text to be displayed when alarm time is reached; maximum length is **<length>**.

By factory default, **<text>** is undefined.

Note: **<text>** will be stored to the non-volatile flash memory when the device enters the Power Down mode via [Table 2.3](#). Once saved, it will be available upon next power-up, until you overwrite it by typing another text. This eliminates the need to enter the full string when setting a fresh alarm.

<text> should not contain characters which are coded differently in ASCII and GSM (e.g. umlauts), see also

"Supported character sets" and "GSM alphabet tables".

<length>(num)

Integer type value indicating the maximum length of **<text>**. The maximum length is 16.

Notes

- After the alarm was executed the parameter **<time>** of [AT+CALA](#) will be reset to "00/01/01,00:00:00", but **<text>** will be preserved as described above.

- If SAMBA75 is totally disconnected from power supply the most recently saved configuration of +CALA: <time>[,<n>[,<type>[,<text>]]] will be presented when SAMBA75 is powered up.
- Each time SAMBA75 is restarted it takes 2s to re-initialize the RTC and to update the current time. Therefore, it is recommended to wait 2s before using the commands **AT+CCLK** and **AT+CALA** (for example 2s after **^SYSSTART** has been output).
- Alarm settings on USB:
 - When the alarm is timed out and executed, the ME sends the URC only on the interface where the most recent alarm setting was made. The alarm time will be reset to "00/01/01,00:00:00" on all interfaces.

Examples:

EXAMPLE 1

You may want to configure a reminder call for May 31, 2004, at 9.30 h, including the message "Good Morning".

AT+CALA="04/05/31,09:30:00",0,0,"Good Morning"

OK

Do not switch off the GSM engine. When the alarm is executed the ME returns the following URC:

+CALA: Good Morning

EXAMPLE 2

To set a fresh alarm using the same message as in Example 1, simply enter date and time. <n>,<type>,<text>,<tlength> can be omitted:

AT+CALA="04/05/31,08:50:00" OK

When the alarm is executed the URC comes with the same message:

+CALA: Good Morning

EXAMPLE 3

To configure the alarm mode, e.g. for May 20, 2004, at 8.30 h, enter

AT+CALA="04/05/20,08:30:00"

OK

Next, power down the ME:

AT^SMSO ^SMSO: MS OFF

When the alarm is executed the ME wakes up to Alarm mode and displays a URC. If available, this line is followed by the individual <text> most recently saved. If no individual message was saved only the first line appears.

^SYSSTART ALARM MODE

+CALA: Good Morning

16.1.1 Summary of AT commands available in Alarm mode

Table 17.1: List of AT commands available in alarm and charge-only mode AT command function

AT+CALA	Set alarm time.
AT+CCLK	Set date and time of RTC.
AT^SCTM	Query temperature of GSM engine.
at^smso	Power down GSM engine.

16.2 AT+CCLK Real Time Clock

Syntax

Test Command AT+CCLK=?	Response(s) OK
Read Command AT+CCLK?	Response(s) +CCLK: <time> OK
Write Command AT+CCLK=<time>	Response(s) +CME ERROR: <err> ERROR OK

Reference(s)	PIN	USB				
GSM 07.05	○	●				

Parameter Description

<time>^(str)

Format is "yy/mm/dd,hh:mm:ss", where the characters indicate the two last digits of the year, followed by month, day, hour, minutes, seconds; for example 6 May 2004, 22:10:00 hours equals to "04/05/06,22:10:00" Factory default is "02/01/01,00:00:00"

Notes

- <time> is retained if the device enters the Power Down mode via [Table 2.3](#).
- <time> will be reset to its factory default if power is totally disconnected. In this case, the clock starts with <time>= "02/01/01,00:00:00" upon next power-up.
- Each time SAMBA75 is restarted it takes 2 s to re-initialize the RTC and to update the current time. Therefore, it is recommended to wait 2 s before using the commands [AT+CCLK](#) and [AT+CALA](#) (for example 2 s after [^SYSSTART](#) has been output).

16.3 AT^SBV Battery/Supply Voltage

Syntax

Test Command AT^SBV=?	Response(s) OK ERROR +CME ERROR:
Exec Command AT^SBV	Response(s) ^SBV: <value> OK ERROR

Reference(s)	PIN	USB				
	○	●				

Command Description

The exec command allows to monitor the supply (or battery) voltage of the module measured on pin BATT+. The reference point for measuring the voltage are the test points BATT+ and GND on the bottom of the module. Refer to [1] for information on the module's test points.

The displayed value is constant over the measurement period. The duration of the measurement period depends on the operating mode on the radio interface: it ranges from 0.5 s in TALK/DATA mode up to 50 s when SAMBA75 is in IDLE mode or Limited Service (deregistered).

Parameter Description

<value>^(num)

supply (or battery) voltage in mV

16.4 AT^SCTM Set critical operating temperature presentation mode or query temperature

Use this command to monitor the temperature range of the module and the battery. The write command enables or disables the presentation of URCs to report critical temperature limits.

CAUTION: DURING THE FIRST 15 SECONDS AFTER START-UP, THE MODULE OPERATES IN AN AUTOMATIC REPORT MODE: URCs CAN BE ALWAYS DISPLAYED REGARDLESS OF THE SELECTED MODE <n>.

Syntax

Test Command AT^SCTM=?	Response(s) ^SCTM: (list of supported <n>s) OK
Read Command AT^SCTM?	Response(s) OK ERROR +CME ERROR: <err>
Write Command AT^SCTM=<n>	Response(s) OK ERROR +CME ERROR: <err>

Reference(s)	PIN	USB					
SIEMENS	○	●					

Unsolicited Result Codes

URC 1

URCs will be automatically sent to the TA when the temperature reaches or exceeds the critical level, or when it is back to normal.

for battery temperature

URC 2

for module (board) temperature

Command Description

The read command returns the URC presentation mode and information about the current temperature range of the module. Please note that the read command does not indicate the temperature range of the battery. The battery temperature can only be reported by an Unsolicited Result Code.

Select <n> to enable or disable the presentation of the URCs. Please note that the setting will not be stored upon Power Down, i.e. after restart or reset, the default <n>=0 will be restored. To benefit from the URCs <n>=1 needs to be selected every time you reboot the GSM engine.

Parameter Description<n>^(num)

0(&F) Presentation of URCs is disabled (except for <m> equal to -2 or +2).

1 Presentation of URCs is enabled.

<m>^(num)

-2 Below lowest temperature limit (causes immediate switch-off)

-1 Below low temperature alert limit

0 Normal operating temperature

1 Above upper temperature alert limit

2 Above uppermost temperature limit (causes immediate switch-off)

Notes

- Please refer to the "Hardware Interface Description" for specifications on critical temperature ranges.
- To avoid damage the module will shut down once the critical temperature is exceeded. The procedure is equivalent to the power-down initiated with [Table 2.3](#).
- URCs indicating the alert level "1" or "-1" are intended to enable the user to take appropriate precautions, such as protect the module or battery from exposure to extreme conditions, or save or back up data etc. The presentation of "1" or "-1" URCs depends on the settings selected with the write command:
- If <n>=0: Presentation is enabled for 15 s time after the module was switched on. After 15 s operation, the presentation will be disabled, i.e. no URCs will be generated. If <n>= 1: Presentation of "1" or"-1" URCs is always enabled.
- Level "2" or "-2" URCs are followed by immediate shutdown. The presentation of these URCs is always enabled, i.e. they will be output even though the factory setting [AT&SCTM=0](#) was never changed.
- If the temperature limit is exceeded while an emergency call is in progress the engine continues to measure the temperature and to deliver alert messages, but deactivates the shutdown functionality. Once the call is terminated full temperature control will be resumed. If the temperature is still out of range ME switches off immediately.

Examples:**EXAMPLE 1**

URCs issued when the operating temperature is out of range:

SCTM_A: 1 Caution: Battery close to overtemperature limit.

SCTM_A: 2 Alert: Battery above overtemperature limit. Engine switches off.

SCTM_B: 1 Caution: Engine close to overtemperature limit.

SCTM_B: 2 Alert: Engine is above overtemperature limit and switches off.

SCTM_A: -1 Caution: Battery close to undertemperature limit.

SCTM_A: -2 Alert: Battery below undertemperature limit. Engine switches off.

SCTM_B: -1 Caution: Engine close to undertemperature limit.

SCTM_B: -2 Alert: Engine is below undertemperature limit and switches off.

EXAMPLE 2

URCs issued when the temperature is back to normal (URC is output once):

 ^sctm_A: 0 Battery temperature back to normal temperature.
 ^sctm_B: 0 Engine back to normal temperature

17 MISCELLANEOUS COMMANDS

The AT commands described in this chapter are related to various areas.

17.1 A/Repeat previous command line

Syntax

Exec Command A/	Response(s)						
---------------------------	-------------	--	--	--	--	--	--

Reference(s)	PIN	USB					
V.25ter	○	●					

Command Description

Repeat previous command line.

Notes

- Line does not need to end with terminating character.
- After beginning with the character "a" or "A" a second character "t", "T" or "/" has to follow. In case of using a wrong second character, it is necessary to start again with character "a" or "A".
- If autobauding is active, the command A/ cannot be used (see AT+IPR).

17.2 ATS3 Write command line termination character

Syntax

Read Command ATS3?	Response(s) <n> OK						
Write Command ATS3=<n>	Response(s)						

Reference(s)	PIN	USB					
V.25ter	○	●					

Command Description

This parameter setting determines the character recognized by TA to terminate an incoming command line.

Parameter Description

<n>^{(num)(&W)(&V)}

command line termination character

000...13^(&F)...127

Note

- Using other value than 13 may cause problems when entering commands.

17.3 ATS4 Set response formatting character

Syntax

Read Command ATS4?	Response(s) <n> OK
Write Command ATS4=<n>	Response(s) OK

Reference(s)	PIN	USB					
V.25ter	○	●					

Command Description

This parameter setting determines the character generated by the TA for result code and information text.

Parameter Description

<n>^{(num)(&W)(&V)}

response formatting character
000...10(&F)...127

17.4 ATS5 Write command line editing character

Syntax

Read Command ATS 5?	Response(s) <n> OK
Write Command ATS5=<n>	Response(s) OK

Reference(s)	PIN	USB					
V.25ter	○	●					

Command Description

This parameter setting determines the character recognized by TA as a request to delete the immediately preceding character from the command line.

Parameter Description

<n>^{(num)(&W)(&V)}

command line editing character
000...8(&F)...127

18 APPENDIX

18.1 Restricted access to SIM data after SIM PIN authentication

The following commands can be used only after data from the SIM have been read successfully for the first time. Reading starts after successful SIM authentication has been performed, and may take up to 30 seconds depending on the SIM used. While the read process is in progress, an attempt to use any of the following commands will result in "+CME Error: 14" (SIM busy).

- ∅ AT command not available.
- AT command accessible immediately after PIN entry has returned OK.
- AT command fully accessible after SIM PIN authentication has been completed.

AT Command	Exec	Test	Read	Write
AT+CMGL	●	○	∅	●
AT^SMGL	●	○	∅	●
AT+CMGR	∅	○	∅	●
AT^SMGR		○	∅	●
AT+CSCA	∅	○	●	○
AT+CPBR	∅	●	∅	●
AT+CPBW	∅	●	∅	●
AT+CPBS	∅	●	●	●
AT^SDLD	●	●	∅	∅
AT^SPBC	∅	●	∅	●
AT^SPBD	∅	●	∅	●
AT^SPBG	∅	●	∅	●
AT^SPBS	∅	●	∅	●
ATD><mem><n	●	∅	∅	∅

18.2 List of *# Codes

The following GSM command strings can be sent with the [ATD](#) command and must be terminated with semicolon. Reference: GSM 2.30 [16].

Table 19.1: List of (*#) Codes

Star-Hash Code	Functionality	Response, also refer Table 19.3
Phone Security		
*#06#	Query IMEI	<IMEI> OK
**04[2]*oldPin*newPin[2]*newPin[2]#	Change SIM pwd	+CME ERROR: <err>/OK
**05[2]*unblkKey* newPin[2]* newPin[2]#	Change/Unblocking SIM pwd	+CME ERROR: <err>/OK
*#0003*MasterPhoneCode#	Unlock "PS" lock with Master Phone Code	+CME ERROR: <err>/OK
*[03][ZZ]*oldPw*newPw*newPw#	Registration of net password	+CME ERROR: <err>/OK
Phone number presentation		

*#30#	Check status of CLIP (Calling Line Identification Presentation)	+CLIP : <n>,<m> OK (see: AT+CLIP)
*#31#	Check status of CLIR (Calling Line Identification Restriction)	+CLIR : <n>,<m> OK (see: AT+CLIR)
*31#<Phonenumber>[;]	Suppress CLIR	(see AT+CLIR)
#31#<Phonenumber>[;]	Activate CLIR	(see AT+CLIR)
*#76#	Check status of COLP (Connected Line Identification Presentation)	+COLP : 0,<m> OK (where <m> = active or not active)
*#77#	Check status of COLR (Connected Line Identification Restriction)	+COLR : 0,<m> OK (where <m> = active or not active)
Call forwarding (See also chapter 0.5.1)		
(choice of *,#,*#,**,##)21*DN*BS#	Act/deact/int/reg/eras CFU	[^] SCCFC : <reason>,<status>,<class> [...] like +CCFC *) (see: AT+CCFC)
(choice of *,#,*#,**,##)67*DN*BS#	Act/deact/int/reg/eras CF busy	see above
(choice of *,#,*#,**,##)61*DN*BS*T#	Act/deact/int/reg/eras CF no reply	see above
(choice of *,#,*#,**,##)62*DN*BS#	Act/deact/int/reg/eras CF no reach	see above
(choice of *,#,*#,**,##)002*DN*BS*T#	Act/deact/int/reg/eras CF all	see above
(choice of *,#,*#,**,##)004*DN*BS*T#	Act/deact/int/reg/eras CF all cond.	see above
Call waiting (See also chapter 0.5.1)		
(choice of *,#,*#)43*BS#	Activation/deactivation/int WAIT	+CCWA : <status>,<class> [...] like +CCWA *) (see: AT+CCWA)
Call barring (See also chapter 0.5.1)		
(choice of *,#,*#)33*Pw*BS#	Act/deact/int BAOC	[^] SCLCK: <fac>,<status>,<class> [,...] like +CLCK' (Refer to chapter AT+CLCK)
(choice of *,#,*#)331*Pw*BS#	Act/deact/int BAOIC	
(choice of *,#,*#)332*Pw*BS#		see above
(choice of *,#,*#)35*Pw*BS#	Act/deact/int. BAIC	see above
(choice of *,#,*#)351*Pw*BS#	Act/deact/int BAIC roaming	see above
#330*Pw*BS#	Deact. All Barring Services Deact.	see above
#333*Pw*BS#	All Outg.Barring Services Deact.	see above
#353*Pw*BS#	All Inc.Barring Services	see above
Call Hold / Multiparty		
C[C] in call	Call hold and multiparty	+CME ERROR: <err> / OK
USSD messages		
[C]...[C]#	Send USSD message	+CME ERROR: <err> / OK
C[C] (excluded 1 [C])	Send USSD message	+CME ERROR: <err> / OK

*) [^]SCCFC, +CCWA, [^]SCLCK: The output depends on the affected basic service of the *# code. One line will be output for every tele- or bearer service coded in basic service code BS.

[^]SCCFC and [^]SCLCK are modified by giving an additional <reason> or <fac> in front of the regular output string generated by the standard commands +CCFC and +CLCK.

Abbreviation	Meaning	Value
ZZ	Type of supplementary services: All services Barring services	330 Not specified
DN	Dialing number	String of digits 0-9

Abbreviation	Meaning	Value
BS	Basic service equivalent to parameter	
class:		
Voice		11
FAX		13
SMS		16
SMS+FAX		12

	Data circuit asynchron	25
	Data circuit synchron	24
	dedicated PAD access	27
	dedicated Packet access	26
	Data circuit asynchron+PAD	21
	Data circuit synchron+Packet	22
		20
	All Services	--
T	Time in seconds	In contrast to AT command AT+CCFC , parameter T has no default value. If T is not specified, an operator defined default or the last known value may be used, depending on the network operator.
PW	Password	--
C	Character of TE character set (e.g. asterics, hash or digit in case of USSD, or digits in case of held calls or multiparty calls)	--

Table 19.2: Abbreviations of Codes and Parameters Used in Table "[List of *# Codes](#)"

Possible responses

Parameter	Meaning
<m>	Mode: 0 = not active, 1 = active
<n>	Unsolicited result code: 0 = presentation disabled, 1 = presentation enabled
<status>	Status: 0 = not active, 1 = active
<class>	Represents BS = basic service. See chapters AT+CCFC , AT+CLCK and 0.5.1 .
<fac>	
<reason>	Call forwarding reason

For the exact specification of the format and parameters for *# strings, please refer to GSM 02.30, Annex C, and GSM 02.04, table 3.2 [15].

Star-Hash Code	Abbreviations in Table 19.1	Functionality
*	act	Activate (except for CLIR, see list above)
**	reg	Register and activate
*#	int	Check status (interrogate)
#	deact	Deactivate (except for CLIR, see list above)
##	eras	Unregister and deactivate

Table 19.3: Function of *# codes for Supplementary Services

18.3 Available AT Commands and Dependency on SIM PIN

- ∅ ... command not available
- ... command does not require PIN1
- ... command requires PIN1
- ◐ ... command sometimes requires PIN1

AT Command	Exec	Test	Read	Write
Configuration Commands				
AT&F	○	∅	∅	∅
AT&V	○	∅	∅	∅
AT&W	○	∅	∅	∅
ATQ	○	∅	∅	∅
ATV	○	∅	∅	∅

ATX	○	Ø	Ø	Ø
ATZ	○	Ø	Ø	Ø
AT+CFUN	Ø	○	○	○
AT+GCAP	○	○	Ø	Ø
AT+CMEE	Ø	○	○	○
AT^SCFG	Ø	○		○
AT^SM20	Ø	○	○	○
Status Control Commands				
AT+CMER	Ø	●	●	
AT+CIND		○	○	
AT^SIND		○	○	○
AT+CEER	●	●		Ø
ATS18	Ø	Ø		○
AT+CPAS	○	○		Ø
	Ø		○	○
AT\Q	○	Ø		Ø
AT&C	○	Ø		Ø
	○	Ø	Ø	Ø
	○		Ø	Ø
	○		Ø	Ø
AT+ILRR	Ø	●	●	
AT+IPR		○	○	○
Security Commands				
AT+CPIN	Ø	○	○	
AT+CPIN2		●	●	
AT^SPIC	○	○	○	○
AT+CLCK		●	Ø	
AT^SLCK		●	Ø	●
AT+CPWD	Ø	●		●
AT^SPWD	Ø	●		●
 Identification Commands				
ATI		Ø	Ø	
AT+CGMI		○	Ø	
AT+GMI	○	○	Ø	Ø
AT+CGMM	○	○	Ø	
AT+GMM		○	Ø	
AT+CGMR	○	○	Ø	

AT+GMR	○	○	∅	
AT+CGSN		○	∅	∅
AT+GSN		○	∅	∅
AT+CIMI		●	∅	
Call related Commands				
ATA	●		∅	∅
ATD	○		∅	∅
	●	∅	∅	∅
ATD><n>		∅	∅	
ATD><str>	●	∅	∅	∅
ATDI	●	∅		∅
ATDL	●	∅		∅
ATH	○	∅	∅	∅
AT+CHUP	●	●	∅	∅
ATS0	∅	∅	○	●
	∅	∅	○	
ATS7	∅	∅	○	○
ATS8	∅	∅	○	○
ATS10	∅	∅	∅	∅
ATP	○	∅	∅	∅
ATO	○	∅	∅	∅
+++	○	∅		∅
ATT	○	∅	∅	∅
AT+CBST	∅	○	○	○
AT+CRLP	∅	○	○	○
AT+CLCC	●	●	∅	∅
AT^SLCC	●	●	●	●
AT+CR	∅	●	●	●
AT+CRC	∅	○	○	○
AT+CSNS	∅	○	○	○
AT^SCNI	●	●	∅	∅
AT^SLCD	●	●	∅	∅
AT^STCD	●	●	∅	∅
Network Service Commands				
AT+COPN	●	●	∅	∅
AT+COPS	∅	○	○	○
AT+CREG	∅	○	○	○
AT+CSQ	○	○	∅	∅
AT^SMONC	●	●	∅	∅
AT^MONI	○	○	∅	○
AT^MONP		○	∅	○
	●	●		●
AT^SALS		●	●	●
AT^SHOM	○	○	∅	∅

AT^SPLM	●	●	Ø	Ø
AT^SPLR	Ø	●	Ø	
AT^SPLW		●	Ø	●
AT+ACCM	Ø	●	●	●
AT^SACM	●	●	Ø	●
AT+CAMM	Ø	●	●	●
AT+CAOC		●	●	●
AT+CCUG	Ø	●	●	●
AT+CCFC	Ø	●	Ø	●
	Ø	●	●	●
AT+CHLD	Ø	●	Ø	●
AT+CLIP	Ø	○		○
AT+CLIR	Ø	●	●	●
AT+CPUC	Ø	●	●	●
AT+CSSN	Ø	○	○	○
AT+CUSD	Ø	●	●	●
GPRS Commands				
AT+CGACT	Ø	●	●	●
AT+CGANS	Ø	●	Ø	●
AT+CGATT	Ø	●	●	●
AT+CGAUTO	Ø	●		●
AT+CGDATA	Ø	●	Ø	●
	Ø	●	●	●
AT+CGPADDR		●	Ø	●
AT+CGQMIN	Ø	●	●	●
AT+CGQREQ	Ø	●	●	●
AT+CGREG	Ø	●	●	●
AT+CGSMS	Ø	●		●
AT^SGAUTH	Ø	○	○	○
	Ø	○	○	○
ATA	●	Ø	Ø	Ø
ATD*99#		Ø	Ø	Ø
ATD*98#	●		Ø	Ø
ATH	●	Ø	Ø	
ATS0	Ø	Ø	○	●
FAX Commands				
AT+FBADLIN	Ø	Ø	○	○
AT+FBADMUL	Ø	Ø	○	○
AT+FBOR	Ø	○	○	○
AT+FCIG	Ø	○	○	○
AT+FCLASS	Ø	○	○	○
AT+FCQ	Ø		○	○
AT+FCR	Ø	Ø	Ø	
AT+FDCC	Ø	○	○	○
AT+FDFFC	Ø	○	○	○

AT+FDIS	Ø	○	○	○
AT+FDR	○	Ø	Ø	Ø
AT+FDT	○	Ø	Ø	○
AT+FET	Ø	Ø	Ø	○
AT+FK		Ø	Ø	Ø
AT+FLID		Ø○	○	○
AT+FMDL	Ø	Ø	○	Ø
AT+FMFR	Ø	Ø	○	Ø
AT+FOPT	Ø	Ø	Ø	○
	Ø	Ø	○	○
AT+FREV	Ø	Ø	○	Ø
AT+FRH	Ø	Ø	Ø	○
AT+FRM	Ø	○	Ø	○
AT+FRS	Ø	Ø	Ø	○
AT+FTH	Ø	Ø	Ø	○
AT+FTM	Ø		Ø	○
AT+FTS	Ø	Ø	Ø	
AT+FVRFC	Ø	○	○	○
Short Message Service (SMS) Commands				
AT+CMGC	Ø	●	Ø	●
AT+CMGD	Ø	●	Ø	●
AT+CMGF	Ø	○	○	○
AT+CMGL	●	●	Ø	●
AT+CMGR	Ø	●	Ø	●
AT+CMGS	Ø	●	Ø	●
AT+CMGW		●	Ø	●
AT+CMSS		●	Ø	●
AT+CNMA	Ø	●	Ø	●
AT+CNMI	Ø	●	●	●
AT+CPMS	Ø	●	●	●
AT+CSCA	Ø	●	●	●
AT+CSCB	Ø	●	●	●
AT+CSDH	Ø	●	●	●
AT+CSMP	Ø	●	●	●
AT+CSMS	Ø	●	●	●
AT^SLMS	●	●	Ø	Ø
AT^SMGL	●	●	Ø	●
AT^SMGO	Ø	●	●	●
AT^SMGR	Ø	●	Ø	●
AT^SSCONF	Ø	○	○	○
AT^SSDA	Ø	○	○	○
AT^SSMSS	Ø	○	○	○
SIM related Commands				
AT+CRSM	Ø	●	Ø	●
AT^SCKS	Ø	○	○	○
AT^SCID	○	○	Ø	Ø
	○	○	Ø	

AT+CXXCID	○	○	∅	∅
Phone book Commands				
AT+CPBR	∅	●	∅	●
	∅	●	●	●
AT+CPBW	∅	●	∅	●
AT^SPBC	∅	●	∅	●
AT^SPBD	∅	●	∅	●
AT^SPBG		●	∅	●
AT^SPBS	∅	●		●
AT^SDLD	●	●	∅	∅
Audio Commands				
ATL	○	∅	∅	∅
ATM	○	∅	∅	∅
AT+CLVL	∅	○	○	○
AT+CMUT	∅		○	○
AT+VTD	∅	○	○	○
AT+VTS	∅	○	∅	○
AT^SNFD	∅	○	○	∅
AT^SNFI	∅	○	○	○
AT^SNFO	∅	○	○	○
AT^SNFPT	∅	○	○	○
AT^SNFV		○	○	○
AT^SNFW		○	∅	∅
AT^SRTC		○	○	
Phone book Commands				
AT+CALA	∅	○	○	○
AT+CCLK	∅	○	○	○
AT^SBV	○	○	∅	∅
AT^SCTM	∅	○		○
Phone book Commands				
A/	○	∅	∅	∅
ATS3		∅	○	
ATS4	∅	∅	○	
ATS5		∅	○	○

Table 19.4: Available AT Commands and Dependency on SIM PIN

18.4 AT Command Settings storables with AT&W

AT Command	Stored parameters
Configuration Commands	
ATQ	
ATV	<value>
ATX	<value>
AT+CMEE	<n>
Status Control Commands	
ATS18	<n>
Serial Interface Control Commands	
ATQ	<n>
AT&C	<value>
AT&D	<value>
AT&S	<value>
ATE	<value>

AT+ILRR	<value>
Call Related Commands	
ATS0	<n>
ATS6	<n>
ATS7	<n>
ATS8	<n>
ATS10	<n>
AT+CBST	<speed>,<name>,<ce>
AT+CRLP	<iws>,<mws>,<T1>,<N2>
AT^SLCC	<n>
AT+CR	<mode>
AT+CRC	<mode>
Network Service Commands	
AT+COPS	
AT+CREG	
Supplementary Service Commands	
AT^SACM	<n> <n>
ATS0	<n>
FAX Commands	
AT+FCLASS	<n>
Short Message Service (SMS) Commands	
AT+CMGF	<mode>
AT+CNMI	<mode>,<mt>,<bm>,<ds>,<bfr>
AT+CSDH	<show>
AT^SMGO	<n>
SIM related Commands	
AT^SCKS	<mode>
Miscellaneous Commands	
ATS3	<n>
ATS4	<n>
ATS5	<n>

Table 19.5: Settings Stored to User Profile on USB

18.5 Factory Default Settings Restorable with AT&F

AT Command	Factory Defaults
Configuration Commands	
ATQ	
ATV	
ATX	
AT+CFUN	
AT+CMEE	
AT^SM20	
Status Control Commands	
AT+CMER	
ATS18	
Serial Interface Control Commands	
ATQ	
AT&C	
AT&D	
AT&S	
ATE	
AT+ILRR	
Call related Commands	
ATD><mem><n	
ATS0	<n>=000

ATS6	<n>=000
ATS7	
ATS10	
AT+CBST	
AT+CRLP	
AT^SLCC	<n>=0
AT+CR	
AT+CRC	
Network Service Commands	
AT+COPS	
AT+CREG	<n>=0
AT^SALS	
Supplementary Service Commands	
AT^SACM	<n>=0
AT+CLIP	
AT+CSSN	
AT+CUSD	
GPRS Commands	
ATS0	
FAX Commands	
AT+FCLASS	
Short Message Service (SMS) Commands	
AT+CMGF	
AT+CNMI	
AT+CSDH	
AT+CSMP	
AT^SMGO	
AT^SSCONF	
AT^SSDA	
AT^SSMSS	
SIM related Commands	
AT^SCKS	
Phone book Commands	
AT+CPBS	
AT^SPBS	
Audio Commands	
AT+VTD	
Hardware related Commands	
AT^SCTM	
Miscellaneous Commands	
ATS3	
ATS4	
ATS5	

Table 19.7: Factory Default Settings Restorable with **AT&F**

18.6 Summary of Unsolicited Result Codes (URC)

AT Command	URC
Configuration Commands	
Table 2.3	
Status Control Commands	
AT+CMER	+CIEV: <indDescr>,<indValue>
Call Related Commands	
AT^SLCC	if the list of current calls is empty: ^SLCC: if one or more calls are currently in the list: ^SLCC: <idx>,<dir>,<stat>,<mode>,<mpty>,<traffic channel assigned>[,<number>,<type>[,<alpha>]]

	[^SLCC: <idx>,<dir>,<stat>,<mode>,<mpty>,<traffic channel assigned>[,<number>,<type>[,<alpha>]]]
	[...]
	^SLCC:
AT+CRC	+CRING: <type>
Network Service Commands	
AT+CREG	+CREG: <stat>
AT+CREG	+CREG: <stat>[,<lac>,<ci>]
AT^SALS	^SALS: <line>
Supplementary Service Commands	
AT^SACM	+CCCM: <ccm>
AT+CCWA	+CCWA: <calling number>,<type of number>,<class>, ,<CLI validity>
AT+CCWA	^SCWA
AT+CLIP	+CLIP: <number>,<type>, , ,<CLI validity>
AT+CLIP	+CLIP: <number>,<type>
AT+CSSN	+CSSI: <code 1>
AT+CSSN	+CSSU: <code 2>
AT+CUSD	+CUSD: <m>[<str>[<dcs>]]
GPRS Commands	
AT+CGREG	+CGREG: <stat>
Short Message Service (SMS) Commands	
AT+CNMI	+CMTI: <mem3>,<index>
AT+CNMI	+CMT: <length><CR><LF><pdu>
AT+CNMI	+CMT: <oa>,<scts>[,<tooa>,<fo>,<pid>,<dcs>,<sca>,<tosca>,<length>] <CR><LPxdata>
AT+CNMI	+CBM: <length><CR><LF><pdu>
AT+CNMI	+CBM: <sn>,<mid>,<dcs>,<page>,<pages><CR><LF><data>
AT+CNMI	+CDS: <length><CR><LF><pdu>
AT+CNMI	+CDS: <fo>,<mr>[,<ra>][,<tora>],<scts>,<dt>,<st>
AT+CNMI	+CDSI:<mem3>,<index>
AT^SMGO	^SMGO: <mode>
SIM Related Commands	
AT^SCKS	^SCKS: <SimStatus>
Hardware related Commands	
AT+CALA	+CALA: <text>
AT^SCTM	^SCTM_A: <m>
AT^SCTM	^SCTM_B: <m>

Table 19.8: Summary of Unsolicited Result Codes (URC)

18.7 Alphabetical List of AT Commands

AT Command	Description	Chapter and Page
+++		chapter 6.18
A/		chapter 17.1
AT&C		chapter 3.2
AT&D		chapter 3.3
AT&F		chapter 1.1
AT&S		chapter 3.4
AT&V		chapter 1.2
AT&W		chapter 1.3
AT+CACM		chapter 8.1
AT+CALA		chapter 16.1
AT+CAMM		chapter 8.3
AT+CAOC		chapter 8.4
AT+CBST		chapter 6.20
AT+CCFC		chapter 8.6
AT+CCLK		chapter 16.2
AT+CCUG		chapter 8.5
AT+CCWA		chapter 8.7

This confidential document is the property of FALCOM GmbH and may not be copied or circulated without permission.

AT+CEER	Extended error report	chapter 2.4
AT+CFUN		chapter 1.8
AT+CGACT		chapter 9.1
AT+CGANS		chapter 9.2
AT+CGATT		chapter 9.3
AT+CGAUTO		chapter 9.4
AT+CGDATA		chapter 9.5
AT+CGDCONT		chapter 9.6
AT+CGMI		chapter 5.2
AT+CGMM		chapter 5.4
AT+CGMR		chapter 5.6
AT+CGPADDR		chapter 9.7
AT+CGQMIN		chapter 9.8
AT+CGQREQ		chapter 9.9
AT+CGREG		chapter 9.10
AT+CGSMS		chapter 9.11
AT+CGSN		chapter 5.8
AT+CHLD		chapter 8.8
AT+CHUP		chapter 6.10
AT+CIMI		chapter 5.10
AT+CIND		chapter 2.2
AT+CLCC		chapter 6.22
AT+CLK		chapter 4.4
AT+CLIP		chapter 8.9
AT+CLIR		chapter 8.10
AT+CLVL		chapter 15.4
AT+CMEE		chapter 1.11
AT+CMER		chapter 2.1
AT+CMGC	Send an SMS command	
AT+CMGD		chapter 11.3
AT+CMGF		chapter 11.4
AT+CMGL	List SMS messages from preferred store	chapter 11.5
AT+CMGR		chapter 11.6
AT+CMGS		chapter 11.7
AT+CMGW		chapter 11.8
AT+CMSS		chapter 11.9
AT+CMUT		chapter 15.5
AT+CNMA		chapter 11.10
AT+CNMI		chapter 11.11
AT+COPN		chapter 7.1
AT+COPS		chapter 7.2
AT+CPAS		chapter 2.6
AT+CPBR		chapter 14.2
AT+CPBS		chapter 14.3
AT+CPBW		chapter 14.4
AT+CPIN		chapter 4.1
AT+CPIN2		chapter 4.2
AT+CPMS		chapter 11.12
AT+CPUC		chapter 8.11
AT+CPWD		chapter 4.6
AT+CR		chapter 6.24
AT+CRC		chapter 6.25
AT+CREG		chapter 7.3
AT+CRLP		chapter 6.21
AT+CRSM		chapter 12.1
AT+CSCA		chapter 11.13

AT+CSCB	Select Cell Broadcast Message Indication	chapter 11.14
AT+CSDH		chapter 11.15
AT+CSMP		chapter 11.16
AT+CSMS		chapter 11.17
AT+CSNS		chapter 6.26
AT+CSQ		chapter 7.4
AT+CSSN		chapter 8.12
AT+CUSD		chapter 8.13
AT+CXXCID		chapter 12.4
AT+FBADLIN		chapter 10.2
AT+FBADMUL		chapter 10.3
AT+FBOR		chapter 10.4
AT+FCIG		chapter 10.5
AT+FCLASS		chapter 10.6
AT+FCQ		chapter 10.7
AT+FCR		chapter 10.8
AT+FDCC		chapter 10.9
AT+FDFFC		chapter 10.10
AT+FDIS		chapter 10.11
AT+FDR		chapter 10.12
AT+FDT		chapter 10.13
AT+FET		chapter 10.14
AT+FK		chapter 10.15
AT+FLID		chapter 10.16
AT+FMDL		chapter 10.17
AT+FMFR		chapter 10.18
AT+FOPT		chapter 10.19
AT+FPHCTO		chapter 10.20
AT+FREV		chapter 10.21
AT+FRH		chapter 10.22
AT+FRM		chapter 10.23
AT+FRS		chapter 10.24
AT+FTH		chapter 10.25
AT+FTM		chapter 10.26
AT+FTS		chapter 10.27
AT+FVRFC		chapter 10.28
AT+GCAP		chapter 1.10
AT+GMI		chapter 5.3
AT+GMM		chapter 5.5
AT+GMR		chapter 5.7
AT+GSN		chapter 5.9
AT+ILRR		chapter 3.6
AT+IPR		chapter 3.7
AT+VTD		chapter 15.6
AT+VTS		chapter 15.7
AT+WS46		chapter 2.7
AT\Q		chapter 3.1
AT^MONI		chapter 7.6
AT^MONP		chapter 7.7
AT^SACM		chapter 8.2
AT^SALS		chapter 7.9
AT^SBV		chapter 16.4
AT^SCFG		chapter 1.13
AT^SCID		chapter 12.3
AT^SCKS		chapter 12.2
AT^SCNI		chapter 6.27

AT^SCTM	Set critical operating temperature presentation mode or query temperature	chapter 16.5
AT^SDLD		chapter 14.9
AT^SGAUTH		chapter 9.12
AT^SGCONF		chapter 9.13
AT^SHOM		chapter 7.10
AT^SIND		chapter 2.3
AT^SLCC		chapter 6.23
AT^SLCD		chapter 6.28
AT^SLCK		chapter 4.5
AT^SLMS		chapter 11.18
AT^SM20		Chapter 1.14
AT^SMGL	READ	chapter 11.19
AT^SMGO		chapter 11.20
AT^SMGR		chapter 11.21
AT^SMONC		chapter 7.5
AT^SMONG		chapter 7.8
Table 2.3		chapter 1.9
AT^SNFD		chapter 15.10
AT^SNFI		chapter 15.11
AT^SNFO		chapter 15.13
AT^SNFPT		chapter 15.14
AT^SNFV		chapter 15.17
AT^SNFW		chapter 15.18
AT^SPBC		chapter 14.5
AT^SPBD		chapter 14.6
AT^SPBG		chapter 14.7
AT^SPBS		chapter 14.8
AT^SPIC		chapter 4.3
AT^SPLM		chapter 7.11
AT^SPLR		chapter 7.12
AT^SPLW		chapter 7.13
AT^SPWD		chapter 4.7
AT^SRTC		chapter 15.19
AT^SSCONF		chapter 11.22
AT^SSDA		chapter 11.23
AT^SSMSS		chapter 11.24
AT^STCD		chapter 6.29
ATA		chapter 6.2
ATA		chapter 9.14
ATD		chapter 6.3
ATD*98#		chapter 9.16
ATD*99#		chapter 9.15
ATD><mem><n		chapter 6.4
ATD><n		chapter 6.5
ATD><str		chapter 6.6
ATDI		chapter 6.7
ATDL		chapter 6.8
ATE	Enable command echo	
ATH		chapter 6.9
ATH		chapter 9.17
ATI		chapter 5.1
ATL		chapter 15.2
ATM		chapter 15.3
ATO		chapter 6.17
ATP		chapter 6.16

ATQ	Set result code presentation mode	chapter 1.4
ATS0		chapter 6.11
ATS0		chapter 9.18
ATS10		chapter 6.15
ATS18		chapter 2.5
ATS3		chapter 17.2
ATS4		chapter 17.3
ATS5		chapter 17.4
ATS6		chapter 6.12
ATS7		chapter 6.13
ATS8		chapter 6.14
ATT		chapter 6.19
ATV		chapter 1.5
ATX		chapter 1.6
ATZ		chapter 2.7

Table 19.9: Alphabetical List of AT Commands