BONUS 1 · BAMBU STUDIO 2.8.2

First Print Checklist

The same eight checks before every print you send. Tick each box as you go. Paths start on the **Prepare** tab.

Before you start

- [ ] The plate on the printer is clean and seated.
- [ ] You know its type (on a two-sided plate, the side facing up).
- [ ] The filament you plan to use is loaded.

The eight-step routine

1 Printer

- [ ] The printer tile names your model. If not, click its arrow and choose yours.
- [ ] **Nozzle** matches the nozzle installed.
- [ ] After any change on the printer, click **Sync info**.

2 Plate

- [ ] The plate tile is set to the plate on the bed.

3 Filament

- [ ] Each **Project Filaments** row names the brand and type on the spool. If not, click the name and choose yours.

4 Process

- [ ] The system preset for your printer is chosen, such as **0.20mm Standard @BBL A1**.
- [ ] If the model needs supports: **Process > Support > Enable support** is on.

5 Model

- [ ] Bring the model in with **Add [Ctrl+I]** or **Add Primitive**.
- [ ] Turn it so its best flat face sits on the plate (**Rotate**, **Auto Orient** or **Lay on Face**).
- [ ] Press A to arrange.

6 Slice

- [ ] Check once more that the plate tile shows the plate on the bed.
- [ ] Click **Slice plate**.

7 Preview

- [ ] Read **Total time** and the filament weight in the **Slicing Result** panel. Compare them with the print time on the model's page.
- [ ] On a print meant as one color, **Filament change times** reads 0.
- [ ] Drag the layer slider on the right down to layer 1.
- [ ] Click Top on the view cube at the bottom left.
- [ ] Layer 1 covers the whole footprint of each part.
- [ ] Drag the layer slider up slowly.
- [ ] Nothing appears with nothing printed beneath it (a part in midair).
- [ ] On any layer that worries you, drag the move slider at the bottom to watch the nozzle path.

8 Send

- [ ] Click **Print plate**.
- [ ] In **Send print job**, check the **Printer** box.
- [ ] The plate tile beside the **Printer** box shows the plate on the bed.
- [ ] Check the filament mapping.
- [ ] **Auto Bed Leveling** is on **Auto** or **On**, not **Off**.
- [ ] Click **Send**.
- [ ] Watch the first layer go down.

REMEMBER

Any change after step 6 needs a new **Slice plate**, because **Preview** shows only the last slice. A 3MF project from MakerWorld or a friend carries its maker's settings: check the plate tile every time you open one.

If something goes wrong

What you see	Where to look
A first layer with gaps, or one that covers too little	Chapter 4, Judge a First Layer in Ten Seconds
A part with nothing beneath it	Supports or a new orientation (Chapter 6)
Filament change times above 0 on a one-color print	A second filament is assigned somewhere (Chapter 7)
The print fails after all eight steps	Chapter 9 order: plate, filament, profile, model, machine. Change one thing at a time.

BONUS 1 · BAMBU STUDIO 2.8.2

Plate Choices

Match the plate to the filament, then tell Studio which plate is on the printer.

Know your plate (names as listed in Studio)

Plate	What Bambu pairs it with	Watch for
Textured PEI Plate	PLA, PETG, TPU, ABS, ASA, PC and PA (ABS and ASA need an enclosed printer)	The texture prints onto the part's bottom
Smooth PEI Plate / High Temp Plate	The same range as textured PEI	Glue for every filament except PLA
Cool Plate SuperTack	PLA and PETG, no glue	No TPU or organic solvents; X1: plate detection may need to be off
Cool Plate	PLA, with glue	PETG and ABS can bubble it and stick
Engineering Plate	Engineering materials	Glue every time; not recommended for PLA

Set the plate tile

- ☐ Two-sided PEI plate: the tile follows the side facing up, **Textured PEI Plate** or **Smooth PEI Plate / High Temp Plate**.
- ☐ **Auto plate type** (**Preferences > User**) may change the tile: set and check it last, just before every slice.
- ☐ The bed target on the printer screen matches the plate. **Bambu PLA Basic @BBL A1** sets 65 °C for both PEI plates, 45 °C for the Cool Plate SuperTack and 35 °C for the Cool Plate.

Glue on Bambu's two-sided PEI plate

Filament	Textured side	Smooth side
PLA	No glue	No glue
PETG, ABS, ASA, PVA, PET-CF	No glue	Glue
TPU	Glue	Glue
PC and the PA family	Glue stick only	Glue stick only

Bambu strongly discourages third-party glues.

Bed temperatures by plate (for checking)

Filament	Cool Plate	Cool Plate SuperTack	Smooth or textured PEI
PLA	35-45 °C	45 °C	45-65 °C
PETG	Not recommended	Suitable; Bambu gives no figure	60-80 °C
TPU	Not recommended	Do not print TPU	35-45 °C
ABS, ASA	Not recommended	Not recommended	90-100 °C

BONUS 1 · BAMBU STUDIO 2.8.2

Plate-Cleaning Card

Cut out the cards along the dashed lines and keep them by the sink or the printer.

✂ Cut along the dashed line

The Two-Minute Wash

For: PEI plates (textured or smooth) and the Cool Plate. Bambu gives no washing method for the SuperTack or the Engineering Plate.

You need: dish detergent, warm running water, a sponge or soft brush, paper towels, and a bed at 35 °C or lower. About two minutes, plus drying.

1. Lift the plate off the bed, holding it by two edges.
2. Wet the printing surface under warm running water.
3. Put a few drops of dish detergent on the sponge or brush.
4. Scrub the whole printing surface.
5. If you print on the other side as well, scrub that side too.
6. Rinse until no suds remain.
7. Dry both sides with a paper towel.
8. Tilt the plate toward a light and look for fingerprints or smudges.
9. Lay the plate back on the bed, still holding it by the edges.
10. Check that it lies flat all over, with its edges square to the bed and nothing caught underneath.

It worked when: no smudges show in step 8, and on the next print the first layer stays down at the corners.

Why not alcohol: Bambu's PEI cleaning guide warns that alcohol may only spread the oils around; detergent and water carry them off.

Warning: do not touch the heated bed while the printer is working. Take the plate off only once the bed is at 35 °C or lower.

✂ Cut along the dashed line

Handling the Plate

- ☐ Hands on the edges, every time the plate comes off or goes back.
- ☐ Once the bed is at 35 °C or lower, bend the steel plate a little to pop the part free.
- ☐ On a Cool Plate SuperTack, use the scraper gently: the surface is soft. For a stuck print, heat the bed to 50 °C to release it.
- ☐ On a SuperTack, no organic solvents, acetone above all.
- ☐ On an A1 or A1 mini, keep oil off the plate when you lubricate the Y axis. If adhesion suffers afterward, wash the plate with hot water and detergent.
- ☐ A PEI plate that no longer holds after a proper wash may be worn: a light pass with fine sandpaper or steel wool, then wash it again. PEI plates only.
- ☐ "The build plate is not placed properly." means: lift the plate and lay it again.