BONUS 3 · MAINTENANCE

Maintenance Calendar

Only what Bambu's page for each family gives. IPA is isopropyl alcohol. Keep this sheet next to the printer.

WARNING

Switch the printer off and unplug it before any task on these pages, and let the nozzle and the bed cool fully. Never reach into a moving printer, and keep gloves, sleeves and cloths away from belts and pulleys.

X1 series (X1, X1 Carbon, X1E) and P1 series (P1P, P1S)

When	Part	Task	Use
Before every print	Nozzle wiper	Look for debris and damage (P1: and a level position); replace if damaged	None
Weekly	Hotend, front cover and auxiliary fans	Blow clean (P1: hold the fan blades still)	Compressed air
Weekly (X1); as needed (P1)	Extruder gear	Blow clean; X1: replace if worn	Compressed air
Monthly	X-axis carbon rods	Clean; never grease	IPA, dust-free cloth
Monthly	Y and Z linear rods	Clean (P1: then a thin coat against rust, no alcohol on the X and Y bearings)	IPA (P1: then oil or grease)
Every 3 months	Z lead screws	Clean, then grease	BX-300/F grease
Every 3 months	Y and Z rods	Anti-rust	X1: anti-rust oil on a cloth; P1: Super Lube 52004
As needed	Idler pulleys	Oil only if they squeak (P1: between flange and holder); never grease the belts	Super Lube 52004

The P1 entries come from Bambu's P1P maintenance page. On a P1S, follow the printer's own reminders first and use the P1 entries as a guide. With ABS, clean the chamber camera lens weekly with IPA; on the X1, also the Micro-Lidar every 3 to 5 days. For the lead screws, Bambu names Super Lube 92003 and Lucas Oil 10533 as alternatives to BX-300/F.

A1

When	Part	Task	Use
Weekly	Part cooling fan, hotend cooling fan	Check and clean the air duct	None
Monthly	X rail	Clean, oil, slide the toolhead	Oil, never grease
Monthly	Y rail	Clean, oil both sides, slide the bed	Accessory-box oil or WD-40 Multi-Use Product
Monthly	Hotend heating assembly	Wipe clean	Absolute alcohol (Bambu's term), lint-free cloth
Every 3 months	Lead screws	Grease the working area, raise and lower the X-axis by hand	Grease
Every 3 months	X and Y idler pulleys	Lubricate (Y: oil between belt and idler)	Oil
When prompted	Belts	Re-tension	H2.0 hex key

Oil for the X rail, the Y rail and noisy idlers; grease for the lead screws and the extruder wheels. Bambu writes that grease on the X-axis linear rail is "strictly prohibited". On the A1 mini, Bambu's own pages confirm the monthly Y-axis oiling and the belt check.

H2D

When	Part	Task	Use
Monthly	X-axis assembly; left nozzle lift rail	Clean, then oil	Oil
Every 3 months	Y-axis linear rods	Clean, then oil	Oil
Every 3 months	Z rods and lead screws	Clean, then grease	Grease
Every 3 months	Cameras and flame sensors	Wipe	Alcohol on a cloth squeezed dry
Every 3 months	Exterior, screen, heatbed, toolhead, enclosure frame, panels, linings	Clean	75% ethanol or 70% IPA, non-woven cloth
Every 3 months	Auxiliary part cooling fan, chamber exhaust fan and exhausts, carbon filter cover	Clean	Brushes

Bambu moves the whole H2D schedule to monthly for long runs of high-temperature or engineering filaments, and asks for more frequent cleaning after laser work, without an interval.

By use: rolls and print hours

Printer	Part	Interval	Task
X1, P1	X carbon rods, Y and Z rods	Every 5 rolls (5 kg) of ABS or ASA, or sooner if ribbing appears	Clean with IPA
X1 series	Activated carbon filter	Monthly in production use; every 3 months at about 8 h a day; X1 Carbon filter page: 1440 hours	Replace

Bambu's two X1 Carbon figures disagree: 3 months at 8 h a day is about 720 hours.

Cutter blade (count rolls)

Printer	Check the blade	Replace when
X1, P1	Every 3 to 5 rolls of PLA, PETG, ABS or PC; every 1 to 2 rolls of PA-CF or PA-GF	Dull
A1	Every 3 rolls of PLA, ABS or PETG	Dull, chipped or missing

PTFE tubes

Where	Regular	Abrasive or high-friction
P1P	Every 10 rolls	Every 5 rolls
A1	Every 6 rolls (PLA, non-CF)	Every 2 rolls (CF, polywood)
AMS	Every two months	Monthly, or when wear shows
AMS lite	Check during regular maintenance	No interval given

Tube intervals come from different product pages; use the row for your hardware. P1P: check, replace if worn. A1, AMS: replace.

AMS, AMS lite, AMS 2 Pro and AMS HT: two minutes every other week

- [ ] Check the desiccant (if the unit has a compartment): lumpy or paste-like means replace it. Spent desiccant left over 3 months may leak water and damage the AMS electronics.
- [ ] Look along each PTFE tube, slot feeder to back outlet, for kinks, sharp bends and worn ends.
- [ ] Spin each spool by hand to feel for a snag.
- [ ] Note the date in your log.

PRINTERS WITHOUT A TABLE

A2L, P2S, X2D, H2S, H2C, H2D Pro: follow the printer's own reminders and the wear-part checks above. Bambu's guides describe no reminder for the wiper, cutter blade, PTFE tubes or AMS desiccant: put them on your calendar.

BONUS 3 · MAINTENANCE

Maintenance Log

Printer: _____

Date	Print hours	Rolls	Task	Notes

Print a fresh copy of this page when it fills up.