BONUS 4 · BAMBU STUDIO 2.8.2.61

Settings Cheat Sheet

Paths start on the **Prepare** tab. "Adv" means the setting shows only with the **Advanced** toggle on. The **Filament settings** window (round button at the end of a filament row > **Edit**) has its own **Advanced** toggle, marked "window Adv". Values: **0.20mm Standard @BBL A1** and **Bambu PLA Basic @BBL A1**; on another preset, read your own.

Printer section and Process

Setting	Where	A1 value	What it does
Plate tile	**Printer** section	**Textured PEI Plate**	Bed temperature and the plate's nozzle height (Ch. 4)
Sync info	**Printer** section		Reads nozzle and AMS from a connected printer (Ch. 2)
Diameter	**Printer > Nozzle**	0.4	Must match the nozzle fitted (Ch. 10)
Purging volumes	**Project Filaments**, two or more rows	**Multiplier** 1	Filament purged at each change (Ch. 7)
Advanced	**Process** section	Off	Shows hidden settings and the **Speed** tab (Ch. 2)
Initial layer height	**Quality**	0.2 mm	0.25 mm on smooth PEI, per Bambu's guide (Ch. 10)
Seam position	**Quality**	Aligned	**Random** can cause zits (Ch. 3)
Elephant foot compensation	**Quality**, Adv, **Precision**	0.075 mm	Pulls in a flared bottom edge (Ch. 10)
Avoid crossing wall	**Quality**, Adv	Off	Travel stays inside the part, fewer strings (Ch. 10)
Thick bridges	**Quality**, Adv	Off	Sturdier long bridges (Ch. 10)
Wall loops	**Strength**	2	Add one at a time for strength (Ch. 3)
Top shell layers	**Strength**	5	One more for a holed or pillowed top (Ch. 10)
Sparse infill density	**Strength**	15 %	Warping guide: not above 50 % (Ch. 10)
Sparse infill pattern	**Strength**	Grid	**Gyroid** shrinks less (Ch. 10)
Outer wall	**Speed**, Adv	200 mm/s	Near 120 mm/s can band (Ch. 10)
Slow down for overhangs	**Speed**, Adv	On	Keep it on (Ch. 10)
Normal printing	**Speed**, Adv, **Acceleration**	6000 mm/s²	Lower in small steps for ringing (Ch. 10)
Enable support	**Support**	Off	Turns supports on (Ch. 6)
Type	**Support**	tree(auto)	(manual) builds only where you paint (Ch. 6)
Threshold angle	**Support**	30 °	Change by 5 degrees, slice again (Ch. 6)
Top Z distance	**Support**, Adv	0.2 mm	Larger gap, easier removal (Ch. 6)
Top interface layers	**Support**, Adv	2 layers	Dense layers under the part (Ch. 6)
Raft layers	**Support**, Adv	0	A raft for ABS (Ch. 10)
Brim type	**Others**	Auto	**Outer brim only** for small or tall parts (Ch. 4, 10)
Brim width	**Others**	5 mm, greyed while **Auto**	Widen in small steps (Ch. 10)
Prime tower > **Enable**	**Others**	Ticked	Leave on for multicolor (Ch. 7)
Purge into objects' support	**Others**	On	Purge goes into supports (Ch. 7)
Timelapse	**Others**, **Special mode**		**Traditional** for a diagnosis print (Ch. 9)

Filament settings, preferences and the Device tab

Setting	Where	Value	What it does
Plate rows	**Filament > Print temperature**	PEI 65, SuperTack 45, Cool Plate 35, Engineering 0 °C	0 means the plate is not supported (Ch. 4)
Nozzle	**Filament > Print temperature**	220 / 220 °C	Down for strings, up for gaps (Ch. 10)
Flow ratio	**Filament**, window Adv	0.98	Set by the **Flow Rate** calibration (Ch. 5)
Max volumetric speed	**Filament**, window Adv	18 mm³/s in PETG HF @BBL A1	Leave it, except owners' PETG fix (Ch. 8)
Length	**Setting Overrides > Retraction**	N/A until ticked	Raise for strings, at or below about 2 mm (Ch. 10)
Part cooling fan	**Cooling**		More for overhangs, less for warping (Ch. 10)
Auto plate type	**Preferences > User**	On	May change the plate tile (Ch. 4)
Automatically transfer modified value when switching process and filament presets	**Preferences > User**	On	Changes follow you to the next preset (Ch. 3)
Auto sync user presets (Printer/Filament/Process)	**Preferences > User**	Off	Your presets in your account (Ch. 2, 15)
Auto Purge	**Preferences > General**	All	When Studio refills the purge grid (Ch. 7)
About Bambu Studio	Arrow next to **File** > **Help**		Your version, for any help request (Ch. 9)
Check for Updates	Arrow next to **File** > **Help**		Studio updates (Ch. 14)
Speed mode	**Device** tab or printer screen	**Standard**	**Ludicrous** mid-print can shift layers (Ch. 10)
Auto-recover from step loss	**Device > Print Options**		Step loss recovery (Ch. 10)

Keys used in this book (Windows)

Key	Does	Key	Does
A	Arrange all objects	**Shift+R**	Auto Orient
M, R, S	Move, Rotate, Scale	**F**	Lay on Face
Ctrl+L	Show Overhang	**L**	Supports Painting (Prepare); one-layer mode (Preview)
N	Color Painting	**E**	Brim Ears
Ctrl+R	Slice plate	**Ctrl+Z**	Undo

Three moves that reach every setting

Show every setting

Switch on the **Advanced** toggle in the **Process** section. The **Speed** tab appears only then. Studio's search (the magnifier) finds only settings that are visible, so switch **Advanced** on before you search.

Open the Filament settings window

1. In **Project Filaments**, click the round button with three dots at the end of the filament row.
2. Click **Edit**.

Tabs: **Filament**, **Cooling**, **Setting Overrides**, plus more with its own **Advanced** toggle.

Type a value

Click the field, press Ctrl+A, type the number with a point for decimals, and press Enter. The reset arrow left of the preset name takes every change back.

Change one setting at a time, then print the same small test again.