

Nexus Integrations — Easy How-To

Plain, step-by-step. Three parts: Corporate connects the keys · Dealer admin gives the team access · Dealer staff use the systems.

Words: a **site** = a property · a **system** = Brivo (doors), Eagle Eye (cameras), Shelly (relays/power), UniFi (network + access doors).

Corporate — connect a property's systems

Only Gate Guard corporate does this. Dealers never see or type these keys.

Get to the right place

1. Open **Internal** → **Site Integrations** (or Operations → Find Property → open the site → **Site Systems** → **Setup**).
2. Each property shows a chip per system: grey "—" = not set, **amber** = saved, **green** ✓ = verified. Use the **"Not connected"** filter to find properties still needing setup.
3. Click the property → the **Setup** tab.

Brivo (doors + door users)

1. **Set up** Brivo → type that property's **username, password, API key, client ID, client secret, site ID**.
2. **Save** → **Test**. Green **Verified** = done.

Eagle Eye (cameras)

1. **Set up** Eagle Eye → type the **client ID + client secret** → **Save**.
2. Click **Connect Eagle Eye** →, log in + approve, and it returns Verified.

One-time: in the Eagle Eye developer portal set the app redirect URL to `https://<our-domain>/api/eagle-eye/callback`.

Shelly (relays / power)

1. **Set up** Shelly → type the **Cloud auth key + Cloud server** (e.g. `shelly-12-eu.shelly.cloud`) → **Save** → **Test**.

UniFi (network + access doors)

1. **Set up** UniFi.
2. **Network:** Network controller URL, Network API key, site (usually `default`).
3. **Access (doors):** Access controller URL (`https://<ip>:12445`) + Access API token. (*The Access controller must be reachable from the internet.*)
4. **Save**.

Edit / remove later: same Setup tab → **Update** (blanks don't erase the rest) or **Remove** to disconnect.

PART 2

Dealer admin — give your team access

New staff start with NOTHING until you switch it on. You (admin) + corporate already have everything.

1. Open **Internal/Users** → click one of your people.
2. Find "**Site Systems access.**"
3. Flip the switches: **Doors** · **Door users** · **Cameras** · **Relays** · **Network**.
4. Choose **All our sites** or **Pick sites** (check the buildings they cover).
5. It saves as you tap. Switch off to remove access later.

PART 3

Dealer staff — use the systems

Where: Operations → Find Property → open your property → the "**Site Systems**" card with tabs. You only see what your admin turned on.

Security tab (the main one — no Eagle Eye needed)

- See each **door with its live camera**.
- **Unlock** a door → confirm → it opens (logged with your name + time).
- **Live recording** → watch the last couple minutes.
- Recent " **unlocked ...**" under a door → tap ► **clip** to watch that exact moment.

Doors tab

- List of doors → **Unlock** (confirm).
- + **Camera** to link the camera that watches a door (or tap the **suggested** one). Add tags if you like.

Relays tab

- Your Shelly relays with ON/OFF → **Turn ON / Turn OFF** (confirm — it's a real switch). Logged.

Network tab

- **Connected devices** on the property's UniFi network.
- **UniFi Access doors** (if used) → **Unlock** with confirm.

"**Not connected**" / "**contact Gate Guard**"? That system isn't set up yet, or you don't have access. Ask Gate Guard (setup) or your dealer admin (access).

Quick cheat sheet

Who	Does what	Where
Corporate	Enter / Test / Remove system keys	Internal → Site Integrations → site → Setup
Dealer admin	Switch on capabilities per person + pick sites	Internal/Users → person → Site Systems access
Dealer staff	Watch + unlock doors, view cameras, switch relays, see network	Operations → Find Property → site → Site Systems