

## Notes:

Since USB is peripheral only, ID pin is unused and VBUS is connected to 3.3V.

Unused pins will be left not-connected for the first prototype.

SWDP programming signals are available on reserved CAN pins.

Firmware upgrade is possible over USB or CAN if BOOT0 is pulled high on applying power.

BOOT0 pin is connected PB7 so that firmware upgrade can be requested from firmware.

CAN tranciever slope control may be enabled by software on PB6.

## USB CAN Adapter

Revision 0.1 – Draft for comment Drawn by: Gareth McMullin <gareth@blacksphere.co.nz>

