

MK2 Deck Overview

BROWSE
toggle browser view

SAMPLING
(unused — free button)

< >
free up free down
(master < / > = browser tree)

LEFT DISPLAY

RIGHT DISPLAY

boots to 'Stems Full Mix'
screen layout follows the Group button — see screen maps
volume / mute / filter / line / FX 1+2 / 3+4 / all

VOL
master volume

SWING
swing-skip A/B target
LED on = Deck A (NEW v0.6)

TEMPO
Load focused track → Deck A

ENTER
Load focused track → Deck B

DIAL (jog)

turn: browse / volume / SKIP
press-hold: SWING-SKIP engage (v0.6)
see Browse Knob section

DISPLAY SECTION — b1-b8 buttons and k1-k8 knobs (change with the Group, see screen maps)

b1

b2

b3

b4

b5

b6

b7

b8

k1

k2

k3

k4

k5

k6

k7

k8

GROUP BUTTONS — pad page + screen

A Stems Pads
per-stem mute + filter

B Loops
8 fixed sizes 1/8..16 beats

C Beatjump
+/- 4..32 beats

D Remix C
4x4 cell trigger grid

E Pitch / Key
semitone shift + RESET

F Loop Station
Capture A-D · recall to C

G FX1 Select
load FX1 + wet (page-press arms)

H Transport
Play / Cue / Sync / Flux

SCENE
Scene layer (A2-H2)

PATTERN
Pattern layer (A3-H3)
(auto-arms FX3/FX4)

SOLO
FX1 engage (route+on)

MUTE
Mute ALL stems (toggle)

VOLUME
Dial = focused deck vol

NOTE REPEAT
Cruise / Auto-DJ

TRANSPORT

RESTART
jump-to-start A+B

STEP <
beatjump -4 focused

STEP >
beatjump +4 focused

GRID
focus A ↔ B

PLAY
play focused deck

REC
audio recorder toggle

ERASE
SYNC ALL (latched)
1st: master+sync 4 · 2nd: off

TAP
(unused)

NAV
(unused)

16 PADS (4x4) — page contents change with Group + Layer

13

14

15

16

9

10

11

12

5

6

7

8

1

2

3

4

top rows (9-16) = DECK A · bottom rows (1-8) = DECK B

v0.6-alpha — SWING-SKIP (hold Dial, turn to seek Swing-selected deck via TID 103, replaces Beatjump-on-encoder)

v0.5-alpha — Group G page-press arms FX1 (route A+B + unit on); F2 Loop Recorder fully wired; H3 + Solo = one-hit pattern fire; Erase = Sync ALL