

SCREEN pages cheatsheet

SCREEN PAGES — display knobs/buttons per Group

GROUP A SCREEN — STEMS FULL MIX (boot screen)

display buttons (b1-b8) + display knobs (k1-k8)

b1 A Mute Drums	b2 A Mute Bass	b3 A Mute Other	b4 A Mute Vocals	b5 B Mute Drums	b6 B Mute Bass	b7 B Mute Other	b8 B Mute Vocals
k1 A Vol Drums	k2 A Vol Bass	k3 A Vol Other	k4 A Vol Vocals	k5 B Vol Drums	k6 B Vol Bass	k7 B Vol Other	k8 B Vol Vocals

GROUP B SCREEN — STEMS ENCODERS

display buttons (b1-b8) + display knobs (k1-k8)

b1 push = mute	b2 push = mute	b3 push = mute	b4 push = mute	b5 push = mute	b6 push = mute	b7 push = mute	b8 push = mute
k1 A Vol Drums	k2 A Vol Bass	k3 A Vol Other	k4 A Vol Vocals	k5 B Vol Drums	k6 B Vol Bass	k7 B Vol Other	k8 B Vol Vocals

GROUP C SCREEN — STEMS MIX CTRL

display buttons (b1-b8) + display knobs (k1-k8)

b1 A Mute Drums	b2 A Mute Bass	b3 A Mute Other	b4 A Mute Vocals	b5 B Mute Drums	b6 B Mute Bass	b7 B Mute Other	b8 B Mute Vocals
k1 A Filt Drums	k2 A Filt Bass	k3 A Filt Other	k4 A Filt Vocals	k5 B Filt Drums	k6 B Filt Bass	k7 B Filt Other	k8 B Filt Vocals

GROUP D SCREEN — STEMS FINE VOL

display buttons (b1-b8) + display knobs (k1-k8)

b1 A Mute Drums	b2 A Mute Bass	b3 A Mute Other	b4 A Mute Vocals	b5 B Mute Drums	b6 B Mute Bass	b7 B Mute Other	b8 B Mute Vocals
k1 A Fine Drums	k2 A Fine Bass	k3 A Fine Other	k4 A Fine Vocals	k5 B Fine Drums	k6 B Fine Bass	k7 B Fine Other	k8 B Fine Vocals

GROUP E SCREEN — STEMS FILTER

display buttons (b1-b8) + display knobs (k1-k8)

b1 A FiltOn Drums	b2 A FiltOn Bass	b3 A FiltOn Other	b4 A FiltOn Vocals	b5 B FiltOn Drums	b6 B FiltOn Bass	b7 B FiltOn Other	b8 B FiltOn Vocals
k1 A Filt Drums	k2 A Filt Bass	k3 A Filt Other	k4 A Filt Vocals	k5 B Filt Drums	k6 B Filt Bass	k7 B Filt Other	k8 B Filt Vocals

GROUP F SCREEN — FX 1 + 2

display buttons (b1-b8) + display knobs (k1-k8)

b1 FX1 On	b2 FX1 Btn1	b3 FX1 Btn2	b4 FX1 Btn3	b5 FX2 On	b6 FX2 Btn1	b7 FX2 Btn2	b8 FX2 Btn3
k1 FX1 D/Wet	k2 FX1 Knob1	k3 FX1 Knob2	k4 FX1 Knob3	k5 FX2 D/Wet	k6 FX2 Knob1	k7 FX2 Knob2	k8 FX2 Knob3

GROUP G SCREEN — FX 3 + 4

display buttons (b1-b8) + display knobs (k1-k8)

b1 FX3 On	b2 FX3 Btn1	b3 FX3 Btn2	b4 FX3 Btn3	b5 FX4 On	b6 FX4 Btn1	b7 FX4 Btn2	b8 FX4 Btn3
k1 FX3 D/Wet	k2 FX3 Knob1	k3 FX3 Knob2	k4 FX3 Knob3	k5 FX4 D/Wet	k6 FX4 Knob1	k7 FX4 Knob2	k8 FX4 Knob3

GROUP H SCREEN — FX ALL

display buttons (b1-b8) + display knobs (k1-k8)

b1 FX1 On	b2 FX2 On	b3 FX3 On	b4 FX4 On	b5 FX1 Btn1	b6 FX2 Btn1	b7 FX3 Btn1	b8 FX4 Btn1
k1 FX1 D/Wet	k2 FX2 D/Wet	k3 FX3 D/Wet	k4 FX4 D/Wet	k5 FX1 Knob1	k6 FX2 Knob1	k7 FX3 Knob1	k8 FX4 Knob1