

MK2 Deck Overview (hardware-positioned)

GideonSTEM-Maschine — Maschine MK2 control map (ALPHA)



BASE layer — Group A-H pads

BASE LAYER — Group A-H pads (Scene & Pattern lights off)

BASE

GROUP A — STEMS PADS

mute & filter per stem

A Filt Drums

A Filt Bass

A Filt Other

A Filt Vocals

A Mute Drums

A Mute Bass

A Mute Other

A Mute Vocals

B Filt Drums

B Filt Bass

B Filt Other

B Filt Vocals

B Mute Drums

B Mute Bass

B Mute Other

B Mute Vocals

BASE

GROUP B — LOOPS

instant fixed-size loop

A Loop 2

A Loop 4

A Loop 8

A Loop 16

A Loop 1/8

A Loop 1/4

A Loop 1/2

A Loop 1

B Loop 2

B Loop 4

B Loop 8

B Loop 16

B Loop 1/8

B Loop 1/4

B Loop 1/2

B Loop 1

BASE

GROUP C — BEATJUMP

jump by beats

A -16

A +16

A -32

A +32

A -4

A +4

A -8

A +8

B -16

B +16

B -32

B +32

B -4

B +4

B -8

B +8

BASE

GROUP D — REMIX DECK C

4x4 cell trigger grid (Deck C)

S4 C1

S4 C2

S4 C3

S4 C4

S3 C1

S3 C2

S3 C3

S3 C4

S2 C1

S2 C2

S2 C3

S2 C4

S1 C1

S1 C2

S1 C3

S1 C4

BASE

GROUP E — PITCH / KEY

key shift, 0 = reset

A 0 RESET

A +1

A +2

A +3

A -4

A -3

A -2

A -1

B 0 RESET

B +1

B +2

B +3

B -4

B -3

B -2

B -1

BASE

GROUP F — LOOP STATION

capture (silent) + recall to Deck C

Recall S3 C1

Recall S3 C2

Recall S3 C3

Recall S3 C4

Recall S2 C1

Recall S2 C2

Recall S2 C3

Recall S2 C4

Recall S1 C1

Recall S1 C2

Recall S1 C3

Recall S1 C4

Capture A

Capture B

Capture C

Capture D

BASE

GROUP G — FX1 SELECT

load FX1 + wet while held (Group G page-press arms FX1 route+on)

Bass-o-Matic

Delay T3

Phaser Pulse

Delay dub

Oscillator

Zzzurp

Strretch

Filter LFO

Iceverb

Phaser

Phaser Flux

Bouncer

Beat-masher

Gater

Delay

Tape Delay

BASE

GROUP H — TRANSPORT

play / cue / sync / flux

A Play

A Cue

A Sync

A Flux

A Play

A Cue

A Sync

A Flux

B Play

B Cue

B Sync

B Flux

B Play

B Cue

B Sync

B Flux

SCENE layer — Group A2-H2

SCENE LAYER — hold/latch SCENE (Mod#2 = 1)

SCENE

GROUP A — STEM FX SEND

route deck->FX + per-stem send

A Send Drums

A Send Bass

A Send Other

A Send Vocals

A ->FX1

A ->FX2

A ->FX3

A ->FX4

B Send Drums

B Send Bass

B Send Other

B Send Vocals

B ->FX1

B ->FX2

B ->FX3

B ->FX4

SCENE (Scene right on)

SCENE

GROUP B — LOOP ROLL

momentary roll size

A Roll 1

A Roll 2

A Roll 4

A Roll 8

A Roll 1/16

A Roll 1/8

A Roll 1/4

A Roll 1/2

B Roll 1

B Roll 2

B Roll 4

B Roll 8

B Roll 1/16

B Roll 1/8

B Roll 1/4

B Roll 1/2

SCENE (Scene right on)

SCENE

GROUP C — PHRASE JUMP

big jumps by beats

A -64

A +64

A -128

A +128

A -16

A +16

A -32

A +32

B -64

B +64

B -128

B +128

B -16

B +16

B -32

B +32

SCENE (Scene right on)

SCENE

GROUP D — REMIX DECK C 5-8

4x4 cells 5-8 (Deck C)

S4 C5

S4 C6

S4 C7

S4 C8

S3 C5

S3 C6

S3 C7

S3 C8

S2 C5

S2 C6

S2 C7

S2 C8

S1 C5

S1 C6

S1 C7

S1 C8

SCENE (Scene right on)

SCENE

GROUP E — TONE PLAY

play one stem chromatically

A 0 RESET

A +5

A +6

A +7

A +1

A +2

A +3

A +4

B 0 RESET

B +5

B +6

B +7

B +1

B +2

B +3

B +4

SCENE (Scene right on)

SCENE

GROUP F — LOOP RECORDER

global, Size + Dry/Wet + transport (mirrored)

Size 4

Size 8

Size 16

Size 32

D/W 0%

D/W 33%

D/W 66%

D/W 100%

Rec

Play

Undo

Delete

Rec

Play

Undo

Delete

SCENE (Scene right on)

SCENE

GROUP G — FX1 SELECT (hard)

same effects, harder/wetter bank

Bass-o-Matic

Delay T3

Phaser Pulse

Delay max

Oscillator

Zzzurp

Strretch

Filter LFO

Iceverb

Phaser

Phaser Flux

Bouncer

Beat-masher

Gater

Delay

Tape Delay

SCENE (Scene right on)

SCENE

GROUP H — TRANSPORT C/D

play / cue / sync / flux

C Play

C Cue

C Sync

C Flux

C Play

C Cue

C Sync

C Flux

D Play

D Cue

D Sync

D Flux

D Play

D Cue

D Sync

D Flux

SCENE (Scene right on)

github.com/gbroeckling/GideonSTEM-Maschine

PATTERN layer — Group A3-H3 (drum Pattern Player)

PATTERN LAYER — hold/latch PATTERN (Pattern Player on FX3/FX4)

GROUP A — FX3 CONTROL ROOM
drum voice 1 (FX3)

Pitch -12	Pitch 0	Pitch +7	Pitch +12
Vol 25%	Vol 50%	Vol 75%	Vol 100%
Pat 1	Pat 3	Pat 5	Pat 7
On	Play / Mute	Next Smp	Prev Smp

GROUP B — FX4 CONTROL ROOM
drum voice 2 (FX4)

Pitch -12	Pitch 0	Pitch +7	Pitch +12
Vol 25%	Vol 50%	Vol 75%	Vol 100%
Pat 1	Pat 3	Pat 5	Pat 7
On	Play / Mute	Next Smp	Prev Smp

GROUP C — DRUM MIXER
route + level the two voices

FX3 Vol-	FX3 Vol+	FX4 Vol-	FX4 Vol+
FX3 Play	FX4 Play	FX3 On	FX4 On
A->FX4	B->FX4	C->FX4	D->FX4
A->FX3	B->FX3	C->FX3	D->FX3

GROUP D — TONE PLAY DRUMS
play drums chromatically

FX4 +4	FX4 +5	FX4 +6	FX4 +7
FX4 +0	FX4 +1	FX4 +2	FX4 +3
FX3 +4	FX3 +5	FX3 +6	FX3 +7
FX3 +0	FX3 +1	FX3 +2	FX3 +3

GROUP E — SOUND DESIGN
flip samples / decay sweep

FX4 Dec 0	FX4 Dec 33	FX4 Dec 66	FX4 Dec 100
FX4 Next	FX4 Prev	FX4 Reset	FX4 Play
FX3 Dec 0	FX3 Dec 33	FX3 Dec 66	FX3 Dec 100
FX3 Next	FX3 Prev	FX3 Reset	FX3 Play

GROUP F — GATE & VOLUME
mute-gate stutter + volume

FX4 Vol 0	FX4 Vol 33	FX4 Vol 66	FX4 Vol 100
FX4 Gate	FX4 Gate	FX4 Play	FX4 Reset
FX3 Vol 0	FX3 Vol 33	FX3 Vol 66	FX3 Vol 100
FX3 Gate	FX3 Gate	FX3 Play	FX3 Reset

GROUP G — MACROS
one-tap combos across both voices

FX3 Play	FX4 Play	FX3 Vol+	FX4 Vol+
FX4 Pat 1	FX4 Pat 3	FX4 Pat 5	FX4 Pat 7
FX3 Pat 1	FX3 Pat 3	FX3 Pat 5	FX3 Pat 7
DROP	BUILD	FILL	CLEAR

GROUP H — PATTERN PICKER
sparse->busy + Solo engaged: pad press = play-from-step-1

FX4 Pat 5	FX4 Pat 6	FX4 Pat 7	FX4 Pat 8
FX4 Pat 1	FX4 Pat 2	FX4 Pat 3	FX4 Pat 4
FX3 Pat 5	FX3 Pat 6	FX3 Pat 7	FX3 Pat 8
FX3 Pat 1	FX3 Pat 2	FX3 Pat 3	FX3 Pat 4

SCREEN pages — display knobs / buttons

SCREEN PAGES — display knobs/buttons per Group

GROUP A SCREEN — STEMS FULL MIX (boot screen)

display buttons (b1-b8) + display knobs (k1-k8)

b1 A Mute Drums	b2 A Mute Bass	b3 A Mute Other	b4 A Mute Vocals	b5 B Mute Drums	b6 B Mute Bass	b7 B Mute Other	b8 B Mute Vocals
k1 A Vol Drums	k2 A Vol Bass	k3 A Vol Other	k4 A Vol Vocals	k5 B Vol Drums	k6 B Vol Bass	k7 B Vol Other	k8 B Vol Vocals

GROUP B SCREEN — STEMS ENCODERS

display buttons (b1-b8) + display knobs (k1-k8)

b1 push = mute	b2 push = mute	b3 push = mute	b4 push = mute	b5 push = mute	b6 push = mute	b7 push = mute	b8 push = mute
k1 A Vol Drums	k2 A Vol Bass	k3 A Vol Other	k4 A Vol Vocals	k5 B Vol Drums	k6 B Vol Bass	k7 B Vol Other	k8 B Vol Vocals

GROUP C SCREEN — STEMS MIX CTRL

display buttons (b1-b8) + display knobs (k1-k8)

b1 A Mute Drums	b2 A Mute Bass	b3 A Mute Other	b4 A Mute Vocals	b5 B Mute Drums	b6 B Mute Bass	b7 B Mute Other	b8 B Mute Vocals
k1 A Filt Drums	k2 A Filt Bass	k3 A Filt Other	k4 A Filt Vocals	k5 B Filt Drums	k6 B Filt Bass	k7 B Filt Other	k8 B Filt Vocals

GROUP D SCREEN — STEMS FINE VOL

display buttons (b1-b8) + display knobs (k1-k8)

b1 A Mute Drums	b2 A Mute Bass	b3 A Mute Other	b4 A Mute Vocals	b5 B Mute Drums	b6 B Mute Bass	b7 B Mute Other	b8 B Mute Vocals
k1 A Fine Drums	k2 A Fine Bass	k3 A Fine Other	k4 A Fine Vocals	k5 B Fine Drums	k6 B Fine Bass	k7 B Fine Other	k8 B Fine Vocals

GROUP E SCREEN — STEMS FILTER

display buttons (b1-b8) + display knobs (k1-k8)

b1 A FiltOn Drums	b2 A FiltOn Bass	b3 A FiltOn Other	b4 A FiltOn Vocals	b5 B FiltOn Drums	b6 B FiltOn Bass	b7 B FiltOn Other	b8 B FiltOn Vocals
k1 A Filt Drums	k2 A Filt Bass	k3 A Filt Other	k4 A Filt Vocals	k5 B Filt Drums	k6 B Filt Bass	k7 B Filt Other	k8 B Filt Vocals

GROUP F SCREEN — FX 1 + 2

display buttons (b1-b8) + display knobs (k1-k8)

b1 FX1 On	b2 FX1 Btn1	b3 FX1 Btn2	b4 FX1 Btn3	b5 FX2 On	b6 FX2 Btn1	b7 FX2 Btn2	b8 FX2 Btn3
k1 FX1 D/Wet	k2 FX1 Knob1	k3 FX1 Knob2	k4 FX1 Knob3	k5 FX2 D/Wet	k6 FX2 Knob1	k7 FX2 Knob2	k8 FX2 Knob3

GROUP G SCREEN — FX 3 + 4

display buttons (b1-b8) + display knobs (k1-k8)

b1 FX3 On	b2 FX3 Btn1	b3 FX3 Btn2	b4 FX3 Btn3	b5 FX4 On	b6 FX4 Btn1	b7 FX4 Btn2	b8 FX4 Btn3
k1 FX3 D/Wet	k2 FX3 Knob1	k3 FX3 Knob2	k4 FX3 Knob3	k5 FX4 D/Wet	k6 FX4 Knob1	k7 FX4 Knob2	k8 FX4 Knob3

GROUP H SCREEN — FX ALL

display buttons (b1-b8) + display knobs (k1-k8)

b1 FX1 On	b2 FX2 On	b3 FX3 On	b4 FX4 On	b5 FX1 Btn1	b6 FX2 Btn1	b7 FX3 Btn1	b8 FX4 Btn1
k1 FX1 D/Wet	k2 FX2 D/Wet	k3 FX3 D/Wet	k4 FX4 D/Wet	k5 FX1 Knob1	k6 FX2 Knob1	k7 FX3 Knob1	k8 FX4 Knob1