# homer\_navigation

# Introduction

Das Package "homer\_navigation" mit seiner gleichnamigen Node ist für die Navigation des Roboters zuständig. Es hält stets die aktuelle Karte des Roboters vor, die auf Topic /map empfangen wurde und berechnet anhand von dieser Karte einen Pfad vom Roboter zu einem gegebenen Zielpunkt. Dafür verwendet die Navigation die sogenannte Pfad-Transformation - eine Kombination aus Distanz-Transformation und Hindernistransformation -, in Verbindung mit A-Stern, um einen optimalen Pfad zu finden. Das Verhältnis zwischen Distanz- und Hindernis-Transformation kann über einen Parameter angepasst werden. Nach der Pfadberechnung ist das Package außerdem dafür zuständig den Roboter diesen Pfad zum Ziel abfahren zu lassen.

# **Topics**

#### Publisher

- /homer\_navigation/target\_reached (std\_msgs/Empty): Wenn der Roboter sein Ziel erreicht hat, wird eine Message über dieses Topic veschickt.
- /homer\_navigation/target\_unreachable (mapnav\_msgs/TargetUnreachable):
  Über dieses Topic wird mitgeteilt, wenn der Roboter sein Ziel nicht erreichen kann und die Navigation abgebrochen wurde. Ein Statuscode wird mitgeliefert (siehe Package map\_messages).
- /homer\_navigation/path (nav\_msgs/Path): Hierüber wird der aktuelle Pfad zur Visualisierung an die GUI geschickt.
- /robot\_platform/cmd\_vel (geometry\_msgs/Twist): Über dieses Topic werden die aktuellen Fahrbefehle zum Roboter geschickt.
- /ptu/set\_pan\_tilt (ptu/SetPanTilt): Über dieses Topic wird die PTU nach navigation auf 0, 0 gefahren.
- /ptu/center\_world\_point (ptu/CenterWorldPoint): Über dieses
  Topic wird die PTU auf den nächsten Wegpunkt centriert.

#### Subscriber

- /map (nav\_msgs/OccupancyGrid): Die jeweils aktuelle Map wird empfangen, um sie für die Pfadplanung und Hindernisvermeidung während der Navigation zu verwenden.
- /pose (geometry\_msgs/PoseStamped): Die aktuelle Pose des Roboters wird als Startpunkt der Pfadplanung verwendet.

- /scan (sensor\_msgs/LaserScan): Der aktuelle LaserScan wird zur Hindernisvermeidung verwendet.
- /front\_scan (sensor\_msgs/LaserScan): Der aktuelle LaserScan wird zur Hindernisvermeidung verwendet.
- /homer\_navigation/start\_navigation (mapnav\_msgs/StartNavigation): Startet die Pfadplanung und anschließend die Navigation zur mitgelieferten Zielpose.
- /move\_base\_simple/goal (geometry\_msgs/PoseStamped): Started die Pfadplanung und anschließende Navigation zur Zielpose.
- /homer\_navigation/stop\_navigation (std\_msgs/Empty): Stoppt die aktuelle Navigation.
- /homer\_navigation/navigate\_to\_POI (mapnav\_msgs/NavigateToPOI): Startet die Pfadplanung und anschließend die Navigation zum POI mit angegebenen Namen. Der entsprechende POI wird anschließend vom map manager erfragt.
- /homer\_navigation/unknown\_threshold (std\_msgs/Int8): Über dieses Topic kann der Schwellwert verändert werden, ab dem ein Zellwahrscheinlichkeit als belegt und damit unbefahrbar markiert wird. Standard ist 50 (%).
- /homer\_navigation/refresh\_params (std\_msgs/Empty): Über dieses Topic lassen sich die Parameter neu auslesen.
- /homer\_navigation/max\_depth\_move\_distance (std\_msgs/Float32): Über dieses Topic lässt sich die Hindernissdistance der Tiefendaten übermitteln.

# Launch Files

• homer\_navigation.launch: Startet die Navigation und lädt alle Navigations-Paramter in den Parameterserver.

#### **Parameter**

#### homer navigation

- /homer\_navigation/safe\_path\_weight: 1.2 # factor weight for safer path in relation to shortest path
- /homer\_navigation/waypoint\_sampling\_threshold: 1.5 # factor of how dense the path waypoints are sampled regarding the obstacle\_distance of the last or next waypoint
- /homer\_navigation/frontier\_safeness\_factor: 1.4 # factor of min\_allowed\_obstacle\_distance to an obstacle of a cell which is considered safe

#### cost calculation parameters

- /homer\_navigation/allowed\_obstacle\_distance/min: 0.3~# m robot must stay further away than this from obstacles
- /homer\_navigation/allowed\_obstacle\_distance/max: 5.0~# m not used at the moment
- /homer\_navigation/safe\_obstacle\_distance/min: 0.7 # m if possible robot should move further away than this from obstacles
- /homer\_navigation/safe\_obstacle\_distance/max: 1.5 # m further away than this from obstacles doesn't give a lesser cost addition

#### collision Avoidance parameters

- /homer\_navigation/collision\_distance: 0.3 # m distance to obstacle from robotFront in which the obstacle avoidance will be executed
- /homer\_navigation/collision\_distance\_near\_target: 0.2~# m distance to obstacle from robotFront where obstacle avoidance won't be executed when near the target
- /homer\_navigation/backward\_collision\_distance: 0.5~# m distance behind robot in which the robot won't back up into while doing collision avoidance
- /homer\_navigation/min\_y: 0.27~# m half robot width for max\_move\_distance calculation
- /homer\_navigation/min\_x: 0.3 # m distance from base\_link to robot front for max\_move\_distance calculation

## check path on map update

- /homer\_navigation/check\_path: true # bool toggles if the calculated path will be checked for obstacles while navigating
- /homer\_navigation/check\_path\_max\_distance: 2 # m maximal distance from robot position in which the path is being checked for obstacles

#### speed parameters

- /homer\_navigation/min\_turn\_angle: 0.15 # rad values lower than this angle will let the navigation assume reaching the designated position
- /homer\_navigation/max\_turn\_speed:  $0.6 \# \mathrm{rad/s} \mathrm{\ max} \mathrm{\ turn} \mathrm{\ velocity} \mathrm{\ the}$  navigation can send
- /homer\_navigation/min\_turn\_speed: 0.3 # rad/s min turn speed for Final Turn so the Robot doesn't stop turning

- /homer\_navigation/max\_drive\_angle: 0.6 # rad threshold for driving and turning if above that value only turn
- /homer\_navigation/max\_move\_speed: 0.4~# m/s max move speed the navigation can send

# caution factors values near 0 mean high caution values greater values mean less caution

## if any factor equals 0 the robot can't follow paths!!

- /homer\_navigation/map\_speed\_factor: 1.2 # factor for the max speed calculation of the obstacleDistancemap
- /homer\_navigation/waypoint\_speed\_factor: 1.2 # factor for the max speed calculation with the distance to the next waypoint
- /homer\_navigation/obstacle\_speed\_factor: 1.0 # factor for the max speed calculation with the last laser may movement distance
- /homer\_navigation/callback\_error\_duration: 0.3 # s max duration between pose and laser callbacks before error handling is executed
- /homer\_navigation/use\_ptu: false# bool toggles if the ptu is being used to look at the next Waypoint during navigation