# Extending gem5 with DRAMSim and DRAMSys



#### Ports are useful interfaces to other simulators



### Why use an external simulator?

Note: I don't advise using external DRAM simulators. gem5's DRAM model is accurate enough for most research

The main reasons to use an external DRAM simulator are:

- For comparisons between gem5's DRAM models and other simulators (e.g., when developing a new DRAM model for gem5)
- When you have already modified the other simulator and need to drive it with realistic traffic



# **Getting DRAMSys**

See gem5/ext/dramsys/README for deatils.

#### Run

cd ext/dramsys
git clone https://github.com/tukl-msd/DRAMSys --branch v5.0 --depth 1 DRAMSys



# **Buidling DRAMSys**

After you add the DRAMSys repo to ext/dramsys, it will automatically be built into gem5.

scons build/NULL/gem5.opt -j\$(nproc)



# **Using DRAMSys**

See <a href="https://github.com/tukl-msd/DRAMSys">https://github.com/tukl-msd/DRAMSys</a> for documentation on DRAMSys

To configure gem5 to use DRAMSys, you can use the standard library.

DRAMSys can be used as a MemorySystem just like the SingleChannel or MultiChannel memories.

```
Open [materials/05-Other-simulators/02-dram/dramsys-example.py].
```

Add the following lines to create a memory system with DDR4 from DRAMSys

```
memory = DRAMSysMem(
    configuration="/workspaces/2024/gem5/ext/dramsys/DRAMSys/configs/ddr4-example.json",
    recordable=True,
    resource_directory="/workspaces/2024/gem5/ext/dramsys/DRAMSys/configs",
    size="4GB",
)
```



# **Configuring DRAMSys**

#### Options for DRAMSys:

- configuration: See gem5/ext/dramsys/DRAMSys/configs/ for the provided configurations.
  - Must be absolute or relative to your run path.
- resource\_directory: Pointer to the configs directory.
  - Must be absolute or relative to your run path.
- recordable: Whether DRAMSys should record a trace file

#### Note on implementation

- DRAMSys uses TLM 2.0
- This is a good example of how to get gem5 to talk to a TLM object.



#### **DRAMSys** output

../../gem5/build/NULL/gem5.opt dramsys-example.py

```
board.memory.dramsys.DRAMSys.controller0
                                         Total Time:
                                                        250027920 ps
                                         AVG BW:
                                                         87.97 Gb/s |
                                                                       11.00 GB/s |
board.memory.dramsys.DRAMSys.controller0
                                                                                     73.67 %
                                         AVG BW\IDLE:
                                                         87.97 Gb/s | 11.00 GB/s |
board.memory.dramsys.DRAMSys.controller0
                                                                                     73.67 %
                                         MAX BW:
                                                        119.40 Gb/s |
                                                                       14.93 GB/s |
board.memory.dramsys.DRAMSys.controller0
                                                                                    100.00 %
```

Outputs a file, board.memory.dramsys.DRAMSys\_ddr4-example\_example\_ch0.tdb which is a database trace.

Does not use gem5's stats output!



#### **DRAMSim**

Similar to DRAMSys in how to obtain and use

Note: DRAMSim3 is not tested regularly

See [gem5/ext/dramsim3/README] for details.

To get DRAMsim run the code below and recompile gem5.

```
cd ext/dramsim3
git clone clone git@github.com:umd-memsys/DRAMsim3
cd DRAMsim3
mkdir build
cd build
cmake ..
make -j$(nproc)
```



# **Using DRAMSim3**

In gem5.components.memory.dramsim\_3 there are single channel configurations available.

from gem5.components.memory.dramsim\_3 import SingleChannelHBM

```
memory = SingleChannelHBM(size="1GiB")
```

You can extend this with other memories using [SingleChannel] from that module.

Find the list of DRAMSim configs: [gem5/ext/dramsim3/DRAMsim3/configs]

SingleChannel(<memory type from configs>, <size>)



#### NOTE: DRAMSim3 doesn't work with v24.0.0.0!

