

General Chipper / EMV Reader Troubleshooting

Here are some general EMV Reader / Credit Card Chipper troubleshooting steps not specific to any one device.

- Reseat Cable (unplug / replug)
- Hard / Soft reset chipper (either with power button or in some cases small reset button)
- Plug cable directly into chipper if previously in cradle
- Try same reader on other terminal (or cradle if applicable)
- Swap cable connecting EMV reader and terminal with a new one. You can use this picture to determine cable type.

💡 Most chippers use a standard **Micro-USB to USB-A**



- ❗ Cables for chippers are **not proprietary**, meaning they are not particular to any one device, and you can purchase a replacement from anywhere that sells cables.

Just be sure that the cable has the ability to **transfer data**. Most modern cables, unless they are very cheap, have this ability and will often be denoted as not data transfer capable if they are not - meaning this is really not a concern, but just something to keep in mind if purchasing a replacement cable

One side of the cable, the side that goes into the terminal, needs to be Type A or USB 3.0, check your USB slots in your terminal to determine which is best (use picture for reference)

Be sure to consider **cable length** as you don't want a cable that is too short to allow the chipper to be freely moved around or a cable that is too long and can create a mess. The standard cable included with most chippers are about 1 meter / 3.3 feet which works for most locations. If anything, measure the current cable in use and get a replacement that is the same size.

- Check if Uniterm is running (use task manager, advanced)
- Relaunch onePOS software on the terminal chipper is connected to (be sure to see if white uniterm screen appears briefly on launch)
- Relaunch Terminal 1 / main terminal
- Check Windows hardware devices to see if device appears as connected

⚠ If none of these steps work, it is possible the EMV Reader is faulty and needs to be replaced.

- ❗ If the issue is occurring with ALL readers and / or all errors say something like COMM error, try restarting the router.