

How to swap a terminal with another

<https://vimeo.com/706976220/94f4bee314>

If you need to change terminal 1. In this case terminal one is dead and needs to be swapped. Terminal two will be taking place for terminal 1. Terminal one is the main head. Make sure that terminal two has replicated and has the Journal.DAT file.

How to check the Journal.DAT? --- Go to file explorer, C: Drive- POS(C) – ONEPOS- JOURNALS.

Go to windows Start (on bottom left)—Log off—Sign in as Administrator

Close out launcher

Go to C Drive—Install--- ConfigTERMINAL—Right click over the ConfigTerminal logo at the top of bar—

Remove Lockdown

It will ask if you are sure you want to unlock the services on the system—Select yes.

Click cancel.

Go to windows start- Control Panel- Search network and sharing

Select the local area connection- Properties

Highlight Internet Protocol Version 4(TCP/Pv4) and click properties

Change IP Address from 202 to 201(term 2 is going to be term 1)

Save the changes (The Terminal will restart)

Go to Public Network—Make it Work connection (Term will refresh again) Now you hope it does not lose connection.

Close Launcher all the way

Go to windows start button—Make sure you go back in as administrator

Go to C drive—Install- ConfigTerminal—Set TerminalID as #01

Delete the Machine IP, Subnet, Gateway, Pri DNS, Unhighlight Optional Components

Go to Remote Support—Get Terminal1 Public IP.

Go to control panel—Network and sharing center—Local area connection—Properties—Back to the Internet Protocol Version 4

Change the IP Address to 101 at the end to make it term 1. (It will restart)

Change Data server IP and data server IP Backup

Data Server IP should say 192.168.0.101

Data Server IP Backup should have 192.168.0.202

Uncheck Lock Down system and type in Accept at the bottom (always make sure optional components are not highlighted. Click ok

Restart the terminal.

Once it turns back on. Make sure the terminal server has changed on onePOS Launcher.

Open MC—Go to Setup- Hardware Devices- Change the locations to terminal 1

Change the device printer to the one Terminal 1 was using.

Close onePOS terminal and MC.

Once you open terminal it should show which terminal it is now, at the bottom.