Power head LED		Possible Problem	Solution
Red LED showing	Green LED showing		
OFF	OFF	Normal operation	None required
Continuous ON		• Programming incomplete	• Complete programming
1 BLINK, Pause (Repeat)		• Transmitter has not learned	• Program Remote
	1 BLINK, Pause (Repeat)	• Programming incomplete • Safe-T-Beam® detects obstruction going down • Door obstruction going down • Door obstruction going up	• Set DOWN LIMIT programming • Check for obstruction, remove • Check for obstruction, remove. – Check door spring – Contact The Genie Company at 1-800-35-GENIE
	2 BLINKS, Pause (Repeat)	• Programming incomplete • Wire to power head or wire connection at power head is bad. • Safe-T-Beam® out of alignment • Continuous obstruction of Safe-T-Beam® sensor	• Set UP LIMIT programming • Check power head wiring, check connections, – Replace or repair • Check Safe-T-Beam® alignment • Check for obstruction
	3 BLINKS, Pause (Repeat)	• Limits set backwards	• Clear limits and reprogram (See section 6)
	4 BLINKS, Pause (Repeat)	• Wall console wire short • Wall console wires reversed in power head connector.	• Check wall console and wiring. Staples can cut insulation and shorts wires. Repair or replace wall console and/or wiring. – Contact The Genie Company at 1-800-35-GENIE • Reverse wire placement in power head connector. (See section 3)
	5 BLINKS, Pause (Repeat)	• Chain/belt is too tight • Control system failure • Thermal Protector activated	• Adjust chain/belt tension (See section 1). – Contact The Genie Company at 1-800-35-GENIE • Contact Genie® authorized dealer for service • Wait until Thermal Protector cools and resets. **NOTE: The 5 BLINKS pattern will remain blinking until the next opener activation.** If the Thermal Protector does not reset. – Contact Genie® authorized dealer for service.