



Your Private Backpack Coach™

COACH LIBRARY · 1 OF 3

The **Fix-It** Library

The 40 most common crochet backpack mistakes — and exactly how to fix each one, step by step.

- ✓ Base, body, flap, straps, seams and tension
- ✓ What you see · why it happens · how to fix it
- ✓ How to stop it from happening on the next bag

How to use this library

Every backpack mistake has a name, a cause and a fix. Find what you see on your bag, read why it's happening, and follow the steps. Most fixes take less than 20 minutes.

1 • STOP AND LOOK

Lay the piece flat on a table in good light. Most problems are only visible flat — never judge a base or a flap in your hands.

2 • COUNT BEFORE YOU FROG

Half of all problems are a stitch count that drifted. Count the last round first; the fix is often one round, not the whole piece.

3 • FROG EARLY

Undoing 1 round costs 5 minutes. Undoing 10 rounds costs an evening. If something looks off, fix it now.

4 • STILL STUCK? ASK YOUR COACH

Open Your Private Backpack Coach™ and describe what you see, with the pattern name and round number. Example: *"Sky Sunflower, round 9, my base is cupping."*

Contents

Part 1 • The Base	Fixes 1–8
Part 2 • The Body & Walls	Fixes 9–15
Part 3 • The Flap	Fixes 16–21
Part 4 • Straps & Hardware	Fixes 22–27
Part 5 • Seams & Assembly	Fixes 28–34
Part 6 • Tension, Yarn & Finishing	Fixes 35–40

ABBREVIATIONS USED (US TERMS)

ch = chain · sl st = slip stitch · sc = single crochet · hdc = half double crochet · dc = double crochet · inc = 2 sc in the same stitch · dec = sc 2 together · MR = magic ring · BLO / FLO = back / front loop only · rnd = round

The Base

The base decides everything. If it's wrong, the body leans, the bag slumps and nothing sits flat. Fixes 1–8.

1 My base is curling up like a bowl

What you see: The circle or oval cups upward before you've even started the walls.

Why it happens: Too few increases per round for your yarn and hook, or your stitches are tighter than the designer's. Chunky t-shirt yarn is especially prone to cupping because each stitch is tall.

FIX IT, STEP BY STEP

1. Lay the base on a table. If the edge lifts more than 1 cm / 0.4 in, frog back to the last round that lay flat.
2. Re-work the next rounds adding the pattern's increases **plus 1–2 extra increases** spread evenly (e.g. 6 inc per round becomes 7).
3. Or keep the count and go up one hook size (e.g. 6 mm → 7 mm / J-10 → K-10.5) for the remaining base rounds only.
4. Check again every round: the base must lie flat before you start the walls. The final stitch count must still match the pattern — adjust the last round with extra sc (no inc) or a few dec to land on it.

Next time: Stagger your increases (don't stack them in the same spot every round) and swatch the first 4 rounds before committing.

2 My base is wavy / ruffled like a potato chip

What you see: The base won't lie flat but instead of cupping, the edge ripples.

Why it happens: The opposite of Fix 1: too many stitches for the circumference, usually from an extra increase or a hook that's too big.

FIX IT, STEP BY STEP

1. Count the last round. If you're over the pattern count, frog to where the count was right.
2. If the count is correct, your hook is too big for your yarn — go down 0.5–1 mm and redo the base.
3. For a slight wave on the final round only: work one round of sc through the **back loop only (BLO)** — that's the turn-up round most backpack walls start with anyway, and it pulls the edge in.

Next time: Place a stitch marker in the first increase of every round so you can count increases at a glance.

3 My round base looks like a hexagon

What you see: Six visible corners or points instead of a smooth circle.

Why it happens: Increases stacked in the same place every round create 'corners'.

FIX IT, STEP BY STEP

1. Keep the stitch count, just move the increases: on every other round, split the plain stitches of the first repeat — e.g. for '(inc, 6 sc) x 6', start with 3 sc, then '(inc, 6 sc) x 5', inc, and finish with 3 sc. The increases now land between the previous ones.
2. If you're already done, block it (Fix 39) with the base pinned in a perfect circle; t-shirt yarn and cotton hold the blocked shape well once they dry.

Next time: Offset the increase every other round. Most patterns in your collection already do this — follow the brackets exactly.

4 My oval base twists or comes out lopsided

What you see: One end of the oval is fatter, or the base spirals into an S.

Why it happens: You increased at one end and not the other, or you lost track of which side of the foundation chain you were on.

FIX IT, STEP BY STEP

1. Put a marker at each end of the foundation chain (the 'turning points').
2. Every round, the increases must happen only between the two markers at each end, and the straight sides must have the same sc count on both sides.
3. Count both straight sides of your current round. If they differ, frog back and redo — it never fixes itself.

Next time: Oval bases twist less in joined rounds (sl st + ch 1) than in continuous spirals.

5 My base is floppy and won't hold the shape

What you see: The bag slumps when set down, the bottom sags with a water bottle inside.

Why it happens: The fabric is too loose — hook too big for the yarn — or the yarn is soft (cotton, thin t-shirt yarn).

FIX IT, STEP BY STEP

1. Quick fix: cut a base insert (plastic canvas, a 2 mm / 0.08 in craft foam sheet or a bag base board) 1 cm / 0.4 in smaller than the base and slip it in, or sew it inside the lining.
2. Real fix: redo the base one hook size smaller, or crochet a second identical base and join the two with sc all around (a double base).

Next time: For bags, go 0.5–1 mm smaller than the hook the yarn label suggests. Firm fabric is what makes a backpack look store-bought.

6 My stitch count is off and I don't know where

What you see: The round ends with 47 stitches instead of 48, or the increases don't line up.

Why it happens: A missed stitch, an extra stitch into the joining sl st, or counting the ch 1 as a stitch.

FIX IT, STEP BY STEP

1. The ch 1 at the start of a joined round is **never** a stitch. The sl st join is **never** a stitch.
2. Count in groups using the repeat: if the round is '(inc, 6 sc) x 6', count 6 groups of 8.
3. If you're 1 short and it's only 1: add one sc in the last repeat without increasing elsewhere. More than 2 off: frog the round.

Next time: Put a marker in the first stitch of every round and move it up each round.

7 There's a hole in the middle of my base

What you see: The magic ring opened up or there's a visible gap at the center.

Why it happens: The ring's tail wasn't pulled tight or wasn't secured, and t-shirt yarn is slippery.

FIX IT, STEP BY STEP

1. Pull the tail firmly to close the ring. If it's already open, thread the tail on a tapestry needle and weave through the stitches of round 1 like a drawstring, then pull closed.
2. Weave the tail back and forth through round 1 and 2 in three different directions before trimming.

Next time: With very thick t-shirt yarn, start with ch 2 and work round 1 into the 2nd ch from hook instead of a magic ring — it can't open.

8

The walls won't turn up at a sharp angle

What you see: The base just keeps getting bigger instead of turning into the side of the bag.

Why it happens: The first wall round wasn't worked in BLO (or FLO for the outside), so there's no fold line.

FIX IT, STEP BY STEP

1. Frog the first wall round.
2. Work it in **BLO** (back loop only) with no increases: this leaves a ridge that forces the fabric to turn up 90°.
3. Continue in regular sc through both loops.

Next time: If your pattern says 'rnd X: BLO sc around', never skip that round — it's what makes the base a base.

The Body & Walls

Walls that flare, narrow, lean or slouch — and the stubborn seam line. Fixes 9–15.

9 The body is opening out / flaring at the top

What you see: The top of the bag is wider than the base, like a flowerpot.

Why it happens: Your tension loosened as you relaxed into the rounds, or you've been adding a stitch in the join each round.

FIX IT, STEP BY STEP

1. Count stitches on the last round — every wall round must have exactly the base count.
2. If the count is right, your tension changed: go down one hook size for the rest of the body.
3. To rescue a finished body, weave a sturdy yarn or elastic cord through the stitches of the top round on the inside, pull to the right width and secure (it disappears under the flap).

Next time: Measure the width at the base and every 5 rounds. Both numbers must match.

10 The body is narrowing / pulling in

What you see: The top is narrower than the base, the bag looks like a vase.

Why it happens: Losing a stitch every round (often at the join) or tightening up.

FIX IT, STEP BY STEP

1. Count the last round. If it's short, add the missing stitches with sc 2 in one stitch spread around the next round.
2. Check your join: after the sl st, the first sc goes into the **same** stitch as the join, not the next one.

Next time: Mark the first stitch of every round; it's the #1 cause of losing stitches.

11 My seam line is slanting across the bag

What you see: The join of each round drifts sideways, making a diagonal line.

Why it happens: Normal behavior of joined rounds: each join shifts slightly right (or left, if you crochet left-handed).

FIX IT, STEP BY STEP

1. Turn your work at the end of every round (ch 1, turn, sc around). The drift cancels itself out and the seam goes straight up.
2. Or move the join on purpose: place it on the side of the bag, where the side seam or a strap will hide it.

Next time: Decide where the seam goes before you start: always at the center back or on one side.

12 The join seam line is very visible

What you see: A line of bumpy, tighter stitches runs up the body.

Why it happens: The sl st join and ch 1 create a stitch that's different from the others.

FIX IT, STEP BY STEP

1. Try the **invisible join**: on the last stitch, don't sl st; cut the yarn, pull it through, thread it on a needle, pass it under both loops of the first stitch and back into the last one. Start the next round with a standing sc.
2. For continuous rounds (spiral), skip the join entirely — just keep crocheting and move a marker. Finish with a sl st and a gradual step: 1 hdc, 1 sc, 1 sl st.

Next time: Spiral rounds have no seam at all; use them whenever the pattern doesn't change color.

13 My walls lean — the stitches spiral around the bag

What you see: The vertical lines of stitches twist diagonally instead of going straight up.

Why it happens: Working in spiral with single crochet always leans a bit, especially with t-shirt yarn.

FIX IT, STEP BY STEP

1. Switch to joined rounds and turn every round (see Fix 11).
2. Or work the body in 'sc in the space between stitches' (the waistcoat / center sc makes stitches stack straight).

Next time: The lean is part of spiral sc. If your bag has a front design, use joined turned rounds.

14 My bag slouches — the walls won't stand up

What you see: The body folds on itself, even though the base is fine.

Why it happens: The fabric is too soft or open for its height.

FIX IT, STEP BY STEP

1. Add a lining with fusible interfacing (see your Lining, Zipper & Hardware Guide bonus).
2. Or insert a strip of plastic canvas 2 cm / 0.75 in shorter than the wall height between the lining and the crochet.
3. Next time: one hook size smaller, or a denser stitch (sc through both loops, or 'moss stitch' instead of dc).

Next time: The taller the backpack, the denser the fabric must be. Adult sizes need it more than kids' sizes.

15 My body came out taller or shorter than the pattern

What you see: Everything is right but the height doesn't match the measurements.

Why it happens: Your row gauge is different: some people make taller stitches than others.

FIX IT, STEP BY STEP

1. Measure how tall 10 rounds are on your bag. Divide the pattern height by that number to know how many rounds you really need.
2. Add or remove rounds before the drawstring/top band rounds — never after, or the top will be off.
3. The flap is measured against the body: if you changed the body, check the flap width before starting it.

Next time: You can hit any height by counting rounds; your stitch count is what keeps the width right.

The Flap

The flap is the face of the backpack. It has to lie flat, sit centered and close cleanly. Fixes 16–21.

16 My flap won't lie flat

What you see: The flap lifts, bows outward or looks inflated.

Why it happens: Rows worked back and forth with the same stitch count everywhere, but the edges pull tighter than the center, or you added stitches without noticing.

FIX IT, STEP BY STEP

1. Count every row — flaps that grow a stitch per row get wider and bow.
2. Wet-block the flap: spray it, pin it flat to its final measurements on a towel or foam mat, let it dry 24 h.
3. If it still bows, work the edging round (sc around the flap) with a hook one size smaller.

Next time: Before you attach the flap, it must lie flat on its own. It never flattens once sewn on.

17 The corners of my flap curl up

What you see: The two bottom corners of a rectangular flap roll toward you.

Why it happens: Sc fabric naturally curls at the corners, especially in cotton.

FIX IT, STEP BY STEP

1. Work 3 sc in each corner stitch on the edging round (not 1 or 2).
2. Block the corners flat, pinning right at the tip.
3. Add one more round of sc or crab stitch (reverse sc) — the extra border weighs the edge down.

Next time: Always end flaps with an edging round; it's the difference between flat and curly.

18 My rounded flap is wavy at the edge

What you see: The curved edge ruffles.

Why it happens: Too many increases on the curve of the flap, or the edging was done with too many stitches.

FIX IT, STEP BY STEP

1. On the edging, work 1 sc per row end on straight parts and only 2 sc per row end on the tight curve.
2. If the flap itself ruffles, frog to the start of the curve and use one less increase per row.

Next time: Hold the flap against the body while you work the curve — it must match the width of the bag.

19 The flap is too narrow or too wide for the body

What you see: The flap doesn't cover the opening, or it hangs past the sides.

Why it happens: The body changed width (gauge) but you followed the flap stitch count as written.

FIX IT, STEP BY STEP

1. Measure the bag width at the top (lying flat). The flap should be that width minus 1 cm / 0.4 in.
2. Recalculate: width in cm × your stitches per cm = new flap starting count (see the Resize & Yarn-Swap Guide).
3. Redo the first row of the flap with the new count and keep the rest as written.

Next time: Measure first, then start the flap. Takes 30 seconds and saves an hour.

20 The flap sits crooked / off-center

What you see: When closed, the flap leans left or right.

Why it happens: It was attached one stitch off-center, or the back is uneven because of the seam line.

FIX IT, STEP BY STEP

1. Fold the bag flat. Mark the exact center of the back with a marker and the center of the flap with another.
2. Pin both centers together first, then pin the two ends. Sew from the center outward to each side.
3. If it's already sewn: unpick only the side that's off (usually 3–4 stitches) and re-sew.

Next time: Place the join/seam line at the center back from the start; it becomes your guide.

21

My magnetic snap / clasp pulls the flap out of shape

What you see: The flap puckers or stretches around the clasp, or the clasp tears through.

Why it happens: The clasp is attached only to crochet stitches; the weight concentrates on 2–3 stitches.

FIX IT, STEP BY STEP

1. Put a backing: a 3×3 cm / 1.25×1.25 in piece of felt or thick fabric behind the crochet where the clasp goes.
2. Push the clasp prongs through the crochet **and** the felt, then close the washer on the felt.
3. For sew-on clasps, sew through a felt patch as well, never through crochet only.

Next time: Any hardware on crochet needs a backing. It's the #1 sign of a pro-made bag.

Straps & Hardware

Straps carry all the weight. They stretch, twist, curl and tear holes if they're not made right. Fixes 22–27.

22 My straps stretch out with weight

What you see: After a day of use, the straps are 5–10 cm / 2–4 in longer and the bag hangs low.

Why it happens: Crochet stretches lengthwise. Straps worked along a long foundation chain stretch the most with cotton or soft t-shirt yarn.

FIX IT, STEP BY STEP

1. Line the straps: sew a strip of cotton webbing or grosgrain ribbon to the inside of each strap.
2. Or work 1 row of sl st along both long edges of each strap: sl st has almost no stretch and locks the length.
3. Best: use purchased webbing straps (2.5 cm / 1 in) with strap adjusters and sew them to the bag with a felt backing.

Next time: Test: hang the bag with 2 kg / 4.4 lb (a bag of flour) overnight. If the straps grow, line them before gifting or selling.

23 My straps twist

What you see: The straps spiral when you put the bag on.

Why it happens: The foundation chain twisted when you started the first row, or the strap was sewn on turned.

FIX IT, STEP BY STEP

1. If the strap itself twists: frog and start again, checking that the chain lies flat (the 'V's all face up) before the first row.
2. If it was sewn twisted: remove the stitching at one end, untwist, pin flat and re-sew.

Next time: Lay each strap flat on the table before sewing and pin both ends facing the same way.

24 My straps came out different lengths

What you see: One strap is 3 cm / 1.25 in longer than the other.

Why it happens: Crocheting 'by length' instead of by count, or different tension on each strap.

FIX IT, STEP BY STEP

1. Count the rows/stitches of both straps. Make the second strap exactly the same count as the first.
2. If the count is equal but the length isn't, block both straps together, pinned to the same length.
3. Adjustable straps (with a slider) hide small differences: an easy fix for kids' bags.

Next time: Crochet both straps in one sitting; your tension will match.

25 The straps are pulling holes in the body

What you see: Where the strap attaches, the stitches of the body stretch open.

Why it happens: All the weight is on 2–4 stitches of the bag.

FIX IT, STEP BY STEP

1. Spread the load: sew the strap over 4–6 cm / 1.5–2.5 in of the body, not 1 cm.
2. Sew a felt patch behind the attachment point (inside) and sew through the strap, bag and felt together.
3. Sew an 'X in a square' (box stitch) with strong thread — the same stitch used on commercial backpacks.

Next time: Always attach straps across at least 3 rounds of the body, never on the top round only.

26 My sc straps curl into a tube

What you see: A narrow strip of sc rolls up along its length.

Why it happens: Narrow sc strips curl naturally, especially 3–4 stitches wide.

FIX IT, STEP BY STEP

1. Block them flat (spray + pin + dry).
2. Work the strap one stitch wider, or in hdc instead of sc, or add an edging of sl st along both long sides.
3. Or make an I-cord / rolled strap on purpose — it's comfortable and doesn't care about curling.

Next time: Work straps in rows of 5+ stitches or make them round on purpose.

27 My strap adjusters / rings slip

What you see: The strap slides through the adjuster and loosens by itself.

Why it happens: Crochet is thicker and slipperier than webbing, so the adjuster doesn't grip.

FIX IT, STEP BY STEP

1. Use an adjuster sized for the strap's thickness, not its width: a 3 cm / 1.25 in slider for a 2.5 cm / 1 in crochet strap.
2. Sew the end of the strap that passes through the adjuster onto a short piece of webbing — the adjuster grips the webbing.
3. For kids' bags, skip adjusters: sew the straps to a fixed length measured on the child.

Next time: Buy hardware after you've made the straps, and take one strap with you to test.

Seams & Assembly

Joining the pieces without the backpack coming out crooked or looking homemade. Fixes 28–34.

28 My seams are visible

What you see: You can see the sewing thread or a lumpy line where the pieces meet.

Why it happens: Seaming with the wrong stitch or contrast yarn, or pulling too tight.

FIX IT, STEP BY STEP

1. Seam with the same yarn as the piece (or a thinner yarn in the same color if the yarn is thick t-shirt yarn).
2. Use the **mattress stitch**: pieces side by side, right side up, go under one loop from each side alternating. Pull every 3 stitches — it closes invisibly.
3. For decorative seams (base-to-body), join with sc through both pieces from the right side: it makes a neat raised border instead of hiding.

Next time: Never seam with a sewing needle and thread on crochet — use a tapestry needle and yarn.

29 My seam puckers

What you see: The seam pulls the pieces into ripples.

Why it happens: Seaming too tight, or seaming stitch-to-row (stitches and rows are different heights).

FIX IT, STEP BY STEP

1. Loosen: undo the seam and redo, pulling just enough to close.
2. When joining stitches to rows, skip every 4th row-end (or join 3 stitches to 4 rows) to compensate for the different heights.

Next time: Pin the pieces together first, every 3 cm / 1.25 in. The pins show you if one piece is longer.

30 The pieces don't match when I join them

What you see: The side panel is longer than the body opening, or the front is 2 cm wider than the back.

Why it happens: Pieces were crocheted with a different tension, or rows were counted wrong.

FIX IT, STEP BY STEP

1. Count rows/stitches in each piece; they must match the pattern.
2. If they're within 1 cm / 0.4 in: block both pieces to the same size before seaming.
3. More than 1 cm: redo the shorter one — easing a big difference gives a crooked bag.

Next time: Make matching pieces one after the other, in the same sitting.

31 My side panels are misaligned

What you see: The side gusset starts at a different height on each side.

Why it happens: Started joining from a different point on each side.

FIX IT, STEP BY STEP

1. Mark the center bottom of the gusset and the center bottom of the body.
2. Pin the centers first, then pin the corners, then the tops. Always sew from bottom center up to each top.

Next time: Always join from the center outward.

32 My drawstring channel is too tight or too loose

What you see: The cord won't pull through, or the top doesn't close.

Why it happens: The eyelet round (the 'ch 1, skip 1' or dc round) was too tight, or there are too few eyelets.

FIX IT, STEP BY STEP

1. If too tight: use a thinner cord or redo the eyelet round with ch 2, skip 2.
2. If it doesn't close: the eyelets are too far apart — redo with an eyelet every 3 stitches.
3. Put a safety pin on the cord end to thread it; knot the end or add a cord stopper.

Next time: Test the cord in the first 5 eyelets before finishing the round.

33 My zipper waves / ripples

What you see: The zipper looks wavy after sewing it to the crochet.

Why it happens: The crochet edge was stretched while sewing, or the zipper is longer than the opening.

FIX IT, STEP BY STEP

1. Measure the opening lying flat, NOT stretched. Buy/cut the zipper to that length.
2. Pin the zipper with the crochet relaxed, pin every 2 cm / 0.75 in.
3. Sew with a backstitch using sewing thread, from the inside, catching only the back loops.

Next time: Details in your bonus Lining, Zipper & Hardware Guide.

34 My lining puckers or bunches up

What you see: The fabric lining is bigger than the bag and bunches, or smaller and pulls the crochet.

Why it happens: The lining was cut from the pattern's measurements, not from your actual bag.

FIX IT, STEP BY STEP

1. Measure your finished bag (inside). Cut the lining to that size + 1 cm / 0.4 in seam allowance.
2. Sew the lining, put it inside, fold the top edge under and hand-sew it 1 cm below the top round.
3. Don't sew to the very last round — the top should stretch a bit.

Next time: Always measure the real bag before cutting.

Tension, Yarn & Finishing

The things that make a bag look homemade: uneven tension, yarn surprises, color changes, loose ends. Fixes 35–40.

35 My tension is uneven

What you see: Some rows are tight, some are loose, the fabric looks 'bumpy'.

Why it happens: Tension changes with mood, fatigue and pauses. Very common in the first project.

FIX IT, STEP BY STEP

1. Warm up: work 2 rounds on a swatch before starting each session.
2. Hold the yarn the same way every time (around the pinky, over the index finger) and avoid pulling the loop tight on the hook.
3. Pull up each loop to the same height on the hook shaft — not on the throat.
4. If only a few rounds are loose, block the piece (Fix 39); it evens out more than you think.

Next time: Crochet in 30–60 min sessions and stop when you notice you're tense.

36 My t-shirt yarn changes thickness

What you see: One cone is thicker/thinner, or the yarn gets thinner in the middle of the cone.

Why it happens: T-shirt yarn is made from fabric remnants; each batch varies.

FIX IT, STEP BY STEP

1. Buy all the yarn for one bag at once and check thickness before starting.
2. If you have to change cones: alternate them every 2 rounds for 6 rounds to blend the difference.
3. Thinner section: work it with a hook 1 mm smaller to keep the gauge.

Next time: Make a swatch with each cone and compare them.

37 My color changes leave a jog or step

What you see: The stripe doesn't line up at the beginning of the round.

Why it happens: Rounds in spiral are like a staircase; the color change shows the step.

FIX IT, STEP BY STEP

1. Change color in the last yarn-over of the previous stitch (yarn over with the new color and pull through).
2. For joined rounds: join with the new color.
3. For spiral: after the color change, work the first stitch as sl st and the second as hdc — it smooths the step. Place color changes at the back/side.

Next time: Plan the color changes on the side where the straps are attached.

38 I ran out of yarn / the new ball is a different shade

What you see: The yarn ran out before finishing, and the new ball is a slightly different color.

Why it happens: Dye lots vary, and the quantity was underestimated.

FIX IT, STEP BY STEP

1. Use the new yarn for a visible design choice: the base, the flap or the straps in the new shade.
2. Or alternate the old and new yarn every 2 rounds for the last rounds to blend.
3. Use the calculator in the Resize & Yarn-Swap Guide to buy the right amount (plus 15%) next time.

Next time: Always buy one extra ball/cone of the same dye lot.

39 My finished bag lost its shape

What you see: After finishing or washing, the bag is misshapen, the base is wavy, the flap curls.

Why it happens: The bag was never blocked, or was washed and dried the wrong way.

FIX IT, STEP BY STEP

1. Block: wet the bag (or spray it), fill it with a towel or a box of the right size, pin the flap flat and let it dry 24 h.
2. Wash by hand with cold water, no wringing, and dry lying flat and filled with a towel.
3. Never tumble-dry crochet: it shrinks cotton and deforms t-shirt yarn.

Next time: Blocking is the last step of every bag, not an optional one.

40 My ends keep working loose

What you see: The ends of yarn stick out or come undone after use.

Why it happens: T-shirt yarn is slippery and cotton ends pop out if woven only in one direction.

FIX IT, STEP BY STEP

1. Weave the end at least 5 cm / 2 in in one direction, then turn and weave back 3 cm / 1.25 in in the opposite direction.
2. For t-shirt yarn: split the end in two, weave each half in a different direction.
3. A dot of fabric glue on the end (on the inside) holds for bags that will be sold.

Next time: Weave ends as you go — never leave 30 ends for the end.

No more half-finished bags.

Every mistake in this library has already happened to thousands of crocheters — and every one of them has a fix. Your next backpack gets finished.

Still stuck? Describe the problem to Your Private Backpack Coach™ — pattern name, round number and what you see — and get a step-by-step answer in seconds.