GFISYSTEM

ENIEQMA

MIDI Implementation chart

Rev - C (Nov 2026)

CONTROL CHANGE

The CC numbers listed in the tables below are the default values. You may assign arbitrary (0 to 127) to each CC functions using the EnieqLab editor software (*Menu > MIDI Configuration*).

OPERATION	CC# (default)	Value Range
EQ bypass / engage	0	*Bypass* = 0, *Engage* = 127
EQ-L bypass / engage	1	*Bypass* = 0, *Engage* = 127
EQ-R bypass / engage	2	*Bypass* = 0, *Engage* = 127
Booster	3	*Off* = 0, *On* = 127
Stereo Expander	4	0 - 2
Delay	5	0 - 127
Depth	6	0 - 127
Preset Up/Down	7	*Down* = 0, *Up* = 127
EQ Mode	8	*0 - 5*
EQ Channel Mode	9	*Linked* = 0, *Independent* = 127
Boost Channel Mode	10	*Linked* = 0, *Independent* = 127
Input Level	11	0 - 127
Volume (L)	12	0 - 127
Volume (R)	13	0 - 127
Boost Level (L)	14	0 - 127
Boost Level (R)	15	0 - 127
Prototype (L)	16	0 - N
Prototype (R)	17	0 - N

Stereo Expander
- 0 = *Off*
- 1 = *Short Delay*
- 2 = *Dimensional Expansion*

EQ Mode
- 0 = *ParaEQ*
- 1 = *SimplEQ*
- 2 = *PultEQ*
- 3 = *SimplEQ + ParaEQ*
- 4 = *PultEQ + ParaEQ*

Prototype
- N = 43 (Parametric EQ)
- N = 11 (Simple EQ)
- N = 11 (Pulteq EQ)

PARAMETERS	CC# (Default)	Value Range
ParaEQ Type (band 1 - ch.L)	18	0 - 4
ParaEQ Type (band 2 - ch.L)	19	0 - 4
ParaEQ Type (band 3 - ch.L)	20	0 - 4
ParaEQ Type (band 4 - ch.L)	21	0 - 4
ParaEQ Type (band 5 - ch.L)	22	0 - 4
ParaEQ Gain (band 1 - ch.L)	23	0 - 127
ParaEQ Gain (band 2 - ch.L)	24	0 - 127
ParaEQ Gain (band 3 - ch.L)	25	0 - 127
ParaEQ Gain (band 4 - ch.L)	26	0 - 127
ParaEQ Gain (band 5 - ch.L)	27	0 - 127

Parameteric EQ Type
- 0 = *Highpass*
- 1 = *Low-Shelving*
- 2 = *Bell*
- 3 = *High-Shelving*
- 4 = *Lowpass*

GFISYSTEM

ENIEQMA

MIDI Implementation chart

Rev - C (Nov 2026)

PARAMETERS	CC# (default)	Value Range
ParaEQ Q (band 1 - ch.L)	28	0 - 127
ParaEQ Q (band 2 - ch.L)	29	0 - 127
ParaEQ Q (band 3 - ch.L)	30	0 - 127
ParaEQ Q(band 4 - ch.L)	31	0 - 127
ParaEQ Q (band 5 - ch.L)	32	0 - 127
ParaEQ Freq (band 1 - ch.L)	33	0 - 127
ParaEQ Freq (band 2 - ch.L)	34	0 - 127
ParaEQ Freq (band 3 - ch.L)	35	0 - 127
ParaEQ Freq(band 4 - ch.L)	36	0 - 127
ParaEQ Freq(band 5 - ch.L)	37	0 - 127
ParaEQ state (band 1 - ch.L)	38	*Off* = 0, *On* = 127
ParaEQ state (band 2 - ch.L)	39	*Off* = 0, *On* = 127
ParaEQ state (band 3 - ch.L)	40	*Off* = 0, *On* = 127
ParaEQ state (band 4 - ch.L)	41	*Off* = 0, *On* = 127
ParaEQ state (band 5 - ch.L)	42	*Off* = 0, *On* = 127

PARAMETERS	CC# (Default)	Value Range
ParaEQ Type (band 1 - ch.R)	43	0 - 4
ParaEQ Type (band 2 - ch.R)	44	0 - 4
ParaEQ Type (band 3 - ch.R)	45	0 - 4
ParaEQ Type (band 4 - ch.R)	46	0 - 4
ParaEQ Type (band 5 - ch.R)	47	0 - 4
ParaEQ Gain (band 1 - ch.R)	48	0 - 127
ParaEQ Gain (band 2 - ch.R)	49	0 - 127
ParaEQ Gain (band 3 - ch.R)	50	0 - 127
ParaEQ Gain (band 4 - ch.R)	51	0 - 127
ParaEQ Gain (band 5 - ch.R)	52	0 - 127
ParaEQ Q (band 1 - ch.R)	53	0 - 127
ParaEQ Q (band 2 - ch.R)	54	0 - 127
ParaEQ Q (band 3 - ch.R)	55	0 - 127
ParaEQ Q (band 4 - ch.R)	56	0 - 127
ParaEQ Q (band 5 - ch.R)	57	0 - 127

Parameteric EQ Type

0 = *Highpass*
1 = *Low-Shelving*
2 = *Bell*
3 = *High-Shelving*
4 = *Lowpass*

GFISYSTEM

ENIEQMA

MIDI Implementation chart

Rev - C (Nov 2026)

PARAMETERS	CC# (default)	Value Range
ParaEQ Freq (band 1 - ch.R)	58	0 - 127
ParaEQ Freq (band 2 - ch.R)	59	0 - 127
ParaEQ Freq (band 3 - ch.R)	60	0 - 127
ParaEQ Freq(band 4 - ch.R)	61	0 - 127
ParaEQ Freq (band 5 - ch.R)	62	0 - 127
ParaEQ state (band 1 - ch.R)	63	*Off* = 0, *On* = 127
ParaEQ state (band 2 - ch.R)	64	*Off* = 0, *On* = 127
ParaEQ state (band 3 - ch.R)	65	*Off* = 0, *On* = 127
ParaEQ state (band 4 - ch.R)	66	*Off* = 0, *On* = 127
ParaEQ state (band 5 - ch.R)	67	*Off* = 0, *On* = 127

PARAMETERS	CC# (Default)	Value Range
SimplEQ Type (ch.L)	68	0 - 6
SimplEQ Bass (ch.L)	69	0 - 127
SimplEQ Mids (ch.L)	70	0 - 127
SimplEQ Treble (ch.L)	71	0 - 127
SimplEQ Type (ch.R)	72	0 - 6
SimplEQ Bass (ch.R)	73	0 - 127
SimplEQ Mids (ch.R)	74	0 - 127
SimplEQ Treble (ch.R)	75	0 - 127

Simple EQ Type

0 = *Tonestack F*
1 = *Tonestack M*
2 = *Tonestack V*
3 = *Bass & Treble*
4 = *Wah*
5 = *Tilt*
6 = *Scooped-Tilt*

PARAMETERS	CC# (Default)	Value Range
PultEQ Low Peak (ch.L)	76	0 - 127
PultEQ Low Freq (ch.L)	77	0 - 127
PultEQ Mid Dip (ch.L)	78	0 - 127
PultEQ Mid Freq (ch.L)	79	0 - 127
PultEQ High Peak (ch.L)	80	0 - 127
PultEQ High Freq (ch.L)	81	0 - 127
PultEQ Low Peak (ch.R)	82	0 - 127
PultEQ Low Freq (ch.R)	83	0 - 127
PultEQ Mid Dip (ch.R)	84	0 - 127
PultEQ Mid Freq (ch.R)	85	0 - 127

GFISYSTEM

ENIEQMA

MIDI Implementation chart

Rev - C (Nov 2026)

PARAMETERS	CC# (default)	Value Range
PultEQ High Peak (ch.R)	86	0 - 127
PultEQ High Freq (ch.R)	87	0 - 127

PARAMETERS	CC# (default)	Value Range
Limiter	88	*Off* = 0, *On* = 127
Limiter Channel mode	89	*Linked* = 0, *Independent* = 127
Limiter Input gain (ch.L)	90	0 - 127
Limiter Threshold (ch.L)	91	0 - 127
Limiter Attack (ch.L)	92	0 - 127
Limiter Input gain (ch.R)	93	0 - 127
Limiter Threshold (ch.R)	94	0 - 127
Limiter Attack (ch.R)	95	0 - 127

Added in firmware v1.0.1

PARAMETERS	CC# (default)	Value Range
Volume Increment/ Decrement	96	*Decrement* = 0, *Increment* = 127
Boost Level Increment/ Decrement	97	*Decrement* = 0, *Increment* = 127
Prototype Increment/ Decrement	98	*Decrement* = 0, *Increment* = 127

Added in firmware v1.2.0

PARAMETERS	CC# (default)	Value Range
Volume (L) Increment/Decrement	99	*Decrement* = 0, *Increment* = 127
Volume (R) Increment/Decrement	100	*Decrement* = 0, *Increment* = 127
Boost Level (L) Increment/Decrement	101	*Decrement* = 0, *Increment* = 127
Boost Level (R) Increment/Decrement	102	*Decrement* = 0, *Increment* = 127
Parametric EQ On/Off	103	*Off* = 0, *On* = 127
Simple /Pultec EQ On/Off	104	*Off* = 0, *On* = 127

Added in firmware v1.3.0

GFISYSTEM

ENIEQMA

MIDI Implementation chart

Rev - C (Nov 2026)

Notes on CC#103 and CC#104.

These two commands are effective only when using the Dual-EQ modes.

When using the "***Simple EQ + Parametric EQ***" mode:

- CC#103 activates/deactivates the Parametric EQ engine.
- CC#104 activates/deactivates the Simple EQ engine.

When using the "***Pultec EQ + Parametric EQ***" mode:

- CC#103 activates/deactivates the Parametric EQ engine.
- CC#104 activates/deactivates the Pultec EQ engine.

PROGRAM CHANGE (PC)

Preset #	PC #
1	0
2	1
3	2
⋮	⋮
64	63

Total preset : 64

Default MIDI Channel

Enieqma is pre-programmed to use MIDI channel 1. You can change the channel number to any number from 1 through 16 in **Global Settings** menu.

Revision History

Rev A (Sep 2023) - Pilot public release.
Rev B (Oct 2023) - Added CC#88 through CC#95 (firmware v1.0.1)
Rev C (Oct 2025) - Added CC#96 through CC#98 (firmware v1.2.0)
Rev D (Nov 2026) - Added CC#99 and CC#100 (firmware v1.3.0)