YOGURT FUNCTION

Press Menu to select "Yogurt". The screen
displays the default cooking time of 8 hours. The cooking time is
adjustable from a minimum of 6 hours to a maximum of 12 hours.

Press Menu to select "Yogurt". The screen
displays the default cooking time of 8 hours. The cooking time is
adjustable from a minimum of 6 hours to a maximum of 12 hours.