COOKING PROGRAMME TABLE

Cooking Time			Temperature (°C)		
Programs Automatic	Food	Default	Range		
Manual (adjust temp. setting)					
Food Type	Default	Range			
Programs Automatic		Default		Temperature Closed	
	Food		Range		
Simmer	4	Veg Fish Poultry Meat	30min 40min 50min 60min	5min-XYZ	100 °C