COOKING PROGRAMME TABLE

Cooking Time Programs Automatic	Food	Default Range	Temperature (°C) Manual (adjust temp. setting)	Food Type Default Range	Temperature Closed
Simmer	4	5min-3h	100 °C	Veg Fish Poultry Meat	30min 40min 50min 60min