COOKING PROGRAMME TABLE

Cooking Time		Temperature (°C)		
Programs Automatic	Food	Default	Range	
Manual (adjust temp. setting)				
Food Type		Default	Range	
Programs Automatic		Default	Temperature	Closed
	Food		Range	
Simmer	4	Veg	30min	5min-3h
		Fish	40min	
		Poultry	50min	
		Meat	60min	