

	1		2	3	
А	(Vref – UE OCD) TO RE X Vref = UEOCD RE + Rref G Rref = ILIM_BRDG> USED TO SET OCD 5.5A> 22A Limit Setting				
В	IP+.) FROM H-BRIDGE IP)	3 IP+_3 IP+_4 IP+ 5 IP2 IP3 IP4 IP-	OCD_INT U_E_OCD UC OCD_EXT VOUT NC VREF GND 9	OCD_INT VREF_OCD +3V3 OCD_EXT_E I_SENSE_BI I_BRDG = Vout = SONVIA VREF_OUT CF5	BRDG RDG
С				GND	
D					
	1		2	3	





