# Limpide on the TempoPAD C16

Choose a bank with **CTRL BANK**, then **A** to **D**. Set every knob to **Relative #1**, and each button as marked: Momentary or Toggle. The pads play the synth.

## A Oscillators

| | | | |
|---|---|---|---|
| K1 CC 1<br>Osc 1 Octave | K2 CC 2<br>FM | K3 CC 3<br>Ring | K4 CC 4<br>Pulse Width |
| K5 CC 5<br>Osc 2 Octave | K6 CC 6<br>Semitone | K7 CC 7<br>Detune | K8 CC 8<br>Osc 2 Env Amount |
| F1 CC 33<br>Osc 1 level | F2 CC 34<br>Osc 2 level | F3 CC 35<br>Noise level | F4 CC 36<br>Sub level |
| M1 CC 49 Momentary<br>Previous Preset | M2 CC 52 Momentary<br>Next Preset | M3 CC 55 Momentary<br>Freeze | M4 CC 58 Momentary<br>Hold |
| S1 CC 50 Toggle<br>free | S2 CC 53 Toggle<br>free | S3 CC 56 Momentary<br>Snapshot | S4 CC 59 Toggle<br>Sub Octave |
| R1 CC 51 Momentary<br>Osc 1 Waveform | R2 CC 54 Momentary<br>Osc 2 Waveform | R3 CC 57 Toggle<br>Noise Colour | R4 CC 60 Toggle<br>Sub Waveform |

## B Filter

| | | | |
|---|---|---|---|
| K1 CC 9<br>Cutoff | K2 CC 10<br>Resonance | K3 CC 11<br>Velocity | K4 CC 12<br>Key Track |
| K5 CC 13<br>Env Amount | K6 CC 14<br>Mode | K7 CC 15<br>free | K8 CC 16<br>free |
| F1 CC 37<br>Attack | F2 CC 38<br>Decay | F3 CC 39<br>Sustain | F4 CC 40<br>Release |
| M1 CC 61 Momentary<br>Previous Preset | M2 CC 64 Momentary<br>Next Preset | M3 CC 67 Momentary<br>Freeze | M4 CC 70 Momentary<br>Hold |
| S1 CC 62 Toggle<br>free | S2 CC 65 Toggle<br>free | S3 CC 68 Momentary<br>Snapshot | S4 CC 71 Toggle<br>free |
| R1 CC 63 Toggle<br>Slope | R2 CC 66 Toggle<br>free | R3 CC 69 Toggle<br>free | R4 CC 72 Toggle<br>free |

## C Amp

| | | | |
|---|---|---|---|
| K1 CC 17<br>Voices | K2 CC 18<br>Glide | K3 CC 19<br>free | K4 CC 20<br>free |
| K5 CC 21<br>free | K6 CC 22<br>free | K7 CC 23<br>free | K8 CC 24<br>Volume |
| F1 CC 41<br>Attack | F2 CC 42<br>Decay | F3 CC 43<br>Sustain | F4 CC 44<br>Release |
| M1 CC 73 Momentary<br>Previous Preset | M2 CC 76 Momentary<br>Next Preset | M3 CC 79 Momentary<br>Freeze | M4 CC 82 Momentary<br>Hold |
| S1 CC 74 Toggle<br>free | S2 CC 77 Toggle<br>free | S3 CC 80 Momentary<br>Snapshot | S4 CC 83 Toggle<br>free |
| R1 CC 75 Toggle<br>free | R2 CC 78 Toggle<br>free | R3 CC 81 Toggle<br>free | R4 CC 84 Toggle<br>free |

## D LFO & Envelopes

| | | | |
|---|---|---|---|
| K1 CC 25<br>LFO 1 Waveform | K2 CC 26<br>LFO 1 Destination | K3 CC 27<br>LFO 2 Waveform | K4 CC 28<br>LFO 2 Destination |
| K5 CC 29<br>LFO 1 Depth | K6 CC 30<br>LFO 1 Rate | K7 CC 31<br>LFO 2 Depth | K8 CC 32<br>LFO 2 Rate |
| F1 CC 45<br>free | F2 CC 46<br>free | F3 CC 47<br>free | F4 CC 48<br>free |
| M1 CC 85 Momentary<br>Previous Preset | M2 CC 88 Momentary<br>Next Preset | M3 CC 91 Momentary<br>Freeze | M4 CC 94 Momentary<br>Hold |
| S1 CC 86 Toggle<br>free | S2 CC 89 Toggle<br>free | S3 CC 92 Momentary<br>Snapshot | S4 CC 95 Toggle<br>free |
| R1 CC 87 Toggle<br>LFO 1 Retrigger | R2 CC 90 Toggle<br>LFO 1 Sync | R3 CC 93 Toggle<br>LFO 2 Retrigger | R4 CC 96 Toggle<br>LFO 2 Sync |

On every bank: M1 Previous Preset, M2 Next Preset, M3 Freeze, M4 Hold, S3 Snapshot. Free places stay Toggle, the C16's own setting. All on MIDI channel 1. gijom33.github.io/limpide