

Product User Manual

1. Safety Precautions

-

Before installing or disassembling the notebook motherboard, fully shut down your notebook, unplug the power adapter, remove the battery, and press the power button for 10 seconds to release residual power. Do not operate with electricity, as this may cause short circuits and permanent damage to the motherboard.

-

-

Always release static electricity before operation—wear an anti-static wristband or touch a grounded metal object. Static electricity is a common cause of damage to the motherboard's precision components.

-

-

Use professional tools (e.g., cross screwdrivers, nylon crowbars) for all operations. Do not use brute force to pry, pull, or twist cables and components, as this can break connections or damage the motherboard.

-

-

Store and use the motherboard away from water, moisture, high temperatures, and dust to prevent corrosion, short circuits, and component failure.

-

2. Installation Guidelines

-

This motherboard is only compatible with specific notebook models. Please confirm that the motherboard model matches your notebook before installation to avoid incompatibility issues.

-
-

When connecting cables (including power cables, screen cables, and keyboard cables), align the interfaces correctly and fasten the locking buckles to ensure a secure, stable connection.

-
-

Tighten the fixing screws appropriately. Over-tightening may damage the motherboard, while loose screws can lead to poor contact and unstable operation.

-
-

After installation, connect the power supply and perform a test: check if the notebook boots normally and if all hardware (such as memory and hard drive) is correctly recognized.

-

3. Basic Maintenance

-

Clean the motherboard and cooling system every 3–6 months to remove dust. This ensures good heat dissipation and prevents overheating, which can damage the motherboard over time.

-
-

Avoid long-term high-load operation of your notebook (e.g., prolonged gaming or video rendering), as this will accelerate the aging of the motherboard and increase the risk of component failure.

-
-

Do not modify BIOS/UEFI settings or weld the motherboard without authorization. Such actions will void the warranty and may cause permanent, irreparable damage.

-

4. Warranty Information

-

Warranty Period: This notebook motherboard comes with a 90-day warranty, starting from the date of purchase.

-

-

Warranty Coverage: Free repair or replacement is provided for non-human damage to the motherboard, such as component failure under normal use conditions.

-

-

Warranty Exclusions: The warranty does not cover damage caused by improper operation, static electricity, water ingress, collision, unauthorized modification, or natural wear and tear.

-

-

For warranty service, please provide your valid purchase certificate and contact the seller promptly to initiate the service process.