




**BMW
MOTORRAD**



Installation instructions

REAR AXLE COVER

MAKE LIFE A RIDE

BEFORE COMMENCING WORK, YOU MUST READ THESE INSTALLATION INSTRUCTIONS THROUGH CAREFULLY AND MAKE SURE YOU UNDERSTAND THEM FULLY.

We congratulate you on your choice of optional accessories from BMW Motorrad that will enable you to customise your motorcycle in accordance with your personal preferences.

Safety is invariably an essential prerequisite for extracting full benefit and enjoyment from new accessories. Some work calls for special tools and possibly a thorough knowledge of motorcycle technology. If you are in doubt consult a specialist workshop, preferably your authorised BMW Motorrad dealer.

Since we provide you with a multitude of accessories and optional equipment, we cannot cover all equipment specifications in these installation instructions. Therefore we restrict ourselves to the basic version of the corresponding model. The removal and installation of other possibly installed accessories is described in the corresponding installation instructions. Consult your authorised BMW Motorrad dealer if you no longer have access to the sets of instructions you need.

If you have questions concerning your motorcycle or any of the accessories from our range, your authorised BMW Motorrad dealer will gladly provide advice and assistance.

We at BMW Motorrad hope you will enjoy riding your BMW and that all your journeys will be pleasant and safe.

THE SYMBOLS USED TO DRAW ATTENTION TO PRECAUTIONARY STATEMENTS IN THIS MANUAL ARE AS FOLLOWS:

 **CAUTION**

Low-risk hazard. Non-avoidance can lead to slight or moderate injury.

 **WARNING**

Medium-risk hazard. Non-avoidance can lead to fatal or severe injury.

 **DANGER**

High-risk hazard. Non-avoidance leads to fatal or severe injury.

 **ATTENTION**

Special notes and precautionary measures. Non-compliance can lead to damage to the vehicle or accessory and, consequently, to voiding of the warranty.

 **NOTICE**

Specific instructions on how to operate, control, adjust or look after items of equipment on the motorcycle.

 **Tightening torque**

Screws, bolts and nuts are tightened in accordance with the applicable DIN/ISO standards. Tightening torques that deviate from the standards are stated. Non-compliance can result in damage to the vehicle or accessories or can endanger the driver.

- ▶ Start of the main activity
- ▷ Start of the secondary activity
- Instruction

- ◀ End of the main activity
- ▷ End of the secondary activity
- ◊ End of validity designation CS (construction status), OE (optional extra) or OA (optional accessory)

All rights reserved.

Rear axle cover

Requisite tools

- Torx wrench set
- Torque wrench



Scope of installation

- Rear axle cover

General instructions

⚠ CAUTION

Hot engine and/or hot exhaust system

Risk of burn injury

- Allow engine and exhaust system to cool before starting work.

⚠ ATTENTION

Vehicle not securely propped

Risk of damage to parts if vehicle topples

- Prop the vehicle securely.

⚠ WARNING

Children and pets in the working area

Injury to persons

- Keep children and pets away from the working area.

⚠ CAUTION

Wearing jewellery during work


Risk of injury by snagging or electrical short circuit

- Remove all items of personal jewellery (rings, chains, wristwatch, etc.) before starting work.

⚠ NOTICE

Once the retrofit kit has been installed by the workshop, these installation instructions must be handed over to the customer.

Make sure that these installation instructions accompany the retrofit kit when it is passed on to a third party.



77 15 000 Install cover for rear axle**1****► Install cover for rear axle**

- Remove protective film of cover for rear axle .
- Apply screw locking agent in both threaded holes of threaded rod (1).


**Thread-locking compound**

Loctite 243, Medium strength	83 19 2 210 339
------------------------------	-----------------


- Screw in threaded rod (1) with cover for rear axle on right (2) hand-tight, counter-holding on mounting flats (**arrow**).
- Fit plastic ring (3) on cover (2).
- Insert cover for rear axle (1) from right into rear axle and install in axle pipe.



- Assemble cover for rear axle on left (1) with plastic ring (2), expanding spinner (3) and limit position for expanding spinner (4).



- Insert cover for left rear axle (1) in rear axle and screw to threaded rod (2) hand-tight.

2

► **Cover for rear axle**

- Tighten cover for rear axle on right (1) and left (2) **in specified sequence**.

Tightening torques		
Cover for rear axle		
	Tightening sequence: 1st	
	10 Nm	
	Tightening sequence: 2.	
	15 Nm	

3

► **Final check of work performed**

- Check the following:
 - The work as performed achieved the intended purpose.
 - All reservoirs and containers have been filled and all fluids and lubricants are at their correct levels.
 - All threaded fasteners released beforehand have been correctly retightened.
 - The fuel system is free of leaks.
 - The lights and signalling equipment are fully operational and the vehicle is roadworthy.
 - The brake pads of the front and rear brakes are bedded against the brake discs.

► **Function test, engine start suppression**

Check

- Set kill switch to centred position.
 - Select neutral.
 - Switch on the ignition.
- » Neutral indicator light "N" lights up.

- Select a gear.
 - » Neutral indicator light "N" goes out.
- Press the starter button.
 - » Starter does **not** operate.
- Extend the side stand.
- Pull the clutch lever.
- Press the starter button.
 - » Starter does **not** operate.
- Retract the side stand.
- Press the starter button without releasing the clutch lever.
 - » Starter operates.

Result

Not all test steps completed successfully.

Measure

- Check the appropriate parts with the BMW Motorrad diagnostic system.

