

OPERATING & SAFETY MANUAL

BG Snap Assembly Machine

Indo-MIM Pvt Limited | Tata Electronics, Hosur

Document Title	Operating & Safety Manual — BG Snap Assembly Machine
Document Number	IndoMIM-BGSnap-OSM-001
Revision	V2.0
Date	May 2026
Prepared By	Certified Safety Professional
Status	DRAFT — Pending site data (schematics, IPC alarms, site photos)

CONFIDENTIAL

TABLE OF CONTENTS

Right-click this area in Word and select Update Field (or press Ctrl+A then F9) to generate the Table of Contents.

1. FRONT MATTER	5
1.1 Document Scope	5
1.2 Intended Audience	5
1.3 General Safety Rules	5
1.4 Signal Word Hierarchy	5
1.5 Revision History	6
1.6 ISO 7010 Safety Signs Used in This Manual	6
2. MACHINE OVERVIEW	7
2.1 Machine Identification	7
2.2 Technical Specifications	7
2.3 Intended Use	7
2.4 Station Layout & Line Configuration	7
2.5 Key Components	8
2.6 Maintenance Access Zones	8
3. HAZARD IDENTIFICATION & RISK ASSESSMENT	10
3.1 Methodology	10
3.2 Hazard Summary	10
3.3 Hazard Narratives	10
3.4 Risk Reduction Hierarchy (ISO 12100)	11
3.5 Applicable Standards	11
3.6 Personnel Categories	11
4. LOCKOUT / TAGOUT (LOTO) PROCEDURES	13
4.1 Energy Isolation Points	13
4.2 LOTO Equipment Required	13
4.3 De-energization Sequence (Tag-Out)	13
4.4 Re-energization Sequence (Tag-In)	14
4.5 Partial Isolation	15
5. EMERGENCY STOP FUNCTION	16
5.1 E-Stop Device Locations	16
5.2 Stop Category	16
5.3 E-Stop Activation Sequence	16

5.4 E-Stop Reset Procedure	17
5.5 What the E-Stop Does NOT Do.....	17
5.6 Periodic E-Stop Testing	18
6. OPERATING INSTRUCTIONS	19
6.1 Operating Modes	19
6.2 Pre-Start Checklist	19
6.3 Machine Startup Procedure	19
6.4 Normal Operating Cycle.....	20
6.5 Process Flowchart.....	21
6.6 Normal Shutdown.....	21
6.7 Emergency Shutdown.....	21
7. MAINTENANCE & CARE.....	23
7.1 Weekly Maintenance.....	23
7.2 Monthly Maintenance.....	23
7.3 Six-Monthly Maintenance.....	24
7.4 Consumables & Spare Parts	25
8. ELECTRICAL SCHEMATIC	26
8.1 Key Electrical Parameters.....	26
8.2 Electrical Schematic Drawings	26
9. PNEUMATIC SCHEMATIC	27
9.1 Key Pneumatic Parameters.....	27
9.2 Pneumatic Schematic Drawings.....	27
10. HYDRAULIC SCHEMATIC	28
11. IPC ALARMS & FAULT CODES.....	29
11.1 Alarm Priority Levels.....	29
11.2 IPC Alarm Code List.....	29
11.3 General Alarm Response Procedure	29
12. SAFETY FEATURES & INTERLOCKS	30
12.1 Safety Architecture	30
12.2 Safety Control System.....	30
12.3 Safety Device Inventory.....	30
12.4 Safety Interlock Logic	31
12.5 Safety Function Testing Requirements.....	32
12.6 Prohibited Actions.....	32

13. COMPLIANCE & CERTIFICATIONS	34
13.1 International Safety Standards	34
13.2 Indian Standards & Regulations.....	34
13.3 Component-Level Standards	34
13.4 Compliance Statement	35
13.5 Document Control.....	35
13.6 Customer Sign-Off	35
APPENDIX B — MAINTENANCE LOG TEMPLATE	39

DRAFT

1. FRONT MATTER

1.1 Document Scope

This manual covers the BG Snap Assembly Machine (Project Reference V67) installed at Tata Electronics, MG Road, Hosur, Tamil Nadu 631604, designed and supplied by Indo-MIM Limited. It addresses machine identification, hazard identification, LOTO procedures, emergency stop, operating instructions, maintenance, schematics, IPC alarms, safety features, and compliance. It does not cover design, manufacture, installation, or commissioning.

1.2 Intended Audience

Audience	Sections to Read
All personnel near machine	Sections 1, 2, 3, Appendix A
Machine operators	Sections 1–6, Appendix A
Setup technicians	All sections
Maintenance technicians	All sections — emphasis on Sections 4, 7, 12
EHS / Safety personnel	Sections 3, 4, 5, 12, 13, Appendix A
Management / Auditors	Sections 1, 3, 13, Appendix A

1.3 General Safety Rules

- Untrained personnel must not operate this machine. No exceptions.
- No maintenance inside the guarding envelope without completing full LOTO (Section 4).
- No safety device, interlock, guard, or label may be removed or bypassed without written authorization from Indo-MIM Limited and Tata Electronics EHS.
- All incidents, near misses, and faults must be reported to the shift supervisor and recorded in the maintenance logbook immediately.
- The machine must be operated only within the intended use defined in Section 2.3.
- PPE must be worn at all times during maintenance as specified in Appendix A.
- This manual must remain at the machine and be available to all operators and technicians during their shift.

1.4 Signal Word Hierarchy

Signal Word	Meaning
WARNING	Imminently hazardous — will result in death or serious injury if not avoided.
WARNING	Potentially hazardous — could result in death or serious injury.
CAUTION	Potentially hazardous — may result in minor or moderate injury.
NOTICE	May result in property or equipment damage. No personal injury risk.

1.5 Revision History

Rev	Date	Description	Prepared By
V1.0	April 2026	Initial issue — DFM V1.4 & RA V1.1 basis. Placeholders for site items. All OAs open.	Certified Safety Professional
V2.0	May 2026	Tier B reissue — condensed to 40 pages. Placeholders retained for schematics, IPC alarms, site photos. OAs remain open pending site visit.	Certified Safety Professional
V3.0	May 2026	Site visit updates: single phase supply correction, IPC nomenclature (replaces HMI), E-stop count updated to 11, LOTO corrections, compulsory energy isolation note added, author field corrected to role only.	Indo-MIM / Tata Electronics

1.6 ISO 7010 Safety Signs Used in This Manual

Code	Description	Used In
W001	General warning	Secs 1, 3, 6
W003	Electricity hazard	Secs 3, 4, 8
W017	Crushing hazard	Secs 3, 5, 6
W019	Automatic start-up	Secs 3, 6
W028	Entanglement hazard	Secs 3, 6
P002	Do not touch	Secs 3, 4
P010	Do not switch on	Secs 4, 5
M008	Wear protective gloves	Secs 4, 7, App A
M009	Wear safety footwear	Secs 4, 7, App A

Refer to Section 13 for the full Liability Disclaimer.

This manual was prepared by Certified Safety Professional, in accordance with ISO 12100:2010, ISO 20607:2019, IEC 82079-1:2019, and IS 4571:2008. Where data was unavailable, gaps are formally recorded as Open Actions — none have been ignored or assumed away. Indo-MIM Limited and Tata Electronics are jointly responsible for final review and verification. All Open Actions must be closed before the machine enters production service.

2. MACHINE OVERVIEW

2.1 Machine Identification

Field	Details
Machine Name	BG Snap Assembly Machine
Project Reference	V67 — BG Snap Assembly Station
Machine Type	Automated Snap & Screw Assembly Line
Manufacturer	Indo-MIM Limited
End User	Tata Electronics
Installation Location	Tata Electronics, MG Road, Hosur, Tamil Nadu — 631604
DFM Reference	BG Snap Assembly DFM V1.4, dated 18-March-2026
Risk Assessment Ref.	Machine Safety Assessment Report V1.1, dated 23-March-2026, by Independent Safety Consultant
Machine Weight	OPEN ACTION OA-P5-004 — Pending Indo-MIM confirmation

2.2 Technical Specifications

Parameter	Specification
Main Supply	230V AC AC, 3-phase, 50 Hz
Station Supply	220V AC per station
Total Connected Power	54 kW (full line)
Maximum Current	[PLACEHOLDER — confirm current rating]
Compressed Air	0.5 – 0.7 MPa (clean, dry, oil-free)
Line Dimensions (L×W×H)	8,400 mm × 2,100 mm × 2,200 mm
Operator Headcount	1 (tray loading and unloading only)
Cycle Time	5 seconds per piece
UPH	629
OEE	87.42% (Avail: 93.04% / Perf: 97.03% / 1PY: 96.84%)
Design Life	10 years (with scheduled maintenance)
Operating Environment	Indoor, controlled temperature & humidity, clean-room-like

2.3 Intended Use

This machine assembles three snap components (part numbers 613-31681, 613-38625, 613-38626) onto each HSG unit, securing each snap with two screws — six screws per unit, every five seconds. Any use outside this scope is foreseeable misuse and is strictly prohibited.

2.4 Station Layout & Line Configuration

Station	Name	Function	Key Equipment
---------	------	----------	---------------

S1	Loading Machine	Picks HSG from input tray, scans barcode, transfers into Maglev fixture	KUKA KR13 R850, barcode scanner, Cognex
S2	Snap Assembly & Screwing	Assembles 1st snap; fastens 2 screws; CCD vision recheck	HIWIN axes, Atlas QMC-21, Deprag feeder, YIG reel feeder
S3	Snap Assembly & Screwing	Assembles 2nd snap; fastens 2 screws; CCD vision recheck	Same as S2
S4	Flipping Station	Flips HSG 180° to expose reverse face for 3rd snap	Rotating cylinder, HIWIN Z-axis, pneumatic unlock
S5	Snap Assembly & Screwing	Assembles 3rd snap on reverse face; fastens 2 screws; CCD vision recheck	Same as S2/S3
S6	Unloading Machine	Picks completed HSG; routes OK to output tray; NG to buffer/NG tray	KUKA KR13 R850, buffer fixture, NG tray

Fixture transport: Product fixtures circulate on the Beckhoff Maglev conveyor — upper layer S1→S6, lower layer return. RFID readers (Pepperl+Fuchs IQT1-18GM-IO-V1) at each station link the HSG barcode to fixture ID for full traceability.

2.5 Key Components

Component	Brand & Model	Station(s)
4-axis SCARA Robot	KUKA KR13 R850 Z200-2 CS	S1, S6
Smart Screwdriver	Atlas Copco QMC-21-10-HM4	S2, S3, S5
Screwdriver Controller	Atlas Copco MTF6000	S2, S3, S5
Screw Feeder	Deprag Mini Screw Feeder	S2, S3, S5
Tape Reel Feeder	YIG Tape Reel Feeder	S2, S3, S5
Maglev Conveyor	Beckhoff / Baeyal-Golytec	Full line
Servo Axes	HIWIN KK / Toyo GTH series	All stations
Safety PLC	FLX3 series	Full line
Safety Door Latch	Keyence GS-51P5 (PLe / Cat 4 / SIL3)	S1–S6
Safety Light Curtain	Keyence GL-VM39FP (PLe / Cat 4 / SIL3)	S1, S6
IPC & Motion Card	Advantech IPC 7132 + PCIE-1203	All stations
RFID Reader	Pepperl+Fuchs IQT1-18GM-IO-V1	All stations
Barcode Scanner	Cognex	S1
3D Snapshot Sensor	LMI Gocator 3506	S2, S3, S5


2.6 Maintenance Access Zones

Zone	Clearance	Purpose
Front — S1 and S6 ends	1,000 mm	HSG tray loading and unloading
Rear of line	1,000 mm	Snap/screw loading, general maintenance

Between S2/S3 and S5	500 mm minimum	Fixture access and channel maintenance
Top of machine	1,000 mm above 2,200 mm	Overhead service and cable management

PLACEHOLDER — Machine Layout Diagram (Figure 2-1)

Full line top-view layout (S1–S6, Maglev conveyor path, access zones). Source: DFM V1.4. 300 DPI, max 160 mm wide.



3. HAZARD IDENTIFICATION & RISK ASSESSMENT

3.1 Methodology

The hazard assessment was conducted at design stage by an Independent Safety Consultant using ISO 12100:2010 methodology, covering all lifecycle phases. Each hazard was scored on Severity (S), Exposure (E), and Avoidance (A) to produce a risk level. Risk reduction was applied until all residual risks reached Low. The formal Machine Safety Assessment Report (V1.1, 23-March-2026) is held by Indo-MIM Limited and Tata Electronics.

3.2 Hazard Summary

Category	Hazards Identified	Initial Risk	Residual Risk
Mechanical	10	Medium	Low (all)
Electrical	4	High (3) / Medium (1)	Low (all)
Ergonomic	2	Low	Low (all)
Control System	4	High (3) / Low (1)	Low (all)
Chemical	0	Not applicable	Not applicable
Total	20	—	All Low

3.3 Hazard Narratives

3.3.1 Mechanical Hazards

Shearing from multi-axis servo gantries during maintenance. Entanglement and pinch at rotating fixtures, winder assemblies, and KUKA robot EOAT. Impact and trapping from KUKA SCARA arms and shuttle transfers. Gravity-assisted crushing at vertical lifting actuators. Controls: fixed perimeter guarding, interlocked access doors, STO on all servo drives.

3.3.2 Electrical Hazards

230V, Single Phase, [PLACEHOLDER — confirm current rating] in electrical enclosures and servo drive cabinets. Hazard types: contact with live parts, shock from insulation failure, residual stored energy, and overheating. Controls: enclosed panel design, lockable main isolator LP-01, protective earthing, LOTO (Section 4).

3.3.3 Ergonomic Hazards

Manual tray loading and unloading at S1 and S6. Awkward posture and physical strain from tray weight and frequency. Assessed Low risk. Managed through operator training and correct work posture guidance (Section 6).

3.3.4 Control System Hazards

Unexpected start-up, hazardous motion with doors open, incorrect reset logic, and safety function bypass. All require PLD/PLC control functions per ISO 13849-1:2015, implemented through the Safety PLC (Section 12).

3.4 Risk Reduction Hierarchy (ISO 12100)

Step	Measure Applied
1 — Inherently Safe Design	Enclosed station housings, Maglev conveyor routing, and single-point operator interaction at defined loading/unloading zones minimize access to hazardous zones.
2 — Safeguarding	Keyence GS-51P5 safety door latches (PLe/Cat4/SIL3), Keyence GL-VM39FP light curtains (PLe/Cat4/SIL3), Safety PLC, STO on all servo drives, dual contactors, robot safety per ISO 10218-1.
3 — Information for Use	This manual, safety warning labels, operator training, PPE requirements, and maintenance procedures address residual risks not eliminated by Steps 1 and 2.

3.5 Applicable Standards

Standard	Title	Relevance
ISO 12100:2010	Safety of Machinery — Risk Assessment and Reduction	All sections
ISO 13849-1:2015	Safety-Related Parts of Control Systems	Safety PLC, STO, interlocks, E-stop
ISO 13850:2015	Emergency Stop Function	E-stop design — Section 5
ISO 14119:2013	Interlocking Devices for Guards	Safety door latches — Section 12
ISO 14120:2015	Guards — General Requirements	Fixed and interlocked guard design
ISO 14118:2017	Prevention of Unexpected Start-Up	Restart prevention — Section 12
ISO 13855:2024	Positioning of Safeguards	Light curtain positioning
ISO 10218-1:2011	Safety Requirements for Industrial Robots	KUKA robot integration
ISO 20607:2019	Instruction Handbook	Manual structure and content
IEC 82079-1:2019	Preparation of Instructions for Use	Signal word hierarchy
IEC 60204-1:2016	Electrical Equipment of Machines	Panel design — Section 8
IEC 61496-1:2020	Electro-Sensitive Protective Equipment	Light curtain spec
IS 4571:2008	Safety of Machinery (Indian Standard)	Indian regulatory compliance
IS 12100:2012	Risk Assessment — Indian Adoption	Indian standards framework
Factories Act 1948	Indian Industrial Labour Law	Statutory compliance — Section 21

3.6 Personnel Categories

Category	Permitted Tasks	Training Required
Operator	Tray loading/unloading, IPC monitoring, alarm acknowledgement, normal cycle start/stop	Machine-specific operator training per this manual
Setup Technician	Recipe selection, parameter	Operator training + setup/changeover

	adjustment via IPC, fixture changeover	training
Maintenance Technician	Scheduled and corrective maintenance, component replacement, LOTO execution	Operator + maintenance training + LOTO certification
Safety / Authorized Person	Safety PLC parameters, safety function testing, RA review	All above + safety system authorization
Manufacturer's Service Engineer	Robot programming, servo parameters, safety PLC config	Manufacturer authorization only

WARNING [ISO 7010 W001]

Residual Risk: Safeguards reduce risk — they do not eliminate it. Residual risks remain manageable only if LOTO is followed, PPE is worn, and procedures are respected. Read Appendix A before your first shift.

4. LOCKOUT / TAGOUT (LOTO) PROCEDURES

Complete LOTO before entering the machine guarding envelope for any maintenance, repair, cleaning, inspection, or fault-clearing activity. No exceptions for quick jobs or familiar tasks.

4.1 Energy Isolation Points

LOTO ID	Energy Type	Description	Isolation Device	Location
LP-01	Electrical	230V, Single Phase, [PLACEHOLDER — confirm current rating] main supply	Lockable rotary main isolator	Main electrical panel — right side of S1
LP-02	Pneumatic	0.5–0.7 MPa compressed air	Solenoid valve + lockout hasp	Air inlet — rear of machine base, S1 end
LP-03	Electrical (Servo)	STO — all HIWIN and Toyo axes	STO command via Safety PLC	Integrated in Safety PLC
LP-04	Electrical (Maglev)	Maglev linear motor supply	Maglev conveyor PLC isolator	Maglev control panel — centre of line

OPEN ACTION [OA-P5-001]

All LOTO points identified from DFM V1.4 and RA. Physical location, labelling, and hasp availability must be verified during site visit at Tata Electronics, Hosur before this section is finalized.

Responsibility: Certified Safety Professional — site visit | Target: Dry run | Status: Open

4.2 LOTO Equipment Required

- Personal padlock — one per technician, keyed differently from all others
- Lockout hasp — multi-lock capable, for LP-01 and LP-02
- Danger tag — pre-printed with technician name, date, time, reason
- Calibrated voltage tester — for LP-01 isolation verification
- Pneumatic pressure gauge — to verify LP-02 bleed-down to zero
- LOTO log sheet — to record all isolation activities

4.3 De-energization Sequence (Tag-Out)

Pre-condition: Machine in stopped state, all cycles complete. Follow steps in exact order.

Step 1 — Notify: Inform all personnel in the vicinity. Confirm no person is inside the guarding envelope.

Step 2 — Stop the Machine: Press IPC STOP. Confirm all axes and robots have stopped and active alarms acknowledged.

Step 3 — Select Maintenance Mode: At IPC, select Maintenance Mode. Disables automatic cycle initiation from all stations. NOTE: Compulsory energy isolation (full LOTO per Section 4) is required before any personnel enter guarded zones, even in Maintenance Mode.

Step 4 — Isolate LP-01 (Main Electrical): Turn main rotary isolator to OFF. Apply personal padlock through hasp. Attach Danger tag.

Step 5 — Verify LP-01 Isolation: Using calibrated voltage tester, verify voltage absent at main panel incoming terminals and servo drive inputs. Do not proceed if voltage detected.

Step 6 — Isolate LP-02 (Compressed Air): Close LP-02 ball valve. Apply padlock and tag. Wait for downstream pressure to bleed. Confirm gauge reads zero before proceeding.

Step 7 — Verify LP-02 Isolation: Confirm pressure gauge reads 0 MPa. Attempt to actuate a pneumatic cylinder — no movement must occur.

Step 8 — Isolate LP-04 (KUKA Robots): At each robot controller (S1 and S6), turn main switch to OFF. Dock robot controller. Apply personal padlock to controller cabinet door hasp.

Step 9 — Isolate LP-05 (Maglev): Turn Maglev conveyor PLC isolator to OFF. Confirm movers are stationary and status indicator shows de-energized.

Step 10 — Confirm LP-03 STO Status: Verify Safety PLC confirms STO active on all servo drives. All servo drive enable indicator lights must be off.

Step 11 — Allow Stored Energy to Dissipate: Wait 60 seconds after LP-01 isolation. Servo drive DC bus capacitors hold charge sufficient to cause a serious shock — this wait is mandatory.

Step 12 — Record in LOTO Log: Record technician name, date, time, all points locked out, reason, and signature.

WARNING [ISO 7010 P010]

Your padlock. Your lock. Your life. No one else's padlock protects you. If you are inside the machine, your lock must be on every isolation point — regardless of who else has locked out.

4.4 Re-energization Sequence (Tag-In)

Pre-condition: All maintenance complete. All tools and materials removed. All guards and covers reinstalled and fastened.

Step 1 — Inspect and Clear: Walk full perimeter. Verify no tools or parts inside machine. Confirm all guards in place, access doors closed, no person inside.

Step 2 — Notify All Personnel: Inform all personnel machine is being re-energized. Ensure all are clear.

Step 3 — Restore LP-05 (Maglev): Turn Maglev PLC isolator to ON. Remove padlock and Danger tag from LP-05.

Step 4 — Restore LP-04 (KUKA Robots): Turn controller main switch to ON. Remove padlock. Allow boot sequence to complete.

Step 5 — Restore LP-02 (Compressed Air): Remove padlock and tag. Slowly open ball valve. Verify pressure builds to 0.5–0.7 MPa.

Step 6 — Restore LP-01 (Main Electrical): Remove padlock and tag. Turn main rotary isolator to ON. Verify panel indicator lights confirm power restored.

Step 7 — Confirm Safety System Status: Confirm Safety PLC reports all functions healthy. Test each access door interlock — machine must not allow cycle start with any door open.

Step 8 — Reset and Return to Normal Mode: Exit Maintenance Mode, select Normal Operating Mode. Perform a dry run cycle without product.

Step 9 — Record in LOTO Log: Record re-energization: technician name, time, confirmation all points restored, signature.

4.5 Partial Isolation

Partial isolation is only permitted with written authorization from the Indo-MIM maintenance supervisor and Tata Electronics safety representative, with a station-specific LOTO procedure documented and approved, a LOTO-certified technician performing the work, and a second authorized person present as safety observer at all times.

WARNING [ISO 7010 W001]

Partial isolation increases residual risk significantly. Never performed by a single person working alone. Never used as a routine shortcut to avoid full LOTO.

OPEN ACTION [OA-P5-006]

Partial isolation procedure conditions and authorization protocol to be finalized by Indo-MIM maintenance supervisor and Tata Electronics safety representative.

Responsibility: Indo-MIM + Tata Electronics | Target: Before V2.0 final release | Status: Open

5. EMERGENCY STOP FUNCTION

The E-stop is a last resort — not a pause button, not a production stop, and not a substitute for LOTO. Use it when something unexpected is happening and you need everything to stop immediately. For planned maintenance, use LOTO.

Designed in accordance with ISO 13850:2015 — Emergency Stop Function — Principles for Design.

5.1 E-Stop Device Locations

E-Stop ID	Location	Station	Access
ES-01	IPC control panel — left side	S1 Loading Machine	Front of machine
ES-02	IPC control panel — left side	S2 Snap Assy & Screwing	Front of machine
ES-03	IPC control panel — left side	S3 Snap Assy & Screwing	Front of machine
ES-04	Flipping station control panel	S4 Flipping Module	Front of machine
ES-05	IPC control panel — left side	S5 Snap Assy & Screwing	Front of machine
ES-06	IPC control panel — left side	S6 Unloading Machine	Front of machine
ES-07	[PLACEHOLDER — location TBC: site visit confirmation required]	[PLACEHOLDER]	[PLACEHOLDER]
ES-08	[PLACEHOLDER — location TBC: site visit confirmation required]	[PLACEHOLDER]	[PLACEHOLDER]
ES-09	[PLACEHOLDER — location TBC: site visit confirmation required]	[PLACEHOLDER]	[PLACEHOLDER]
ES-10	[PLACEHOLDER — location TBC: site visit confirmation required]	[PLACEHOLDER]	[PLACEHOLDER]
ES-11	[PLACEHOLDER — location TBC: site visit confirmation required]	[PLACEHOLDER]	[PLACEHOLDER]

OPEN ACTION [OA-P5-007]

Physical E-stop locations, mounting heights, and panel positions to be verified during site visit at Tata Electronics. Locations above are from DFM V1.4.

Responsibility: Certified Safety Professional — site visit | Target: Dry run | Status: Open

5.2 Stop Category

Category 1 Stop (IEC 60204-1:2016) — controlled deceleration to standstill, then power removal. Selected because high-speed servo axes and KUKA robots require controlled deceleration to prevent mechanical damage and secondary hazards.

5.3 E-Stop Activation Sequence

(1) Signal transmitted to Safety PLC via dual-channel hardwired circuit. (2) All HIWIN and Toyo axes decelerate to standstill under controlled braking. KUKA robots execute Category 1 stop per ISO 10218-1. (3) STO applied to all servo drives once standstill reached. Maglev conveyor de-energized.

(4) Pneumatic system moves to fail-safe state. (5) All five IPC stations display E-stop active alarm with station identifier.

5.4 E-Stop Reset Procedure

The E-stop function is latching — cannot be reset remotely or automatically. Follow all steps.

WARNING [ISO 7010 W019]

The machine will move on restart. Before pressing RESET, walk the machine and identify why the E-stop activated. If you cannot identify the cause, do not reset — call the maintenance technician.

Step 1 — Identify Cause: Walk full machine perimeter. Identify reason. Resolve any hazardous condition. Confirm all personnel clear.

Step 2 — Release E-Stop Pushbutton: At the activated station, rotate mushroom-head pushbutton clockwise until released. Cannot be released from IPC.

Step 3 — Acknowledge Alarm at IPC: At the station IPC, acknowledge the E-stop alarm. Confirm no other active alarms before proceeding.

Step 4 — Confirm Safety System Status: Confirm Safety PLC reports all safety functions healthy. All door interlocks engaged. Light curtains unobstructed.

Step 5 — Restart Authorization: Only authorized operator or technician may authorize restart. Must be initiated from IPC.

Step 6 — Initiate Controlled Restart: Press RESET then CYCLE START. Machine performs controlled homing before resuming operation. Monitor first cycle carefully.

Step 7 — Record E-Stop Event: Record in maintenance log: station, time, cause, corrective action, name of person who reset.

5.5 What the E-Stop Does NOT Do

- Does not isolate the 230V AC main electrical supply — the main panel remains energized.
- Does not immediately vent all pneumatic pressure — residual pressure may remain.
- Does not substitute for LOTO — never use E-stop as a lockout device for maintenance.
- Does not prevent re-energization by another person — apply your personal LOTO padlock when entering.

5.6 Periodic E-Stop Testing

Test	Frequency	Acceptance Criteria
Daily (once per shift)	Operator activates each accessible E-stop button. Machine must enter safe state. Reset and confirm normal operation resumes before production starts.	Operator
Functional test — all E-stop buttons	Weekly	All axes stop, STO applied, IPC alarm displayed, no auto-restart
Dual-channel integrity test	Monthly	Safety PLC fault alarm within 500 ms on channel disconnect
Response time verification	Six-monthly	Standstill achieved within manufacturer-specified deceleration time
Full safety function audit	Annually	All safety functions verified to PLd/Category 3 per ISO 13849-1

6. OPERATING INSTRUCTIONS

During automatic operation your role is: load trays at S1, collect trays at S6, monitor the IPC. Do not interfere with the automatic cycle. If something looks wrong, press E-stop and call the technician.

6.1 Operating Modes

Mode	Description	Who Can Select
Automatic	Full automatic assembly cycle. Runs continuously. Screw loading on assembly station Snap-loading, Reel loading	Trained Operator
Manual	Individual station/axis movements one step at a time. Setup, changeover, troubleshooting only.	Setup Technician or above
Maintenance	All automatic functions disabled. Used with LOTO during maintenance.	Maintenance Technician or above

6.2 Pre-Start Checklist

#	Check Item	Required Condition
1	All access doors and safety guards	Fully closed and latched
2	All E-stop pushbuttons ES-01 to ES-06	Released — buttons in extended position
3	Safety light curtains at S1 and S6	Unobstructed — green indicator active
4	Compressed air pressure gauge at inlet	0.5 to 0.7 MPa
5	Main electrical isolator LP-01	ON position
6	All IPC displays	Powered on — no active alarms
7	KUKA robot controllers S1 and S6	Powered on — no fault indicators
8	Maglev conveyor	Powered on — status normal on IPC
9	Input tray area at S1	Clear of obstructions — tray loaded with HSG units
10	Output tray area at S6	Empty tray in position
11	Screw feeders S2, S3, S5	Loaded — feeder level indicator showing adequate supply
12	Tape reel feeders S2, S3, S5	Snap tape reels loaded and threaded correctly
13	LOTO log	No open LOTO entries — machine released from maintenance
14	Work area around machine	Clear of personnel, tools, and obstructions
15	Reel Feeder	To ensure all reel feeders in place

6.3 Machine Startup Procedure

Pre-condition: All pre-start checks in Section 6.2 completed.

Step 1 — Power On: Confirm LP-01 in ON position. Confirm all IPC displays showing home screen.

Step 2 — Clear All Alarms: At each IPC (S1–S6), acknowledge and clear residual alarms. Do not proceed if any alarm cannot be cleared.

Step 3 — Initialize Safety System: At S1 IPC, confirm Safety PLC reports all functions healthy. Confirm all door interlocks engaged and light curtains active.

Step 4 — Home All Axes: Select Homing at S1 IPC. Initiate automatic homing sequence. Do not interrupt once started.

Step 5 — Initialize KUKA Robots: Confirm both robots (S1 and S6) show ready status. Contact maintenance if either shows a fault.

Step 6 — Initialize Maglev Conveyor: Confirm Maglev initialized and all fixture movers detected on IPC.

Step 7 — Select Recipe: Navigate to Recipe screen. Select correct product recipe. Confirm name and version match production order.

Step 8 — Select Automatic Mode: Select Automatic Mode at S1 IPC. Confirm mode indicator changes on all station IPCs.


Step 9 — Load Input Tray: Place loaded input tray at S1. Seat in guide rails. Push until clamping jaws engage audibly. Confirm tray detected on IPC.

Step 10 — Start Cycle: Press CYCLE START at S1 IPC. Monitor first cycle to confirm all stations operating normally.

6.4 Normal Operating Cycle

Station	Sequence
S1 — Loading	KUKA robot picks HSG → barcode scan → secondary positioning fixture → Maglev fixture mover. Barcode fail → NG conveyor.
S2 — 1st Snap & Screw	Tape reel advances snap. Voice coil picks snap. CCD pre-inspection. Snap placed at 1st position. Atlas screwdriver drives 2 screws to torque. CCD recheck. Torque or seating NG → screws tossed, HSG flagged.
S3 — 2nd Snap & Screw	Same sequence as S2 for the 2nd snap position.
S4 — Flip	Flipping module suctions HSG, rotates 180°, replaces in fixture with reverse face exposed.
S5 — 3rd Snap & Screw	Same sequence as S2/S3 for 3rd snap on reverse face.
S6 — Unloading	KUKA robot picks completed HSG. OK → output tray. NG at any station → buffer fixture or NG tray.

6.5 Process Flowchart



6.6 Normal Shutdown

Step 1 — : Let the current cycle finish. Mid-cycle stops leave partially assembled HSG units requiring manual clearance.

Step 2 — : At S1 IPC, press CYCLE STOP. Machine completes current cycle and comes to a controlled stop.

Step 3 — : Remove input trays from S1, output trays from S6. Remove and segregate NG parts from buffer tray.

Step 4 — : At IPC, select Controlled Shutdown. Machine homes all axes, de-energizes Maglev, powers down robot controllers.

Step 5 — : Once IPC confirms shutdown complete, turn LP-01 to OFF if required by site procedure.

Step 6 — : Record any alarms, faults, or observations in the machine logbook.

6.7 Emergency Shutdown

Use only when an immediate stop is required due to an unsafe condition.

Step 1 — : Press the nearest E-stop (ES-01 through ES-06). Machine executes Category 1 controlled stop.

Step 2 — : Do not attempt to restart until the cause has been identified and resolved.

Step 3 — : Follow E-stop reset procedure (Section 5.4) before returning to service.

Step 4 — : Record the event in the logbook. Report to shift supervisor immediately.

DRAFT

7. MAINTENANCE & CARE

All maintenance must be performed by trained and authorized technicians only. Complete full LOTO (Section 4) before entering the guarding envelope for any task.

WARNING [ISO 7010 P010]

Every task that requires entering the machine requires LOTO first. Stated once here — applies everywhere. No exceptions for quick jobs or familiar tasks.

7.1 Weekly Maintenance

#	Task	Station	LOTO
W-01	Test all E-stop pushbuttons individually — verify controlled stop and IPC alarm	All	No
W-02	Inspect all fixed guards and enclosure panels — verify fasteners are tight	All	No
W-03	Clean CCD camera lenses (upper and lower) — lint-free cloth and approved optical solution only	S2,S3,S5	⚠ LOTO
W-04	Clean LMI Gocator 3D sensor windows — lint-free cloth only, no solvents	S2,S3,S5	⚠ LOTO
W-05	Inspect HIWIN/Toyo linear axis rails — remove debris, check for contamination	All	⚠ LOTO
W-06	Inspect KUKA robot EOAT grippers and nozzles — check for wear, damage, or contamination	S1,S6	⚠ LOTO
W-07	Inspect snap tape reel feeder mechanism — clean feed path, check for tape debris	S2,S3,S5	⚠ LOTO
W-08	Inspect Deprag screw feeder — clean feed track, check for jammed or deformed screws	S2,S3,S5	⚠ LOTO
W-09	Inspect Atlas screwdriver nozzles — check for wear and screw seating integrity	S2,S3,S5	⚠ LOTO
W-10	Inspect Maglev mover carriages — check for debris on rail surface	Full line	⚠ LOTO
W-11	Inspect fixture bodies — check push blocks, datum blocks, clamping surfaces	All	⚠ LOTO
W-12	Check pneumatic tubing and fittings for leaks or damage	All	No
W-13	Verify RFID reader status at all six stations — confirm correct fixture ID reading	All	No

7.2 Monthly Maintenance

#	Task	Station
M-01	Lubricate HIWIN linear guide rail blocks — apply recommended grease via grease	All

	nipple. See OA-P5-008.	
M-02	Lubricate Toyo servo axis ball screw — apply recommended grease. See OA-P5-008.	All
M-03	Inspect and clean Pepperl+Fuchs RFID reader faces — check mounting and cable condition	All
M-04	Inspect Keyence safety door latch mechanisms — check latch pin condition and actuator alignment	All
M-05	Test dual-channel E-stop circuit integrity at Safety PLC input terminals — verify fault alarm within 500 ms	All
M-06	Check servo drive cooling fan operation — confirm airflow, listen for abnormal noise	All
M-07	Inspect pneumatic cylinder seals at tray locking and flipping modules — check for air weeping	S1,S4,S6
M-08	Check Maglev mover wheel condition — inspect for flat spots or uneven wear	Full line
M-09	Verify Atlas screwdriver torque calibration — run calibration check per Atlas MTF6000. Confirm within $\pm 5\%$ of set value.	S2,S3,S5
M-10	Inspect IPC/motion card cooling — clean dust filters on Advantech IPC cabinets	All
M-11	Back up IPC recipe files and PLC program to approved storage location	All
M-12	Inspect voice coil actuator stroke — verify correct snap pick-up and placement position	S2,S3,S5

7.3 Six-Monthly Maintenance

#	Task	Station	Specialist?
SM-01	Full safety function audit — verify all PLe/Cat4 safety functions per ISO 13849-1 verification checklist	All	Authorized safety technician
SM-02	KUKA robot full calibration check — verify TCP, axis positions, and working envelope	S1,S6	KUKA authorized engineer
SM-03	Vision system full calibration — all CCD cameras using calibration plate	S2,S3,S5	Vision-trained technician
SM-04	LMI Gocator 3D sensor full calibration — using reference target	S2,S3,S5	Vision-trained technician
SM-05	Replace Atlas screwdriver nozzles — scheduled replacement regardless of visual condition	S2,S3,S5	Maintenance technician
SM-06	Replace fixture push blocks (PU material) — scheduled replacement due to wear	All	Maintenance technician
SM-07	Full electrical inspection — cable terminations, earth continuity, insulation resistance	All	Qualified electrician
SM-08	Maglev conveyor full system check — mover positioning accuracy and rail alignment	Full line	Beckhoff authorized technician
SM-09	E-stop response time verification — measure time from activation to full axis standstill	All	Authorized safety technician

7.4 Consumables & Spare Parts

Item	Station	Replacement Trigger	Min. Stock
Snap components (613-31681, 613-38625, 613-38626)	S2,S3,S5	Tape reel empty	Per production plan
Screws (M-type per assembly spec)	S2,S3,S5	Feeder at minimum level	2-shift supply minimum
Atlas screwdriver nozzle tips (QMC-21-10-HM4)	S2,S3,S5	Worn / 6-monthly schedule	4 sets minimum
Fixture push blocks (PU material)	All	Worn or deformed / 6-monthly	2 sets per station
Fixture datum blocks (PPS)	All	Cracked or out of tolerance	1 set per station
Tape reel feeder drive belt (YIG compatible)	S2,S3,S5	Worn or slipping	2 per feeder type
Safety door latch (Keyence GS-51P5 complete)	All	Latch pin worn / interlock fault	2 units minimum

OPEN ACTION [OA-P5-008]

Lubrication schedule — lubricant types, approved brands, application quantities, and service intervals for all HIWIN axes, Toyo axes, KUKA robot joints, and pneumatic cylinders — pending Indo-MIM engineering confirmation.

Responsibility: Indo-MIM Engineering | Target: Before manual finalization | Status: Open

OPEN ACTION [OA-P5-009]

Troubleshooting guide — common fault conditions, probable causes, and corrective actions — pending Indo-MIM engineering and Tata Electronics maintenance input following site visit.

Responsibility: Indo-MIM Engineering + Tata Electronics Maintenance | Target: Before manual finalization | Status: Open

8. ELECTRICAL SCHEMATIC

WARNING [ISO 7010 W003]

The main electrical panel operates at 230V, Single Phase, [PLACEHOLDER — confirm current rating]. Access restricted to authorized electricians only. Complete full LOTO including LP-01 isolation and voltage verification before opening any electrical enclosure.

8.1 Key Electrical Parameters

Parameter	Specification
Main Supply	230V AC AC, 3-phase, 50 Hz
Maximum Current	[PLACEHOLDER — confirm current rating]
Total Connected Power	54 kW (full line)
Station Supply	220V AC per station
Control Voltage	24V DC (Safety PLC and I/O)
Robot Controller	KUKA KR CS Box-2
Safety PLC	FLX3 series
Motion Control	Advantech IPC 7132 + PCIE-1203 motion card
Communication	EtherCAT (motion), TCP/IP (MES/TRACE), OPC-UA
Main Isolator	Lockable rotary type, [PLACEHOLDER — confirm current rating], main panel
Protection Standard	IEC 60204-1:2016

8.2 Electrical Schematic Drawings

PLACEHOLDER — Full Electrical Schematic Drawing Set (Figure 8-1)

Drawing set: (1) Main power distribution single-line (230V AC/3-phase/[PLACEHOLDER — confirm current rating]); (2) Control circuit — Safety PLC I/O wiring; (3) E-stop dual-channel circuit; (4) Servo drive and STO wiring; (5) KUKA robot controller interface; (6) Maglev conveyor PLC wiring; (7) Cable schedule. Source: Indo-MIM electrical design team. A3 at 300 DPI.

OPEN ACTION [OA-P5-002]

Electrical schematic drawings for the BG Snap Assembly Machine have not been provided at the time of preparation of this manual.

Responsibility: Indo-MIM Engineering | Target: Before manual finalization | Status: Open

9. PNEUMATIC SCHEMATIC

WARNING [ISO 7010 W017]

Residual pneumatic pressure remains in downstream lines after LP-02 isolation until fully bled down. Always verify pressure gauge reads zero before reaching near any pneumatic actuator.

9.1 Key Pneumatic Parameters

Parameter	Specification
Supply Pressure	0.5 to 0.7 MPa
Air Quality	Clean, dry, oil-free compressed air
Main Isolation	Solenoid valve — de-energise via IPC/control panel; manually verify vent before entry (LP-02)
Actuator Types	SMC and FESTO cylinders — tray locking, flipping, rotating
Solenoid Valves	24V DC solenoid actuation via Safety PLC I/O
Fail-Safe Design	System dumps to safe state on E-stop activation
Design Standard	ISO 4414 — Pneumatic Fluid Power: Safety Requirements

9.2 Pneumatic Schematic Drawings

PLACEHOLDER — Full Pneumatic Circuit Diagram (Figure 9-1)

Diagram: (1) Main air supply to machine manifold; (2) FRL unit at inlet; (3) Solenoid valve bank all stations; (4) Individual actuator circuits; (5) ISO 1219-1 symbol legend; (6) Pressure settings table. Source: Indo-MIM pneumatic design team. A3 at 300 DPI.

OPEN ACTION [OA-P5-010]

Pneumatic schematic drawings for the BG Snap Assembly Machine have not been provided at the time of preparation of this manual.

Responsibility: Indo-MIM Engineering | Target: Before manual finalization | Status: Open

10. HYDRAULIC SCHEMATIC

NOT APPLICABLE — The BG Snap Assembly Machine does not use any hydraulic systems. All motion is achieved through servo-driven electric axes, KUKA robots, and pneumatic actuators. This section is retained for completeness of the standard documentation framework.

DRAFT

11. IPC ALARMS & FAULT CODES

The machine is equipped with five IPC stations (one per major section). All alarms are displayed on the relevant station IPC and simultaneously logged in the SQL-based production database.

11.1 Alarm Priority Levels

Level	Colour	Description	Machine Response
1 — Critical	Red	Safety-related or machine-stopping fault. Immediate attention required.	Machine stops automatically. Cycle cannot restart until alarm resolved.
2 — Warning	Amber	Non-critical condition requiring attention within current shift.	Machine continues. Operator must acknowledge and monitor.
3 — Information	Blue	Operational notification — no immediate action required.	Machine continues. Logged automatically.

11.2 IPC Alarm Code List

PLACEHOLDER — Full IPC Alarm Code Table (Figure 11-1)

Table columns: Alarm Code | Description | Station | Priority (1/2/3) | Probable Cause | Operator Action | Reset Procedure. Source: Indo-MIM software engineering — to be extracted from C# alarm module and SQL alarm table.

OPEN ACTION [OA-P5-003]

Complete IPC alarm code list has not been provided at the time of preparation of this manual.

Responsibility: Indo-MIM Engineering | Target: Before manual finalization | Status: Open

11.3 General Alarm Response Procedure

Step 1 — Read the Alarm: Note alarm code, description, and station on IPC. Do not acknowledge before understanding the alarm.

Step 2 — Assess Priority: Identify priority level from colour. For Level 1 Critical, stop all manual interaction and contact maintenance.

Step 3 — Do Not Override: Never use Manual Mode or maintenance bypass to override an active alarm without identifying the cause.

Step 4 — Contact Maintenance: For any alarm outside trained knowledge, contact maintenance immediately.

Step 5 — Record the Alarm: Record alarm code, time, and observations in the machine logbook.

12. SAFETY FEATURES & INTERLOCKS

This section documents what is protecting you, how it works, and what happens when it activates. Operators must not modify, bypass, or interfere with any safety device or interlock under any circumstances.

12.1 Safety Architecture

Level	Measure
1 — Inherently Safe Design	Enclosed station housings, Maglev routing, and single operator interaction point at defined loading/unloading zones minimize access to hazardous zones during normal operation.
2 — Fixed Guarding	All stations enclosed within fixed metal guarding panels fastened with tools. Must be reinstalled and fully fastened after any maintenance before return to service.
3 — Interlocked Safeguarding	All access doors interlocked with Safety PLC. Opening any door during operation triggers safety-rated stop. Light curtains at S1 and S6 provide area sensing at operator interaction points.
4 — Complementary Measures	E-stop pushbuttons at all six stations. Warning labels, PPE, operator training, and this manual address residual risks not eliminated by Levels 1–3.

12.2 Safety Control System

Parameter	Details
Safety PLC	FLX3 series — dual-channel, self-monitoring
Standard	ISO 13849-1:2015
Independence	Operates independently from machine software (C#). Machine app fault does not affect Safety PLC.
Safety Outputs	Dual contactor control — servo drives and Maglev conveyor
STO Function	Safe Torque Off on all HIWIN and Toyo servo drives
Robot Interface	KUKA KR CS Box-2 safety I/O — ISO 10218-1 compliant
E-Stop Circuit	Dual-channel hardwired, monitored by Safety PLC
Door Circuit	Dual-channel per door, monitored by Safety PLC
Light Curtain	Direct Safety PLC input — OSSD dual-channel
Diagnostic Coverage	High DC per IEC 62061

12.3 Safety Device Inventory

OPEN ACTION [OA-P5-013]

Safety device inventory is from DFM V1.4 and RA. Physical installation, cable routing, mounting positions, and label verification must be confirmed during dry run at Tata Electronics.

Responsibility: Certified Safety Professional — site visit | Target: Dry run | Status: Open

ID	Type	Brand & Model	Station	PL/Cat	Function
SD-01	Safety door latch	Keyence GS-51P5	S1	PLe / Cat 4	Interlocks S1 access door
SD-02	Safety door latch	Keyence GS-51P5	S2	PLe / Cat 4	Interlocks S2 access door
SD-03	Safety door latch	Keyence GS-51P5	S3	PLe / Cat 4	Interlocks S3 access door
SD-04	Safety door latch	Keyence GS-51P5	S4	PLe / Cat 4	Interlocks S4 access door
SD-05	Safety door latch	Keyence GS-51P5	S5	PLe / Cat 4	Interlocks S5 access door
SD-06	Safety door latch	Keyence GS-51P5	S6	PLe / Cat 4	Interlocks S6 access door
SD-07	Safety light curtain	Keyence GL-VM39FP	S1	PLe / Cat 4	Area sensing at tray loading zone
SD-08	Safety light curtain	Keyence GL-VM39FP	S6	PLe / Cat 4	Area sensing at tray unloading zone
SD-09	E-stop pushbutton	Per IEC 60947-5-5	S1	PLd / Cat 3	E-stop ES-01
SD-10	E-stop pushbutton	Per IEC 60947-5-5	S2	PLd / Cat 3	E-stop ES-02
SD-11	E-stop pushbutton	Per IEC 60947-5-5	S3	PLd / Cat 3	E-stop ES-03
SD-12	E-stop pushbutton	Per IEC 60947-5-5	S4	PLd / Cat 3	E-stop ES-04
SD-13	E-stop pushbutton	Per IEC 60947-5-5	S5	PLd / Cat 3	E-stop ES-05
SD-14	E-stop pushbutton	Per IEC 60947-5-5	S6	PLd / Cat 3	E-stop ES-06
SD-15	Servo STO	Integrated in drives	All	PLd / Cat 3	Safe Torque Off — all HIWIN and Toyo axes
SD-16	Robot safety I/O	KUKA KR CS Box-2	S1,S6	PLd / Cat 3	Robot safety stop per ISO 10218-1
SD-17	Dual contactor	Integrated in panel	All	PLe / Cat 4	Power removal on safety demand

12.4 Safety Interlock Logic

Safety Condition	Safety PLC Response	Machine Response	Restart Method
------------------	---------------------	------------------	----------------

E-stop activated (any station)	STO all drives	Category 1 stop — all axes	Manual reset + IPC acknowledge
Safety door opened (any station)	STO affected station	Category 1 stop — affected station	Door closed + IPC acknowledge + manual restart
Light curtain beam broken (S1/S6)	STO to S1 or S6	Category 1 stop — affected station	Beam cleared + IPC acknowledge + manual restart
Safety PLC fault	STO all drives	Full machine stop	Fault resolved + authorized reset
Power failure	STO by default	All drives de-energized	Full startup sequence
Robot safety I/O fault	Robot safety stop	Robot stops — other stations may continue	Robot fault resolved + IPC acknowledge

12.5 Safety Function Testing Requirements

Safety Function	Frequency	Acceptance Criteria
Safety door interlock — all doors	Weekly	Machine stops on door open; alarm displayed; no auto-restart
Safety light curtain — S1 and S6	Weekly	Machine stops on beam break; curtain alarm; green indicator returns on clear
E-stop function — all buttons	Weekly	All axes stop; STO confirmed; IPC alarm displayed
Dual-channel door interlock integrity	Monthly	Safety PLC fault alarm within 500 ms on channel disconnect
Dual-channel light curtain integrity	Monthly	Safety PLC fault alarm within 500 ms on OSSD disconnect
STO on all servo drives	Monthly	Motor produces no torque with STO active
Robot safety stop	Monthly	Robot stops within defined deceleration time; no fault on restart
Full safety function audit	Six-monthly	All safety functions verified to stated PL and Category

12.6 Prohibited Actions

- Bypassing, defeating, or disabling any safety door interlock, light curtain, E-stop, or STO for any reason
- Entering any guarded zone without completing full LOTO (Section 4)
- Modifying Safety PLC parameters or safety circuit wiring without written authorization from Indo-MIM engineering
- Removing or covering safety warning labels on the machine
- Operating the machine with any fixed guard removed or access door open
- Using tape, cable ties, or any device to hold a safety door latch closed while the door is open
- Allowing untrained or unauthorized personnel to operate the machine in any mode

WARNING [ISO 7010 W028]

The KUKA KR13 moves at up to 2700°/s with a 13 kg payload. There is no safe distance inside the working envelope while the robot is powered. Complete LP-04 isolation — both S1 and S6 controllers — before entering. Every time.

DRAFT

13. COMPLIANCE & CERTIFICATIONS

13.1 International Safety Standards

Standard	Title	Relevance
ISO 12100:2010	Safety of Machinery — Risk Assessment and Risk Reduction	Overall risk methodology — all sections
ISO 13849-1:2015	Safety-Related Parts of Control Systems	Safety PLC, STO, interlocks, E-stop
ISO 13850:2015	Emergency Stop Function	E-stop design — Section 5
ISO 14119:2013	Interlocking Devices for Guards	Safety door latches — Section 12
ISO 14120:2015	Guards — General Requirements	Fixed guard design
ISO 14118:2017	Prevention of Unexpected Start-Up	Restart prevention — Section 12
ISO 13855:2024	Positioning of Safeguards	Light curtain positioning
ISO 10218-1:2011	Safety Requirements for Industrial Robots	KUKA robot integration
ISO 20607:2019	Instruction Handbook	Manual structure
IEC 82079-1:2019	Preparation of Instructions for Use	Signal word hierarchy
IEC 60204-1:2016	Electrical Equipment of Machines	Panel design — Section 8
IEC 61496-1:2020	Electro-Sensitive Protective Equipment	Light curtain spec

13.2 Indian Standards & Regulations

Standard	Title	Relevance
IS 4571:2008	Safety of Machinery (Indian Standard)	Indian regulatory compliance — all sections
IS 12100:2012	Safety of Machinery — General Principles (Indian adoption)	Risk assessment under Indian standards framework
Factories Act 1948	Indian Industrial Labour Law — Section 21: Fencing of Machinery	Legal basis for machine guarding at Tata Electronics

13.3 Component-Level Standards

Component	Applicable Standard	Compliance Basis
Safety door latch (Keyence GS-51P5)	ISO 14119, IEC 60947-5-3	Manufacturer's declaration — PLe / Cat 4 / SIL3
Safety light curtain (Keyence GL-VM39FP)	IEC 61496-1, ISO 13849-1	Manufacturer's declaration — PLe / Cat 4 / SIL3
Safety PLC (FLX3 series)	ISO 13849-1	Manufacturer's declaration
KUKA KR13 R850 Z200-2 CS	ISO 10218-1, IEC 60204-1	Manufacturer's declaration — CE

		marked
Atlas QMC-21-10-HM4	IEC 60745, ISO 11148 series	Manufacturer's declaration
Deprag Screw Feeder	IEC 60204-1	Manufacturer's declaration

13.4 Compliance Statement

This manual was prepared by Certified Safety Professional, based on the Machine Safety Assessment Report (V1.1, March 2026), DFM V1.4 (March 2026), and the standards listed above. Where the machine was not available for physical inspection, gaps are documented as Open Actions — not assumed, not ignored, not filled with generic content. The Open Actions Register closes when the machine is verified, not before.

Final review and verification is the responsibility of Indo-MIM Limited as machine manufacturer and Tata Electronics as end user. All Open Actions must be closed before this manual is released as a controlled document and the machine enters production service.

13.5 Document Control

Field	Details
Document Title	Operating & Safety Manual — BG Snap Assembly Machine
Document Number	IndoMIM-BGSnap-OSM-001
Revision	V2.0
Classification	Confidential — Indo-MIM Limited / Tata Electronics
Language	English
Format	Word (.docx) — editable / PDF (.pdf) — controlled copy
Retention Period	Minimum 10 years from commissioning per Factories Act 1948
Next Review Date	Following site visit and dry run — target V2.0 final release

13.6 Customer Sign-Off

The following sign-off is required before this manual is released as a controlled document and the machine is placed into production service.

Indo-MIM Limited — Manufacturer Authorization

I confirm that this manual has been reviewed by Indo-MIM Limited's engineering and quality team, all technical content verified as accurate, and all Open Actions assigned to Indo-MIM reviewed and accepted for closure.

Name:	Designation:	Signature:	Date:

Tata Electronics — End User Authorization

I confirm that this manual has been reviewed by Tata Electronics' EHS and operations teams, all procedures are suitable for the facility's operating conditions, and all Open Actions assigned to Tata Electronics reviewed and accepted for closure.

Name:	Designation:	Signature:	Date:

Certified Safety Professional — Manual Author

I confirm that this manual has been prepared in accordance with applicable standards and professional obligations, and that all known safety gaps have been formally documented as Open Actions.

Name:	Designation:	Signature:	Date:

The safeguards on this machine are good. They are not perfect. This appendix tells you what risk remains after everything that could be engineered has been engineered. These risks are real — they are low, but only because the people working with this machine respect the procedures.

All operators, setup technicians, and maintenance technicians must read this appendix in full before working with or near this machine.

[SECTION REMOVED — Residual Risk Summary appendix permanently removed per OSM standard V1.2]

Hazard	Control Applied	Residual Risk	Requirement
Servo axis shearing (maintenance)	Interlocked safety doors (PLe/Cat4), STO, LOTO	Low	Full LOTO per Section 4 before entering
Electrical shock — live parts (230V AC)	Lockable main isolator LP-01, voltage verification, LOTO	Low	Full LOTO; voltage test before panel work
Stored energy — DC bus capacitors	60-second wait after LP-01 isolation	Low	60-second wait mandatory — no exceptions
KUKA robot impact during operation	Fixed guarding, interlocked door, light curtain (PLe/Cat4)	Low	Light curtain must be unobstructed during operation
KUKA robot impact during maintenance	LP-04 isolation of both robot controllers	Low	Full LOTO including LP-04 before entering S1 or S6
Snap/screw feeder entanglement	Fixed guarding, interlocked access, LOTO	Low	Full LOTO before accessing feeder mechanisms
Tray lifter gravity hazard	STO on Z-axis servo; LP-01 and LP-03 required	Low	Isolate LP-01 and confirm LP-03 STO before reaching under tray lifter
Residual pneumatic pressure after LP-02	Bleed-down via pressure gauge verification	Low	Confirm gauge at zero before reaching near pneumatic actuators
Ergonomic strain — tray loading/unloading	Operator training, correct posture guidance	Low	Use correct manual handling posture; observe tray weight limits
Unexpected restart after E-stop reset	Mandatory manual restart sequence from IPC	Low	Follow E-stop reset procedure in Section 5.4 fully

A.2 PPE Requirements

PPE Item	Required For	ISO 7010
Safety footwear (steel-capped)	All personnel at all times on shop floor	M009
Protective gloves (cut-resistant)	Maintenance technicians during LOTO and	M008

	component handling	
Safety glasses	Maintenance during pneumatic work or component handling	M004
High-visibility vest	Any personnel entering machine access zones	—

DRAFT

APPENDIX B — MAINTENANCE LOG TEMPLATE

All completed maintenance tasks must be recorded below. One entry per task. Result codes: S = Satisfactory | R = Item Replaced | F = Fault Found | D = Deferred

Date	Task #	Description	Station	Result	Observations	Technician	Sign

Maintenance records must be retained by Tata Electronics for a minimum of three years per Factories Act 1948.

APPENDIX C — LOTO LOG TEMPLATE

A new entry must be made for every LOTO event without exception. Log must remain at machine at all times. Stations/Points: list all isolation points applied (e.g. LP-01, LP-02, LP-04 S1, LP-05).

Date	Time Out	Time In	Stations / Points	Reason	Technician Name	Observations	Sign