

EMERGENCY RESPONSE GUIDE

RIDE Type-A Electric School Bus



SHUTDOWN PROCEDURE

SECURE: Gear to **N**, set **Parking Brake**, and **chock wheels**.

1) Method A Shutdown

Doors: Close all.

Ignition: Turn to **OFF**.

Child Check: Press and hold button (last row).

Key: Remove.

Power: Turn **24V Disconnect** to **OFF**.

2) Method B: Press and hold **Start/Stop** (3+ seconds).

Power: Turn **24V Disconnect** to **OFF**.

IF VEHICLE IS SUBMERGED

If water is not higher than the first step, drive slowly out of the water. If water is higher than the first step, press and hold the **START/STOP** Button for over 3s to shutoff the bus and then evacuate.

DO NOT attempt to remove manual service disconnects.

THERMAL EVENT

WARNING: If a thermal event occurs, use a dry powder or liquid carbon dioxide extinguisher. Do not use water or foam suppressors to extinguish. Continue with standard first responder procedures.



24-V Battery Disconnect Switch

The 24-V Battery Disconnect Switch is on the curbside behind the rear axle. Turn to **OFF** position to cut off 24-V supply.

Manual Service Disconnect

The Manual Disconnect Switch is under the front hood. Remove the plug to manually cut off the high voltage supply.

