






LEXUS ES350e/ES500e
4 doors / 5 seats / sedan
MY: 2026-Present



	Airbag		Stored gas inflator		Seat belt pretensioner		SRS control unit		Pedestrian protection active system
	Gas strut / Preloaded spring		High strength zone		Zone requiring special attention		Battery low voltage		Ultra-capacitor, low-voltage
	Battery pack, high-voltage		High voltage component		High voltage power cable		Cable cut		
ID No.		Version No.		Version date		Page			
ESEV20		01		03 / 2026		1 / 4			

1. Identification / Recognition



SILENT MOVEMENT OR INSTANT RESTART CAPABILITY EXISTS UNTIL VEHICLE IS FULLY SHUT DOWN.

■ Location of vehicle badges




■ Energy source: Lithium-ion battery




2. Immobilisation / Stabilisation / Lifting

■ Completely immobilize the vehicle




1) Chock the wheels and engage the parking brake.



1) Press the P position switch.

■ Stabilisation-lifting point

Place cribbing such as wooden blocks at the four points under the front and rear pillars.



Extra Reinforced Lifting Points



Standard Jack Locations



Vehicle Center of Gravity



DO NOT PLACE CRIBBING SUCH AS WOODEN BLOCKS OR RESCUE AIR LIFTING BAGS UNDER THE HIGH VOLTAGE POWER CABLES.
DOING SO MAY RESULT IN FIRE, OR ELECTRIC SHOCK.

	ID No.	Version No.	Version date	Page
	ESEV20	01	03 / 2026	2 / 4

3. Disable direct hazards / Safety regulations

■ If any of the following systems are required to be operated, operate them **BEFORE** disconnecting the battery.

Power door lock

Power window

Trunk opener

Moon roof

Power seat

Power tilt and telescopic steering





Electric parking brake

Electronic shift lever

When the 12 V battery is disconnected, electrical components cannot be operated.





■ Perform procedure Main or Alternative to completely shut off the vehicle.

< Main Procedure >







*1: 5 m (16.4 ft) or more

< Alternative Procedure >




In the event of an accident in which the airbags are deployed, the high-voltage system will be automatically deactivated.

■ Access to 12 V Battery



4. Access to the occupants

■ Window Glass




A	Laminated	B	Tempered
C	Outside Release Handle	D	Inside Release Handle (pull twice)

	ID No.	Version No.	Version date	Page
	ESEV20	01	03 / 2026	3 / 4

5. Stored energy / Liquids / Gases / Solids



High Voltage Li-ion Battery: 391.0 V



Low voltage battery: 12 V



Air Conditioner Refrigerant Gas



- ALWAYS WEAR APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT (PPE) WHEN DEALING WITH ANY OF THESE ITEMS.
- NEVER BREACH OR REMOVE THE BATTERY ASSEMBLY COVER UNDER ANY CIRCUMSTANCES, INCLUDING FIRE. DOING SO MAY RESULT IN SERIOUS INJURY OR DEATH FROM SEVERE BURNS OR ELECTRIC SHOCK.

6. In case of fire



USE COPIOUS AMOUNTS OF WATER

If it is difficult to apply copious amounts of water to the high voltage battery, it is recommended to allow the high voltage battery to burn itself out.



RE-IGNITION POSSIBLE !



Gas strut / Preloaded spring




As it is possible for a gas strut / preloaded spring to become a projectile, refer to the component layout drawing.

7. In case of submersion



DO NOT TOUCH ANY OF THE HIGH-VOLTAGE COMPONENTS OR CABLES, INCLUDING THE INTERLOCK CONNECTOR, WHILE THE VEHICLE IS SUBMERGED. DOING SO MAY RESULT IN ELECTRIC SHOCK. WORK ON THE VEHICLE ONLY AFTER THE VEHICLE HAS BEEN PULLED OUT OF THE WATER.

8. Towing / Transportation / Storage



RE-IGNITION POSSIBLE !

Store the vehicle at a safe distance (15 m (49.2 ft) or more) from other vehicles.

9. Important additional information

For further details, please refer to "Emergency Response Guide". <http://www.techinfo.toyota.com>

	ID No.	Version No.	Version date	Page
	ESEV20	01	03 / 2026	4 / 4