




FORD F-150 Lightning

2022 - Present



	Airbag		Structural Reinforcements		Control unit		High-voltage battery		High-voltage disconnection point
	Gas generator		Gas filled spring device		Battery		High-voltage wire / components		Seat belt tensioner
	Pedestrian / active hood								



FORD F-150 Lightning

2022 - Present



For more detailed information, please refer to the full F-150 Lightning Emergency Response Guide.

1. Identification / recognition



ELECTRIC VEHICLES DO NOT HAVE ENGINE NOISE. LACK OF ENGINE NOISE DOES NOT MEAN VEHICLE IS OFF. SILENT MOVEMENT OR INSTANT RESTART CAPABILITY EXISTS UNTIL VEHICLE IS FULLY SHUT DOWN. WEAR APPROPRIATE PPE.




1. Charging port on the driver's side.
2. Lightning badging on tailgate.

2. Immobilization / stabilization / lifting

IMMOBILIZATION

1. Position wheel and tire chocks
2. Put vehicle into PARK position (1). Ensure parking brake is engaged (2).
3. Shut vehicle off with the push button. Remove the key or PAAK (Phone As A Key) from the vehicle to prevent vehicle from turning back on.






Appropriate Stabilization Lifting Points
High Voltage (HV) Battery

3. Disable direct hazards / safety regulations

Under Non-urgent situations refer to, "Non-urgent situations" in the Emergency Response Guide.

Deactivate the high-voltage system.

1. Release the retainers and remove the left-hand underhood trim panel.
2. Cut the wires adjacent to the Low Voltage Service Disconnect. Isolate the wires to prevent reconnection.





FORD F-150 Lightning

2022 - Present





12-Volt Battery Disconnect. (Disables Safety Restraint System)



Locate the negative battery cable to ground. Cut the cable at two locations that are 3 in (7.6 cm) apart from each other. Isolate the cable to prevent reconnection.




Emergency Release During Charging




1. Attempt to de-power the charging unit.
2. Detach the manual charge cord release cable tab from the degas bottle.
3. Pull the manual charge cord lock actuator release cable tab.
4. Disconnect the EVSE charge cord from the vehicle.

4. Access to the occupants




- ① Laminated Safety Glass
② Toughened Safety Glass

5. Stored energy / liquids / gases / solids



12 V



400 V

Refer to the vehicle overview illustration on Page 1 for location reference of the high voltage battery, 12V battery, gas tank, and other vehicle component locations.

6. In case of fire



LITHIUM-ION BATTERIES CAN IGNITE SPONTANEOUSLY OR RE-IGNITE AFTER THE FIRE HAS BEEN EXTINGUISHED. WEAR APPROPRIATE PPE.





FORD F-150 Lightning

2022 - Present



7. In case of submersion

After rescuing the vehicle from the water, deactivate the high-voltage system (See Section 3) and allow the water to drain.

Wear appropriate PPE.




8. Towing / transportation / storage



LITHIUM-ION BATTERIES CAN IGNITE SPONTANEOUSLY OR RE-IGNITE AFTER THE FIRE HAS BEEN EXTINGUISHED. WEAR APPROPRIATE PPE.



If the vehicle has been involved in an accident or if the HV battery is damaged or unstable: Deactivate the high-voltage system (See Section 3). Do not store a severely damaged vehicle inside a structure or within 50 ft (15m) of any structure or vehicle.



Front Tow Hook



9. Important additional information

For specific information and safety preparation regarding the High Voltage system, refer to: <https://www.motorcraftservice.com>, select quick guides for the appropriate vehicle emergency response guide.

For First Responder Resources, refer to <https://www.ford.com/firstresponder/>

© Copyright 2025, Ford Motor Company. All rights reserved. This document may be reproduced in its entirety and distributed for emergency responder use only. It may not be excerpted for any purpose.

10. Explanation of pictograms used



Flammable



Explosive



Corrosives



Hazardous
to the
human health



Environmental
hazard



Electric
vehicle



Left-Hand
Drive



Use water
to extinguish
the fire



General
warning



Warning,
Electricity



Open
Hood/Frunk



Use infrared thermometer /
Thermal Infrared camera