




LAND ROVER RANGE ROVER SPORT (L461)
5 DOOR PHEV
2024-



Legend

 Airbag	 Stored gas inflator	 Seat belt pretensioner	 SRS control unit	 Pedestrian protection active system
 Automatic rollover protection system	 Gas strut / Preloaded spring	 High strength zone	 Zone requiring special attention	
 Battery, low voltage	 Ultra capacitor, low voltage	 Fuel tank	 Gas tank	 Safety valve
 High voltage battery pack	 High voltage power cable / component	 High voltage disconnect	 Fuse box disabling high voltage system	 Ultra capacitor' high voltage
 High voltage Component	 Cable Cut			

ID No

Version No

Page No

ERG461_PHE_24_ON

2.0

1 of 4

1. IDENTIFICATION / RECOGNITION

Range Rover Sport PHEV models can be identified by the following badges fitted to the vehicle.
LACK OF ENGINE NOISE DOES NOT MEAN VEHICLE IS OFF: SILENT MOVEMENT OR INSTANT RESTART CAPABILITY EXISTS UNTIL VEHICLE IS FULLY SHUT DOWN. WEAR APPROPRIATE PPE.




P440e

P510e

2. IMMOBILISATION / STABILISATION / LIFTING


Immobilise the vehicle

1. Chock the wheels.
2. When the **P** button is pressed, the transmission engages (**P**) and the EPB applies to help secure the vehicle.



Vehicle lifting and jacking.

Only lift or jack the vehicle using the jacking points shown in the illustration below.



Do not place cribbing such as wooden blocks or rescue air lifting bags under the exhaust or fuel system, doing so may result in fuel leaks or fire.

3. DISABLE DIRECT HAZARDS / SAFETY REGULATIONS



Note: The high voltage system is automatically disabled if the airbags are deployed.


1. 12v and High Voltage system isolation

Note: Disconnecting the 12v system will automatically isolate the High Voltage system.

1. Switch off ignition. 2. Remove all smart keys from the vehicle and store at least 5 metres away. 3. Open the hood.
4. Disconnect the start-up battery. 5. Disconnect the auxiliary battery.



2





3






4

Main Battery





5

Auxiliary Battery



Always disconnect the negative terminal first and reconnect last.
Failure to do so may lead to an electrical shock.





1. Press the forward part of the door handle (1) to present the rear of the handle.
2. Pull the rear of the handle (2) to open the door.



		12v
		398.2v
		Petrol: 71.5l
		R1234yf: 1,060 g ± 10 g



- Small vehicle fires, that do not involve the High Voltage (HV) system, can be treated with normal firefighting methods.



A PHEV battery involved in a fire, or exposed to high heat levels, will release toxic vapours. These vapours include sulfuric acid, oxides of carbon, nickel, lithium, copper, and cobalt. Responders must protect themselves with full PPE and breathing apparatus.



If the PHEV battery or components within the HV system are subject to fire or high heat levels, the HV system must be treated as UNSAFE, therefore, sufficient PPE must be worn and any contact with the vehicle is to be avoided.



Areas exposed to fire or high heat must be treated using high volumes of water, DO NOT attempt to extinguish a HV system fire without sufficient water supply.

The HV system has it's own coolant which is glycol based coolant. If the system is damaged, this orange coolant can leak out of the battery or surrounding components.



An Infrared camera should be used to monitor the temperature of the PHEV battery.





7. IN CASE OF SUBMERSION


Work on the vehicle only after it has been removed from the water.

8. TOWING / TRANSPORTATION / STORAGE

Front towing eye





Rear towing eye



Recovery method

Transporter or trailer:

The recommended method for recovery or transportation of the vehicle is on a transporter or trailer designed for that purpose.



If the vehicle cannot be recovered by using the recommended method, in an emergency, the vehicle can be towed on all four wheels for a short distance if essential. Do not tow the vehicle for more than 50 km (30 miles). Do not exceed 50 km/h (30 mph).



Straight bar tow on all wheels:

9. IMPORTANT ADDITIONAL INFORMATION

For further details, please refer to TOPIx <https://topix.jaguar.jlrext.com>

10. EXPLANATION OF PICTOGRAMS USED



General Warning



Warning, Electricity



Explosive



Corrosives



Hazardous to human health



Acute Toxicity



Flammable



Use water to extinguish the fire



Infrared camera



Cable Cut