




Porsche AG, Panamera S E-Hybrid (970) Coupé from Model Year 2014

PORSCHE




	Airbag		Body reinforcement		SRS-Control unit		High voltage battery
	Gas generator		Gas strut		12-volt Battery		High voltage cable / component
	Seat belt pretensioner		Pedestrian protection system		Fuse box		High voltage cut-off
	Fuel tank		Roll-over protection		Condenser		

Vehicle identification and marking


Panamera S Hybrid identification features – standard equipment



“e-hybrid” logo on the **engine cover**




“e-hybrid” logo on the **right- and left-hand doors**




On the **instrument cluster**

A = battery charge state,
B = E-Power meter indicator,
C = “e-hybrid” logo



E-POWER and E-CHARGE buttons
on the center console



Vehicle charging connection behind the charging-socket lid on rear left side of the vehicle

Marking of the hybrid components



All high-voltage components are clearly marked with warning labels.

All high-voltage cables have orange insulation.

Safety information about the hybrid system

Undamaged plugs, cables and sockets in the on-board high-voltage system are safe to touch.



Risk of serious or fatal injury from electric shock if handled incorrectly!

If high-voltage components are not handled correctly, there is a risk of fatal injury.

- Do not touch high-voltage components that are in operation.
- Do not damage the orange high-voltage cables in the on-board high-voltage system.
- There may still be voltage in the high-voltage battery even after the on-board high-voltage system has been switched off. The high-voltage battery must not be damaged or opened.

Switching off the passive safety system and high-voltage system

WARNING

The electric motor is silent when stationary!

You cannot always tell from the operating noise whether the car is ready to start because the electric motor is silent when stationary.

- The vehicle may be ready to start even when no engine noises can be heard.
- If the ignition is switched on, the combustion engine may start automatically depending on the level of charge of the high-voltage battery.

NOTE

Deactivating the HV system

The high-voltage system switches off automatically in accidents where the airbags or seat belt pre-tensioners are activated.

To make sure that the **high-voltage system** is deactivated, it is recommended – depending on accessibility – to use the **primary or secondary emergency disconnection point as the deactivation method:**

1. Primary emergency disconnection point: Switch ignition key to “OFF” and unplug the 12-volt service plug in the rear luggage compartment.
2. Secondary emergency disconnection point: Switch ignition key to “OFF” and pull out fuse number 46 in the front left fuse box.

Other deactivation methods as described in the manual may only be performed by appropriately qualified personnel.

NOTE

Deactivating the passive safety systems


The following steps should be taken to make sure that the **passive safety systems** (airbags and seat belt pre-tensioners) are switched off:

1. Disconnect the 12-volt battery in the driver's footwell. The waiting time after disconnection of the 12-volt battery is 1 minute.
2. Switch off the high-voltage system via the primary or secondary emergency disconnection point to ensure there is no voltage in the on-board 12-volt battery network.

Deactivating the high-voltage system


Switching off the ignition

The method of switching off the high-voltage system described below applies to both vehicles with a conventional key and those with Porsche Entry & Drive (keyless entry system).



1. Turn the ignition key to “OFF” (0 position).


Primary emergency disconnection point: unplugging the 12-volt service plug in the rear luggage compartment



1. Unplug the 12-volt service plug.
2. Unlock -a- and unplug -A- the service plug.

- ➔ There is no voltage in the high-voltage system approx. 20 seconds after it has been switched off.
- ➔ The passive safety systems, such as airbags and seat belt pre-tensioners, are still supplied with voltage from the on-board 12-volt battery.

Secondary emergency disconnection point: removing fuse number 46 from the fuse box on the left-hand side of the dashboard




1. Open the lid of the fuse box on the left-hand side of the dashboard.
2. Pull out fuse number **46**.

- ➔ There is no voltage in the high-voltage system approx. 20 seconds after it has been switched off.
- ➔ The passive safety systems, such as airbags and seat belt pre-tensioners, are still supplied with voltage from the on-board 12-volt battery.

Deactivating the passive safety systems

Disconnecting the 12-volt battery



1. Ensure that no jumper cables are connected to the vehicle.
2. Remove the cover of the 12-volt battery on the rear left-hand side of the luggage compartment.
3. Disconnect the negative cable of the 12-volt battery and secure it to prevent accidental contact.

- Additionally deactivate the HV system at an emergency disconnection point.
- The passive safety systems (airbags and seat belt pre-tensioners) are deactivated. The waiting time after disconnection of the 12-volt battery is 1 minute.

Other accident situations

Vehicle in water
There is no risk that the car body will be live. Once the vehicle has been recovered: 1. Allow the water to run out of the interior. 2. Begin switching off the high-voltage system.

Vehicle/battery fire	
Suitable extinguishing agent:	water (H ₂ O), larger quantities to cool the lithium ion battery

Battery fire	
Suitable extinguishing agent for a battery fire:	dry sand, carbon dioxide (CO ₂)

 WARNING

Battery cells explode when hot!

Battery modules might explode if the high-voltage battery becomes too hot.
→ Keep to the required safety distances when fighting the fire.