

## **UAVX Telemetry Only for OpenTx**

Connect a “D” class of Receiver e.g. D4RII, to RC2 on the UAVXArm board. UAVX continuously emits FrSky telemetry compatible with OpenTx. It does this regardless of the telemetry type selected for the UAVXGUI.