

VELORA ELECTRONICS

Velora V55 Smart TV

User Manual

Model	V55
Product code	VEL-V55-2025
Edition	Revision 1.2 - February 2025

Instructions for installation, everyday use, connections, maintenance and fault diagnosis.

Read the safety information before installing or operating the product.

Contents

This manual is organised around the normal life of the television: installation, setup, everyday use, connected equipment and service.

Section	Page	Section	Page
Safety information	3	HDMI operation	11
Package and controls	4	Network and smart services	12
Placement and installation	5	Broadcast and channels	13
First-time setup	6	Accessibility	14
Remote and daily controls	7	Maintenance	15
Picture settings	8	General troubleshooting	16
Sound settings	9	Error codes	17
External devices	10	Reset and software update	18
Technical summary	19	Service and compliance	20

Page references apply to this English edition. Menu names may vary slightly after a software update.

Safety information

Observe these instructions throughout installation and use. Improper mounting, ventilation or cleaning can damage the television or create a risk of injury.

Electrical safety

Use the supplied mains lead with a correctly earthed indoor outlet. Disconnect the plug during thunderstorms, before cleaning, and when the television will not be used for an extended period. Never handle the plug with wet hands.

Ventilation and heat

Leave at least 10 cm around the upper and side ventilation openings. Do not install the set inside a sealed cabinet or near a radiator, cooking appliance, candle or other heat source.

Children and stability

Furniture and wall fixings must support the television safely. Route cables so that they cannot be pulled or tripped over. Never allow a child to climb on the television or its furniture.

- **Do not** remove the rear cover; there are no user-serviceable parts inside.
- Keep liquids, aerosol cleaners and small metal objects away from openings.
- If smoke, an unusual smell or crackling occurs, unplug the set and contact authorised service.
- Two adults should lift and move the television; hold the lower frame, not the panel.

Package contents and controls

Check the carton before disposal. Retain the packaging for transport and record the model information shown on the rear rating label.

Local controls

The single multi-function button is under the centre of the lower bezel. Press once for the quick menu; press and hold for power. The status lamp is white in standby and turns off during normal viewing.

Rear label

The rating label identifies Model V55 and Product code VEL-V55-2025. Quote both identifiers when requesting service.

Item	Quantity	Notes
Velora V55 display unit	1	55-inch panel with integrated stand sockets
Stand legs and screws	2 + 4	Left and right legs are marked
Voice remote control	1	Requires two AAA batteries
AAA batteries	2	Observe polarity markings
Mains lead	1	Detachable, regional plug
Quick-start sheet	1	Basic installation sequence

Placement and installation

Choose the location before attaching the stand. The screen should be at a comfortable height and away from direct sunlight.

Attaching the stand

Place the television face down on a clean, padded, level surface. Insert each marked leg into the matching socket and tighten the supplied screws by hand until secure. Do not use a powered driver.

Wall mounting

Use a VESA 300 × 200 mm bracket rated for at least 25 kg. Use M6 screws with a depth appropriate to the bracket and spacer arrangement. The wall and anchors must be assessed by a competent installer.

Cable access

Leave enough clearance to reach the side HDMI and USB sockets and to avoid sharp bends in the optical and antenna cables.

- Recommended viewing distance: approximately 1.8-3.0 m for mixed HD and UHD material.
- Operating position: upright, indoors, on a stable level surface.
- Ambient operating temperature: 5-35 °C; relative humidity: 20-80%, non-condensing.

First-time setup

The setup assistant appears when the television is first powered on or after a factory reset.

Language and region

Choose the display language, country and time zone. These choices affect broadcast tuning, programme information and available services.

Network connection

Select a Wi-Fi network or connect an Ethernet cable. Network setup may be skipped; broadcast inputs and locally connected devices remain available.

Channel scan

For antenna reception, select the signal type and start an automatic scan. Do not disconnect the antenna or mains power while scanning.

Account and privacy

An optional Velora account supports app installation and settings synchronisation. Review diagnostic-data and personalised-content choices separately; declining optional data does not prevent normal television use.

After setup, check Settings > System > About to confirm Model V55 and Product code VEL-V55-2025.

Remote control and daily operation

Insert the batteries with the indicated polarity. Point the remote toward the lower-centre sensor for infrared commands.

Bluetooth pairing

Hold Home and Back together for five seconds within one metre of the television. A confirmation appears when pairing completes.

Standby behaviour

A short press places the television in standby. For a full restart, hold Power for five seconds and select Restart, or disconnect mains power for one minute.

Control	Function
Power	Switch between standby and operation
Source	Open the input list
Home	Open the main navigation screen
Directional pad / OK	Move focus and confirm
Back	Return to the previous screen
Volume / Mute	Adjust or silence audio
Channel	Move through tuned channels
Voice key	Hold while speaking after pairing

Picture settings

Picture modes provide a starting point; adjustments are stored separately for each input and dynamic-range format.

Recommended starting modes

Standard suits mixed daytime use. Cinema uses warmer colour and reduced processing for film material. Game reduces input latency when a console is connected. Vivid is intended for bright retail environments and may exaggerate colour.

Backlight and brightness

Backlight changes panel illumination. Brightness changes the black-level reference and should normally remain near its default. Excessive sharpness can add visible halos.

High dynamic range

HDR is detected automatically from compatible HDMI and streaming sources. Dynamic tone mapping may be enabled for bright rooms, but can alter intended highlight detail.

Symptom	Adjustment to check
Dark image in daylight	Increase backlight or choose Standard
Motion appears unnatural	Reduce Motion Smoothing
Console controls feel delayed	Enable Game mode for that HDMI input
Edges appear outlined	Reduce Sharpness

Sound settings

The television can use its internal speakers, an HDMI eARC receiver, optical digital audio or a paired Bluetooth device.

Speaker modes

Standard provides balanced speech and music. Dialogue raises the centre-frequency range. Cinema widens ambience. Night reduces large volume differences.

External audio

Connect an eARC-capable receiver to HDMI 2 and enable HDMI control. For optical equipment, select Digital Audio Output and choose PCM if the connected device cannot decode multichannel formats.

Lip synchronisation

Use Audio Delay only after disabling delay controls on the receiver. Bluetooth audio may introduce unavoidable latency and is not recommended for rhythm games.

- Mute affects the currently selected output only.
- Headphone or Bluetooth volume may be stored independently.
- Very low broadcast dialogue can reflect the source mix rather than a television fault.

Connecting external devices

Switch equipment off before making or changing connections. Use certified cables appropriate to the required signal rate.

Input naming

Open Sources, highlight an input and choose Edit to apply a descriptive name. Input labels do not change electrical behaviour.

USB limits

USB storage should use FAT32, exFAT or NTFS. The television may not supply enough current for some portable drives; use the drive manufacturer's powered enclosure where required.

Connection	Quantity	Typical use
HDMI	4	Set-top box, game console, media player, computer
USB-A	2	Media storage or powered accessories within rating
Ethernet (RJ-45)	1	Wired network connection
Optical digital audio	1	Soundbar or receiver
Antenna input	1	Terrestrial or cable broadcast feed

HDMI 2 supports eARC. HDMI 3 and HDMI 4 support the lowest-latency Game mode.

HDMI operation

HDMI carries digital picture and sound. Reliable operation depends on the television, source device and cable completing an authentication and capability exchange.

Signal format

For 4K sources, open Settings > Inputs > HDMI Signal Format and choose Enhanced. If the source becomes unstable, return to Standard and test with a shorter certified cable.

HDMI control

Device control may power connected equipment and select inputs automatically. Manufacturers use different names for this feature; behaviour is not guaranteed across every product.

eARC

Connect the audio receiver or soundbar to HDMI 2. Enable eARC on both devices and select External Audio System. If sound is intermittent, confirm that the cable supports Ethernet channel functions.

Connection recovery

When a source is detected but picture or sound is absent, restart both devices and allow them to establish a fresh connection before changing resolution settings.

- Avoid passive adapters for high-bandwidth 4K signals.
- Connect the source directly during diagnosis; add switches or receivers afterward.
- A black screen may be caused by an unsupported resolution, cable fault or incomplete HDMI handshake.

Network and smart services

A network connection is required for streaming applications, software updates and optional account services.

Wi-Fi

The television supports 2.4 GHz and 5 GHz Wi-Fi. A 5 GHz connection generally offers higher throughput at shorter range; 2.4 GHz may travel farther through walls.

Ethernet

Connect the router to the Ethernet port for a stable wired link. Network settings normally use automatic addressing; enter manual values only when supplied by the network administrator.

Applications

Install applications from the on-screen store. Availability, subscriptions and service terms are controlled by their providers. Close an unresponsive application from Settings > Apps before restarting the television.

Privacy controls

Microphone permission, viewing diagnostics and personalised recommendations can be reviewed independently under Settings > Privacy.

A successful network test does not confirm that every third-party service is available.

Broadcast and channel management

Connect the antenna before scanning. Reception quality depends on the installation, local coverage and signal distribution equipment.

Automatic tuning

Choose Antenna or Cable and select the available service type. A full scan may take several minutes. Previously saved channel order may change.

Manual tuning

Use manual tuning to inspect signal level for a known frequency. Signal quality is generally more useful than raw signal strength when diagnosing breakup.

Programme guide

Guide data is supplied by the broadcaster. Missing descriptions or schedule changes do not normally indicate a television fault.

Favourites and parental control

Create favourite lists for faster navigation. Parental restrictions require the local PIN; they do not replace controls offered by streaming services.

- Do not repeatedly retune when all channels fail during severe weather.
- Check wall outlets, splitters and powered amplifiers before requesting television service.

Accessibility

Accessibility features can be enabled individually and remain available without a Velora account.

Shortcut

Hold the Mute key for three seconds to open the Accessibility menu.

Source limitations

Caption, description and language availability depend on the programme or application. The television cannot generate missing provider content.

Feature	Purpose
Audio description	Plays a broadcaster-provided descriptive audio track
Subtitles	Displays broadcast or application captions when available
High contrast	Increases contrast in supported menus
Screen reader	Reads selected interface labels and controls
Text size	Enlarges supported menu text
Button sounds	Confirms navigation with an audible cue

Maintenance and panel care

Routine care preserves ventilation and reduces the risk of permanent screen damage.

Cleaning

Switch off and unplug the television. Wipe the frame with a dry, soft cloth. For the panel, lightly dampen a clean microfibre cloth with water and wipe without pressure; dry immediately.

Ventilation

Remove dust from external vents using a soft brush. Do not insert a vacuum nozzle or any object through the openings.

Image retention

Avoid leaving static graphics at maximum brightness for extended periods. Screen-saver and logo-dimming functions reduce risk but cannot prevent every case.

Transport

Use the original carton where possible. Keep the television upright and protect the panel from impact or twisting.

- Do not spray liquid directly onto the screen.
- Do not use alcohol, abrasive cleaners, solvents or paper towels.
- Disconnect all external cables before moving the television.

General troubleshooting

Begin with the checks below before performing a reset or requesting service.

Power cycle

A full power cycle clears temporary state: switch off, unplug for 60 seconds, reconnect and wait for startup.

Record details

Before contacting service, note the model, product code, software version, connected equipment and exact on-screen error code.

Condition	Checks
No power or status lamp	Confirm outlet, mains lead and local power button
Picture but no sound	Check mute, output selection and external audio power
Sound but no picture	Change source, inspect HDMI cable and restart source device
Remote not responding	Replace batteries, clear sensor area and re-pair
Wi-Fi disconnects	Restart router, test closer range or use Ethernet
Broadcast breakup	Inspect antenna path and signal quality
Application closes	Check network, clear app cache and update software

Error codes

An error code identifies the subsystem that reported a problem. It does not by itself prove that a hardware repair is required.

E06 recovery procedure

Turn the television and the HDMI source device off. Unplug both devices from mains power for 60 seconds. Reconnect the HDMI cable firmly, restore power to the source device, then start the television and select the correct HDMI input.

If E06 returns

Test another HDMI input and a known-good certified cable. Connect the source directly to the television, temporarily removing switches, splitters, capture devices or receivers. Set the source to a supported resolution. If the same error remains with more than one source, record the affected input and contact service.

Code	Meaning	First action
E02	Broadcast tuner could not lock to a signal	Check antenna connection and signal source
E04	Network address could not be obtained	Restart router and repeat network test
E06	HDMI handshake or connection failure	Power-cycle both connected devices and reconnect
E09	Software package could not be verified	Retry update on a stable network
E12	USB storage could not be read	Reconnect supported storage and check its format

E06 on this Velora V55 relates to HDMI connection negotiation. Error codes used by another manufacturer or product model may have a different meaning.

System reset and software update

Use the least disruptive recovery action first. A restart preserves settings; a factory reset removes them.

Restart

Hold the remote Power key for five seconds and choose Restart. This reloads system services without removing channels, applications or accounts.

Software update

Open Settings › System › Software Update and choose Check now. Keep mains power connected until the television restarts. Updates may change menu wording or app compatibility.

Factory reset

Open Settings › System › Reset and enter the local PIN. This removes tuned channels, network credentials, installed app data and account sign-ins. External storage is not erased.

Recovery after interruption

If an update was interrupted and the television does not start normally, disconnect external equipment, power-cycle the set once and contact authorised service with the status-lamp pattern.

Do not perform repeated factory resets for an E06 connection error; complete the HDMI checks on page 17 first.

Technical summary

The following values identify the supplied configuration. Performance can vary with software version, source material and regional broadcast services.

Category	Specification
Product	Velora V55 Smart TV
Model / product code	V55 / VEL-V55-2025
Display	55-inch 3840 × 2160 LED-backlit LCD
Refresh input	Up to 120 Hz on supported HDMI inputs
Audio	2 × 12 W internal speakers; eARC and optical output
Connections	4 × HDMI, 2 × USB-A, Ethernet, optical audio, antenna
Wireless	Dual-band Wi-Fi; Bluetooth remote/audio support
VESA mount	300 × 200 mm, M6
Operating range	5-35 °C; 20-80% RH, non-condensing
Typical power	92 W in Standard picture mode
Standby power	Below 0.5 W with network standby disabled

Detailed dimensions, energy and package information are provided in the separate Velora V55 Product Specification.

Service, compliance and index

Keep the purchase record and warranty terms with this manual. Service eligibility is determined from the applicable warranty document and proof of purchase.

Before requesting service

Complete relevant troubleshooting, note the serial number from the rear label, and record the software version. Remove account credentials only if requested before the unit is transported.

Compliance

This product is designed for indoor household use and bears the applicable regional electrical, radio and environmental conformity markings shown on the rating label and packaging.

Responsible disposal

Do not discard the television or batteries with unsorted household waste. Use an approved collection point and remove remote-control batteries where local procedures require.

Index	Page
Accessibility	14
Antenna and channels	13
Audio outputs	9
E06 HDMI error	17
HDMI connections	10-11
Maintenance	15
Network	12
Reset	18
Warranty records	20

Velora Electronics documentation reference: UM-V55-EN-1.2.